
Bodytronics

Model Two Mechanical Stopwatch Instructions

FEATURES:

- · Measures up to 60 minutes with 1/5th second resolution
- · Precision 13 jewel movement
- · Long-hand range: 0-60 seconds, 1/5th second resolution
- · Short-hand range: 0-30 minutes, 1 minute resolution
- Average Run Time: 12 hours +/-
- +/- .2 seconds
- Operating Temperature Range: -10 to +40 degrees Celsius

WATCH WINDING:



Before using your watch, you must wind the mainspring. Turn the knurled section of the crown clockwise until you feel resistance to winding. Do not overwind! Broken mainsprings caused by overwinding are not covered under waranty – no exceptions!

STANDARD OPERATION:

- 1. Press the reset button (10 o'clock) to reset your watch to 0.
- 2. Press the crown down firmly to start the stopwatch
- 3. Press the crown down firmly to stop the stopwatch
- 4. Repeat step 1 to ready the stopwatch for the next event

WARRANTY CERTIFICATE

Bodytronics warrants this product to be free from defect in materials and workmanship under normal use for a period of six months from the date of purchase. Bodytronics will, at it's option, regain or replace the product free of charge. The warranty does not apply to damage caused by negligence, accident, misuse, repair, or damage to the mainspring as a result of over-winding. No responsibility is assumed for any incidental or consequential damages.

For warranty service, please do not return to retailer. Simply complete the certificate below and return the unit along with a dated proof of purchase to: TKO Enterprises, Inc., 220 Etowah Trace, Fayetteville GA 30214.

(PLEASE PRINT CLEARLY)

Name		
Address		
City		Zip
Telephone		
Email Address		
Retailer purchased from		
	Purchase price	
Problem with product		

AFTER WARRANTY SERVICE

After the warranty period has expired, you may return the unit to Bodytronics for servicing. Fill out the form above and include a check or money order in the amount of \$29.95 for repair and return postage and handling. Bodytronics will, at its option, repair or replace the unit returned for repair.

Bodytronics

TKO Enterprises Inc 220 Etowah Trace • Fayetteville, GA 30214 www.bodytronics.com