KEYPhantom<sup>™</sup> USB Users Guide

# KEYPhantom<sup>™</sup> USB USB Keylogger

This page is intentionally left blank.

**Users Guide** 

### Website

For Frequently Asked Questions, Troubleshooting, or more general information, feel free to visit us at:

http://www.keyphantom.com/

### Warranty Claims

Please do not return devices to the place of purchase. In the event that a device is defective, please browse to: http://www.keyphantom.com/warranty/

Instructions are provided for repair/replacement of a defective device. All warranty claims must be submitted in the original anti-static bag with identification sticker in place. Warranty claims which are due to a forgotten password will be charged a \$40 fee for resetting the device to its factory default password. Please note that as the contents of the flash is encrypted, resetting the password will erase the contents of the log.

### Terms of Use

All users must agree to the terms described in the "Use Agreement" (located at the end of this guide) before using this device. If you do not agree to the terms described, DO NOT USE THE DEVICE.

### Trademarks

Wordpad® is a trademark of Microsoft Corporation.

Microsoft Windows<sup>®</sup> is a registered trademark of Microsoft Corporation.

KEYPhantom<sup>™</sup> is a trademark of DesignREM Limited.

## 1. Overview

The KEYPhantom USB device records USB keystrokes from any PC or Macintosh computer, from the moment the computer is powered on.

It is compatible with any operating system running on a PC or Macintosh, including Windows® 95, 98, 98SE, 2000, XP, Vista, Linux, BeOS, DOS, or OS/2, or Mac OS.

This guide covers the following devices available from <u>www.keyphantom.com</u>:

- KEYPhantom USB Home (256K). Product code: "KP-USB-301".
- KEYPhantom USB Corporate (1024K). Product code: "KP-USB-302".
- KEYPhantom USB Corporate SE (1568K). Product code: "KP-USB-303".
- KEYPhantom USB Forensic (2048K). Product code: "KP-USB-305".

For a comparison between these products, see: <u>http://www.keyphantom.com/comparison/</u>.

# 2. Installation

Installation of the KEYPhantom<sup>™</sup> is very simple - the KEYPhantom<sup>™</sup> USB is inserted between the USB keyboard and the PC.

- 1) Unplug the USB keyboard cable from the back of the computer.
- 2) Plug the USB keyboard into the KEYPhantom<sup>™</sup> cable.
- Plug the KEYPhantom<sup>™</sup> USB cable into the back of the computer, with the keyboard cable still attached. See figure 1 below.



Figure 1 - Installation Diagram

### 3. Retrieving Log

The log of keystrokes can be retrieved from the KEYPhantom<sup>™</sup> using either the "Text Editor" or "Windows<sup>®</sup> Utility" method, as shown in table 1:

Log Download Method:	Log Download - Windows® Utility	Log Download - Text Editor
Method of downloading log:	Download log using a Windows® utility – the "KEYPhantom™ USB Windows Toolkit".	Download log using a standard text editor.
Operating system:	Windows® 2000/XP/Vista.	Windows <sup>®</sup> (all versions), Linux (all version), DOS, BeOS, OS/2, Mac OS (all versions).
Advantages:	Recommended for Windows® users; log is downloaded very quickly, log can be filtered, keyboard layouts can be changed, log is more comprehensive.	Recommended for Linux or Macintosh users; works in any text editor.
Instructions:	See chapter 4.	See chapter 5.

Table 1: Methods for retrieving log of keystrokes from the KEYPhantom<sup>™</sup> USB.

### 4. Retrieving log using a Windows® utility

The log of keystrokes can be downloaded using a Windows<sup>®</sup> utility, namely the "KEYPhantom<sup>™</sup> USB Rapid Downloader". See the screenshot in figure 2, below.

The "KEYPhantom™ USB Rapid Downloader" is available from:

http://www.keyphantom.com/rapiddownload/

The "KEYPhantom<sup>™</sup> USB Rapid Downloader" is compatible with Windows<sup>®</sup> 2000/XP/Vista. This utility is highly recommended - the log downloads very quickly compared to the traditional method of scrolling keystrokes into an editor; there are more features such as log filtering and firmware upgrading.

🌀 sample.kpr - KeyPhantom	USB	Rapid Downloader	×	
Eile Edit Processing Options	<u>T</u> ool	s ⊻iew <u>H</u> elp	T	
: 🖻 🔒   🖪 🕘   🦆 🖉 🕖		⊆onfigure Password		
Note: Running out of log mem	↓	Import KEYPhantom USB Log		
Note: Upgrade to a Corporate	2	Erase KEYPhantom USB Log		
Note: Or consider purchasing	۲	Synchronize Forensic Clock to Computer Clock	L	
Begin Log		Upgrade <u>F</u> irmware		
[pwr 2006/04/25 12:03]				
W< ts 2006/04/25 11:42>elcome to the KEYPhantom USB Rapid Downloader.				
Select the "Processing Options->Process Edit Keys" menu to see the next line clearly.				
Doesn't thas <ts 04="" 11:43="" 2006="" 25="">is look better?</ts>				
<pre><esc><f1><f2><f3><f4>&lt; ~l@#\$%^&amp;*()_+ '1234567890-= <rshift+tab>QWERTYUIOF <tab>qwertyuiop[]\ ASDFGHJKL:" asdfghjkl;' ZrovZphid e 2</tab></rshift+tab></f4></f3></f2></f1></esc></pre>	: <b>F5&gt;</b> '{}	<f6><f7><f8><f9><f10><f11><f12></f12></f11></f10></f9></f8></f7></f6>		
ZXCVBINIVI<>/			v	
Import the log from a KEVPhaptom LIS	5B	CAP NUM SCR		

Figure 2 - KEYPhantom<sup>™</sup> USB Rapid Downloader utility

# 5. Retrieving the log using a text editor

Open any word processor, or any text editing program. It is recommended that you use Microsoft Wordpad. Wordpad comes with all versions of Windows®. Wordpad can be launched by selecting: "Start ... Run" then typing "Wordpad" into the text entry box. Wordpad is also available by selecting "Start ... Programs ... Accessories ... Wordpad".

- Type phxlog into Wordpad. This is the default password that is set at the factory. If you make an error typing in the password sequence, start typing the password from the beginning again. Do not press any keys after the password. Do not press the enter key after the password.
- 2) You should now see the menu appear on the screen (see Figure 3 on the next page).
- In order to view the contents of the memory, press the "1" key. At this point, the memory contents will be displayed on the screen.
- 4) After you have finished viewing the contents of the memory, you may wish to erase the contents of the memory. This is done by pressing the "3" key. The menu will be re-displayed when the memory has been fully erased.
- 5) After you have erased the contents of the memory, press any key to exit the menu. The KEYPhantom<sup>™</sup> will display "Record mode." on the screen to indicate that you have exited the menu. Any key other than the numbers 0 to 9 will also exit the menu.

You have now learned most of the things that you will need to know in order to use the KEYPhantom<sup>M</sup>. Read on to learn about the other options.

🗟 Document - WordPad 📃 🗖 🔀		
<u>File E</u> dit <u>V</u> iew Insert F <u>o</u> rmat <u>H</u> elp		
phxlog		
Press c for compatibility mode KEYPhantom(tm) USB Corporate SE (1568KB) Firmware: v2.1.0.1315 www.keyphantom.com		
ROOT MENU 1) Full memory download 2) Partial memory download 3) Erase memory (quick) 4) Erase memory (thorough) 5) Modify password 6) Diagnostics 7) Firmware upgrade mode 8) Options 9) Speed 0) Quit		
Select:		

Figure 3 - KEYPhantom<sup>™</sup> USB menu

The following menu options are available from the KEYPhantom USB device:

### 1. Full Memory Download

When you select the 'Full Memory Download' option, the KEYPhantom<sup>™</sup> will begin sending the memory contents to the screen. When the entire memory has been displayed, the menu will be sent to the screen. Pressing any key will abort the download process.

2. Partial Memory Download

When you select the 'Partial Memory Download' option, the KEYPhantom<sup>™</sup> will first ask which point in the log to begin sending from. It will then begin sending the memory contents to the screen.

3. Erase Memory (quick)

When you select the 'Erase Memory (quick)' option, the KEYPhantom<sup>™</sup> will perform a quick erase of the log contents. Note that unlike the menu option "Erase Memory (thorough)", it would still be possible in theory to recover the contents of the memory with a flash chip reader.

4. Erase Memory (thorough)

When you select the "Erase Memory (thorough)" option, each sector in the flash is overwritten multiple times. This option is useful if it becomes absolutely necessary to delete the contents of the log, with no possibility of retrieval.

### 5. Modify Password

The default password set at the factory is **phxlog**. It is highly recommended that the password be changed from the default setting. There are a couple of points about the password that are *very important*.

Review and understand this section *before you change the password*.

- 1) Select a unique password.
- 2) Do not use a password or subset of a password that you are using elsewhere on your system.
- 3) The password should not be a string of characters that would be typed in normal usage. Examples of poor password choices would include: father, avenue, your pet's name. Here are some good password choices: tabthett, ddfrhome, and ddghurdd. A password should be

a consecutive set of characters that would never be typed, except by someone who knew the password.

- 4) The password must consist of the letters A-Z.
- 5) Passwords are not case sensitive.
- 6) The KEYPhantom will prompt you to enter the password, and then re-enter the password.
- 7) If the password is forgotten or lost, the device must be returned to the factory for a reformat. It is recommended that the password be written down in the event that it is forgotten.
- 8) The password has a maximum length of 17 characters.
- 9) The number of combinations for the password is 26<sup>17</sup> or 1,133,827,315,385,150,725,554,176. It is virtually impossible that anyone else could guess your password.
- 6. Diagnostics

Displays diagnostics information about the device, including the percentage of the device used, encryption status, date/time (for Forensic units) and more.

### 7. Firmware Upgrade Mode

Used to upgrade the firmware in the device, to add additional features such as encryption of the data inside the device, and a larger memory size.

To download the KEYPhantom<sup>™</sup> Windows Toolkit utility used to upgrade the firmware inside the device, browse to:

http://www.keyphantom.com/firmware/.

See chapter 6 for more information.

### 8. Options - Language

The language that the menu is displayed can be changed.

If you wish to support for additional languages to the device, such as French, German, Japanese or Arabic, email <u>support@keyphantom.com</u>.

### 8. Options - Date/Time

This section is applicable to the KEYPhantom  $^{\rm M}$  USB Forensic model (KP-USB-305) only.

Use this menu to alter the date and time for the time stamping of the log.

The date/time stamps in the log are inserted every 60 seconds.

The date/time in the unit is automatically set whenever a firmware upgrade takes place, and can be set using the "KEYPhantom<sup>™</sup> USB Rapid Downloader" - see chapter 4.

### 9. Speed

Certain older computers will not work properly if the menu is generated at extremely high speed. If the menu exhibits the occasional incorrect character, use the "Speed" menu option to slow the menu operation down.

Most modern computers will easily handle menu generation at the fastest speed.

If you are using a Macintosh the fastest menu speed you can use is setting 5.

### 0. Quit

When you are finished with all KEYPhantom  $^{\tt \tiny M}$  activities, be sure to choose the 'Quit' option from the menu.

# 6. Firmware Upgrade

The KEYPhantom  $^{\rm M}$  USB is completely firmware upgradeable. See figure 4 below.

See <u>http://www.keyphantom.com/firmware/</u> for instructions, and the Windows<sup>®</sup> utility to perform the firmware upgrade.

If you experience any compatibility problems with your KEYPhantom<sup>™</sup>, email <u>support@keyphantom.com</u>. Most problems can be resolved within 1-5 business days.

GUI Firmware Upgrade for KEYPhantom
(c)2005 DesignREM Ltd. (firmware toolkit licensed from www.microchipC.com)
The upgrade is being applied to your device now. Do not unplug the USB cable or power off the device until complete.
Writing data
< <u>B</u> ack <u>N</u> ext > <b>Cancel</b> Help

Figure 4 - KEYPhantom<sup>™</sup> USB Firmware Upgrade Utility

### **USER AGREEMENT**

This Agreement is between DesignREM, Inc. ("DesignREM") and you, the user or installer of the KEYPhantom keystroke recording device (the "Device"). Your installation or use of the Device indicates your consent to all of the terms of this Agreement. If you do not agree to any term of this Agreement, do not install the Device. Return the bag unopened to the place of purchase for full refund.

### PERMISSIBLE USES

The Device was designed and is to be used solely for parents to monitor what their children are doing on the computer and for businesses to monitor what their employees are doing on the computer (the "Permissible Uses").

### **IMPERMISSIBLE USES**

The Device may not be used to violate the privacy rights of others, or to access or intercept electronic communications in violation of wiretap statutes, or to violate company regulations ("Impermissible Uses"). Impermissible Uses include, but are not limited to the following acts: retrieval of credit card information, passwords, personal and/or medical information, confidential and/or proprietary information, or trade secrets.

Privacy and wiretapping laws change from time to time and vary from state to state. It is your responsibility to ensure that you are in compliance with federal, state, and local laws.

### **MUST POST NOTICE of MONITORING**

If anyone other than you will be using the computer on which the Device is installed, you agree to post a notice visible to each user of the computer to the effect that (i) activities on this system may be monitored and recorded and (ii) that anyone using this system expressly consents to such monitoring and is advised that if such monitoring reveals possible evidence of unauthorized or criminal activity, such evidence may be provided to company or law enforcement officials.

# SERIAL NUMBER FOR INVESTIGATING ILLEGAL ACTS

A unique serial number may be electronically stored in the Device to aid company and law enforcement officials in the investigation of any unauthorized or illegal acts that may be committed with the Device. You agree to permit DesignREM to assist these officials by providing serial number and sales information as necessary in the course of the investigation. DesignREM may request the assistance of its distributors and customers in providing information relating to the serial numbers of such Device(s), and you agree to cooperate with such requests.

#### LICENSE

The Device contains software and firmware instructions (the "Program") on the internal microcontroller. The Device and Program are protected by copyright and other intellectual property laws.

DesignREM hereby grants you the right to:

a) use the Program for the Permissible Uses in the United States for as long as you own the Device.

b) view, copy, print and distribute copies of the information provided by the Device provided

(1) the information is used for informational purposes only; and

(2) any copy of the information (or portion thereof) includes the following copyright notice: (c)2000-2006, DesignREM, Inc. All Rights Reserved.

This license is limited to the rights above. Therefore, you are expressly prohibited from taking any other action with the Device, including but not limited to:

a) modify, reverse engineer, de-compile or disassemble the Device or the Program;

b) make any attempts to defeat the code protection which is in place on the internal microcontroller;

c) make any attempts to read or copy the Program;

d) attempt to open the casing around the Device;

e) rent, lease, lend, or sublicense the Device to others;

f) transfer your rights to another, unless the recipient agrees to the terms of the Agreement.

### LIMITED WARRANTY

DesignREM warrants that the Device, if provided by DesignREM, is free from defects in material and workmanship and for ninety (30) days from the date of original purchase of the Device, provided the Device was not subject to accident, abuse, or improper use.

THIS IS A LIMITED WARRANTY AND ALL OTHER WARRANTIES ARE EXPRESSLY DISCLAIMED, INCLUDING BUT NOT LIMITED TO WARRANTIES OF TITLE, NON-INFRINGEMENT OR IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. DesignREM'S SOLE LIABILITY FOR ANY BREACH OF THIS WARRANTY SHALL BE, IN DesignREM'S SOLE DISCRETION: (i) TO REPAIR OR REPLACE YOUR DEVICE.

DesignREM will honor this warranty only if you inform DesignREM of your problem with the Device during the applicable warranty period and promptly provide evidence of the date the Device was originally purchased. This warranty is void if you violate the terms of this Agreement.

To invoke the warranty, complete the warranty form found in the back of the Operating Guide or at www.keyphantom.com. Send the completed warranty form, the defective device, and a copy of the purchase receipt or other evidence of the purchase date to: Allen Concepts Inc., 1900 W. Chandler Blvd., Suite 15-264, Chandler, AZ 85224. Include your name, address, and telephone number. Allen Concepts Inc., on behalf of DesignREM, will repair or replace the device and return it to you. If the device is working properly and the password stored inside the Device does not match the password provided on the Warranty Form, you will be charged \$40 for resetting the password. The Device will be returned to you along with the new password, and an empty log.

### FORGOTTEN PASSWORD

If you have forgotten your password, send the Device to: ACI, 1900 W. Chandler Blvd., Suite 15-264, Chandler, AZ 85224. Include your name, address, and telephone number. ACI will reset your password and charge you \$10 for this service. The Device will be returned to you along with the new password. Users should be aware that resetting the password also clears the log.

#### **INDEMNIFICATION**

You agree to defend, indemnify, save and hold DesignREM harmless from any and all claims, demands, liabilities, costs or expenses including direct, indirect, incidental or consequential damages and reasonable attorney's fees resulting from the Device, including loss of business or profit.

### LIMITATION OF LIABILITY

UNDER NO CIRCUMSTANCES AND UNDER NO LEGAL THEORY, WHETHER TORT, CONTRACT, OR OTHERWISE, SHALL DesignREM OR ITS SUPPLIERS OR RESELLERS BE LIABLE TO YOU OR ANY OTHER PERSON FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY CHARACTER INCLUDING, WITHOUT LIMITATION, DAMAGES FOR VIOLATION OF THE RIGHT TO PRIVACY, VIOLATION OF WIRETAPPING STATUTES, LOSS OF GOODWILL, WORK STOPPAGE, COMPUTER FAILURE OR MALFUNCTION, OR ANY AND ALL OTHER COMMERCIAL DAMAGES OR LOSSES. IN NO EVENT WILL DESIGNREM BE LIABLE FOR ANY DAMAGES IN EXCESS OF THE PURCHASE PRICE, EVEN IF DESIGNREM SHALL HAVE BEEN INFORMED OF THE POSSIBILITY OF SUCH DAMAGES, OR FOR ANY CLAIM BY ANY THIRD PARTY.

### **EXPORT CONTROLS**

You may not export or re-export the Device or the Program (i) into (or to a national or resident of) Cuba, Iraq, Libya, Sudan, North Korea, Iran, Syria or any other country to which the U.S. has embargoed goods; or (ii) to anyone on the U.S. Treasury Department's list of Specially Designated Nationals or the U.S. Commerce Department's Table of Denial Orders.

#### **GOVERNING LAW**

This Agreement shall be governed in all respects by the laws of New Zealand, except for conflict of laws provisions. The parties agree that for any dispute, controversy or claim arising out of or in connection with this Agreement, venue and personal jurisdiction shall be in a court with competent jurisdiction located in New Zealand.

#### SEVERABILITY

The provisions of this Agreement will be deemed severable, and the invalidity or unenforceability of any provision will not affect the validity or enforceability of another provision hereof.

### **ENTIRE AGREEMENT**

This Agreement constitutes the entire agreement and understanding between the parties and may be amended only by a writing executed by both parties.

All Materials are the property of DesignREM, Ltd. Copyright 2004 - 2006 DesignREM, Ltd. All Rights Reserved.