

BG6 - Bluetooth talking glove

User manual



1 Multi function button

2 Multi function LED

3 Mic

4 Battery charging jack

5 Receiver

6 Conductive fabric

Charge Bluetooth Talking Glove

To charge the battery connect the Bluetooth talking glove plug to a power source such as an USB port of your computer, a car charger or a wall charger compatible with standard USB.

The multi function LED lights on in red color when it is in charging mode and it turns off once the battery is fully charged

Power On and Power Off the Bluetooth talking glove


To turn on the unit, press and hold the button  for 3seconds on the unit, you will hear an alert tone and the Blue LED will blink every 2 seconds.

To turn off the unit, press and hold the button  for 3 seconds again, you will hear an alert tone and then the red LED flash three times

Pairing the Bluetooth talking glove with a Mobile Phone

Make sure your mobile phone is with Bluetooth function. Specified pairing steps may vary with different cell phones, please refer to user guide of your mobile phones for further information.

The general Bluetooth pairing steps are as follows:


1. Keep the Bluetooth talking glove close to your mobile phone.
2. In power off mode, press and hold the button  about 6 seconds to 8 seconds, the multi function Led will flash alternatively red and blue.
3. Now, you can find “BT gloves” from the list of found devices on your mobile.
4. As soon as the device is paired, the multi function LED flashes in blue color for every 3 seconds. In case, your mobile needs to enter matching code for pairing, please press “0000”.
5. The pairing is completed now and the Blue LED of the Bluetooth talking glove will blink for every 3 second.

Notes: If you cannot pair the unit successfully, please switch Off the Bluetooth talking glove and then redo the above pairing procedure again. If the 1st pairing is successful, the paired device will remember each other. Unless the pairing information is deleted because of a new pairing, there is no need to go through the pairing procedure again when using the same devices the next time.


Make and receive phone calls

If Bluetooth talking glove is paired to mobile phone, which is in connected status, you can use the Bluetooth talking glove to make a phone call or answer the phone call. The receiver is placed on the thumb of the right glove, the microphone and buttons which control Bluetooth glove are placed on the glove over the wrist.

Answer an incoming call

To answer an incoming call, press briefly the multifunction button 

End a phone call

To end a phone call, press briefly the multifunction button  when you want to end a call,

Touch screen of your smartphone

With capacitive technology for the thumb, index finger and middle fingers of the Bluetooth talking glove, you can control the touch screen of your smartphone.

Technical specifications

Connecting to mobile phone through Bluetooth technology

Battery life: until 7~ 8 hours

Battery duration on standby time: 7 days

Charge time: about 80 mins

Operating range: 10 meter

Warning:

- Do not wash Bluetooth talking glove in a washing machine. Bluetooth talking glove is not waterproof. Never immerse Bluetooth talking glove in water. It is not washable product
- Follow the local rules about mobile phones usage and their accessories while driving.
- Keep the Bluetooth talking glove out of the reach of small children to avoid choking hazard
- Keep Bluetooth talking glove dry and avoid humidity
- Disconnect Bluetooth talking glove from charging cable before polishing it.
- Do not use Bluetooth talking glove if it does get wet.
- Do not try to open, disassemble or overcharging the lithium-ion battery of Bluetooth talking glove: danger of explosion
- At the end of battery lifecycle do not dispose it as household waste. Dispose of batteries according to local regulations.