

Vacuum Sealer Instruction Manual



Model

CD204-A

Safety Tips

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components on this product.
- Consult Local and National Standards to comply with the following:
 - Health and Safety at Work Legislation
 - o Fire Precautions
 - o IEE Wiring Regulations
 - o Building Regulations
- DO NOT immerse the appliance in water.
- The sealing bar becomes hot during use. DO NOT touch the sealing bar during or immediately after operation.
- Do not turn Off at the plug to halt operation; always use the Stop/Start button.
- Do not use the appliance for anything other than its intended use.
- Only use bags recommended by the supplier/manufacturer with the appliance.
- Always switch off and disconnect the power supply to the appliance when not in use.
- Not suitable for outdoor use.
- Keep all packaging away from children. Dispose of the packaging in accordance to the regulations of local authorities.
- If the power cord is damaged, it must be replaced by a APURO agent or a recommended qualified technician in order to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance

Introduction

Please take a few moments to carefully read through this manual. Correct maintenance and operation of this machine will provide the best possible performance from your APURO product.

Pack Contents

The following is included:

- APURO Vacuum Pack Machine
- Instruction Manual

APURO prides itself on quality and service, ensuring that at the time of packaging the contents are supplied fully functional and free of damage.

Should you find any damage as a result of transit, please contact your APURO dealer immediately.

Controls and Features



Control Panel



-3-

Operation

The Vacuum Sealer automatically comes on when plugged in, indicator light will turn green.

The Vacuum Sealer is now ready for use.

Vacuum Packing Food

- 1. Place the food inside in the bag and remove any excess liquid or food residue.
- 2. Allow minimum of 25mm-50mm of space at the top of bag to ensure a good seal.
- 3. Place the open end of the bag across the Sealing Strip, keeping opening within the chamber ring and close lid.
- 4. Press "Vac & Seal" button. Indicator light will turn on.
- 5. Vacuum pump will engage until required vacuum level is achieved. Machine will automatically go into seal mode.
- 6. Pulse function can be used if not requiring full vacuum of bag (i.e. for delicate items that may be damaged) . Pressing pulse button until desired vacuum result is achieved. Press Seal button to seal bag.
- 7. When sealing is complete lid will raise slightly.
- 8. Remove bag and inspect bag and seal.

(Note: A good seal will look clear upon inspection. If the seal is spotty, incomplete, wrinkled, white or milky, remove sealed portion and run vacuum and seal process again.)

9. To abort process, press "Cancel" button.

Extended Seal time

Seal time can be extended by pressing the extended seal button. This may be necessary if using thick vacuum bags or using in a cold environment.

Cleaning, Care & Maintenance

- · Always allow to cool before cleaning.
- · Use warm, soapy water and a damp cloth to clean the appliance.
- · Dry thoroughly after cleaning.
- · A APURO dealer or qualified technician should carry out repairs if required.

WARNING: Do not allow any water to spill into the appliance when cleaning.

Troubleshooting

Fault	Probable Cause	Action	
The unit is not working	The Unit is not switched on	Check the unit is plugged in correctly and	
		switched on	
	Plug and lead are damaged	Call APURO agent or qualified technician	
	Fuse in the plug has blown	Replace the plug fuse	
	Power supply	Check Power Supply	
	Internal wiring fault	Call APURO agent or qualified technician	
Appliance does not remove all the air from the	Open end of bag not completely inserted	Open lid and reposition bag	
bag	Gaskets dirty	Clean gaskets	
	Open end of bag is dirty	Clean bag	
	Bag may be punctured	Replace bag	
	Incorrect bags used	Call Vacuum Pack machine supplier	
	Suction nozzle blocked	Clear suction nozzle	
	Lid is not locked into position correctly	Ensure lid is locked in position correctly	
Bags are not sealing correctly	Moisture in bag under the sealing bar	Ensure inside of the bag is dry and free from	
		moisture where it is to be sealed	
	Incorrect bags used	Call Vacuum Pack machine supplier	
	End of bag not placed above sealing bar	Move end of bag over sealing bar	

Technical Specification

Model	Voltage	Power	Current	Vacuum Pressure (approx.)	Dimensions h x w x d mm	Weight (kg)
CD204-A	230V 50Hz	110W	0.5A	-711mBar	97.5 x 390 x 160	1.8

Electrical Wiring

The plug is to be connected to a suitable mains socket.

This appliance is wired as follows:

- · Live wire (coloured brown) to terminal marked L
- · Neutral wire (coloured blue) to terminal marked N
- · Earth wire (coloured green/yellow) to terminal marked E

This appliance must be earthed, using a dedicated earthing circuit.

If in doubt consult a qualified electrician.


Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

Compliance

The WEEE logo on this product or its documentation indicates that the product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.

APURO parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.

APURO products have been approved to carry the following symbol:



All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of APURO. Every effort is made to ensure all details are correct at the time of going to press, however, APURO reserve the right to change specifications without notice.

DECLARATION OF CONFORMITY

Equipment Type Vacuum Packing Machine

Model CD204-A

Legislation C-Tick

AS/NZ 3820 Essential Safety Requirements for Low Voltage Electrical

Equipment

Standards AS/NZS CISPR 14.1:2013

AS/NZS 60335.1:2010

IEC 60335-2-45+A1:2008+A2:2011

Producer Name Apuro

Producer Address 15 Badgally Road,

Campbelltown,

NSW 2560

I, the undersigned, hereby declare that the equipment specified above conforms to the above Legislation and Standard(s).

Date 30/10/14

Signature $\sqrt{\int mwd}$

Full Name Richard Cromwell

Position Commercial Director

