





ELECTRIC BIANKET

SY-ME80

WELCOME

Dear Customer,

Welcome to Sytech! Thank you for purchasing the Electric Blanket SY-ME80. Please read this manual carefully before operating your product and pay close attention to the precautions which are mentioned below. Store this user manual in a safe place for future reference. We are sure that this new Electric Blanket will satisfy your needs.

PLEASE READ ALL THE INSTRUCTIONS PRIOR TO USING YOUR HEATING BLANKET.

BASIC SAFETY GUIDELINES

- Only use this appliance for the purposes described in this manual.
- This appliance is not intended for use by persons (including children) whose physical, sensory or mental capabilities are impaired, or by persons lacking experience or knowledge, unless they have had the benefit of prior supervision and instruction in using the device from a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- Please do not use accessories which are not recommended or which are not supplied with this appliance.
- If the power lead is damaged, it must be replaced by a special or similar lead available from the supplier or after-sales department.
- Do not use this appliance if the plug is damaged, if it is not working correctly, if it has been dropped or if it is damaged or if it has fallen into water. If this is the case, contact Sytech Service Centre
- Do not transport this appliance by carrying it by its power lead and do not use this lead as a handle.
- Always disconnect the appliance from the mains after use or before cleaning it.
- Should the appliance fall into water, unplug it immediately before retrieving it.
- An electrical appliance should never be left plugged in and unsupervised. Disconnect it from the mains if
 you are not using it.
- Only use you electric blanket with the plug provided.
- Do not bend the flex and do not use the blanket while it is creased, rolled or folded.
- Never use this appliance in a room where aerosol products (sprays) are used or in a room where oxygen is administered.
- In order to disconnect the blanket, switch the button to the «0» position, then remove the plug and unplug the connector from the heating blanket.
- Do not use safety pins, do not scratch the blanket with a sharp object and do not hit it with a blunt object.
 Do not fix the blanket with pins or other metal objects. Never let anything fall into and never insert anything into one of the openings.
- Do not expose your blanket to sunlight and do not iron it. In this way, you will avoid damaging the insulation of the electrical circuits.
- · This blanket is not intended for use in a hospital environment but only intended for home use.
- Do not use the blanket with other heating devices or to warm other equipment (hot-water bottle, electric blanket,).
- If you are worried about your health, consult a doctor before using this appliance.
- · If you feel any pain while using this appliance, stop using it immediately and consult your doctor.
- Never use this appliance in contact with a part of the body that is swollen or inflamed or if you have any
 form of skin rash.
- The control must remain within reach. Do not leave the concealed switch under the blanket, pillow or other objects.
- Do not use the blanket when it is wet and do not switch it on in order to dry it.
- Do not position the blanket on top of you in any way. Only use as a blanket is permitted.
- · Do not use this blanket with animals.
- When you store your blanket for long periods, store it in a place that is dry. Check its condition carefully before using it again for the first time. If the power lead seems damaged, do not use the blanket.
- This blanket must not be used by young children or people that are insensitive to heat.
- Do not expose your electric blanket to sunlight and do not iron it. In this way, you will avoid damaging the insulation of the electrical circuits.
- The appliance should not be used on an adjustable bed.
- Examine the appliance frequently for signs of wear or damage. If there are such signs or if the appliance has been misused, return it to the supplier before using it further.

USING THE ELECTRIC BLANKET SY-ME80

Diagram and description:

- 1) 3 Heating levels to select from
- 2) LED function indicator



- Position the blanket flat on the bed. The end of the blanket without the controls is positioned at the foot
 of the bed.
- Only put a sheet or thin cotton spread over the blanket so that you can feel the heat and know whether the blanket is creased or not.

Adjusting the temperature:

- Start by connecting the plug to the female input connector located on the side of the blanket and the other end to the electricity supply (AC220-240V). Switch the button to «position 2» so that the heating blanket reaches the desired temperature more quickly. Leave it on for about 30 minutes before going to bed.
- When you want to go to bed, adjust the button to choose the temperature you want. You can adjust the temperature to 3 different levels.
 - Position 1 Low heat
 - Position 2 Medium heat
 - Position 3 High heat
- We strongly recommend switching the blanket off by switching the button to «position 0» before going to sleep (the indicator light goes off).

CLEANING AND MAINTENANCE

When you are not using the heating blanket and before cleaning it, please follow the following instructions:

- · Make sure the control is in «position 0».
- Disconnect the power supply.
- Disconnect the connector linking the control to the blanket.
- · Leave the blanket to cool down before cleaning it.

Small marks may be removed with a cloth or a damp sponge and, if required, using a little liquid detergent suitable for delicate textiles.

Please note, your heating blanket should not be dry-cleaned, nor twisted, nor dried in a tumble dryer, nor calendared or ironed.

If the blanket is very dirty, it can be washed in a washing machine. Set it to the 30°C programme for delicate fabrics. Use a washing product for delicate fabrics and use the amount stated by the manufacturer. Do not wash the blanket too frequently in order not to strain it excessively. The heating blanket must not be washed in a washing machine more than five times during its lifetime.

To dry, do not hang it up using clothes pegs or similar items.

Do not expose the heating blanket to sources of heat such as sunlight, radiators or other sources. Only reconnect the power lead to the blanket when the connector and the blanket are completely dry.

WARNING: NEVER SWITCH THE ELECTRIC BLANKET ON TO DRY IT.

STORAGE

If you are not going to use the blanket for a long period, we recommend storing it in its original packaging in a dry place and that you do not place anything on top of it

SPECIFICATIONS

Electric Heating Blanket – Therapeutic Heat

Long lasting heat – provides great relief for any kind of body ache

Single size - for one person use

3 Temperature settings: High, Medium, Low

LED indicator on switch

Over heating protection system Detachable connector +VDE plug

Detachable and washable Material: Polar fleece Size: 150*80cm

Voltage: 220V-240V~ 50-60HZ

Power: 60W

DECLARATION OF CONFORMITY

Manufacturer Name: Satyatrade S. L. Address: Pol.Ind.La Raya. C/ Guadalquivir, 2. Camarma de Esteruelas, 28816 Madrid

Tel: 902 430 967 Fax: 91 8864285 NIF: B83254763

Manufacturing country: China

Sytech® SY-ME80 Complies with the following standards:

EMC Standards: Directive 2004/108/CE

LVD Standards: 2006/95/EC

ROHS standard: 2011/65/EC Restriction of Hazardous Substance

Signed: Ajeet Nebhwani Utamchandani

Sole Administrator



