



UMBWORKS 011413V1

Table of Contents

1.	Introduction	2
2.	System Requirements	2
3.	Install B-Works 2	3
4.	Connection to the Hardware	7
5.	Start to Use B-Works 2	7
6.	Operation Interface Description	8
	6.1 Software screen introduction	8
	6.2 Thumbnail (Saved image window)	
	6.3 Main menu	
	6.4 Annotation Tools	. 11
	6.5 Camera Settings	. 13
	6.6 Options	. 14
	6.7 Time Lapse (Burst Settings)	
7.	Function Descriptions	16
	7.1 Turn on/off the Document Camera	. 16
	7.2 I would like to display a live image	. 16
	7.3 I would like to capture images	. 16
	7.4 I would like to capture images continuously	. 16
	7.5 I would like to freeze the live image	. 16
	7.6 I would like to annotate the displayed image	. 17
	7.7 I would like to add textual annotation to images	. 18
	7.8 I would like to adjust the drawing object	. 19
	7.9 I would like to record images	. 19
	7.10 I would like to use the mask mode	. 20
	7.11 I would like to use the spotlight mode	. 20
	7.12 I would like to manage saved image files	. 20

1.Introduction

B-Works 2 PC and USB driver which support WIA and TWAIN standards.

After installing the USB driver and B-Works 2 application, you can use the software to:

- Control the Document Camera
- Capture and record images
- Annotate the image, highlight important details and save it

2. System Requirements

Windows XP

CPU: P4 2.8 GHz and above

Memory: 512MB
Support Direct X 9
Resolution: 1024x768
500MB Min Disc Space

Windows XP SP2 and above

Windows Vista / 7 / 8

• Min CPU: P4 2.8 Ghz

Min Memory: 1GB (32-bits)/2GB(64-bits)

Direct X 9 CompatibleMin Resolution: 1024x768500MB Min Disc Space

MAC OS X 10.4 / 10.5 / 10.6 / 10.7 / 10.8

• Min CPU: PowerPC G4 866MHz or Intel Pentium® 1.83GHz Intel Core 2 Duo

Min Memory: 512MBMin resolution 1024x768

• 24-bit color display monitor

• 1GB Min Disc Space

• Min QuickTime 7.4.5


3.Install B-Works 2

3.1 in Windows XP/ Vista




<Very Important> To ensure successful installation, please make sure each of the following steps is completed


- 1. Put the software CD-ROM into your computer
- 2. The software setup program will start automatically. Please select [Install B-Works 2] to start the installation progress
- 3. Read the description, and then press [NEXT]
- 4. Click [Setup.exe] to start the installation of B-Works 2
- 5. Follow the on-screen instruction, and then press [Next] to proceed the next step



6. Press [Yes] to create B-Works 2 shortcut on your desktop



7. Once the installation is completed, press [Finish] to restart the computer




3.2 in MAC


- 1. Insert the software CD-ROM into the CD-ROM drive
- 2. Click on the CD icon
- 3. Select MAC folder and click **[B-Works 2]** to open the installation wizard and begin to install following the on-screen instruction



4. Press [Continue]



5. Press [Install]




6. Type the Name and Password, and then press [Install Software]



7. Press [Continue Installation]



8. Press [Restart] to finish the software installation




4. Connection to the Hardware




<Very Important> To ensure successful installation, please follow each of the following steps

4.1. Connect the power cord of the Document Camera



<Note> Appearance may vary depending on country/region

4.2. Connect USB cable to the Document Camera and your computer.



5. Start to Use B-Works 2

5.1. Double-click the [B-Works 2] icon on the desktop to activate B-Works 2



5.2. Click [POWER] icon to power on




5.3. Click [PREVIEW] icon to start the use




<Remark> Under MAC OS, if the Document Camera displays the message "The Disk was not ejected properly" after power-on, please press "OK".

6.Operation Interface Description



- 1. Live image
- 2. Main menu
- 3. Thumbnail window
- 4. Menu for file management

6.2 Thumbnail (Saved image window)



- ①
 - 1. OFF/ON Thumbnail
- 2. Thumbnail image of saved video or captured image (It will be displayed as video) if it is a
- 3. Save the image which has been edited
- 4. Save as a new file
- 5. Change the storage folder
- 6. Delete the file
- 7. Send the captured image by e-mail


6.3 Main menu




C	POWER: Turn on/off the Document Camera		LAMP: Turn on/off the lamp
	AUTO TUNE: Automatically adjust the image to have the best brightness and focusing performance		PREVIEW: Display live images
73	OPTIONS: Select image compression method and the audio source. Please refer to 6.6 Options for the setting screen	黨	BRIGHTNESS: Adjust the brightness of the image
	MAIN: Open the main functions menu. Right click on this icon to show information about the B-Works 2.	9	ZOOM: Increase or decrease the image size
	Mask Mode: Open the mask mode. Please refer to 7.10 I would like to use the mask mode		CAMERA SETTING: Activate the Camera Settings window to adjust live images. Please refer to 6.5 Camera Settings for the setting screen
	FREEZE: Freeze the live image		ANNOTATION: Open annotation tools. Please refer to 6.4 Annotation
	Spotlight Mode: Open the spotlight mode. Please refer to 7.11 I would like to use the spotlight mode	(2)	TIME LAPSE CAPTURE: Use the continuous mode and adjust the interval of automatic image capturing. Please refer to 7.4 I would like to capture images continuously.
	RECORD: Record the current image		CAPTURE: Capture images

6.4 Annotation Tools

- Click to open annotation tools
- For Windows' User Interface




> For MAC User Interface



Icon	Description
B	Pointer tool
•	Laser tool
A	Insert text
	Eraser (Clear marks of free-hand drawing tool)
>	Draw a line
0	Draw an ellipse
	Draw a rectangle
	Delete
0	Free-hand drawing tool
•	Back
t	Next
	Clear all
	Select pen color
Line Width 11	Select the line width
0 1 2 34 5 6	Select transparency
Arial	Select the font
24 💠	Select the font size

Click the inverted triangle symbol on the drawing object



Right-click on a blank area of the screen

Paste Ctrl+V	Paste: Paste the drawing object	
Select All Ctrl+A Ctrl+A	Select All: Select all the drawing objects	
	Clear All: Clear all the drawing objects	

6.5 Camera Settings


Control the live image via the *Camera Settings* interface. The operating procedure is the same as the **control panel** and **remote control** of the Document Camera. Refer to the <u>Document Camera user manual</u> for more information.

<Remark> The display of the button may vary depending on product functions.
An inactive button will grey out.



to open Camera Settings interface

For Windows' User Interface



For MAC User Interface



6.6 Options



> For Windows' User




> For MAC User




- 1. Factory Reset: Reset all configurations to factory default settings.
- 2. Video Compression Type: Set up the recording format
- <Note> You need to enable the [Enable Video Compress] before setting in Windows OS.
- 3. Enable Audio Recorder: Enable the audio recorder and set the audio source

6.7 Time Lapse (Burst Settings)

Click to open Time Lapse menu



➤ For MAC User



- 1. Specify a file name
- 2. Set the start time
- 3. Set the capture interval and the capture time

7. Function Descriptions

7.1 Turn on/off the Document Camera

Click to turn on/off the power

<Note> When the machine is turned on, the light will flash. After shutdown, you cannot restart it until the light finishes flashing

7.2 I would like to display a live image

Click to display the live image


7.3 I would like to capture images

Click to capture images
 [Note] The captured images will be displayed in the Thumbnail area

7.4 I would like to capture images continuously

Click to open continuous mode setting. Click [OK] after setting.
 Note> Refer to 6.7 Time Lapse for more information about Time Lapse setting
 Note> The captured images will be displayed in the Thumbnail area


7.5 I would like to freeze the live image




Click once again to lift the freeze

7.6 I would like to annotate the displayed image.

<Note> To annotate the saved image, please open the images of the Thumbnail area



Select an annotation tool



Select pen color



Select the line width



Select transparency



Mark or annotate the displayed image



<Remark> You can Click to capture images if they are live images. You can click [SAVE] or [SAVE AS] to save the files if they are image files opened from the Thumbnail
<Remark> You can add annotation when recording but cannot save it

7.7 I would like to add textual annotation to images



Click

to open the annotation tools

Select text color



Select transparency



Select font and font size




> Select




For Windows OS

- Click the screen to display the [Text Tool] window
- > Enter text in the blank area and press [OK]



For MAC OS


Pull a block in the image to start entering text



<Remark> You can Click to capture images if they are live images. You can click [SAVE] or [SAVE AS] to save files if they are image files.

7.8 I would like to adjust the drawing object

Rotate the direction of the object: Click the object and move it to the green point on the screen. Press and hold the left mouse button, and move to left and right to rotate the object



- Change the size of the object: Click the object and move it to the white point on the screen. Press and hold the left mouse button to adjust the size of the object
- Click the object, and click the "inverted triangle" symbol on the upper right of the object to open the operation menu. Please refer to <u>6.4 Annotation</u> for the function descriptions of menu

7.9 I would like to record images



to open the recording tool.



Press

<Note> Click to open the setting window of image format and audio source.
Please refer to 6.6 Options for more information

- Click to start recording
- Click to stop recording
- Click to close the recording tool
- <Remark> You can add annotation when recording but cannot save it

7.10 I would like to use the mask mode

- Click to open the mask mode
- You can use the mouse to directly modify the length and the width of the block
- Click to modify the transparency of the block
- Click to close the mask mode

7.11 I would like to use the spotlight mode

- > Click to open spotlight mode
- You can use the mouse to directly modify the length and the width of the block
- Click to modify the transparency of the block
- Click to close the spotlight mode

7.12 I would like to manage saved image files

7.12.1 Save as a new file

- > First, double-click the picture or image file in the "Thumbnail" window on the left side of the screen
- ➤ Click [Save as] to display the "Save image" window
- > Enter the "file name" and click [Save] to finish saving

7.12.2 Change the location of file access

➤ Click [Directory] to display the "Browse Folder" window

After selecting the location of the folder, click [Confirm] to change the folder where the pictures will be saved next time

7.12.3 Delete the file

First, double-click the picture in the "Thumbnail" window on the right side of the screen





e] 📕 to delete the file

7.12.4 Send out the files by E-mail

- First, double-click the picture in the "Thumbnail" window on the right side of the screen
- ➤ Click [E-mail] to open a new E-mail

Thumbnail

Save
Save as
Directory
Delete
E-mail

DUKANE CORP AV SERVICE DEPT 2900 Dukane Drive St Charles, IL 60174 800-676-2487 / 630-762-4032 Fax 630-584-5156 avservice@dukane.com www.dukane.com/av