

User's Manual
SPH10 Manager

V1.0

2012-01-04

Copyright Information

Copyright 1998-2012 Sena Technologies, Inc. All rights reserved.

Sena Technologies reserves the right to make any changes and improvements to its product without providing prior notice.

Notice to Users

Proper back-up systems and necessary safety devices should be utilized to protect against injury, death or property damage due to system failure. Such protection is the responsibility of the user.

This device is not approved for use as a life-support or medical system.

Any changes or modifications made to this device without the explicit approval or consent of Sena Technologies will void Sena Technologies of any liability or responsibility of injury or loss caused by any malfunction.

Technical Support

3150 Almaden Exselectway, Suite 238

San Jose, CA 95118

United States

Toll Free (US/Canada): 8668-US-SENA (866-887-7362)

Main: 408-448-1997

Fax: 408-907-3738

E-Mail: support@senablutooth.com

Website: <http://www.senablutooth.com>

Facebook: <http://www.facebook.com/senablutooth>

Table of Contents

1. Software Installation	4
1.1. Windows XP	4
1.2. Windows Vista or Windows 7	7
2. Getting Started	15
2.1. Starting SPH10 Manager	15
2.2. Updating Firmware	17
2.3. Restore Firmware	21
2.4. Update Firmware from specific file	25
2.5. Device Settings	28
2.6. Checking version of SPH10 Manager	30

1. Software Installation

Please note that all software installation should be running with **administrator** privilege of your computer.

1.1. Windows XP

Step 1. Power off the SPH10.

Note:

Do not connect the SPH10 to your computer until software installation is completed.

Step 2. Run the setup program, *sph10manager-v1.0-setup.exe*, and then SPH10 Manager setup window will be started as follows.



Figure 1-1 Welcome Message

Step 3. Click "Next" button and then specify the destination location of program.




Figure 1-2 Choose the destination location of program

Step 4. Click “Install” button after choosing destination location of the program and then installation will be started.




Figure 1-3 Program Installation

This process may take a few minutes according to the performance of your computer. Please wait until final completing message is displayed.



Figure 1-4 Complete message

Step 5. Click “Finish” button to complete the installation, then SPH10 Manager will be started automatically.

Please refer to Chapter 2 to learn how to use SPH10 manager.

1.2. Windows Vista or Windows 7

Step 1. Power off the SPH10.

Note:

Do not connect the SPH10 to your computer.

Step 2. Run the setup program, *sph10manager-v1.0-setup.exe*, then SPH10 Manager Setup window will be started as follows. In case that you have 64-bit OS, please run different set-up program, *sph10manager-V1.0-setup_x64.exe*.

Note:

A warning message on *User Account Control* windows may be popped up. Please select “Allow” or select “Yes” button to proceed to the installation of SPH10 Manager.



Figure 1-5 Welcome Message

Step 3. Click “Next” button and then specify the destination location of program.




Figure 1-6 Choose the destination location of program

Step 4. Click “Install” button after choosing destination location of the program and then installation will be started.




Figure 1-7 Program Installation

Step 5. A message window will pop up to guide you to connect the SPH10 to the computer. Please hook up the SPH10 with your computer by using USB cable and then turn it on by selecting “Phone button” and “Jog Dial” together.

Note:

Please do not select “Cancel” button if it is the first time installation on your computer.

Step 6. A message box will disappear after 10 seconds, and it means the SPH10 is found successfully in the installation.




Figure 1-8 SPH10 is found

Step 7. Device Driver Installation Wizard will be started, then. Select “Next” button to proceed to the installation process of device driver.



Figure 1-9 Device Driver Installation Wizard is started

Step 8. It may take up to 10 minutes to lead you the next step. Please wait until you can see the next message window.




Figure 1-10 Device Driver is in installation

Step 9. Select "Finish" button to complete the installation to go to the final stage of the installation.



Figure 1-11 Completing the Device Driver Installation

Step 10. Final Installation message will be popped up. Select "Finish" button, and then SPH10 Manager will be started automatically.



Figure 1-6 Completing Setup Wizard

Please see the section 3 to learn how to use SPH10 manager.



Troubleshooting for failure in Device Driver Installation

If you see the error message on device driver installation failure, please follow the steps below to do troubleshooting.



Figure 1-7 Cannot complete the Device Driver Installation

1. Select "Finish" button and close SPH10 manager setup windows.
2. Uncheck the "Run SPH10 Manager 1.0" checkbox in the next pop-up window and then select "Finish" button.



Figure 1-8 Completing Setup Wizard

3. Restart your computer system.

Note:

Please make sure that SPH10 remains connected to your computer with keeping power-on status.

4. After your computer is restarted, please go to the menu, of SPH10 Manager program, by moving to *Start Menu -> All Programs -> Sena Technologies -> SPH10 Manager*.
5. Select "Install Driver" in the SPH10 menu.




Figure 1-9 Run Install Driver manually

6. Device Driver Installation Wizard will be started again. Please repeat the steps from **Step 6** to Step 10 to complete the installation.

2. Getting Started

2.1. Starting SPH10 Manager

Step 1. When you start SPH10 Manager, message box will be popped up as follows,




Figure 2-1 Start-up Instruction

Step 2. Please follow the steps on the message box and then click "OK" button.

Note: [Windows XP]

The further driver installation is required and it will be running automatically. Please look into the Windows task bar until the installation is completed. And, then select "OK" button if the process is completed.

Step 3. Then SPH10 Manger will display the firmware version of your SPH10 automatically. You may find the message, "SPH10 is connected with computer" if the program is successfully connected to the SPH10.



Figure 2-2 SPH10 is connected

If you fail to connect the SPH10, please close *SPH10 Manager* and restart it again.



Figure 2-3 SPH10 is not connected

2.2. Updating Firmware

Step 1. To update firmware of your SPH10, select “F/W Update” Button.

SPH10 Manager will automatically check the newest firmware on the management server. Please be sure to connect your computer to the Internet. If there is a newer version firmware on the server following message will be displayed.



Figure 2-4 New firmware is available

Step 2. Select “Yes” button and then select firmware download location on your computer.




Figure 2-5 Save New firmware

Step 3. After selecting download location and then select “Save” button.

Then new firmware will be downloaded from server and progress bar will be displayed as follows.



Figure 2-6 Firmware Downloading progress bar

Step 4. If new firmware download is completed, “Update” button will be displayed as follows. Select “Update” button to proceed to the next stage of firmware update.



Figure 2-7 Select Update button

Step 5. A yellow-colored message box will be popped up. Please press the “Phone” button of SPH10 and hold it awhile until the message disappears.



Figure 2-8 Press Phone button message

Step 6. Firmware is to be updated into the SPH10. During the process, please look into the message display of the program in order to check the progress. SPH10 Manager will first back up the firmware from the SPH10, and then write the new one to the device.




Figure 2-9 Firmware Back up process




Figure 2-10 Firmware Writing process

Note:

When the progress is reached 99%, the process may look halted about 10 seconds. This is normal operation for checking firmware on the SPH10.

Step 7. A yellow-colored message box will be popped up again. Please press “Phone button” and “Jog Dial” together until the message disappears.




Figure 2-11 Press Phone button and Jog Dial message

Step 8. Firmware Update is completed and the current firmware version will be displayed on the program window.




Figure 2-12 Update is completed

2.3. Restore Firmware

Step 1. To restore the SPH10 firmware to the original, select “F/W RESTORE” button. A message will show you the information of the firmware which is stored as a back-up.

Note:

Firmware restore function is available only in the computer where SPH10 had been updated. You need to use the same computer or firmware update when you restore it.



Figure 2-13 Firmware Back up Information

Step 2. Select “RESTORE” button to proceed and then yellow-colored message will pop up. Press “Phone” button of SPH10 until the message disappears. Then, firmware restore process will be started.




Figure 2-14 Restoring firmware




Figure 2-15 Press Phone button message




Figure 2-16 Firmware Restoring progress bar

Note:

When the progress is reached 99%, the process may look halted about 10 seconds. This is normal operation for checking firmware on the SPH10.

Step 3. After the process is completed, a message box will pop up again. Press “Phone button” and “Jog Dial” together until the message disappears.




Figure 2-17 Press Phone button and Jog Dial message

Step 5. Then firmware restore is completed and the current firmware version will be displayed on the program window.




Figure 2-18 Firmware Restore is completed

2.4. Update Firmware from specific file

Step 1. To update the firmware of your SPH10 using the firmware stored on your computer, select “F/W UPDATE” Button.



Figure 2-19 Update firmware

Step 2. Select “SELECT” button to open selection window, and then choose a firmware to be updated for your SPH10.




Figure 2-20 Open firmware

Step 3. Select “UPDATE” button to proceed.



Figure 2-21 Select update button



Figure 2-22 Progress bar in Firmware Update

Step 4. A yellow-colored message box will be popped up. Please press the “Phone” button of SPH10 and hold it awhile until the message disappears, and then the process will be continued.




Figure 2-23 Press Phone button message

Step 5. Press “Phone button” and “Jog Dial” together until the message disappears.




Figure 2-24 Press Phone button and Jog Dial message

Step 6. Firmware update is completed and the current firmware version will be displayed on the program window.




Figure 2-25 Updating is completed

2.5. Device Settings

You can set up some parameters of your SPH10 by using "DEVICE SETTINGS" menu.




Figure 2-26 Device settings

Please note that changing device settings is supported from firmware version 3.2. Please update your firmware first to set up the parameters.




Figure 2-27 changing device settings

After changing settings, select “SAVE” button to save the changes to SPH10.




Figure 2-28 Confirm save changes

Note:

Change of device settings is effective only after SPH10 is restarted.

2.6. Checking version of SPH10 Manager

In order to check the software version of *SPH10 Manager*, click **[?]** button on the upper-left corner of the *SPH10 Manager* program.



Figure 2-29 Check the version of SPH10 Manager