

“Build your own 3D Theater at Home.”
REAL-TIME 2D-3D CONVERSION SOFTWARE

3Dplus™

3Dplus version 2.0

USER'S MANUAL

What is 3Dplus™?

Principles of Stereoscopic effect

Basically, human see slightly different images from left eye and right eye. This binocular disparity is main factor of stereoscopic effect. The brain interprets these images into 3D image unconsciously, by repeated learning processes since the birth.

In case of existing 2D contents, both eyes see the same image. It is not convenient experience since it is unlike reality, but we are already familiarized with 2D images by repeated experiences.

The technology nobody has expected to be realized.

It is theoretically impossible to extract perfect 3D information from existing 2D contents. However, with diverse theories and US patented algorithms, Seoul Systems Co., Ltd. and Soft4D Co., Ltd. have succeeded in converting 2D contents into those with pertinent feeling of depth in real time.

This algorithm performs precise analysis on image sequences to extract movement between the images. From this motion type analysis, it determines which direction the camera or object moves, and provides pertinent depth feeling to each objects in the image by using this information. This algorithm can convert the image with not only the movement in left, right, up and down direction, but also in very fast movement or no movement at all.

Watch whatever movies you like in Stereoscopic 3D now

Currently there are very limited 3D movies, which has been specially designed and produced with huge cost and complex technologies.

3Dplus™ provided by Seoul Systems Co., Ltd. is the world-first software which converts any normal DVD and downloadable MPEG-2 movies into stereoscopic movies in real-time. This incredible technology is patented in US and Korea. Also it is under patent-pending in other 9 countries worldwide.

With 3Dplus™, people can enjoy real 3D movies whenever they want.

WARNING !

The most cost-effective way to enjoy stereoscopic movies individually is to use LCD shutter glasses. The 3Dplus package includes LCD shutter glasses.

In general operation system, LCD shutter glasses are very safe for ordinary people to use.

But a few people may feel uncomfortable with it due to hardware, software, or physical visual system.

Please stop using 3Dplus™ package if the following symptoms occur.

- Phenomena of Headache, eye injection, dimly images or duplicated images for more than 2~3 seconds.
- Epilepsy: if there's someone who suffers epilepsy in your family, you should consult a physician. A few people may suffer epilepsy when seeing lights and flashing from games or videos and someone who has not suffered epilepsy can suffer epilepsy at a certain conditions.
- Phenomena of unconscious physical motions, convulsions of muscle and eyes, imperceptibility of environment, mental confusion, dizziness, losing sense of direction, losing self-consciousness and etc.

It is stressed again that you should stop using 3Dplus™ system when above symptoms occur and consult a physician immediately.

Information : LCD Shutter glasses

LCD Shutter glasses are a kind of stereoscopic glasses. This glasses alternatively block left and right eye to show right display to right eye and left display to left eye. This process makes stereoscopic effect by showing different scene to each eye. 3Dplus™ is compatible with all LCD shutter glasses which support '**Sync-Doubling(above-below)**' format.

Table of Contents in this manual

| | |
|-------------------------------------|----|
| What is 3Dplus™? | i |
| WARNING ! | ii |
| Before Installation | 1 |
| Installation of LCD shutter glasses | 2 |
| Installation of 3Dplus™ software | 4 |
| Enjoying Stereo Movie with 3Dplus™ | |
| Frequently Asked Questions | |

Special Notice !

3Dplus requires the monitor refresh rate of min. **120Hz**.

General CRT monitors can support 120Hz of refresh rate at 800X600 resolution.

If you see **“Black Screen”** or **“Out-of-Sync”** error in your monitor when running 3Dplus in 3D mode, please **LOWER your CURRENT REFRESHRATE** until you see ordinary 3D images.

You can adjust refresh rate in Display Control window

(right click on desktop > display control > monitor(or adapter) > refresh rate).

Before Installation

3Dplus™ -compatible LCD shutter glasses

3Dplus™ version 2.0 currently supports Sync-Doubling stereoscopic format. So all Sync-Doubling supporting LCD shutter glasses are compatible.

* 3Dplus™ version 2.0 will support Interlaced format very soon. Also, it is scheduled to support page-flipping format too.

3Dplus™ -compatible movie file format

3Dplus™ version 2.0 currently supports PAL/NTSC DVDs and MPEG 2.

3Dplus™ version 2.0 is including basic direct DVD playback function.

Current 3Dplus™ version 2.0 supports Dolby/L-PCM sound format.

(Other DVD player software is required to be installed when playing MPEG2 files or DVDs in MPEG2 or other incompatible sound format. In this case, please install other DVD player software supporting various sound codec like PowerDVD - except for PowerDVD XP version - or WinDVD together.)

System Requirement


- Windows 98, SE, ME, 2000, XP
- Pentium III 733 Mhz or more
- 128 MB Memory
- 5 MB free space in H/D
- Overlay-supporting Graphic card
- Sound card
- IBM compatible Multi-scan CRT color monitor
- DVD-rom

Warning

- 3Dplus™ does not run on Pentium II or Celeron CPU. (It runs on AMD 900 or more)
- 3Dplus does not run with Laptop or LCD monitor. If you use Laptop, you can connect another CRT monitor to play 3Dplus.
- If sound card is not equipped in PC, 3Dplus will not run.


Installation of LCD shutter glasses

A. Wired Type Package



3Dplus™ Manual

B. Wireless Type Package





*IR emitter is to be fixed on the desk or monitor.
LCD shutter glasses will get signals from it wirelessly.*

Installation of 3Dplus™ software

Please Insert 3Dplus™ software CD” in your CD-ROM.




Below display will appear automatically. If you cannot see it, please execute install.exe file in your DVD-ROM drive.



3Dplus™ Manual

After seconds, below window will appear. Please click “Next” button.




License Agreement will show. Please read it carefully and click “Yes” button if you agree with it.



3Dplus™ Manual

You will be requested to write in serial number of your permitted license. The 16 digit license number can be found on software CD face. You should not skip bar (“-”) character.



The screenshot shows the 'InstallShield Wizard' dialog box with the 'Customer Information' tab selected. The dialog prompts the user to enter their name, company name, and a 16-digit serial number. The fields are pre-filled with 'Kwangseok Jung', 'Soft4D', and 'XXXX-XXXX-XXXX-XXXX' respectively. The 'Next >' button is highlighted.

InstallShield Wizard
Customer Information
Please enter your information.

Please enter your name, the name of the company for whom you work, and the product serial number.

User Name:
Kwangseok Jung


Company Name:
Soft4D

Serial Number:
XXXX-XXXX-XXXX-XXXX

InstallShield

< Back Next > Cancel

Below window is for selecting file location for installation. Default location is C:/program files/soft4d/3dplus2.0. If you want to change the location, please use “Browse...” button. Please click “Next” button.



The screenshot shows the 'InstallShield Wizard' dialog box with the 'Choose Destination Location' tab selected. The dialog prompts the user to select a folder for installation. The default location is 'C:\Program Files\Soft4D\3Dplus2.0'. The 'Next >' button is highlighted.

InstallShield Wizard
Choose Destination Location
Select folder where Setup will install files.

Setup will install 3Dplus2.0 in the following folder.

To install to this folder, click Next. To install to a different folder, click Browse and select another folder.


Destination Folder
C:\Program Files\Soft4D\3Dplus2.0 Browse...

InstallShield


< Back Next > Cancel

3Dplus™ Manual

You'll see brief Information of 3Dplus2.0 Program Specification.
Please click "Next" button.




You'll see Setup Status bar.



3Dplus™ Manual

Installation process is finished. Please complete installation by clicking “Finish” button.



You can see 3Dplus™ short cut icon in your desktop display.




Warning



When you see DVDs in 3D mode after your first run of the software, you may see very rarely ‘vertically mismatched stereoscopic image’. The software detects the feature of VGA card and automatically positions the left image and right image. However, in case of some rare VGA cards, this automatic offset-control can generate slightly wrong vertical placement. In this case, please use **Up/Down Arrow keys** to fit the vertical position of images in 3D mode or type in exact value of offset in configuration window. You can do this more easily by using **Setting Wizard** of configuration menu.



Enjoying Stereo Movie with 3Dplus™


With double-clicking 3Dplus™ icon, below main program window will appear.




1. Play mode

There're 2 play modes. DVD mode() and File() mode. Default mode is DVD mode. Mode changes when clicking the button.

On DVD mode, put DVD into your DVD-rom of PC and click Play() button. You'll see automatically converted stereoscopic movie when clicking 3D() button.



On File mode, push play() button or right-click on display window to load file browser window. Open preferred MPEG file or VOB file to play. (Some VOB files

3Dplus™ Manual







cannot be loaded because of access protection. You'll see automatically converted stereoscopic movie when clicking 3D() button. Press ESC to go back to 2D movie.

2. Basic Playback function

3Dplus™ version 2.0 software can directly access DVD and provides basic playback control functions. Please refer to the below instruction for each commands.



Slider bar, click for time seeking (available only when main movie playing)


-  Minimize the window
-  Terminate the program
-  Mode change (DVD mode and File mode)
-  Volume up
-  Volume down
-  Mute on/off

In stereoscopic 3D, you can see overlaid 2 pictures without wearing LCD shutter glasses (One for left eye and the other for right eye). 2 pictures should have the same vertical position. If 2 pictures looks slightly separated vertically, please use “Up/Down” arrow keys (↑ / ↓) to fit 2 pictures placed at the same vertical position.


3Dplus™ Manual

3. Context menu commands

On DVD mode, when you right-click on the Display window, you'll see below context menu.




On File mode, when you right-click on the Display window, you'll see below context menu.



In 3D mode, when you click the window, you will see 2 mouse pointers at the same time. When your mouse pointer cannot click the context menu in 3D mode, please move the pointer upside and find the other lower mouse pointer and use it.

4. Configuration



This button is short cut to “Setting Wizard”. Please use this option for easy and fast settings.



- Offset control : Offset means the vertical position value of right-eye images. The software detects the feature of VGA card and automatically positions the left image and right image. However, in case of some rare VGA cards, this automatic offset-control can generate slightly wrong vertical placement. In this case, please use Up/Down Arrow keys to fit the vertical position of images in 3D mode or type in exact value of offset in configuration window.
- Select Glasses : Default value is IO-Display’s H3D glasses. If you have another glasses, please select others. Please be sure to use Sync-double supporting glasses.

3Dplus™ Manual

5. Wizard.

When you execute 3Dplus™ first time, Setting Wizard will appear automatically. This Setting Wizard will help users set optimized configuration with minimal knowledge.

You can use this Setting Wizard again any time you want with using button of Preference menu of context menu (right-click to show it in display window). Please click “Next” button




Below step is for selecting glasses. 3Dplus™ is compatible with all kinds of LCD shutter glasses, which support Sync-Doubling stereoscopic format.



3Dplus™ Manual

Below step is for setting stereoscopic environment. You can adjust optimized stereoscopic environment for your system. Please click “End” button and use upper and lower arrows to adjust stereoscopic bars to be clear.

Please push ESC key to complete setting and return to the main window.



Warning



If you see separate bars like above picture, please check below conditions.

- Are all hardware components properly installed? Please check if there is loose connection of cables and ports.
- Are you sure that you are using CRT monitor? 3Dplus does not run with LCD monitor.
- Have you installed correct version of VGA card driver and monitor driver?
- If you suffer from the same problem after checking all above conditions, please contact 3Dplus customer care center.

Frequently Asked Questions

I see “Black Screen” or “Out-of-Sync” error in your monitor when running 3Dplus in 3D mode

Please LOWER your CURRENT REFRESHRATE until you see ordinary 3D images. 3Dplus requires the monitor refresh rate of min. 120Hz.

General CRT monitors can support 120Hz of refresh rate at 800X600 resolution. You can adjust refresh rate in Display Control window (right click on desktop > display control > monitor(or adapter) > refresh rate).

I cannot see ordinary stereoscopic picture. I see just 2 separate images in above and below on my screen.



Basically, 3Dplus™ version 2.0 software converts normal movies into sync-doubling (above-below) format of stereoscopic 3D movies. When the software generates 2 separate images in above and below (sync-doubling format), VGA controller (a component of LCD shutter glasses) puts those separate images together and generates ordinary stereoscopic image. So, please check whether you've installed hardware components correctly and whether you selected proper type of glasses in glasses list of preference menu of 3Dplus program first and please try again. Or please be sure that you're using CRT monitor. (LCD monitor or notebook does not work.)

When I see my DVDs or MPEG2 files in 3D mode, I feel 2 images are overlaid and one image is vertically not perfectly placed on the other image.



3Dplus™ Manual

There're 2 images in stereoscopic image. One is for Left eye and the other is for Right eye. 2 images should be piled up perfectly in vertical position.

3Dplus™ version 2.0 software controls the vertical position of 2 images automatically (So called "Offset Control"). The software detects the feature of VGA card and automatically positions the left image and right image.

However, in case of some rare VGA cards, this automatic offset-control can generate slightly wrong vertical placement. In this case, please use Up/Down Arrow keys to fit the vertical position of images. Single click of arrow key will move right-eye image by single pixel.

Sometimes slider bar, next/previous chapter buttons, 3D button does not work. Why?

Before main movie starts, slider bar, next/previous chapter buttons, 3D button does not work. All functions will work after main movie starts. It is general for all DVD playback software.

Some VOB files does not work in File mode. Why?

VOB files exists in DVD. VOB is each divided Chapter movie file. Generally, DVD and individual VOB files are protected from unauthorized access. DVD playback software like 3Dplus version 2.0 can play protected DVD but it cannot play protected VOB files.

I cannot hear sound when playing MPEG2 file of some DVDs. Why?

Current version of 3Dplus version 2.0 supports Dolby and L-PCM format of sound. So sound will not hear when playing files or DVDs in other format of sound (MPEG2, MP3 and etc.). In this case, please install other DVD player software supporting various sound codec like PowerDVD (except for PowerDVD XP version) or WinDVD together. Then you'll be able to hear ordinary sound with any MPEG2 files and DVDs.

I cannot click in DVD menu in 3D mode. Why?

In 3D mode, the position of mouse pointer is not correct. You'd better return to 2D mode to select on DVD menu.



3Dplus Customer Care Center

e-mail : 3Dplus@ssc.co.kr

Tel : +82-2-510-0765

Fax : +82-2-515-0522

**Address : 3Dplus Customer Care Center, 5F SSC Bldg.
#213-5 Nonhyun-Dong, Kangnam-Gu, Seoul, Korea 135-010**

[Http://3dplus.ssc.co.kr](http://3dplus.ssc.co.kr)