XR3000

SET UP GUIDE 13.

DRAFTING BY DATA, NO WEIGHING, NO EID

(E.G. PREGNANCY STATUS)

This setup is used if you are drafting by data but not using EID or weighing, such as drafting by pregnancy scan result.

STEP 1:

If required, set up a field for data entry in the Life Data or File Data screens.

To set up a data field, XV, WELLAIA or ELLICAIA.

Set up field options, as required.

For more information about setting up data fields, see the XR3000 User Manual.

In this example, a life data field has been set up to record pregnancy scan status (Preg Sc):

File Data S	etup		FILE: 1	
GROUP WEIG	CARCASS WEIGHT::	×		
DATE STAM			TIME STAMPING	
DATE STAM LABEL	IPING:X	TYPE	TIME STAMPING FORMAT OR LENGTH	

STEP 2:

Press and set up the screen as shown:

Note: Pregnancy Status (PREG SC) is ticked so it will appear as a data entry field on the right hand side of the Weighing screen.

Weighing Screen Setup	FILE: PREG SCAN DRAFT				
Tick the items you want on the main weighing screen.					
LHS (FOR VIEWING)	RHS (FOR DATA ENTRY)				
✓ Prompt message × Draft range × Carcass weight × Value × Weight gain × Prediction × Days ▼ FID ▼ × EID	<pre> ✓ FID × EID . LID . Mob . Class × Breed . DOB . Spare ✓ PREG SC</pre>				
	W.GAIN SYSTEM				

STEP 3:

To select a file, press **FILES** then scroll to the new file.

Note: It is good practice to start a new file each time a new session is started. You should name the file relevant to the job you are doing. This is good practice for record keeping.

List o	List of Files					
FILE	FILE NAME	RECORDS	START DATE			
01234567899 ▼10	PREG SCAN DRAFT	000000000000000000000000000000000000000	•			
TOP	BOTTOM SORT FI	ND][FILE	JATA] >>			

XR3000

SET UP GUIDE 13.

DRAFTING BY DATA, NO WEIGHING, NO EID

(E.G. PREGNANCY STATUS)

STEP 4:

Optimise the system for the task being performed.

Press XY, SYSTEM.

As animals are not being weighed, set Weight Recording to **Off** in order to increase the speed of data entry.

Tick ID Entry Creates File Rec to allow the XR3000 to record data without weighing.

System Setup рамр system: Superdamp III (Sheep) WEIGHT RECORDING: Off DATE: 30/11/2009 RESOLUTION: 0.1 TIME: 16:11 0.0 kg SET TARE: FONT: Original auto zero track : On Net васкызыт: Auto POWER UP ZERO : ▼ contrast: 5 AUTO POWER OFF : ✔ STARTUP SCREEN: ✓ REWEIGH SOFTKEY: X ID ENTRY CREATES FILE REC. : ✓ REVERSE WEIGHING: X DISABLE POPUPS: X sound: Standard COUNTRY: NZ

STEP 5:

Press X, DRAFT.

Set up drafting options, as required.

Drafting S	etup	FILE: PREG SCAN DRAFT		
DRAFTING: ✔ DRAFT BY: PI NO EID TIMEOU	REGISC	DRAFTING RANGES: 3 ICONS: Lar9e Arrows NO EID DIRECTION: ↑		
RANGE	FROM	TO	ARROW	
123	0 1 2	OM TO ARROW 0		
RECALC				

STEP 6:

The main Weighing screen should be displayed as shown:



