

## SERVICE MANUAL

### Biological degreasing fountain



CE

## **Contents**

Introduction	Page 3
Initial checks and packing	Page 3
Contents of the supply	Page 3
Handling the fountain	Page 3
General Description	Page 4
Characteristics	Page 5
Preparation for Start-up	Page 5
First Start-up	Page 5
Initial filling procedure	Page 6
Instrument panel – Commands and indications	Page 7
Adjustment parameters	Page 8
Normal refilling during use	Page 9
Normal cleaning and maintenance	Page 10
Wearing parts	Page 11
Annual preventive maintenance	Page 13
Draining the tank	Page 13
Electrical fault finding	Page 14
Electrical diagram	Page 15
Precautions in use for the biological fountain (Display on base of tank)	Page 21
Quality control card	Page 22-23
Guarantee form	Page 24
Rapid diagnostics and fault finding	Page 25
Manufacturer's guarantee card	Page 26
Letter of intent	Page 27
EVIC France report	Page 28

## INTRODUCTION

This equipment is intended for the exclusive use of biological fountain degreasing fluid.

No part of this manual may be reproduced or communicated in any form or by any means whatsoever, electrical or mechanical, without the express written permission of ERAD FRANCE.

### Initial checks and packing

You have just received your biological degreasing fountain.

It is essential, immediately upon delivery, to check the condition of the equipment that has just been delivered to you. You will find the quality control card in the Service Manual.

If you discover anything missing from your supply or any damage when you unpack it, it is essential that you state the facts on the delivery note.

Only by stating the facts on the original documents can you ensure replacement or repair.

The fountain is delivered fully packed in a palletised box.



Keep all the packaging until final commissioning of the equipment.

Do not destroy the packaging or the various packing pieces, since return to our factory or logistics platforms is only possible using the original packaging.

### Contents of the supply

The biological fountain is delivered mounted and ready for commencement of the commissioning procedure.

- Biological degreasing fountain
- Service Manual
- first filling kit (20 litres)
- 1 litre glass bottle (for sampling the solution) – Identification card from the CERECO laboratory – Letter of Intent (see page 27).

***Never handle the fountain by carrying it or pulling it by the working tank. Always use a pallet truck, a base being provided for this purpose.***



Handle the equipment with care.

## GENERAL DESCRIPTION

The fountain is delivered fully assembled ready for use

