

**Warranty
Registration:**

register online today for a
chance to win a FREE Tripp Lite
product—www.tripplite.com/warranty



Owner's Manual

USB 2.0 / eSATA to SATA Hard Drive Quick Dock

Model:
U239-UE1

Features	2
Package Contents	2
Installation	3
Warranty & Warranty Registration	4



1111 W. 35th Street, Chicago, IL 60609 USA • www.tripplite.com/support

Copyright © 2012 Tripp Lite. All rights reserved.

Features

- Works with both 2.5" and 3.5" SATA hard drives
- Supports high-speed USB 2.0 data transfer rates up to 480 Mbps
- Supports SATA data transfer rates up to 3 Gbps
- Features two USB 2.0 hub ports
- Supports Windows 98/ME/2000/XP/Vista/7, Mac OS 9.x/10.x, Linux

Package Contents

- U239-UE1 Quick Dock
- USB Device Cable
- 7-Pin eSATA Cable
- External Power Supply (Input: 100-240V, 50/60Hz, 0.8A Output: 12V, 2A)
- Owner's Manual

Installation

1. Make sure that the power to the computer you are connecting is turned off.
2. Using the included USB cable or eSATA cable, connect the unit to your computer. **Note:** *Both USB and eSATA cables can be connected at the same time, but the USB cable must be connected if you are using the USB 2.0 hub ports.*
3. Insert your 2.5" or 3.5" SATA hard drive into the slot on the top of the unit.
4. **Optional** – Connect up to two USB devices to the USB 2.0 hub ports on the front of the unit. **Note:** *The USB cable must be connected if you are using the USB 2.0 hub ports.*
5. Connect the external power supply to the unit, and then plug it into an appropriate power source.
6. Turn on the power to the unit.
7. Turn on the power to the connected computer.

Warranty & Warranty Registration

1-Year Limited Warranty

TRIPP LITE warrants its products to be free from defects in materials and workmanship for a period of one (1) year from the date of initial purchase. TRIPP LITE's obligation under this warranty is limited to repairing or replacing (at its sole option) any such defective products. To obtain service under this warranty, you must obtain a Returned Material Authorization (RMA) number from TRIPP LITE or an authorized TRIPP LITE service center. Products must be returned to TRIPP LITE or an authorized TRIPP LITE service center with transportation charges prepaid and must be accompanied by a brief description of the problem encountered and proof of date and place of purchase. This warranty does not apply to equipment, which has been damaged by accident, negligence or misapplication or has been altered or modified in any way.

EXCEPT AS PROVIDED HEREIN, TRIPP LITE MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Some states do not permit limitation or exclusion of implied warranties; therefore, the aforesaid limitation(s) or exclusion(s) may not apply to the purchaser.

EXCEPT AS PROVIDED ABOVE, IN NO EVENT WILL TRIPP LITE BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF THIS PRODUCT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE. Specifically, TRIPP LITE is not liable for any costs, such as lost profits or revenue, loss of equipment, loss of use of equipment, loss of software, loss of data, costs of substitutes, claims by third parties, or otherwise.

Use of this equipment in life support applications where failure of this equipment can reasonably be expected to cause the failure of the life support equipment or to significantly affect its safety or effectiveness is not recommended. Do not use this equipment in the presence of a flammable anesthetic mixture with air, oxygen or nitrous oxide.

WARRANTY REGISTRATION

Visit www.triplite.com/warranty today to register the warranty for your new Tripp Lite product. You'll be automatically entered into a drawing for a chance to win a FREE Tripp Lite product!*

* No purchase necessary. Void where prohibited. Some restrictions apply. See website for details.

Tripp Lite follows a policy of continuous improvement. Product specifications are subject to change without notice.



1111 W. 35th Street, Chicago, IL 60609 USA • www.triplite.com/support

12-133 • 93-3239_RevA