

Release Notes


IRRICAD Pro Version 11

By Lincoln Ventures Ltd



This manual was produced using *ComponentOne Doc-To-Help*.™

Contents

1 Release Notes Pro V11	1
1.1 In Pro Version 11.0	1
1.1.1 Tools Menu Changes.....	1
1.1.2 Contour Generation	2
1.1.3 DEM Improvements.....	2
1.1.4 Zone Pressure Map 	4
1.1.5 Control Valve Selection and Specification Improvements	5
1.1.6 Pipe Reduction Symbols.....	5
1.1.7 User Attributes are Enabled For Pipes, Tapes and Spraylines.....	6
1.1.8 Database Editor – What’s New	6
1.1.9 Language Compatibility	14
1.2 Previous Additions and Bug Fixes	17
1.2.1 In Pro Version 10.5.....	17
1.2.2 In Pro Version 10.0.....	32
1.2.3 In Pro Version 9.5.....	38
1.2.4 In Pro Version 9.....	45
1.3 Hot off the Press – New Patch Additions to Pro Version 11.....	54
2 Index	55




1 Release Notes Pro V11

1.1 In Pro Version 11.0

1.1.1 Tools Menu Changes


The **Tools** menu has now been split between the new **Modify** menu and the **Tools** menu. The items now found in the Modify menu are:

The items in the **Tools** menu are:



1.1.2 Contour Generation

Contours can now be calculated from spot heights using the Calculate Contours tool (*Tools|Calculate Contours*). The tool allows the contour interval and the properties of the calculated contours to be set.



1.1.2.1 CONTOUR PROPERTIES

Contour Interval: The elevation difference between contours

Minimum Elevation: the minimum elevation based on the existing spot height elevations

Maximum Elevation: the maximum elevation based on the existing spot height elevations


No. of Contour Levels: Based on the contour interval and the range of elevation, the number of contours to be produced will be calculated.

Note: Calculated contours are for display purposes only and their elevations cannot be edited. They are classed as secondary sources of elevation data and do not form inputs to the elevation interpolation functions.

1.1.3 DEM Improvements

The DEM (Digital Elevation Model) used by Irricad has been greatly improved with the implementation of an ABOS system (**A**pproximation **B**ased **O**n **S**MOOTHing). The ABOS method is much faster than the old AEI method, and is much better at representing likely topography, especially when based on a low number of height points. It does not show the artefacts sometimes generated by the old method.


The images below show a height map generated from five spot heights by both DEM methods



Old AEI Method

New ABOS method


The ABOS method also provides an interpolation summary after calculation:



Also note that the grid lines are off by default in the 3D DEM view. These can be turned back on by pressing the <G> key on the keyboard.

1.1.3.1 ABOS PARAMETERS

There are three parameters to the ABOS method that the user may change. These are found on the Designs Parameters dialog ([Design](#)|[Design Parameters](#)|[Analysis Parameters](#)).



D.E.M. Options

Interpolation Method: The ABOS method is the default, but the user may switch back to using the old AEI method if required.

D.E.M. Resolution: The ABOS method internally represents contours as individual points. These points are automatically generated along contour lines at this resolution.


D.E.M. Accuracy: The target precision of the ABOS method. It is the maximum difference between the source height point data and the surface generated by ABOS and is defined as a percentage of the height range – i.e., a percentage of the difference between the maximum and minimum heights.

D.E.M. Grid Size: If this value is set to 0 then IRRICAD will choose a suitable grid size. However this may result in a large number of grid points and consequently slow the generation and loading of the 3D DEM.

1.1.4 Zone Pressure Map

A graphical representation of the pressures in a zone can now be created using the *Reports>Show Zone Pressure Map* function.

Select a control valve (Design / Analyse needs to have been completed for the zone) and choose *Reports>Show Zone Pressure Map|Selected Valve*.



The Pressure Map dialog box contains the following sections:

- Drawing Properties:**
 - Layer: <DEFAULT>
 - Line width: 4
- Map Info:**

Zone pressure limits:	Min	12.00 m
	Max	25.00 m
Actual limits:	Min	12.46 m
	Max	23.09 m
Number of emitters: 15732		
- Map Properties:**
 - ☐ Use zone pressure limits
 - ☒ Use custom pressure limits:
 - Min pressure: 14 m
 - Max pressure: 20 m
 - ☐ Individual markers on connected spraylines

Buttons: OK, Cancel

Map Info:


The pressure map dialog shows the pressure limits for the zone, as well as the actual maximum and minimum emitter pressures in the zone.

Map Properties:


The pressure map can be created using the zone pressure limits or custom limits may be specified on the dialog. Custom limits could be used to show the range within a smaller tolerance if required e.g: 14m – 20m (as seen below in the Tape Block image).

Individual markers on connected spraylines:

Individual circular fills can be placed at the location of each emitter by enabling the check box (as below in the Spray Block image). This can cause slow redrawing at higher numbers of emitters, uncheck the “Individual markers on connected spraylines” check box.








Tape Block



Spray Block

The pressure map symbol is colour coded as follows:


	Emitter pressure is below the minimum allowable pressure.
	Emitter pressure is within 10% of the lower pressure limit.
	Emitter pressure is within the allowable pressure range
	Emitter pressure is within 10% of the higher pressure limit.
	Emitter pressure is above the maximum allowable pressure.

Note: The pressure map can only be shown for one zone at a time.

1.1.5 Control Valve Selection and Specification Improvements


1.1.5.1 SELECTING CONTROL VALVES

The flow range of each control valve has been added to valve combo box. This assists with the selection of the correct valve.



1.1.5.2 VALVE SPECIFICATION SUMMARY

A new valve specification summary dialog has been added (*Design|Valve Specification Summary*). After running *Valve Analysis*, open this dialog to see the valves and their design flows. Valves that have flows outside of their specified range will be displayed in red. The “*Valve Type*” can be changed in this dialog. The drop down shows the available valves and their flow ranges. *Valve Analysis* is rerun automatically when the dialog is closed.



List suitable valves: Only valves which have flow ranges appropriate for the zone flow will be listed as well as the currently selected valve.

List all valves: All valves enabled in the database will be listed.

1.1.6 Pipe Reduction Symbols



Pipe reduction symbols can be automatically placed on the design to show the location, and direction, of changes in pipe size.

To place the symbols on the plan:

1. Select *Draw|Pipe Reductions*.
2. Select the type of item or items to be labelled with pipe reduction symbols.
3. Click the **[OK]** button.

The items which are labeled with pipe reduction symbols can also be controlled by using *Select* tools. Both pipe sizes need to be selected for the smaller pipe to be labelled with the pipe reduction symbol.

If no items are selected, then all items of the types specified in the “Tool Options” will be labeled (i.e. this is equivalent to a *Select All*).



Drawing Properties

Layer: The default layer is IRRICAD.
Symbol Name: The default symbol is **PipeReduction** but can be replaced by any other symbol.
Symbol Size: The default symbol size is 5.

Tool Options

Symbol Spacing: The spacing in 'symbol size' from the junction i.e 1 is the same length as the symbol itself at the current “Base Database Symbol Size”: if the symbol measures 2m in length on the plan, then the symbol will be placed 2m from the junction at symbol size 1.

Mainline items: Check this option to place reduction symbols on Mainline items.
Zone items: Check this option to place reduction symbols on Zone items.
Include hydraulic items: Any reduction occurring at a valve, pump or other hydraulic item will not produce a reduction symbol unless this option is checked.
Use pipe colours: When checked, the reduction symbols will be the same colour as the smaller pipe. When unchecked all reduction symbols will be black.

1.1.7 User Attributes are Enabled For Pipes, Tapes and Spraylines

See User Guide – Enhancing the Presentation of Plans – Automatic Labeling.

1.1.8 Database Editor – What’s New

In response to requests for improvements we have made significant changes, including introducing standard Windows functions for navigation and editing. Details below :-

1.1.8.1 WAREHOUSE CODE – 32 CHARACTERS ALLOWED

The maximum number of length of Warehouse codes has been increased from 12 to 32 characters.

Note that databases created, or edited, in the Pro Version 11 Database Editor cannot be used with older versions of IRRICAD unless the warehouse code field is converted to 12 characters. For information on how to accomplish this contact your local Irricad support agent

1.1.8.2 WHAT'S NEW IN THE FILE MENU

Close

To close the currently viewed database without saving any changes:

1. Select **File|Close**.
2. Select **[Yes]** to close all databases, saving changes or **[No]** to close all databases without saving or **[Cancel]** to not close the Database Editor.

Save Copy As

To save a copy of the database under a different name:

1. Select **File|Save Copy As**.
2. Change the name of the database.
3. Click the **[Save]** button.

1.1.8.3 EDITING FUNCTIONS

The Database Editor has incorporated standard windows functions for manipulating and finding text and specific record based methods for copying and pasting groups of, and individual, components.

U <u>ndo</u>	Ctrl+Z
R <u>edo</u>	Ctrl+R
U <u>ndo Record</u>	
 C <u>ut</u>	Ctrl+X
 C <u>opy</u>	Ctrl+C
 P <u>aste</u>	Ctrl+V
C <u>opy Component</u>	Ctrl+Shift+C
P <u>aste Component</u>	Ctrl+Shift+V
 F <u>ind...</u>	Ctrl+F
R <u>eplace...</u>	Ctrl+H
 F <u>ind next</u>	F3
 F <u>ind previous</u>	Shift+F3

The functions below are found in the **Edit** menu.

Undo

Select to undo the last action.

Redo

Repeats the last action which was undone (see above).

Undo Record

Undoes multiple changes to the same record, e.g., description, warehouse code and supplier.

Cut

Cuts out part of a description, warehouse, supplier code, etc on to the clipboard to be used at a later time. This function will only copy the highlighted text.

Copy

Copies a description, warehouse, supplier code, etc on to the clipboard to be used at a later time. This function will only copy the highlighted text.

Paste

Pastes from the clipboard (after copying) into the currently selected field.

Copy Component and Paste Component

Complete components can now be copied and pasted into the current database or other databases. Multiple components can be copied and pasted in one action.

To copy a component(s) to be pasted into another open database:

1. Select the component(s) to be copied by clicking on the grey box the left of the component name. This will highlight the whole line associated with the component.
2. Select **Edit|Copy Component**.
3. Open or select the required database from the **Window** menu.
4. Place the cursor where required for the new record(s), in the required component group.
5. Select **Edit|Paste Component**.

Notes:

The Copy Component function differs from Copy in that it will completely copy all the fields of a component, including assembly items or nozzles.

The copied component, or groups of components, will be pasted into the correct component group regardless of the current group.

You can copy a component into the same database. This is useful if you need to create an item, or set of items, very similar to an existing one.

To maintain uniqueness between records, IRRICAD will automatically add a ~ to the name of each copied item. The combination of name and warehouse code will then be able to be differentiated from other similar items in IRRICAD and the Database Editor.

Find

Searches the database for particular word or phrase. **Find** only looks in the current field (column) and tab.

1. Select the required component group to search.
2. Select **Edit|Find** and type in the required word or phrase.
3. Click the **[Find Next]** button until the required entry is found.

Note:

"Match Case" and "Up" or "Down" options may be selected as required.

Find Next:	This action will move to the next record which contains the keyword.
Cancel:	[Cancel] will stop the search and close the Find dialog.
Match Case:	If checked, the only items which the search will find will be those with the correct case e.g. ANGLE if typed in upper case in the "Find" field.
Direction:	The direction of the search can be specified as above the current cursor position ("Up") or below the current cursor position ("Down").

Replace

Searches and replaces specific words or phrases with a new word or phrase. **Replace** only looks in the current field (column) and tab.

1. Select the required component group to search.
2. Select **Edit|Replace** and type in the required keyword to find and the required word to replace.
3. Click the **[Find Next]** button until the required entry is found.
4. Click the required action button for the current record.

Replace:	Clicking this button will replace the keyword or phrase in the "Find what" field with the word or phrase in the "Replace with" field for the current record.
Replace All:	Clicking this button will replace the keyword or phrase in the "Find what" field with the word or phrase in the "Replace with" field for all records containing the keyword or phrase as per the "Find what" field.
Cancel:	[Cancel] will stop the search and close the Replace dialog.

Match Case:

If “**Match Case**” is checked, the only items which the search will find will be those with the correct case e.g. ANGLE if typed in upper case in the “**Find**” field.

Find Next

Continues the search as per the current **Find** dialog settings.

Find Previous

Finds the previous records found in the search one at a time.


1.1.8.4 IMPROVEMENTS TO CURVE FITTING

A vast improvement to the **Curve Fitting** utility is the introduction of a button that will copy the calculated constant, index and intercept into the relevant fields on the current record.

The calculated curve is now shown below the curve fit grid.

Select the required curve fitting type from the drop down box.


The **Curve Fitting** utility can be turned off via **View|Curve Fit**. This window will appear on the right-hand side but can be floating.



1.1.8.5 IMPROVEMENTS TO THE GRID VIEW

Many improvements have been made to the Database Editor, giving it a new look and fast editing functions. Major improvements are:

- Pipes and tapes now show the line types and colours in the grid.
- Double-clicking on an item will bring up the item dialog.
- A right-click menu allows adding, editing, and deleting items as well as assembly actions and editing nozzles on outlets.
- Double-clicking on the column names (i.e. Description, Warehouse Code, Supplier Code or Usage) will sort the items alphabetically. To return to the default order, click on another tab and then return to the group.
- Adding, editing or deleting components are now actioned on the toolbar through the buttons shown below or via the *Component* menu.



Some functions have changed slightly, in that they need to be put into editing mode before adding or removing can be actioned. This applies to assemblies and nozzles.

Edit Assembly

When in edit mode, double clicking on an item in the assembly grid will allow editing of the number of items.

This tool needs to be actioned before adding items to or removing items from an existing assembly.

To edit an assembly:

1. Select the assembly in the component group by clicking on the name.
2. Select *Component|Edit Assembly*.
3. Now select *Component|Add to Assembly* or *Component|Remove from Assembly*.

Add to Assembly

For adding items to an existing assembly:

1. Select *Component|Edit Assembly*.
2. Select *Component|Add to Assembly*.
3. Add components as required to the assembly.
4. Select *Component|Finish Assembly*.

Remove From Assembly

Used to remove the selected item from an existing assembly.

1. Select *Component|Edit Assembly*.
2. Click on the item to be removed from the assembly.
3. Select *Component|Remove from Assembly*.
4. Select *Component|Finish Assembly*.

Finish Assembly

Select *Component|Finish Assembly* to finish creating, adding to or removing items from an assembly.

Edit Nozzles

This tool is to be actioned before adding nozzles to or removing nozzles from an existing outlet.

To edit an outlet:

1. Select the outlet in the outlet component group by clicking on the name.
2. Select **Component|Edit Nozzles**.
3. Now select **Component|Add Nozzles** or **Component|Remove Nozzles**.
4. To finish adding or removing nozzles, select **Component|Edit Nozzles**.

Add Nozzles

Used to add existing nozzles to an outlet. After invoking this tool, the view is taken to the nozzles component group.

After adding a new outlet to the database, select the **Component|Edit Nozzles** and then **Component|Add Nozzles** to select existing nozzles for the new outlet. This will open the nozzle tab.

1. Click on the required Outlet.
2. Select **Component|Edit Nozzles**.
3. Now select **Component|Add Nozzles** and select the required nozzles.
4. To finish adding nozzles, select **Component|Edit Nozzles**.

Remove Nozzles


Used to remove selected nozzles from an existing outlet. Highlight the required nozzle in the Nozzles area at the bottom of the Outlets group dialog.

1. Click on the required Outlet and then the required nozzle to be deleted.
2. Select **Component|Edit Nozzles**.
3. Now select **Component|Remove Nozzles**.
4. To finish removing nozzles, select **Component|Edit Nozzles**.

1.1.8.6 QUERIES

The Query function allows low level access to Irricad databases via Microsoft® Jet SQL. Using this facility could cause corruption of databases and therefore creating new queries shouldn't be attempted without a reasonable knowledge of both SQL and the structure of Irricad databases.

IRRICAD Pro Version 11 does come equipped with pre-set queries, which can be used to view or update various database tables. Examples include:- showing the Pipe Table (this also allows you to add or edit pipe codes); and an example of increasing pipe prices for a particular supplier.



The Query tab is only visible if “[Show Query tab](#)” is checked in [Tools|Options](#).

The tools are available from the [Query](#) menu or short cut icons on the toolbar:



Execute Query

This option executes the current query (the SQL code for this is shown in bottom pane of the query tab). Results of the query are shown in the main grid pane of the Query tab.

An option is available ([Tools|Options](#)) that will execute SELECT queries automatically when they are selected.

To execute a query:

1. Choose the required query from the dropdown list on the tab.
2. Select [Execute Query](#) from the menu or toolbar.

Save Query

This saves the current query with the title as specified in the “[Query name](#)” combo box. Note that all queries are saved in a text file, [Queries.irq](#), located in the main Irricad Pro folder.

If a query with that name already exists, the user will be prompted to over-write it.

Delete Query

This option removes the current query from the query configuration file.

To delete a query:

1. Select the query to be deleted.

Reload Query

Select this option to reload all queries and redisplay the current query. This is useful if the user wishes to “undo” the modification to a query, or if the query file has been updated externally.

1.1.8.7 WINDOW OPTIONS

These options control how the open databases can be displayed. These are detailed below.

Cascade

An option for displaying multiple databases in a cascading fashion i.e. each next window displayed below the previous title bar.

Tile

An option for displaying two database one below the other on the screen.

Arrange Icons

In the event that many windows are open but minimised, [Arrange Icons](#) will arrange the minimized window icons in the left-hand corner.

Open Databases List

Lists all databases that are open and indicates which one currently has the input focus. Found in [Window|Open Database List](#).

1.1.8.8 TOOLS MENU

This menu includes the *Clean Fields* and *Delete Orphan Nozzles* that were originally in the *Utilities* menu.

Setup Options have moved from the *Help* menu and have been renamed *Options*. New options have been added to this dialog and are detailed below.

Units are now accessed from this menu.

Units

These settings control the units used for display and entry for each type of quantity.

To set units:

1. Select *Settings|Units*.
2. Edit each measurement as required.
3. Click [OK].

Note: The units set here will also change the default units in IRRICAD.

Options

Tools|Options contains the original *Setup Options* which were in the *Help* menu previously. Additions are:

Maximize application on start-up

When checked, the database editor will open full screen.

Maximize database window on open

When checked databases will open full screen within the main pane of the Editor.

Open database on start-up

When checked, select the default database or last opened database to open on start-up.

Show Query tab

When checked, the Query tab will be visible after the Nozzles component tab.

Execute SELECT queries automatically

When checked, the query will run automatically when selected.

Customize

Toolbars can be customized and their viewing controlled through the *View|Toolbars* menu. A shortcut is also available by right-clicking on any toolbar. The operation of this facility is described below.

Toolbars Tab

The display of individual Toolbars may be toggled using the check boxes provided. At any time when the Toolbar "Customize" dialog is open buttons may be 'dragged' from one toolbar to another, dragging a button onto the main view area or any other area that is not a Toolbar will remove a button.

New Button:	IRRICAD contains a set of default Toolbars (Design, Dimension, Drawing, Electric, File, Hydraulic, Modify, Select, Snap, Tool, and Zoom). It is possible to add new blank Toolbar by clicking the [New] button.
Reset Button:	When one of the default IRRICAD toolbars is highlighted the reset button is available. Clicking this will repopulate the current Toolbar with its default buttons. If any buttons have been previously moved to other Toolbars then copies of these buttons will be retained in those Toolbars.
Delete Button:	User defined Toolbars (created with [New]) can be removed by selected the desired Toolbar and clicking the [Delete] button which will be available. Note that it is not possible to remove the default IRRICAD Toolbars although they can be depopulated or hidden.
Show ToolTips:	Controls whether tooltips are displayed when the mouse cursor is paused above a Toolbar button.
Cool Look:	This check box changes the appearance of the Toolbars to a 'flat' style.

Large Buttons: This button will increase the size of the buttons on the screen.

Commands Tab

This tab contains the commands that can be represented by a button; they are grouped in a way that matches the default Toolbars. Clicking on a category shows the buttons that are available; these buttons can then be dragged onto any existing Toolbar (default or user defined). Note that the same command/button can exist in more than one Toolbar.

Winicad.ini

The current Toolbar configuration for IRRICAD is stored in an initialization file called Winicad.ini in the main Windows folder (normally C:\WINDOWS or C:\WINNT).

Supplementary Character set

This accesses the same setting as in IRRICAD and needs to be set to enable Left to Right languages or East Asian languages to display correctly in the “grid” views. For more information see the section entitled Language Compatibility.

1.1.8.9 CHANGES TO THE HELP MENU


The *Help* menu no longer contains the *Setup Options*. These can now be found in *Tools|Options*.

1.1.9 Language Compatibility

Pro Version 11 has added support for the supplementary character set which enables IRRICAD to display fonts from other language sets.

This, in conjunction with the Windows “Language for Non-Unicode Programs” setting (found in Control Panel | Regional and Language Options | Advanced tab), enables non-western character sets to be displayed correctly.

1. Ensure the Control Panel | Regional and Language Options | Advanced tab has the required “Language for non-unicode programs” selected.
2. In *Settings|Miscellaneous* select the matching language from the “Supplementary character set” dropdown. Note this setting is not design specific and will be retained between designs.




In some cases you may not need to set the above settings as in the case of having a Windows Operating System in your language.

Note: As Visual Cadd only has western fonts, use Truetype fonts in IRRICAD.


1.1.9.1 EXPORTING TO DXF AND DWG FILES

In addition this setting also controls the “Codepage” used when exporting DWG and DXF files (R2004/2006 and older formats). It is necessary to do this so that the codepage in the exported DXF and DWG files is set which means your ‘foreign’ characters will be displayed correctly.




To export with a non-western character set to DXF or DWG files:

1. Set the Supplementary character set in [Settings/Miscellaneous](#).
2. Use a Truetype font that supports the character set you want (e.g. Arial or one of the specialized fonts e.g. "David").
3. Go to [Settings/Import/Export Settings](#).
4. Select the "Export to AutoCAD version" as **R2004/2006** or older. The newer formats of Autocad don't support the "codepage" property that this method relies on.
5. If you know that the target machine will NOT have an Autocad font (.SHX) of the same name loaded then check the "Ignore font map..." checkbox.
6. If the font used does have a corresponding Autocad font (or you are not sure – note that an Arial .SHX file does seem to be installed with Autocad by default) then make sure the checkbox in 5. above is UNCHECKED. Add a mapping under the "DWG Font Export" tab to map the TT font explicitly to the appropriate .TTF file as below.



7. To do this enter the name of the TTF font file in the dialog box that corresponds to the TT font chosen. Click [\[Add\]](#), now select the font in the "Visual Cadd" column then the .TTF file in the "AutoCAD" column and then click the [\[->\]](#) button. Your set of mappings can be saved or loaded via the [\[Save Map\]](#) or [\[Load Map\]](#) buttons. Note the correct .ttf file name can be found by looking in Control Panel | Fonts. Some things to note are:
 - There is a limit of 12 characters for the Visual CADD part of the map: for example if you try to map "Traditional Arabic" to itself (Trado.ttf) this will fail because "Traditional →TRADO.TTF" will appear in the Map (as Traditional_ is 12 characters) and the resulting text style will be exported as TXT.



8. Exporting to both DWG and DXF works with these methods but our experience is that DXF gives a better result in terms of the position and size of text.


1.2 Previous Additions and Bug Fixes

All additions and bug fixes for each version can be found in the Readme.txt file, commonly found in the C:\Program Files\AEI Software\IRRICAD Pro 11\Help folder.

1.2.1 In Pro Version 10.5

1.2.1.1 AUTOCAD COMPATIBILITY

Compatibility between AutoCAD and IRRICAD has been significantly improved. IRRICAD now supports importation of DXF and DWG up to Autocad vR2007/2009. The settings for AutoCAD import and export can be found through [Settings\Import/Export Settings](#). IRRICAD can now import AutoCAD files that contain layouts (note that only the model space is imported, but the application will not hang if a paper space is encountered, previously files had to have the layouts removed before importing).



1.2.1.2 DWG SETTINGS TAB

Import Settings

Base Import Unit:

Selects the unit of measurement in which the AutoCAD drawing was created. This is the same setting as the “[Imported](#)” unit in [Settings\Units](#).

Xref Conversion:

Set this as “[Keep as DWG](#)”.

Symbol Conversion:

Scale Placement:

Specifies that during AutoCAD import/export, when converting to a unit other than inches, the current placement scale is used and the symbol definition remains unchanged. This is the default setting.

Scale Symbol:

Specifies that during AutoCAD import/export, when converting to a unit other than inches, the symbol definition is scaled and the placement is left at 1:1.

Ignore Font Map:

When checked, current font mapping in DWG Font tabs is overridden. All fonts are mapped to the existing fonts of the same name. If the font of the same name does not exist, IRRICAD will map the font to the default font.

Default Import Font:

During import, specifies the font name to be used when no mapping exists for a font.

Export Settings**Base Export Unit:**

Selects the unit of measurement in which the AutoCAD drawing was created. This is the same setting as the “Imported” unit in [Settings|Units](#).

Export to Autocad Version:


Selects whether an exported DWG is saved in R12, R13, R14 or R2000/R2002, R2004/2006 or R2007/2009.

Ignore Font Map:

When checked, current font mapping in DWG Font tabs is overridden. All fonts are mapped to the existing fonts of the same name. If the font of the same name does not exist, IRRICAD will map the font to the default font.

Default Export Font:

During export, specifies the font name to be used when no mapping exists for a font.

1.2.1.3 DWG FONT IMPORT TAB

This tab allows the user to control how fonts in translated AutoCAD drawings are imported into IRRICAD. The Import AutoCAD Font Mapping options display list boxes of AutoCAD font names, IRRICAD font names, and a list box showing which AutoCAD fonts have been mapped to which IRRICAD fonts.

To map AutoCAD fonts to IRRICAD fonts

1. Click the name of an AutoCAD font the user wishes to translate to a specific IRRICAD font.
2. Click the name of the IRRICAD font the user wishes to substitute for the specified AutoCAD font.
3. Click the right arrow button.


The pair of font names will appear in the map table list box.

To delete a mapped pair of fonts from the map list

1. Click and highlight the pair of mapped font names the user wishes to delete from the map list.
2. Click the left arrow button.

The font pair will be deleted from the map list.

1.2.1.4 DWG FONT EXPORT TAB



This tab allows the user to control how fonts will be translated when IRRICAD drawings are exported into AutoCAD .dwg format. The “Export AutoCAD Font Mapping” options display list boxes of IRRICAD/Visual CADD font names, AutoCAD font names, and a list box showing which IRRICAD fonts have been mapped to which AutoCAD fonts.

To map IRRICAD fonts to AutoCAD fonts

1. Click the name of an IRRICAD font the user wishes to translate to a specific AutoCAD font.
2. Click the name of the AutoCAD font the user wishes to substitute for the specified IRRICAD font.
3. Click the right arrow button.

The pair of font names will appear in the map table list box.

To delete a mapped pair of fonts from the map list

1. Click and highlight the pair of mapped font names the user wishes to delete from the map list.
2. Click the left arrow button.

The font pair will be deleted from the map list.

Tips: IRRICAD will not map one source font to more than one destination font.

The user can save font maps and then load them for later conversions.

The user can add new fonts and delete fonts from the AutoCAD font list in both Import and Export to be used in mapping.

1.2.1.5 AUTOCAD COLOR IMPORT

IRRICAD/Visual CADD and AutoCAD have very different color indexes. Because AutoCAD maps colors to pen width for printed output, it is often important to retain these colors on drawings that the user imports and then must export back to consultants or others the user shares drawing files with. Color mapping provides the ability to match to other color indexes.

Default maps are provided for both AutoCAD Windows's colors and a default of 1-to-1 (DWG color 0 to VCD color 0, DWG color 1 to VCD color 1, etc.). It is however possible to create maps, for AutoCAD DOS or any other combination of colors. Line widths can also be mapped to colors or color mapping ignored on import and all colors forced to a designated color.

To Create a New Color Import Map:


1. Select the “Use Custom Map” radio button.
2. Press the [New Map] button.

3. Enter a name for the new color map and press [OK].

The new name is shown as current in the dialog dropdown list.

4. In the edit boxes, make changes to IRRICAD colors to correspond with each DWG color. If the user wants to include line width mapping, uncheck the "Ignore" box and type a line width to correspond with each DWG color.
5. Press [OK] to save the new map.

Alternatively, check the "All Colors to:" checkbox and type a color number in the right hand edit box to force all DWG colors to the one IRRICAD color.




1.2.1.6 AUTOCAD COLOR EXPORT

IRRICAD/Visual CADD and AutoCAD have very different color indexes. Because AutoCAD maps colors to pen width for printed output, it is often important to retain these colors on drawings that the user imports and then must export back to consultants or others the user shares drawing files with. Color mapping provides the ability to match to other color indexes.

Default maps are provided for both AutoCAD Windows colors and a default of 1-to-1 (DWG color 0 to VCD color 0, DWG color 1 to VCD color 1, etc.). It is however possible to create maps, for AutoCAD DOS or any other combination of colors. Line widths can also be mapped to colors, color mapping ignored on import and all colors forced to a designated color.

To Create New Color Export Map


1. Select the "Use Custom Map" radio button.
2. Press the [New] button.
3. Enter a name for the new color map and press [OK].
4. The new name is shown as current in the dialog dropdown list.
5. Decide whether to convert color to color or IRRICAD line width to DWG color.
6. In the edit boxes, make changes to IRRICAD line width and/or DWG colors.
7. Press [OK] to save the new map.



1.2.1.7 IMAGE IMPROVEMENTS

Image handling in IRRICAD has been extensively updated, and a number of new image functions are available. These are outlined below:

- The image import dialog now includes a preview window (select “**Show Preview**”), making image selection easier:
- “**Save Current Path**” can now be set when importing
- A [**Settings**] button allows individual settings to be made




To import an Image file into IRRICAD select **Import Image** from the **File** menu. Choose the format required from the “**Files of Type**” dropdown box, allowable formats are:-

- BMP
- JPEG
- TIFF
- Windows Metafile
- Paintbrush
- PNG

For an explanation of the merits and features of the various image formats see the manual Section 5.2.10 - Export Image_D2HLink_2589. Now select the file from the file explorer window (or type the name into the “**File Name**” dialog box). For ease of finding images, “**Recent Folders**” can be selected for browsing.

Image Settings



Each image has the following individual settings:-

Embed Image:	Embeds (saves) the image directly into the design
Image Path: Relative Path:	A link to the image file is inserted into the design rather than embedding the entire image. When “Use relative path” is checked, the link (i.e., folder path) will be relative to the location of the IRRICAD design. This feature is very useful if the design is shifted to another computer, drive or folder. As long as the image file is located in the same place relatively then the link will be intact and the image displayed. Note that all images are inserted using a “Relative Path” if possible. Relative paths cannot be used if the design has not been saved or if the image is on a different drive to the design. In these cases, the absolute path is used instead.
Lock Aspect Ratio:	If this item is checked, the image rectangle will be constrained to the aspect ratio (height/width) of the original image during placement. If unchecked then the image can drawn so that it is distorted compared to the original. Once the Image file has been selected (by clicking the [Open] button) the image can be placed on the screen using the mouse or keyboard entry. The lower left corner is located first (with a left mouse click or keyboard coordinates), a rectangle is then drawn out (when using the mouse the left button should NOT be depressed during this stage) and then the upper right corner is placed. Note that in previous versions the upper left, and then lower right, corners of the image were specified.
Rotation:	A rotation angle <i>cannot</i> be entered before placement, but the orientation (rotation) of the image may be set after it has been inserted into the design.
Flip Horizontal:	When checked, the image is mirrored horizontally.
Flip Vertical:	When checked, the image is mirrored.
Show Image as Grayscale:	Can be shown as grayscale only (black and white).
Display a border around the image:	A border around the image can be turned on or off. Once inserted, the color and line style of this border can be set by editing the image.
Display Image:	Each image can now be individually turned on or off.


Tips: *If an image is embedded this will increase the design file size dramatically. Though this may be a preferred option if sending designs from branch to branch, it may not be the best option.*

Borders can now be turned on or off by the “Show Border” check box. The user may want to turn off the borders when tessellating or overlapping multiple images.

Images can be individually turned off for display by unchecking the “Show Image” option. If the image is turned off in “Show Image” the border automatically displays.

Images can now be added to symbols, including plot layouts (e.g., adding logos).

After an image has been imported, the settings can be edited by double-clicking on the image when in **Select Object** mode, or by using **Change**. Note the previous settings for Images in the **Settings** menu no longer exists.



Old style images are automatically converted to new style images when a design is opened in v10.5. New style images are also automatically converted back to old style images when exporting as a previous version. Note that this may result in some loss of information (e.g., rotation), which is not supported by the old image format.

To import an image:

1. Select **File|Import Image**.
2. Type in the name of the image file to import or search for the file.
3. Click **[Open]** or double-click on the highlighted file.
4. Left click to place the bottom left corner.
5. Draw the rectangle to the required size and click again to place the top right corner.
6. If required, trace over features in the image using any drawing tools.

Tips: When prompted for the bottom left corner, the user may type in coordinates e.g. 0,400 (in world units).



When prompted for the top right corner, the user may type in coordinates e.g. 300,0, or the user may type in a distance (diagonal distance from top left corner) in world units.

The user may simply place the bottom left and top right at any scale and resize using **Tools|Scale Image**.

If the image is not placed using the 'bottom-left, top right' order, then it can be flipped horizontally and/or vertically as appropriate.

1.2.1.8 SCALE IMAGE TOOL

Changes have been made to the **Adjust Image** tool in the **Tools** menu – it has been replaced by the **Scale Image** tool. This tool (**Tools|Scale Image**) allows an image to be scaled using a feature in the image of a known size. Select the tool, then the image you want to scale (or vice versa). You will then be prompted to define a feature in the image with a line. Following this a dialog will show the length of the marked feature.



The actual length of the feature can then be typed in.

The image will then be resized so that the marked feature has the newly specified length. Note that the image is resized around its center-point and may need to be moved after scaling.

Scale

Marked Length:

The current length of the defined feature.

Scaled Length:

The actual known length of the defined feature – enter length.

Scale:

IRRICAD calculates the change in scale.

1.2.1.9 LAYER MANAGER

The new, dockable, layer manager can be access through the main **View** menu (**View|Layer Bar**), through the **Right-click|Layers** menu or can be toggled with the shortcut key combination Ctrl+L. The layer manager has three panes:

- **Layers** – this tab displays information about the layers in the current design. It allows the user to see whether a layer is visible, whether it will print and whether it contains data. Layers may be added and/or removed and all items on a given layer may be selected. Any selection of items can be easily moved to any layer.
- **Groups** – layer groups define sets of visible layers that may be associated under a single name and provide a quick way to access these. A group may relate to different aspects of the design – an ‘Electrical’ layer group, for instance, could show topography and electrical items while hiding hydraulic items. A default set of layer groups can be defined and saved to the registry. These defaults will be included in any new designs and can be ‘loaded’ into existing designs.
- **Views** – named views are shortcuts to different views of a design. They can be used to move quickly between different areas of a design, and might typically be defined for each stage of a multi-stage development, or for each hole of a golf course, for example. Views can be linked with layer groups (views and groups with identical names are automatically linked). When a view with a linked group is activated, that layer group is also activated.

Layers Tab




- IRRICAD layers are displayed in blue, extra layers in black.
- - this column indicates the visibility of the layers.
- - this column indicates whether a layer will print.
- These check boxes can be toggled individually, by making a multiple selection with the mouse or by selecting the full column by clicking the icon. The selection can also be toggled by pressing the space bar.
- - indicates an empty layer.
- - indicates that the layer has data.
- The lower panel shows the color, line type and line width associated with the selected layer.
- The bottom edit box and buttons (and) can be used to add or remove layers. Layers may also be deleted by selecting them and pressing the <Delete> or <Backspace> key.
- Layers can be renamed *in situ* by clicking in the name column and typing the new name. Use the <Esc> key to cancel an edit.
- A context menu allows layers to be deleted, all entities on a layer to be selected and a selection to be moved to a layer.

Delete Layers


Select Layer Entities

Move Selection To Layer

Groups Tab



- The top panel shows the name of the group, the bottom panel shows the list of visible layers that belong to the selected group.
- Groups can be created and deleted using the edit box and buttons under the top panel (🔍...✖).
- Layers can be added and removed from groups using the combo box and buttons under the bottom panel (📁...✖).
- 📁 - indicates an unlinked group.
- 📁 - indicates a group with a linked view.
- 📁 - indicates an empty layer.
- 📁 - indicates that the layer has data.
- 📁 - this button will save the currently defined groups as the default set. These groups will also be automatically added to new designs.
- 📁 - this button will load the default set of groups.
- Layer groups can be activated by double-clicking the group name in the top panel, or selecting it and hitting <Enter>.
- Groups can also be deleted by selecting and pressing delete or backspace in the top panel.
- Layers can be removed from groups by selecting and pressing delete or backspace in the bottom panel.
- Functions are also accessible through context menus:



- The **Goto View** command switches the focus to the linked view on the **Views** tab.

To create a Layer Group:

Turn on or off the required layers in the main tab.

Go to the **Group** tab and type in a name in the blank middle field (or overwrite the name in this field) and click the **[Add Group]** icon.

To activate a Layer Group:

Go to the **Groups** tab.


Double-click on the Group Name or highlight, then right-click and select **Activate Group**.

To make changes to a Layer Group:

In the Visible Layers In Group section highlight the layer that you wish to remove.

Right-click and select **Remove from Group**.

Views Tab



- Views can be created and deleted using the edit box and buttons under the top panel (🔍...✖).
- 🔍 - indicates an unlinked view.
- 🔍 - indicates a view with a linked group.
- Checking the “Auto sync layer groups” option will automatically create a group to go with new named views.
- Views can be activated by double-clicking the name in the panel, or selecting it and hitting <Enter>. If a view has a linked layer group, the group will also be activated.
- Views can also be deleted by selecting and pressing delete or backspace in the top panel.
- Functions are also accessible through context menus:



- The **Goto Group** command switches the focus to the linked group on the **Groups** tab.

To create a Layer View:

Go to a required view on the main screen (e.g. zoom in).

Go to the **Views** tab and type in a name in the blank bottom field (or overwrite the name in this field) and click the **[Add Views]** icon.


To activate a Layer View:

Go to the **Views** tab.

Double-click on the View Name or highlight, then right-click and select **Activate View**.

1.2.1.10 DATABASE ITEM DISPLAY

The currently selected item is now shown in bold font in the component list.



If a database component is not found in the external database, IRRICAD will now display the correct item description in combo boxes instead of defaulting to the first item in the list. The description will show in a red font to indicate to the user that it was not found in the database.

The screenshot shows the 'Control Valve' dialog box. Under 'Drawing Properties', the 'Layer' is set to 'CONTROL_VALVES'. Under 'Control Valve Properties', the valve description '3/4" (20mm) Electric Valve' is displayed in red font. Other fields include 'Zone Name' (Zone no. 1), 'Orientation' (0), 'Pipe Type' (Z), 'Depth' (0 mm), and 'Scope' (Design + BOM). Buttons at the bottom include OK, Cancel, Fittings, and Attributes.

If a database component *is* found in the external database, but it is switched off (usage code 'N'), IRRICAD will display the item description in a green font.

The screenshot shows the 'Control Valve' dialog box. Under 'Drawing Properties', the 'Layer' is set to 'CONTROL_VALVES'. Under 'Control Valve Properties', the valve description '4" (100mm) Al valve opener' is displayed in green font. Other fields include 'Zone Name' (Zone no. 4), 'Orientation' (0), 'Pipe Type' (Z), 'Depth' (0 mm), and 'Scope' (Design + BOM). Buttons at the bottom include OK, Cancel, Fittings, and Attributes.

Assemblies are now marked in the database lists with a much more visible icon.

The screenshot shows the 'Control Valve' dialog box. Under 'Drawing Properties', the 'Layer' is set to 'CONTROL_VALVES'. Under 'Control Valve Properties', the valve description 'Wheel line 4" active hydrant assembly' is displayed in bold black font with a gear icon to its right. Below this, a list of components is shown: '3/4" (20mm) Electric Gate Valve', '1" (25mm) Electric Valve', '3" (80mm) Electric Valve', and '4" (100mm) Gate Valve (Flanged)'. Other fields include 'Depth' (0 mm) and 'Scope' (Design + BOM). Buttons at the bottom include OK, Cancel, Fittings, and Attributes.

1.2.1.11 CONNECT OUTLETS TOOL

The screenshot shows the 'Outlet Connector' dialog box. Under 'Connection Properties', the 'Match nearest pipe' checkbox is checked, and the 'Maximum length of connecting pipe' is set to 100 m. Under 'Drawing Properties', the 'Layer' is set to '<DEFAULT>' and the 'Line width' is set to 1. Under 'Pipe Properties', the 'Item' is set to 'Computer Selected', the 'Computer Sized' checkbox is checked, the 'Permanent Junctions' checkbox is unchecked, and the 'Depth' is set to 0 mm. Buttons at the bottom include OK and Cancel.

This new tool (*Tools|Connect Outlets*) is analogous to the existing *Connect Valves* tool and automatically connects outlets to the nearest piece of mainline or zone pipe, depending on the outlet type.

Connection Properties

Match nearest pipe:

If this option is checked then the properties of the pipe selected to join outlets to the pipe will be taken from the pipe that is closest to each of the outlets.

Maximum length of connecting pipe:


This field controls whether an outlet will be automatically connected to the pipe. If the distance from the closest pipe exceeds this value then no connecting pipe will be placed.

If “Match nearest pipe” is not checked then the remaining pipe property fields are available. In this case outlets will be connected to the closest pipe with a pipe that has the properties specified in the fields.

***Note:** If the outlet is very close to the nearest pipe, then the outlet will be connected directly to the pipe.*

1.2.1.12 HATCH PREVIEW

The hatch dialog now displays a preview of the selected hatch using the current screen background colour and the appropriate hatch line colour, style and thickness. The preview scale is based on the current zoom state and is automatically calculated from the hatch pattern. This means that what is shown in the preview is directly reflected on screen when the hatch is drawn, provided that the user does not change the zoom state.



Drawing Properties

Layer:

The layer the symbol will be stored in. The <DEFAULT> layer is DRAWING.

Color:

The colour of the hatch.

Line Type:

Line type of the hatch.

Line Width:

Width of all lines in the hatch.

Hatch Properties

Name:

This is the name of the style of hatch to use. Select from the dropdown list to change the current style.

Scale:

Sets the size of the hatch pattern. If the hatch tool seems to be unsuccessful, increase the scale.

Auto Scale:

Automatically calculated from the hatch pattern and based on the current zoom state.

Angle:


Type in an angle from 0° to 360° to rotate the hatch pattern as required.

Show Boundary:

Displays hatch boundaries as a line on the screen.

1.2.1.13 SYMBOL PREVIEW

The symbol dialog now also has a preview pane, and symbols may be inserted at an angle.



Drawing Properties

Layer:

The layer the symbol will be stored in. The <DEFAULT> layer is DRAWING_SYMBOLS.

Use Placement Color:

Check to draw the symbol in the current drawing color. Leave unchecked to draw the symbol in its definition color i.e., the color used when the symbol was created.

Symbol Properties

Name:

The name of the currently selected symbol. Symbols available in the dropdown list have been previously loaded (see [Load Symbol, Section 5.5.12.2](#)).

Width:

The width of the symbol in the defined units.

Height:

The height of the symbol in the defined units.

Orientation:

The orientation (rotation) of the symbol.

Dynamically Size:

Check to drag the symbol to any size using a rubberband rectangle. Uncheck to enter a size.

Maintain Shape:

Check to maintain a ratio of the width and height at which the symbol was created. Uncheck to stretch or squash the symbol in one direction.

Tips: The user can replace all instances of one symbol in the drawing with another by lassoing the items and choosing **Tools|Change Type**.


The user can create a symbol in the drawing by highlighting (selecting) the existing entities to be included in the symbol and then selecting **Tools|Create Symbol**. This also saves the named symbol to a file for use in other designs.

The user can divide a symbol into its individual component entities by first selecting it, and then selecting **Tools|Explode**.

1.2.1.14 GRADELINE DIALOG EXPORT

It is now possible to export the graphing information from the hydraulic gradeline dialog direct to Excel files, tab or comma delimited text files. Click the **[Export]** button on the dialog and chose a location to save the file.

Note: To get gauge pressure results of just the pipes / outlets turn off elevations by clicking the **[Elevation]** button before exporting.




1.2.1.15 CLEAR MANAGEMENT

A new option in the *Design* menu (*Design|Clear Management*) deletes all the current zone and water supply management information.

1.2.1.16 ROTATE TOOL IMPROVEMENTS

The rotate tool now ghosts the selection so that it is easier to control. Once the center of rotation has been selected the angle may be typed in directly (hit <Enter> to accept).

Use the *Rotate* tool to rotate a selection around an axis.



To rotate a selection:

1. Select *Tools|Rotate*.
2. Select the object to be rotated.
3. Place a point to serve as the center of rotation.

The selection will rotate as the cursor moves around the axis point.

4. Place a point when the object is rotated to the correct orientation.
5. Repeat steps 2 to 4 as required.


If a single point hydraulic item (e.g., an outlet) is selected then step 3 is omitted; the reference point is automatically taken to be the center of the symbol.

***Note:** Some objects like continuous line are treated as a single object and a segment cannot be rotated on its own unless the object is first exploded.*

*To rotate a group of objects reverse Steps 1 and 2 above i.e., select the objects first then the *Rotate* tool.*

1.2.1.17 FILE STAMP

The file stamping functionality has been moved on the *Print* dialog and now all settings, including “Add Stamp” are to be found by clicking on the [File Stamp] button.



To include a file stamp on your print job:

- Select *File|Print*.
- Select the [File Stamp] button.
- Check the “Add Stamp” check box.
- Edit the criteria for the required File Stamp.
- Click [OK] and print the job.

File/Date Stamp

- | | |
|--------------|---|
| Add Stamp: | When checked, the requested File Stamp including the file name and path will be printed in the selected location. |
| Font: | Select the required font of the File Stamp. |
| Font Height: | Select the required font height of the File Stamp. |
| Date Format: | Select the required date format option. |
| Location: | Select the required location option. |


1.2.1.18 WATERMARKING

The File Stamping functionality (accessed through the *Print* dialog) has been extended to include a text watermark for the printed output.

To include a watermark on your print job:

- Select *File|Print*.
- Select the [File Stamp] button.
- Check the “Use Watermark” check box.
- Enter required “Watermark Text”.
- Move the slide for the required “Text Density”.
- Click [OK] and print the job.

The watermark text will be written across the print job on a diagonal.



Watermark

Use Watermark:

Watermark Text:

Text Density:

Check to print a watermark across the print job.

Type in the required text – this will be printed in Courier font.



Move the slide to control how dark the watermark is printed.



1.2.2 In Pro Version 10.0

1.2.2.1 HATCH & FILL EDITING


It is now possible to edit a fill as a Geometric Object. This allows the colour and the layer to be changed.

Hatch editing has also been enabled, allowing all properties of a hatch to be changed.






1.2.2.2 TEXT DIALOG IMPROVEMENTS



The text dialog now displays using the font and text properties specified (for non-vector fonts). This enables the user to better judge how the text will actually look when rendered on the design. This is particularly useful for labels and when using mono-spaced fonts.

1.2.2.3 KEYWORD COMBO

A keyword dropdown box has also been added to the *Label* text dialog. This displays and briefly describes the label keywords, and allows them to be easily inserted.



1.2.2.4 LABELS

The current label text settings are shown in a button tooltip on the *Label Settings* dialog.

Update Labels no longer resets the position of labels that have been manually moved. The new location is now retained.

New Keywords

More comprehensive hydraulic labeling has been enabled with the introduction of several new label keywords:


#DEPTH#	Depth of object
#DEPTHUNIT#	Unit of Depth as per <i>Settings\Units</i>
#HY_ELVCHG#	Elevation change in elevation units
#HY_ELVPCHG#	Elevation change in pressure units
#HY_FLOW#	Flow
#HY_HL#	Head loss
#HY_MAX_F#	Maximum flow
#HY_MAX_HL#	Maximum head loss
#HY_MAX_P#	Maximum pressure
#HY_MAX_PABS#	Maximum absolute pressure
#HY_MAX_V#	Maximum velocity
#HY_MIN_F#	Minimum flow
#HY_MIN_HL#	Minimum head loss
#HY_MIN_P#	Minimum pressure
#HY_MIN_PABS#:	Minimum absolute pressure
#HY_MIN_V#	Minimum velocity
#HY_PRESS#	Pressure
#HY_PABS#:	Absolute Pressure
#HYN_MAX_F#	System flow with maximum flow
#HYN_MAX_HL#	System flow with maximum head loss
#HYN_MAX_P#	System flow with maximum pressure
#HYN_MAX_V#	System flow with maximum velocity
#HYN_MIN_F#	System flow with minimum flow
#HYN_MIN_HL#	System flow with minimum head loss
#HYN_MIN_P#	System flow with minimum pressure
#HYN_MIN_V#	System flow with minimum velocity
#SCOPE#	Object Scope – Design + BOM, Design Only or BOM Only
#VELUNIT#	Velocity unit

Added new Label keywords for Irrigation Blocks: (See Appendix J, Section 6.10 1 for the list of keywords and where they can be used).


#FLOWUNIT#	Current large (sys flow/zone) flow unit
#FLOWPERAREA#	Flow per unit area
#GRPSPACE#	Group Spacing
#GRPLATS#	Number laterals per group
#H2OQUANT#	Water requirements either volume or depth
#MAXINTENS#	Maximum allowable intensity
#NOMFLOW#	Block flow based on nominal SDR from database
#NOMPRESS#	Nominal Inlet pressure of Tape laterals
#NUMEMIT#	Number of emitters in a block entity
#NUMROW#	Number rows or laterals
#PRESSUNIT#	Current pressure unit
#ROWSPACE#	Row spacing (= lateral spacing if no groups)
#TOTLATLEN#	Total 3D length of laterals (calculated with slope method)
#VALVEPRESS#	The calculated downstream pressure for the control valve attached to the block

1.2.2.5 USER ATTRIBUTES AND USER KEYWORD

A 'User Attributes' text field has been added to control valves, water supplies, block entities and miscellaneous hydraulic items. It allows the user to attach any textual information to these items, that can be subsequently displayed in labels and reports. (See the User Manual, User Attributes and User Keyword, Section 2.7.11.11 for instructions on using keywords to achieve the desired result).



Using the correct keywords will produce the desired results:



1.2.2.6 GO TO COORDINATES

The automatic pasting of coordinates into *Go To Coordinates* and into the *Settings|Grid / Origin* dialogs has been enabled. This means that a coordinate string copied from the *Object Info* screen which includes both X and Y coordinates, units and descriptors (e.g. x = 25.28 m, y = 8.46 m) can be inserted in one action into the appropriate fields in these dialogs..

1.2.2.7 HYDRAULIC ITEM CREATION


All hydraulic and electrical items can now be created from relevant drawing items. By simply highlighting a drawing item you can turn it into an Area, Outlet, Pipe, Control Valve, Pump, Irrigation Block, Light, Controller, Wire, Misc. Electrical, Misc. Hydraulic, Sprayline or Tape. The behavior of creating hydraulic items from drawing items is listed in the User Manual, Converting Drawing Items into Hydraulic Entities, Section 2.4.3.

1.2.2.8 NAMES

Holding the <Shift> key down when placing a zone valve, mainline outlet or mainline spraylines now doesn't show the "Name" dialog but accepts the default name.


1.2.2.9 UNCONNECTED SPRAY BLOCK ENTITY

It is now possible to specify that a sprayline block entity be 'unconnected' – that is, to create a sprayline block consisting of individual pipes and outlets.




1.2.2.10 DOCUMENT SUMMARY INFO

Design details are now copied to the design file properties summary information section, allowing specific designs to be more readily identified in Windows Explorer.



1.2.2.11 MERGE DESIGNS

IRRICAD designs may now be merged together using the *Merge...* option in the *File* menu. This function will merge drawing and hydraulic objects, as well as fittings selection, Management and Design information.



1.2.2.12 STATUS BAR – INFO PANEL

Added the z-coord to the Info panel. This displays the elevation, calculated from the DEM, at the current mouse position. If the DEM has not been created then 'No Elevation' is displayed.

1.2.2.13 ZONE DESIGN CONFIGURATION

Improvements have been made to the sizing of the *Zone Design Configuration* dialog – it can now be dragged to a larger size. In addition the space bar can now be used to toggle check boxes.

The minimum/maximum emitter pressures from the zone design configuration dialog are now copied to the clipboard as two tab-separated numbers. This means that when values from the table are pasted into Excel, separate columns will be created for each of these values.

1.2.2.14 DESIGN PARAMETERS

In *Design Parameters* the last visited tab is now remembered.

1.2.2.15 REPORT TEMPLATES

Added the ability to create report templates that save directly to a file, this is accomplished by adding keywords to the *Report Options* in the report template editor. Possible keywords are:- #CSV# - Excel comma separated values; #TSV# - Tab separated values; #TXT# - standard text file; #XML# - text file where all leading and trailing blanks are removed also blank lines.

1.2.2.16 SAVING TO PREVIOUS VERSIONS OF IRRICAD

A more generic 'Save As' functionality has been Implemented. Designs can now be saved in the format of all previous versions of IRRICAD (to Version 7). See *File|Export – "Save as type"*

1.2.2.17 NEW TOOLBARS

New toolbars with many new icons, including large icons and popup menus, have been added. In addition, the currently enabled tool and snap is indicated on toolbars.

Any toolbar docking area can now be customized by right-clicking on any icon or toolbar. This is simply a short cut to the *View|Toolbars* option and allows immediate customization.

1.2.2.18 ZONE PRESSURE LIMITS NOW EDITABLE

The format of the minimum/maximum zone pressure label can now be edited. Go in to *Reports|Report Settings* and click on the *[Text]* button.

1.2.2.19 SYMBOL COLORS

Multi-colored symbols may be selected for Valves etc. If a symbol is specified with the "Use symbol colour(s)", in the database editor, then the symbol will be displayed using the colors contained in the symbol definition.

1.2.2.20 CHANGES TO IMPORTING CONTOURS

Drawing and elevation data from CSV and ESRI SHP files can now be directly imported into IRRICAD.

Elevation data is entered via *File|Import Contours* while *File|Import* is used for normal drawing information.

See the User Manual, Importing a DXF, VCD, DWG, GCD, SHP MIF or CSV File, Section 2.4.1.1 for importing tips and instructions.

1.2.2.21 TRIM ELEVATIONS

A *Trim Elevations* tool has been added to the *Tools* menu.

1.2.2.22 NEW COPY TOOLS

Mirror and *Offset* copy tools have been added to the *Tools|Copy* menu. All Copy tools have been enabled for use with hydraulic objects.

1.2.2.23 MULTIPLE WATER SUPPLY SYSTEMS

Designs with multiple but separate water supplies can now be fully analyzed (and *LP Design* used where appropriate) directly. It is no longer necessary to 'join' the separate systems with notional pipes. When the systems are completely separate, no pressure or flow information needs to be entered. However if more than one water supply is feeding the same system, at least the pressures need to be entered as before.

1.2.2.24 NEW TOOLS

Trim and *Extend* are now available as are *Move to Front* and *Move to Back Z-Order* tools.

1.2.2.25 BACK UP FOLDER SPECIFICATION

The location of the Backup folder can now be specified in *Settings|Miscellaneous*.

1.2.3 In Pro Version 9.5

1.2.3.1 DONGLE SERIAL NUMBER

The serial number of the Irricad dongle is now displayed in the program title.



1.2.3.2 INSERT OLE CHANGES

Bitmap data on the clipboard can now be inserted/pasted into Irricad. This enables copy and paste of HGL charts.

1.2.3.3 BLOCK PIPE STUBS



The pipe stub functionality of irrigation block entities has been extended. The block now supports three stub lengths, one for the submain and two for the valve:

1. The Submain Stub
2. The Valve Submain Stub
3. The Valve Stub



1.2.3.4 BLOCK VALVE POSITIONING

Control valve placement in block entities can now be entered as a percentage distance along the submain.



1.2.3.5 FLUSHING MANIFOLDS

A new tab has been added to the block entity tools allowing flushing manifolds to be automatically created.

The 'Tape Irrigation Block' dialog box is shown with the 'Flushing' tab selected. It contains the following settings:

- Drawing Properties:**
 - Layer: <DEFAULT>
 - Colour: Cyan (selected), By Layer (unselected)
 - Line Type: 0 (SOLID)
 - Line Width: 1
- Create Manifolds:** ☐ (unchecked), Scope: BOM Only
- Pipe Properties:**
 - Pipe: PVC Pipe 32mm/Class 6
 - Depth: 0 mm
- Manifold Properties:**
 - ☒ Max. Laterals Per Manifold: 2
 - ☐ No. of Manifolds
 - ☐ No. of Manifolds (Even Flow): 0.4 m/s
- Flushing:** CF
- End:** CF
- Depth:** 0 mm, **End Depth:** 0 mm
- Assemblies Per Manifold:** 1, **Position:** Downstream
- Stub Length:** 0 m

Buttons at the bottom: Laterals, Block, **Flushing** (selected), Area, OK, Cancel.

1.2.3.6 LABEL ROUNDING & ROLL LENGTHS


It is now possible to round numeric values in labels to a 'nearest value'. New keywords (#ROLLS# and #ROLLS3D# cf. #LENGTH# and #LENGTH3D#) have also been added, such that pipe lengths can be displayed as a number of 'rolls' (based on the roll length of the pipe type in the database – see the Pipe Fitting Matching Table).

1.2.3.7 HYDRAULIC GRADELINE

After a design is completed it is now possible to view the hydraulic gradeline (HGL) of mainline pipes as well as zone pipes and tapes. The tool can be accessed from the [Reports](#) menu.


Mainline Gradelines

The HGL tool cannot automatically determine which mainline 'path' to analyze. The user must therefore select the mainline pipes to be included before invoking the tool.



Gradeline Toolbar

Some new functions have been added to the HGL dialog and are accessible using the toolbar.



The y-axis on HGL graphs has been changed to elevation rather than pressure units (converts pressures to equivalent hydrostatic elevation).


Toggling the elevation in the *Hydraulic Gradeline* dialog now adds or removes elevations from the data sets, as opposed to just showing or hiding the elevation series.

1.2.3.8 STATUS BAR

Three new panels have been added to the status bar. All the panel options can be selected by right-clicking the panel to access a popup menu, or left clicking to cycle through the available options.


Info Panel

This panel displays a variety of information about the currently selected objects. This includes UID, connections, selected item count, cumulative length of selected items, elevation and depth, cumulative area and cumulative nominal flow. The menu also allows the user to select the items connected to the current item.




Snap Panel

This panel shows the currently selected default snap mode (Connect, Place or Grid) and, through the popup menu, allows quick access to the Snap and Grid settings.




Selection Filter Panel

This panel shows the status of the selection filter - a red panel indicates that the filter is active. The user can also access the filter settings through the popup menu and flip the filter status using *Ctrl+Shift+F*



When active, a summary of the current filter settings is shown in the tooltip for this panel:



1.2.3.9 SELECT TOOL

The select tool now has the following features:


- The tool defaults to selecting a single object at a time. Multiple selections can be made by holding the *Shift* key. Permanent multi-select can be enabled from the *Settings|Mouse* menu.
- In the single select mode clicking nothing (empty space) will clear the current selection.
- Window-select mode can be entered by holding down the left button and dragging the mouse.

- A block may be automatically selected from a block sub-item (e.g., a lateral) by holding down the <Alt> key when selecting. The block outline (irrigation area) must be visible for this to work.
- Pressing the <Esc> key twice in quick succession will now clear the current selection and return the user to the default *Select* tool.

1.2.3.10 SNAPS

Snaps are now enabled for the *Move* tool.

1.2.3.11 LAYERS MENU




A dynamic layers menu has been added to the default right-click context menu. This provides a quick way for the user to enable or disable layers. It also includes two shortcut functions 'Hide Layer' (*Ctrl+Shift+H*) hides the layer of the currently selected item, while 'Show Layer' (*Ctrl+Shift+L*) re-shows the last hidden layer (the menu shows which layer will be hidden or restored).

1.2.3.12 CONVERTING DRAWING ITEMS INTO HYDRAULIC ITEMS

Irrigated Areas can now be created from polylines and curves (in the same way as the block entity tools).

1.2.3.13 OBJECT INFO

The display of hydraulic and debug object info can now be controlled directly from the object info dialog.





1.2.3.14 Go To COORDINATES

The *Go To Coordinates* dialog now retains the last set of coordinates.

1.2.3.15 IRRIGATED AREAS

In a similar manner to block entities, irrigated areas can now be created from existing geometric entities, including curves.




1.2.3.16 ZONE PRESSURE MINIMUM AND MAXIMUM

When creating Min/Max pressure labels for selected valves labels for other valves are no longer cleared. Note that any existing labels for the selected valves are also not cleared and need to be deleted manually before operating the tool.

1.2.3.17 OBJECT SCOPE FLAG

A 'scope' flag has been added to many hydraulic items. This allows for 'BOM only' items which are included in BOM / Costing reports but not included in hydraulic design. The user may also specify 'Design Only' items, which are treated normally in the design process but do not feature in the BOM / Costing reports (can be used to specify existing irrigation equipment).

Added the ability to globally change scope (Design + BOM etc.) for all hydraulic items at one time. To do this select the items required and then use the *Change* tool (not *Change Type*) and adjust the "Scope" field. Note that objects that do not have scope (drawing items, junctions etc.) are unaffected by changes to this field.



1.2.3.18 REPORTS

Added keywords to costing reports for the coordinates of unconnected pipes and spraylines. This means that a report can be created listing the locations of all unconnected items in a design.

1.2.3.19 UNIFORMITY

The design process now calculates a number of zone uniformity parameters, which are available in the zone reports.

Zone Name :		Area no. 1		Valve Description :		20 mm Gate Valve			
Zone Head (D/S) :		9.00 (m)		Zone Head (U/S) :		9.00 (m)			
Total Zone Flow :		8.69 (m3/h)		Valve Headloss :		0.00 (m)			
		<u>Allowable Flow</u>		<u>Actual Flow</u>		<u>Allowable Pressure</u>		<u>Actual Pressure</u>	
		(lph)		(lph)		(m)		(m)	
Minimum Outlet		2.03		2.23		6.00		7.40	
Maximum Outlet		2.31		2.43		7.99		8.95	
Outlet Variation (%)		12.13		8.16		24.98		17.23	
Coefficient of variation =		0.035		Mean Emitter Flow =		2.28		No. of Emitters per Plant = 1	
Cu = 97.9 (%)				Eu = 93.44 (%)				Du = 97.78 (%)	
Outlet Locations (X,Y)		Minimum :		87.3 , 25.2		Maximum :		14.6 , 88.4	

1.2.3.20 HELP MENU

The dongle version number is now shown in [Help/Help About](#).

Added a link to the Irricad web site in the [Help](#) menu.

1.2.3.21 RECENT FILES

Increased the number of recent files shown in the [File](#) menu to 8.

1.2.3.22 DATABASE

Made a change to the database editor so that fractional numbers of items can be added to assemblies.

Fittings are now selected for two-ended items (e.g. Misc Hydraulic) that are only connected on one side.

Irricad databases can now be edited and save in newer versions of Microsoft Access. Additional versions now supported are 2000, XP (2002), 2003 and 2007. Note that once a database has been converted to the newer format it will no longer be able to be used in previous versions of Irricad (i.e. earlier than V9.50).

In the database editor increased the limit for "% above" flow/pressure tolerance for Outlets to 2000%.

1.2.3.23 EMITTER COEFFICIENT OF VARIATION (COV)

A new field for the COV (CV_M) has been added to the database editor for Tapes and Nozzles. This is simply entered as a number, in the following example the COV is 0.03 (3%).

1.2.4 In Pro Version 9

1.2.4.1 NEW VISUAL CADD ENGINE

This version upgrades the version of VisualCadd DLLs to V5.06.137.

1.2.4.2 INSERTING OLE DATA

OLE Functionality

Items such as Irricad reports, spreadsheets, documents etc. can now be inserted into the Irricad design.

<i>Edit\Paste:</i>	This option allows only a single instance of the object to be inserted.
<i>Tools\Insert OLE:</i>	Allows multiple instances of the object to be inserted.
<i>Edit\Open OLE Item:</i>	OLE items that have previously been added can be opened and altered in the appropriate application.

OLE objects print first in PDF files, so that they don't obscure the design.

1.2.4.3 AREAS

The maximum number of Irrigation Areas has been increased to 1001.

The maximum number of areas that can be enclosed by another has been increased to 1000.

The maximum number of Areas a Zone can span has been increased to 25.

Zones may now span multiple Irrigation Areas (e.g. a zone made up of multiple block entities) when calculating area and water requirements. Note that the V7 style reports (if enabled) still only allow for zones being in one area.

1.2.4.4 TAPE AND SPRAY IRRIGATION BLOCKS

This version introduces the concept of 'Block Entities' which are essentially an extension of the current block tools. Block Entities retain the drawn boundary of the block tools as an Irrigation Area and 'group' the laterals contained by them. They also facilitate the automatic placement of submain, creation of block labels, and simplify the process of changing the type, spacing etc. of laterals.

At present blocks of tapes or blocks of Spraylines can be treated in this way they can be created by selecting *Tape Irrigation Blocks* or *Spray Irrigation Blocks* from the *Zone* menu. Note that you may need to add these to your Toolbar by selecting the *View\Toolbars* menu item (on the *Commands* tab select **Hydraulic Tools** and then dragging the button onto the desired toolbar).

Most of the items on this dialogs are self-explanatory. The fields on the *Lateral* tab have exactly the same function as those on the *Tape Block* or *Sprayline Block* tool dialogs. Similarly those on the *Area* tab are identical to those on the *Irrigation Area* tool dialog.

Any line can be used when specifying the submain direction (i.e. not just block boundaries).

See the Tool and Command Reference or User Manual for more information.

1.2.4.5 LABELS

Added *"Check Label Length"* and *"Label Length Allowance"* fields to the *Label* settings tab. These values were previously only available by editing the registry. They are now saved for each design.

Now Irrigation Areas can be labeled using the Irrigation block label settings.

When labeling pipes, with the *"Combine Pipes"* option set, Zone and Mainline pipes are now considered independently. This means, for example, that submain connected to an inline valve doesn't force multiple labels in the mainline pipes at that point.

The text colour for labels can now be specified in [Settings|Labels \[Text\]](#).

New Keywords

ROLLS: 2D pipe lengths as a number of rolls based on the roll length of the pipe type in the Pipe Fitting Matching Table
ROLLS3D: 3D pipe lengths as a number of rolls based on the roll length of the pipe type in the Pipe Fitting Matching Table

Added new Label keywords for Irrigation Blocks:

AREA: Total plan area within block boundary
AREAUNIT: Current area unit
ACTFLOW: The flow for the block as calculated during the design process. If the design is incomplete, then the nominal flow is displayed.
SHIFT: Lists the system flows that the block operates in.
MINEMITPRESS: The minimum emitter pressure in the block, from design.
MAXEMITPRESS: The maximum emitter pressure in the block, from design.
MEANPRESS: The mean tape inlet pressure in the block.

If the label does not currently have a value then 'NA' is displayed.

1.2.4.6 PLOT TEMPLATES KEYWORDS ADDED

More keywords have been enabled for Plot Templates:-

#DDES#: Design Details Description
#CLSN#: Client Details Short Name
#CLAD#: Client Details Address
#CLHP#: Client Details Home Phone
#CLPH#: Client Details Work Phone
#CLFA#: Client Details Fax
#CLCO#: Client Details Code (3 chars only)
#EDATE#: End Date,
#SDATE#: Start Date,
#ADATE#: Acceptance date,
#REPCO#: Rep Code,
#REPNM#: Rep Name,
#LHRS#: Labour Hours,
#MILE# : Mileage,
#ICOST#: Installation Cost,
#SIGNT#: Signitary,
#SIGTL#: Signitary Title,
#LCOST#: Labour Cost,
#MCOST#: Mileage Cost,
#TAXR#: Tax Rate,
#COSN#: Company Short Name,
#COLN#: Company Full Name,
#BRCO#: Branch Code,
#BRNM#: Branch Name,
#BRPH#: Branch Phone,
#BRFX#: Branch Fax,
#BRAP#: Branch After Hours Phone,
#BRCT#: Branch Contact

1.2.4.7 RUNNING SNAPS CHANGES

Running Snaps have now been enabled for hydraulic tools.

1.2.4.8 SNAPS CHANGES

Standard drawing snaps have now been enabled for hydraulic tools.

1.2.4.9 UNDO VERTEX

Added *Undo Vertex* to the Right-click menu when drawing polyline items (applies to all hydraulic and drawing 'Polyline' tools).

1.2.4.10 CHANGE MATCH DIALOG CHANGES

The Change/Match dialog has been changed to a grid format.

1.2.4.11 VALVE CONNECTOR TOOL

IRRICAD has a tool that automatically connects control valves to the nearest mainline. To run this select *Connect Valves* from the *Tools* menu.

1.2.4.12 DESIGN PARAMETERS CHANGES


In *Design Parameters* changed the recommended minimum for velocity to 0.1 m/s and recommended minimum/maximum for lateral length to 1.0 and 100.0 m respectively.

1.2.4.13 NEW TAPE CALCULATION METHOD

The screenshot shows the 'Design Parameters' dialog box with the 'Analysis Parameters' tab selected. The dialog is divided into several sections: 'Iterations' with 'Max. for Velocity & LP' set to 200 and 'Max. for Detailed Analysis' set to 50; 'Convergence Ratios' with 'Mainline Analysis Factor' at 0.001 and 'Detailed Analysis factor' at 0.75; 'Miscellaneous' with 'Max. Contours for Interpolation' at 50 and 'Delay Time for information warnings (milliseconds)' at 2500; 'Tolerances' with 'Tape Calculation' at 0.01 m, 'LP Convergence' at 0.001, and 'Detailed Analysis Flow Close Fraction' at 0.001; and 'Tape Parameters' with 'Number of Virtual Emitters for Tape Calculations' at 200, 'Elevation Calculation Method' set to 'Slope Elevation', 'D.E.M. Grid Size' at 100, 'Calculation Formula' set to 'Darcy Weisbach', and 'Kinematic Viscosity (m^2/s x 10^-6)' at 1.13. At the bottom are buttons for 'Restore Defaults', 'Save As Defaults', 'OK', 'Cancel', and 'Help'.

This version includes a new method of analyzing tapes where the elevation at each emitter (or virtual emitter) is used in the calculations. To enable this method select **DEM Elevations** in the "Elevation Calculation Method" dropdown box of the *Analysis* tab under the *Design|Design Parameters* menu item.

1.2.4.14 CONNECTIVITY CHECK




The Connectivity check has been improved. Unconnected outlets, tapes, spraylines and valves are indicated on screen by a special symbol. The coordinates of the unconnected items are no longer displayed in warning messages but are logged to the error log file and can be viewed with *View Errors* under the *Reports* menu.

1.2.4.15 CLEAR CONNECTIVITY MARKS

The *Clear Connectivity Marks* menu item will remove all connectivity symbols, any existing symbols are also removed as part of the connectivity check.

1.2.4.16 SUBDIVISION TOOL


The **Subdivision** tool allows existing Irrigation Block entities to be subdivided into smaller sub blocks. It can be selected from the **Tools** menu. In common with the majority of Irricad tools it can be applied to an existing selection or, if no items are selected, applied to a particular object by clicking on that object.



1.2.4.17 NEW MANAGEMENT OPTIONS

The management options in the **Design** menu have been rearranged and a new graphically based option added.


The new option is called **Assign System Flows to Zones**.



1.2.4.18 MANAGEMENT SYMBOL

The graphical management process automatically creates a symbol, representing the current management arrangement, that can be subsequently drawn onto the plan (see figure below).

This symbol is accessed from *Draw|Management Symbol*, a symbol dialog is displayed that contains the normal symbol placement and creation options.



1.2.4.19 CONVERT TO ELEVATIONS CHANGES

Made changes to the *Convert to Elevations* tool so that only items on visible layers are considered when attempting to join lines to create contours.

1.2.4.20 IMPORT CONTOURS


Import Contours now allows for multiple entities sections and also for LWPOLYLINE DXF entities.

Extra information about the number of contour segments found during *Import Contours* has been included. The number of raw and simplified segments is now shown.

1.2.4.21 CONTOUR SIMPLIFICATION

Irricad has an internal limit for the number of contour segments that can be used during the elevation interpolation process. If contours are imported from a DXF file it is occasionally possible for this limit to be exceeded due to a combination of the 'smoothness' (i.e. the number of small line segments making up the line) and the number of contours lines that are imported. It is also possible for a similar situation to arise when using the *Convert to Elevations* tool.


In this version a facility has been added to 'simplify' any curves and polylines, that are imported as contours (or selected by the *Convert to Elevations* tool), to avoid exceeding the allowable number of contour segments. Two new items have been added to the *Irrigation Items* option of the *Settings* menu (see figure below) to control the behavior of this option.



1.2.4.22 ELEVATION COLOUR CODING


The new **Highlight Elevations** tool colour codes contours and spot heights based on their elevation making any anomalies much easier to locate and correct.

The tool is activated by simply selecting **Highlight Elevations** from the **Tools** menu. When the tool is selected the range of elevation is displayed on the dialog.



1.2.4.23 3D DEM VIEW

If **DEM Elevations** has been selected for the “**Elevation Calculation Method**” in the **Analysis Parameters** tab of **Design Parameters** then it is also possible to view a 3D representation of the resulting ground surface. The advantage of this 3D view is that small inconsistencies in elevations, that are not apparent with colour coding, can be located visually.




This facility is available by selecting **3D DEM View** from the **Reports** menu. Elevations of the DEM points are colour coded in a similar fashion to contours – from red through yellow green and then blue.

1.2.4.24 RE-INTERPOLATE ELEVATIONS

Re-interpolate Elevations on the *Design* menu now re-interpolates all elevations (not just new Hydraulic Items).

1.2.4.25 IMPROVED ZONE DESIGN CONFIGURATION TABLE

The menu item for this option has been moved to immediately above *Zone Design* and many improvements have been made to the functionality of the dialog.




The dialog box titled "Zone Design Configuration" contains a table with 12 columns: Zone Name, Process, Allow For Minor Losses, Change Diameter At Outlet, Number Of Lateral Sizes, Number of Submain Sizes, D/S Valve Pressure (m), Actual Valve Pressure (m), Min/Max Emitter Pressures (m), Minimum Allowable Pressure (m), Maximum Allowable Pressure (m), and Don't Use Database Envelope. The table lists various zones and blocks with their respective parameters. At the bottom, there are buttons for "Set Selected", "Unset Selected", "Paste Selected", "OK", and "Cancel".

Zone Name	Process	Allow For Minor Losses	Change Diameter At Outlet	Number Of Lateral Sizes	Number of Submain Sizes	D/S Valve Pressure (m)	Actual Valve Pressure (m)	Min/Max Emitter Pressures (m)	Minimum Allowable Pressure (m)	Maximum Allowable Pressure (m)	Don't Use Database Envelope
Area 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1	3	6.50	6.11	6.04 - 6.11	5.50	8.00	<input checked="" type="checkbox"/>
Area 12	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1	3	6.50	6.12	6.06 - 6.12	5.50	8.00	<input checked="" type="checkbox"/>
Area 5	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1	3	6.50	6.51	6.44 - 6.51	5.50	8.00	<input checked="" type="checkbox"/>
Area no. 1-16	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1	3	6.50	6.16	6.08 - 6.16	5.50	8.00	<input checked="" type="checkbox"/>
Block 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	2	3	6.50	6.12	6.06 - 6.12	5.50	8.00	<input checked="" type="checkbox"/>
Block 11	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	2	3	6.50	6.11	6.05 - 6.11	5.50	8.00	<input checked="" type="checkbox"/>
Block 12	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	2	3	6.50	6.12	6.06 - 6.12	5.50	8.00	<input checked="" type="checkbox"/>
Block 2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	2	3	6.50	6.22	6.16 - 6.22	5.50	8.00	<input checked="" type="checkbox"/>
Block 3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	2	3	6.50	6.32	6.26 - 6.32	5.50	8.00	<input checked="" type="checkbox"/>
Block 6	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	2	3	6.50	6.62	6.56 - 6.62	5.50	8.00	<input checked="" type="checkbox"/>
Block 7	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	2	3	6.50	6.72	6.66 - 6.72	5.50	8.00	<input checked="" type="checkbox"/>
Zone 23	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	3	3	6.50	6.23	6.17 - 6.23	5.50	8.00	<input checked="" type="checkbox"/>
Zone 3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	3	3	6.50	6.33	6.27 - 6.33	5.50	8.00	<input checked="" type="checkbox"/>
Zone 4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	3	3	6.50	6.43	6.36 - 6.43	5.50	8.00	<input checked="" type="checkbox"/>
Zone 6	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	3	3	6.50	6.63	6.57 - 6.63	5.50	8.00	<input checked="" type="checkbox"/>
Zone 7	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	3	3	6.50	6.73	6.66 - 6.73	5.50	8.00	<input checked="" type="checkbox"/>

1.2.4.26 ZONE PRESSURE MINIMUM AND MAXIMUM

A reporting function has been added that indicates the position and pressure value of the minimum and maximum pressure emitters for a zone (control valve).



Settings for the minimum and maximum zone pressure labels can be found in *Reports|Report Settings*.

1.2.4.27 REPORTS VIEWER

Incorporated a new version of the report writing/viewing engine. Only minor cosmetic changes including enabling the mouse wheel in the report viewer.

1.2.4.28 ZONE REPORTS

A new brief tabular report has been added entitled *Zone CV Table*.

The Zone Design Summary report has been re-titled Zone Design Summary (Pressure Variation).

A revised *Zone Design Summary* report now includes flow variations and the location of the emitters having the minimum and maximum pressures.

Added ZoneArea field to *Zone Design Reports*. Note this only allows for zones being in one area at the moment and will only be populated when a zone is inside an Irrigation Area or Irrigation Block.

The *Zone Design Summary* and *Zone CV Table* reports are now ordered by Zone name. In addition the calculation of percentage pressure and flow ranges has been changed to $100 \times (\text{Max} - \text{Min}) / \text{Max}$ rather than $100 \times (\text{Max} - \text{Min}) / \text{Nominal}$ or $100 \times (\text{Max} - \text{Min}) / ((\text{Max} + \text{Min}) / 2)$.

1.2.4.29 MAINLINE REPORTS

A version of the *Mainline Pipe Report* that lists nodes rather than coordinates has been added. Normally this would be used in conjunction with labelling using the 'UID' keyword to identify junctions on the plan.

A Water Supply elevation field has been added to the mainline reports (Sysflow->WSElevation).

Zones are now sorted by name in the Mainline Summary Report and ML Design Pipe Report – Nodes.

Added an 'OutletFlow' field for mainline reports.


The headloss through a control valve is now available in the MLItem->Outloss mainline report field.

1.2.4.30 CONVERTING DRAWING ITEMS INTO HYDRAULIC ENTITIES

It is now possible to convert drawing items, both those drawn in IRRICAD or imported via a DXF/DWG file, to hydraulic items. This is achieved by selecting the required drawing items and then the appropriate hydraulic tool. Currently tapes and all block tools (including Tape Block entities) can operate this way.

1.2.4.31 HYDRAULIC GRADELINE

After a design is completed it is now possible to view the hydraulic gradeline of submain, spraylines and tapes. The tool can be access from the *Reports* menu.



1.2.4.32 HYDRAULIC DIALOG SETTINGS

The last values entered or database items selected in all the dialogs for Hydraulic Items are now retained with each individual design. Previously they would revert to the default values.

1.2.4.33 UNDO VERTEX

This command allows you to sequentially 'undo' placement of the line segments while running the *Continuous Polyline*. You can correct a misplaced segment without having to erase then redraw the entire line. If desired, *Right-click|Undo Vertex* can be repeated over and over again until the current line is completely undone.

1.2.4.34 PIPE LEGEND

If placeholder lines in the pipe legend templates have a line width, IRRICAD now allows for that line width to be used when pipe legends are created as part of *Draw|Plot Layout*.

1.2.4.35 MOUSE WHEEL

Panning via the mouse wheel button (by clicking and dragging the mouse wheel) has been added.

1.2.4.36 DATABASE CHANGES

A utility to 'clean' fields in databases has been added to the database editor. This utility is used to correctly format fields, in the database, after directly importing data via Access. It is not necessary to use this if data has been entered via the Irricad database editor.

1.2.4.37 SELECTION

Any selected entities on invisible layers are now deselected.

1.3 Hot off the Press – New Patch Additions to Pro Version 11

Currently there are no other additions to Pro Version 11.

2 Index

.
. 14

3

3D DEM View 50

A

ABOS Parameters 3
Add Nozzles .. (database button) 11
Add to Assembly .. (database button) 10
Areas 45
Assemblies
 modifying 10
Autocad Color Export 20
Autocad Color Import 19
AutoCAD Compatibility 17

B

Back Up Folder Specification 38
Block Pipe Stubs 39
Block Valve Positioning 39

C

Change Match Dialog Changes 47
Changes to Importing Contours 38
Changes to the Help Menu 14
Clear Connectivity Marks 47
Clear Management 30
Connect Outlets Tool 27
Connectivity Check 47
Contour Properties 2
Contour Simplification 49
Convert to Elevations Changes 49
Converting Drawing Items into Hydraulic
 Entities 52
Converting Drawing Items into Hydraulic Items
 42

D

Database 44
 file menu 14

 window 12
Database Changes 53
Database Item Display 26
Design Parameters 37
Design Parameters Changes 47
Document Summary Info 36
Dongle Serial Number 38
DWG Font Export Tab 19
DWG Font Import Tab 18
DWG Settings Tab 17

E

Editing Functions 7
Elevation Colour Coding 50
Emitter Coefficient of Variation (COV) 44
Execute Query 11
Exporting to DXF and DWG Files 14

F

File Menu
 database 14
File Stamp 31
Finish Assembly .. (database button) 10
Flushing Manifolds 40

G

Go To Coordinates 35, 43
Gradeline Dialog Export 29

H

Hatch & Fill Editing 32
Hatch Preview 28
Help Menu 44
Hydraulic Dialog Settings 53
Hydraulic Gradeline 40, 52
Hydraulic Item Creation 35

I

Icons
 arrange 12
Image Improvements 21
Import Contours 49
Improved Zone Design Configuration Table 51
Improvements to Curve Fitting 9
Improvements to the Grid View 10
Insert OLE Changes 39
Inserting OLE Data 45
Irrigated Areas 43

K

Keyword Combo 33

L

Label Rounding & Roll Lengths 40
Labels 34, 45
Language Compatibility 14

Layer Manager 24
Layers Menu 42

M

Mainline Reports 52
Management Symbol 49
Menu
 file (database) 14
Merge Designs 37
Mouse Wheel 53
Multiple Water Supply Systems 38

N

Names 36
New Copy Tools 38
New Management Options 48
New Tape calculation method 47
New Toolbars 38
New Tools 38
New Visual CADD Engine 45

O

Object Info 42
Object Scope Flag 43

P

Pipe Legend 53
Plot Templates Keywords Added 46

Q

Queries 11

R

Recent Files 44
Re-interpolate Elevations 51
Reload Query 11
Remove Nozzle .. (database button) 11
Report Templates 37
Reports 43
Reports Viewer 51
Rotate tool 30
Rotate Tool Improvements 30
Running Snaps Changes 46

S

Save Query 11
Saving To Previous Versions of IRRICAD 37
Scale Image Tool 23
Select Tool 41
Selecting Control Valves 5
Selection 53
Settings
 units 13
Snaps 42
Snaps Changes 46
Status Bar 41

Status bar - Info Panel 37
Subdivision Tool 48
Supplementary Character set 13
Symbol Colors 38
Symbol Preview 29

T

Tape and Spray Irrigation Blocks 45
Text Dialog Improvements 33
Tools Menu 13
Trim Elevations 38

U

Unconnected Spray Block Entity 36
Undo Vertex 47, 53
Uniformity 44
Unit settings 13
User Attributes and User Keyword 35

V

Valve Connector Tool 47
Valve Specification Summary 5

W

Warehouse Code - 32 Characters Allowed 6
Watermarking 31
What's New in the File Menu 7
Window
 arrange icons 12
 cascade 12
 tile 12
Window Options 12

Z

Zone Design Configuration 37
Zone Pressure Limits now Editable 38
Zone Pressure Minimum and Maximum 43, 51
Zone Reports 51