



the  
**t.bone**

free solo HT 1.8 GHz  
UHF wireless system

Musikhaus Thomann  
Thomann GmbH  
Hans-Thomann-Straße 1  
96138 Burgebrach  
Deutschland  
Telephone: +49 (0) 9546 9223-0  
E-mail: [info@thomann.de](mailto:info@thomann.de)  
Internet: [www.thomann.de](http://www.thomann.de)

## Table of contents

<b>1</b>	<b>General information</b>	<b>5</b>
1.1	Further information	6
1.2	Notational conventions	7
1.3	Symbols and signal words	8
<b>2</b>	<b>Safety instructions</b>	<b>9</b>
<b>3</b>	<b>Features</b>	<b>13</b>
<b>4</b>	<b>Installation and operation</b>	<b>14</b>
4.1	General Information	14
4.2	Receiver	15
4.3	Transmitter	17
<b>5</b>	<b>Connections and controls</b>	<b>18</b>
5.1	Empfänger	18
5.2	Sender	26
<b>6</b>	<b>Operating</b>	<b>30</b>
6.1	Empfänger	30

6.2	Sender.....	34
<b>7</b>	<b>Technical specifications.....</b>	<b>38</b>
7.1	Sender.....	38
7.2	Empfänger.....	39
<b>8</b>	<b>Plug and connection assignment.....</b>	<b>41</b>
<b>9</b>	<b>Troubleshooting.....</b>	<b>44</b>
<b>10</b>	<b>Protecting the environment.....</b>	<b>47</b>

## 1 General information

This manual contains important instructions for the safe operation of the unit. Read and follow the safety instructions and all other instructions. Keep the manual for future reference. Make sure that it is available to all those using the device. If you sell the unit please make sure that the buyer also receives this manual.

Our products are subject to a process of continuous development. Thus, they are subject to change.

## 1.1 Further information

On our website ([www.thomann.de](http://www.thomann.de)) you will find lots of further information and details on the following points:

Download	This manual is also available as PDF file for you to download.
Keyword search	Use the search function in the electronic version to find the topics of interest for you quickly.
Online guides	Our online guides provide detailed information on technical basics and terms.
Personal consultation	For personal consultation please contact our technical hotline.
Service	If you have any problems with the device the customer service will gladly assist you.

## 1.2 Notational conventions

This manual uses the following notational conventions:

### Letterings

The letterings for connectors and controls are marked by square brackets and italics.

**Examples:** *[VOLUME]* control, *[Mono]* button.

### Instructions

The individual steps of an instruction are numbered consecutively. The result of a step is indented and highlighted by an arrow.

**Example:**

1. ▶ Switch on the device.
2. ▶ Press *[Auto]*.  
    ⇒ Automatic operation is started.
3. ▶ Switch off the device.

## 1.3 Symbols and signal words

In this section you will find an overview of the meaning of symbols and signal words that are used in this manual.

Signal word	Meaning
<b>DANGER!</b>	This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided.
<b>NOTICE!</b>	This combination of symbol and signal word indicates a possible dangerous situation that can result in material and environmental damage if it is not avoided.
Warning signs	Type of danger
	Warning – danger zone.

## 2 Safety instructions

### Intended use

This device is intended to be used for the wireless transmission of audio signals from microphones or instruments to amplifiers or active speakers. Use the device only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This device may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.

### Safety



#### DANGER!

##### Danger for children

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard!

Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke!

Never let children unattended use electrical devices.



#### NOTICE!

##### Operating conditions

This device has been designed for indoor use only. To prevent damage, never expose the device to any liquid or moisture. Avoid direct sunlight, heavy dirt, and strong vibrations.



**NOTICE!**

**External power supply**

The device is powered by an external power supply. Before connecting the external power supply, ensure that the input voltage (AC outlet) matches the voltage rating of the device and that the AC outlet is protected by a residual current circuit breaker. Failure to do so could result in damage to the device and possibly the user.

Unplug the external power supply before electrical storms occur and when the device is unused for long periods of time to reduce the risk of electric shock or fire.



**NOTICE!**

**Risk of fire due to incorrect polarity**

Incorrectly inserted batteries may destroy the device or the batteries.

Ensure that proper polarity is observed when inserting batteries.



### **NOTICE!**

#### **Possible damage by leaking batteries**

Leaking batteries can cause permanent damage to the device.

Take batteries out of the device if it is not going to be used for a longer period.

## 3 Features

Das UHF-Wireless-System eignet sich besonders für professionelle Tonübertragungen, zum Beispiel bei Veranstaltungen, auf Rockbühnen und Konzertpodien, im Theater- und im Musikbereich oder in Diskotheken.

Ihr UHF-Wireless-System free solo HT 1.8 GHz besteht aus folgenden Komponenten:

- 9,5-Zoll-Diversity-Empfänger
  - Zwei Antennen für optimale Empfangsqualität
  - Automatischer Frequenz-Scan
  - Infrarotschnittstelle zur Übertragung der Frequenzauswahl vom Empfänger zum Sender
  - 16 vorprogrammierte Frequenzbaugruppen (User Banks) mit je 12 Kanälen
  - Sehr hohe Empfindlichkeit bei sehr hohem Geräuschspannungsabstand
  - Regelbare Rauschsperrre (Squelch)
  - Ausgänge: XLR, 6,35-mm-Klinkenbuchse
  - Befestigungswinkel für Montage in ein 19-Zoll-Rack
  - Stromversorgung: 12 V == (DC), ein passendes Steckernetzteil gehört zum Lieferumfang
- Sender: Batteriebetriebenes Handheld-Mikrofon mit Nierencharakteristik

free solo HT 1.8 GHz

**th·mann**  
MUSIC IS OUR PASSION

## 4 Installation and operation

### 4.1 General Information

Unpack and carefully check that there is no transportation damage before using the unit. Keep the equipment packaging. To fully protect the device against vibration, dust and moisture during transportation or storage use the original packaging or your own packaging material suitable for transport or storage, respectively.

Create all connections while the device is off. Use the shortest possible high-quality cables for all connections. Take care when running the cables to prevent tripping hazards.

### Notes on wireless transmission

- This device utilizes frequencies that are not harmonized within the European Union (EU) and therefore may only be used in certain EU member states. In all European countries, the frequencies used for the transmission of audio signals are strictly regulated. Before you start, make sure the frequencies are allowed in the respective country and check whether the operation must be reported to the appropriate authority.  
For more information, please visit: <http://www.thomann.de>.
- Make sure that transmitter and receiver are both tuned to the same channel.
- Never set multiple transmitters to the same channel.
- Make sure that there are no metal objects between the transmitter and receiver.
- Avoid interference from other radio or in-ear systems.

## 4.2 Receiver

### Rack mounting

The unit has been designed for rack mounting in a standard 19" rack; it occupies one rack unit. The fixing material required for assembly is included.

### Connecting the power supply



#### NOTICE!

##### External power supply

The device is powered by an external power supply. Before connecting the external power supply, ensure that the input voltage (AC outlet) matches the voltage rating of the device and that the AC outlet is protected by a residual current circuit breaker. Failure to do so could result in damage to the device and possibly the user.

Unplug the external power supply before electrical storms occur and when the device is unused for long periods of time to reduce the risk of electric shock or fire.

First, connect the power adapter to the receiver and then plug the power adapter into the power outlet.

### Attaching the antennas

Attach the included antennas to the rear panel of the transmitter. To improve the transmission quality and to adapt to the spatial conditions they are rotatable and swivelling.

In case the space provided on the device for direct assembly of the antennas is not sufficient, for example because the space on the rack is narrow, you can use the optionally available coaxial cable to assemble the antennas separately from the device. For larger combinations with up to four receivers, an antenna distributor is optionally available.

### Connecting audio and starting up

Connect one of the audio outputs of the receiver to your mixer or your amplifier. Ensure that only one of the two outputs is ever used at a time, because faults might occur otherwise.

## 4.3 Transmitter


### Inserting batteries into the receiver

Unscrew the bottom housing section of the hand-held microphone. Insert the batteries. Pay attention to the correct location of the poles. The correct arrangement of the batteries is indicated with symbols in the battery compartment. Close the battery compartment, screw the bottom housing section back on, and switch the transmitter on.

## 5 Connections and controls

### 5.1 Empfänger


#### Vorderseite



1	<i>[POWER]</i> Drücken Sie den Schalter mehrere Sekunden, um das Gerät ein- bzw. auszuschalten. Drücken Sie den Schalter kurz, um das Gerät stummzuschalten. Alle zuvor vorgenommenen Einstellungen werden gespeichert, auch wenn Sie das Gerät ausschalten und vom Stromnetz trennen.
2	Infrarotempfänger.
3	<i>[ADL]</i> Startet die Synchronisation der Einstellungen mit dem Sender.
4	Display.
5	<i>[SET]</i> Öffnet das Menü.
6	▲ Erhöht den angezeigten Wert um eins.
7	▼ Verringert den angezeigten Wert um eins.

8	<b>[AUTO]</b> Startet die automatische Suche nach einem freien Kanal.
12, 13	Abgestimmte UHF-Antennen. Der Empfänger wertet das Funksignal von beiden Antennen aus und wählt das Signal mit der höheren Qualität für die Weiterverarbeitung aus.

Rückseite




free solo HT 1.8 GHz

**th•mann**  
MUSIC IS OUR PASSION

9	<i>[DC 12-18V]</i> Buchse zum Anschluss des mitgelieferten Steckernetzgeräts. Falls Sie ein anderes Netzgerät verwenden, beachten Sie die korrekte Spannung, die Polarität des Steckers und die Leistungsaufnahme.
10	<i>[BALANCED OUTPUT]</i> XLR-Einbaustecker als symmetrischer Audiosignalausgang zur direkten Verbindung mit einem Mischpult, einer Endstufe oder einem Aufnahmegerät.
11	<i>[UNBALANCED OUTPUT]</i> 6,35-mm-Klinkenbuchse als unsymmetrischer Audiosignalausgang zur direkten Verbindung mit einem Mischpult, einer Endstufe oder einem Aufnahmegerät.
12, 13	<i>[ANTENNA-B], [ANTENNA-A]</i> Abgestimmte UHF-Antennen. Der Empfänger wertet das Funksignal von beiden Antennen aus und wählt das Signal mit der höheren Qualität für die Weiterverarbeitung aus.
14	Angabe des Frequenzbereichs, in dem das Gerät arbeitet. Die Angabe hier muss mit der Angabe am Sender übereinstimmen.

## Display




free solo HT 1.8 GHz

**th•mann**  
MUSIC IS OUR PASSION


15	[RF]	Zeigt den Pegel des empfangenen Funksignals an.
16	[AF]	Pegelanzeige für das Audiosignal.
17	[GP]	Zeigt die eingestellte Frequenzgruppe an.
18	[CH]	Zeigt den eingestellten Kanal an.
19	[GAIN]	Zeigt die Signalanhebung bzw. -Abschwächung in dB an.
20	[RF]	Zeigt die Ausgangsleistung an.
21	[SQL]	Zeigt das eingestellte Niveau der Rauschsperre (Squelch) für das Funksignal an. Eine zu hoch eingestellte Rauschsperre senkt die Dynamik des Systems.

22	<i>[AUTO]</i>	Zeigt an, dass die automatische Suche nach einem freien Kanal läuft.
23	<i>[IR]</i>	Zeigt an, dass ein Infrarotsignal empfangen wird.
24	<i>[MHz]</i>	Anzeige der Frequenz, die der eingestellten Kombination aus Frequenzgruppe und Kanal zugeordnet ist.
25	<i>[ANT.A], [ANT.B]</i>	Zeigt an, welche der beiden Antennen gerade zur Signalübertragung genutzt wird.

## 5.2 Sender



31	Display.
32	Mikrofonkorb zum Schutz vor Beschädigungen und zur Reduzierung von Wind- und Atemgeräuschen.
33	Hauptschalter  Drücken Sie den Schalter mehrere Sekunden, um das Gerät ein- bzw. auszuschalten. Drücken Sie den Schalter kurz, um das Mikrofon stummzuschalten oder die Stummschaltung wieder aufzuheben.
34	Unterer Gehäuseteil. Zum Öffnen aufschrauben.
35	[SET]  Halten Sie die Taste für mehrere Sekunden lang gedrückt, um das Menü zu öffnen.
36	[SEL]  Taste zum Einstellen von Werten im geöffneten Menü.
37	Angabe des Frequenzbereichs, in dem das Gerät arbeitet. Die Angabe hier muss mit der Angabe auf der Rückseite des Empfängers übereinstimmen.
38	Batteriehalter für zwei Mignonzellen (AA, LR06), 1,5 V, oder entsprechende Akkus.
39	Infrarotsensor.



51	[MHz]
	Anzeige der eingestellten Frequenz.
56	[GP]   [CH]
	Im Menümodus Anzeige der Frequenz, die der eingestellten Kombination aus Frequenzgruppe und Kanal zugeordnet ist.
52	Zustandsanzeige der Batterien. Wechseln Sie die Batterien, sobald nur noch ein blinkender Balken angezeigt wird. Sinkt die Spannung der Batterien noch weiter, wird der Sender automatisch abgeschaltet.
53	🔇
	Zeigt an, dass der Sender stummgeschaltet ist. Dies ist der Fall, wenn der Sender und der Empfänger auf verschiedenen Frequenzen arbeiten, wenn der Empfänger kein brauchbares Signal empfängt oder wenn Sie den Sender durch kurzes Drücken des Hauptschalters stummgeschaltet haben.
54	[GAIN]
	Zeigt die Signalanhebung bzw. -Abschwächung in dB an.
55	Zeigt die Ausgangsleistung an.

## 6 Operating

### 6.1 Empfänger

#### Frequenz auswählen

- 1.** ➤ Drücken Sie [SET].  
⇒ Die Anzeige [GP] blinkt.
- 2.** ➤ Benutzen Sie die Pfeiltasten, um die Frequenzgruppe auszuwählen.  
Drücken Sie [SET], um die Auswahl zu bestätigen.  
⇒ Die Anzeige [CH] blinkt.
- 3.** ➤ Benutzen Sie die Pfeiltasten, um innerhalb der eingestellten Frequenzgruppe einen Kanal auszuwählen.  
Haben Sie die Frequenzgruppe 'U' ausgewählt, können Sie mit den Pfeiltasten die Frequenz direkt in 25-kHz-Schritten einstellen. Stellen Sie dabei zunächst den Wert vor dem Dezimalpunkt ein, drücken Sie anschließend [SET] und stellen Sie danach den Wert hinter dem Dezimalpunkt ein.  
Drücken Sie [SET], um die Auswahl zu bestätigen.

- ⇒ Das Display zeigt an, dass der Empfänger auf die neue Frequenz abgestimmt wird.  
Nach einigen Sekunden zeigt das Display wieder den Grundzustand an.

## Sender und Empfänger synchronisieren

- 1.** Öffnen Sie den Sender, um den Infrarotsensor freizulegen.
- 2.** Drücken Sie [ADL]. Die Anzeige [IR] blinkt.
- 3.** Halten Sie innerhalb von zehn Sekunden den Infrarotsensor des Senders nahe an die Infrarotschnittstelle des Empfängers.
- 4.** Wenn die Synchronisation erfolgreich abgeschlossen ist, hört die Anzeige [IR] auf zu blinken.
  - ⇒ Nach drei Sekunden zeigt das Display wieder den Grundzustand an.

## Rauschsperrre (Squelch) einstellen

- 1.** Drücken Sie [SET] so lange, bis im Display der Bereich [SQ] blinkt.
- 2.** Benutzen Sie die Pfeiltasten, um den gewünschten Wert einzustellen. Der aktuelle Wert wird an der rechten Seite des Displays angezeigt.
- 3.** Drücken Sie [SET], um die Auswahl zu bestätigen.  
⇒ Nach drei Sekunden zeigt das Display wieder den Grundzustand an.

## Automatische Suche nach freiem Kanal

- 1.** Drücken Sie [AUTO].
  - ⇒ Die Anzeige [AUTO] blinkt, das Display zeigt die Anzahl der verfügbaren freien Kanäle.
- 2.** Benutzen Sie die Pfeiltasten, um einen der freien Kanäle auszuwählen.  
Drücken Sie [SET], um die Auswahl zu bestätigen.
  - ⇒ Nach drei Sekunden zeigt das Display wieder den Grundzustand an.
- 3.** Falls das System innerhalb von fünf Sekunden keinen freien Kanal findet, kehrt es automatisch wieder in den Grundzustand zurück.

## Tastensperre

- 1.** ➤ Drücken Sie [SET] so lange, bis das Symbol  erscheint.
  - ⇒ Alle Tasten außer dem Hauptschalter sind gesperrt.
- 2.** ➤ Um die Tastensperre wieder aufzuheben, drücken Sie [SET] so lange, bis das Symbol  nicht mehr sichtbar ist
  - ⇒ Die Tasten haben wieder ihre ursprüngliche Funktion.

## 6.2 Sender

Die Tasten zur Bedienung des Geräts sind zugänglich, wenn Sie das untere Gehäuseteil abschrauben.

## Frequenz auswählen

Wenn Sie den Sender nicht über die Infrarotschnittstelle mit dem Empfänger synchronisieren möchten, können Sie die Sendefrequenz in der konfigurierbaren Frequenzgruppe (User Bank) auch manuell einstellen.

- 1.** ➔ Drücken Sie **[SET]** so lange, bis im Display der Wert im Feld **[GP]** blinkt.
- 2.** ➔ Benutzen Sie **[SEL]**, um die Frequenzgruppe auszuwählen.  
Drücken Sie **[SET]**, um die Auswahl zu bestätigen.  
⇒ Die Zahl im Feld **[CH]** blinkt.
- 3.** ➔ Benutzen Sie **[SEL]**, um innerhalb der eingestellten Frequenzgruppe einen Kanal auszuwählen.  
Haben Sie die Frequenzgruppe „U“ ausgewählt, können Sie mit **[SEL]** die Frequenz direkt einstellen. Stellen Sie dabei zunächst den Wert vor dem Dezimalpunkt ein, drücken Sie anschließend **[SET]** und stellen Sie danach den Wert hinter dem Dezimalpunkt ein.  
Drücken Sie **[SET]**, um die Auswahl zu bestätigen.  
⇒ Nach einigen Sekunden zeigt das Display wieder den Grundzustand an.

## **Senderverstärkung (Gain) einstellen**

- 1.** Drücken Sie [SET] so lange, bis im Display die Zahl im Feld [GAIN] blinkt.
- 2.** Benutzen Sie [SEL], um die Senderverstärkung (Gain) in Schritten von 3 dB zu verändern (-3 dB, 0 dB, 3 dB, 6 dB, 9 dB).  
Drücken Sie [SET], um die Auswahl zu bestätigen. Drücken Sie den Hauptschalter, um das Menü ohne Änderungen zu schließen.

## **Sendeleistung einstellen**

- 1.** Drücken Sie [SET] so lange, bis im Display das Symbol  blinkt.
- 2.** Benutzen Sie [SEL], um die Sendeleistung zu verändern (5 mW, 10 mW, 20 mW).  
Drücken Sie [SET], um die Auswahl zu bestätigen. Drücken Sie den Hauptschalter, um das Menü ohne Änderungen zu schließen.

## Frequenzgruppe und Kanal anzeigen

- 1.** Drücken Sie [SEL].
  - ⇒ Das Display zeigt die benutzte Frequenzgruppe und den benutzten Kanal an.
- 2.** Drücken Sie [SEL] oder warten Sie fünf Sekunden, um wieder in den Grundzustand zu kommen.

## Tastensperre

- 1.** Drücken Sie [SET] so lange, bis das Symbol  erscheint.
  - ⇒ Alle Tasten außer dem Hauptschalter sind gesperrt.
- 2.** Um die Tastensperre wieder aufzuheben, drücken Sie [SET] so lange, bis das Symbol  nicht mehr sichtbar ist
  - ⇒ Die Tasten haben wieder ihre ursprüngliche Funktion.

## 7 Technical specifications

### 7.1 Sender

Trägerfrequenz	UHF-Band (600 MHz...1,8 GHz)
Frequenzband	1,7815 GHz...1,7955 GHz
Bandbreite	140 MHz
Anzahl der Kanäle	192
Schaltbandbreite	25 kHz
Modulationstyp	Frequenzmodulation (FM)
Maximale Sendeleistung	20 mW
Nebenempfangsunterdrückung	> 55 dBc
Spitzenabweichung	± 55 kHz
NF-Frequenzgang	60 Hz...18 kHz

Klirrfaktor	< 0,5 %
Geräuschspannungsabstand	> 102 dB (A)
Energieversorgung	2 Mignonzellen (AA, LR06, 1,5 V) oder entsprechende Akkus
Betriebsdauer	> 8 h (mit Alkaline-Zellen)
Abmessungen (L × D)	246 mm × 53 mm
Gewicht	250 g

## 7.2 Empfänger

Ausgang	XLR-Einbaustecker, symmetrisch 6,35-mm-Klinkenbuchse, unsymmetrisch
Empfindlichkeit	-102 dBm
NF-Frequenzgang	50 Hz...15 kHz ( $\pm 3$ dB)

free solo HT 1.8 GHz

**th•mann**  
MUSIC IS OUR PASSION

## Technical specifications

---

Klirrfaktor	< 0,8 %
Geräuschspannungsabstand	> 105 dB (A)
Energieversorgung	12 V $\text{⎓}$ (DC)
Abmessungen (B $\times$ T $\times$ H, ohne Antennen)	212 mm $\times$ 160 mm $\times$ 44 mm
Gewicht	900 g

Trägerfrequenz, Frequenzband, Anzahl der Kanäle, Bandbreite, Schaltbandbreite und Modulationstyp entsprechen denen des Senders.

## 8 Plug and connection assignment

### Introduction

This chapter will help you select the right cables and plugs to connect your valuable equipment in such a way that a perfect sound experience is ensured.

Please note these advices, because especially in 'Sound & Light' caution is indicated: Even if a plug fits into the socket, an incorrect connection may result in a destroyed power amp, a short circuit or 'just' in poor transmission quality!

### Balanced and unbalanced transmission

Unbalanced transmission is mainly used in semi-professional environment and in hifi use. Instrument cables with two conductors (one core plus shielding) are typical representatives of the unbalanced transmission. One conductor is ground and shielding while the signal is transmitted through the core.

Unbalanced transmission is susceptible to electromagnetic interference, especially at low levels, such as microphone signals and when using long cables.

In a professional environment, therefore, the balanced transmission is preferred, because this enables an undisturbed transmission of signals over long distances. In addition to the conductors 'Ground' and 'Signal', in a balanced transmission a second core is added. This also transfers the signal, but phase-shifted by 180°.

free solo HT 1.8 GHz

**th•mann**  
MUSIC IS OUR PASSION

Since the interference affects both cores equally, by subtracting the phase-shifted signals, the interfering signal is completely neutralized. The result is a pure signal without any noise interference.

### 1/4" TS phone plug (mono, unbalanced)




1	Signal
2	Ground, shielding

### 1/4" TRS phone plug (mono, balanced)



1	Signal (in phase, +)
2	Signal (out of phase, -)
3	Ground

**XLR plug (balanced)**



1	Ground, shielding
2	Signal (in phase, +)
3	Signal (out of phase, -)

# 9 Troubleshooting

In the following we list a few common problems that may occur during operation. We give you some suggestions for easy troubleshooting:

Symptom	Remedy
No sound	<ol style="list-style-type: none"><li>1. Check the power supply of the transmitter and receiver.</li><li>2. Make sure that both transmitter and receiver operate in the same frequency range. The frequency range is stated on the devices.</li><li>3. Are both transmitter and receiver set to the same channel?</li><li>4. Check the connection between the receiver and the connected audio device (amp, mixer). Is the connected audio device switched on and does the signal level on the output of the receiver match the input sensitivity of the audio device?</li><li>5. Try to improve the transmission by moving the transmitter closer to the receiver.</li><li>6. Make sure that no metal objects near the transmitter or receiver obstruct the transmission.</li></ol>
Transmission is disturbed	<ol style="list-style-type: none"><li>1. Modify the orientation of the antennas.</li><li>2. If you use more than one wireless system at the same time, check the used frequencies and channels.</li><li>3. Interference can also be caused by other radio or in-ear systems.</li></ol>

If the procedures recommended above do not succeed, please contact our Service Center. You can find the contact information at [www.thomann.de](http://www.thomann.de).

## 10 Protecting the environment

### Disposal of the packaging material



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling.

Ensure that plastic bags, packaging, etc. are properly disposed of.

Do not just dispose these materials with your normal household waste, but make sure that they are fed to a recovery. Please follow the notes and markings on the packaging.

### Disposal of batteries



Batteries must not be disposed of as domestic waste or thrown into fire. Dispose of the batteries according to national or local regulations regarding hazardous waste. To protect the environment, dispose of empty batteries at your retail store or at appropriate collection sites.

### Disposal of your old device



This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE). Do not dispose with your normal household waste.

Dispose this device through an approved waste disposal firm or through your local waste facility. When discarding the device, comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.

free solo HT 1.8 GHz

**th•mann**  
MUSIC IS OUR PASSION





**Musikhaus Thomann · Hans-Thomann-Straße 1 · 96138 Burgebrach · Germany · [www.thomann.de](http://www.thomann.de)**