



BLACK DIAMOND
274 Huey Lenard Loop Rd.
West Monroe, LA 71292
Phone: (318) 322-3458
Sales / Tech: (800) 551-4955
Fax: (318) 397-3040
www.blackdiamondoffroad.com

**Black Diamond adjustable rear track bar for
JEEP WRANGLER (TJ)
INSTALLATION INSTRUCTIONS**

INTRODUCTION

Installation requires a professional mechanic. Prior to beginning, inspect the vehicles steering, driveline, and brake systems, paying close attention to the suspension link arms and bushings, anti-sway bars and bushings, tie rod ends, pitman arm, ball joints and wheel bearings. Also check the steering sector-to-frame and all suspension-to-frame attaching points for stress cracks. The overall vehicle must be in excellent working condition; repair or replace all worn parts.

Read instructions several times before starting. Be sure you have all needed parts and know where they install. Read each step completely as you go.

NOTES:

- The instructions below detail only the installation of the adjustable rear track bar. Refer to the main instruction form supplied with the lift system for all other installation steps.
- This track bar only fits vehicles equipped with a 4"-6" lift system and should be compatible with lift systems from most reputable manufacturers.
- In addition to the adjustable track bar supplied, any TJ equipped with a 6" lift will also require the track bar bracket supplied with the suspension lift system to be retained. Track bar brackets supplied with a 4" lift system may be removed provided that the maximum adjustment on the Black Diamond track bar is not exceeded. Otherwise, the bracket supplied with the lift system must be retained.
- A foot-pound torque reading is given in parenthesis () after each appropriate fastener.
- Do not fabricate any components to gain additional suspension height.
- Paint or undercoat all exposed metal surfaces.
- Prior to attaching components, be sure all mating surfaces are free of grit, grease, undercoating, etc.
- A factory service manual should be on hand for reference.
- Use the check-off box "☐" found at each step to help you keep your place. Two "☐☐" denotes that one check-off box is for the driver side and one is for the passenger side. Unless otherwise noted, always start with the driver side.

PARTS LIST ... The part number is stamped into each part or printed on an adhesive label. Identify each part and place the appropriate mounting hardware with it.

PART NO	DESCRIPTION	NEW ATTACHING HARDWARE
---------	-------------	------------------------

(Qty.- if more than one) (Qty.- if more than one)

55-12-5100	adjustable track bar body, rear	(2) bushing half
	(1) sleeve	
	(1) extra-thick washer	
	(2) 1/2" X 2-3/4" bolt	
	(2) 1/2" SAE washer	
	(2) 1/2" nyloc nut	
	(2) spacer	
	(1) heim joint end	
	(1) 3/4" jam nut	

INSTALLATION PROCEDURE

1) PREPARE VEHICLE...

- ☐ Position the vehicle on a level surface with the front tires pointing straight ahead. Put the vehicle in park or First gear, set the emergency brake, and chock the rear wheels to prevent any possibility of movement. The vehicle should remain on the ground with the suspension "loaded" at normal operating weight to reflect the true ride height.

2) FACTORY TRACK BAR REMOVAL...

- ☐ Remove the factory track bar from the vehicle and set aside. Save all hardware for reuse

3) TRACK BAR #55-12-5100...

- ☐ Lubricate and install the supplied bushings and sleeves in the upper end of the track bar (55-12-5100). Note that the supplied extra-thick washer should be positioned between the bushing halves in the eye of the bar.
- ☐ Thread the heim joint with the supplied jam nut in the lower end of the track bar. Set the length of the track bar at 32-5/8" measured from eye-to-eye. This will provide a baseline for adjustment.
- ☐ Position the supplied spacers on both sides of the heim joint and then insert the heim end of the track bar into the track bar bracket on the axle. Loosely secure using the factory hardware.
- ☐ Slide the bushing end of the track bar into the frame bracket and attach using the supplied 1/2" x 2-3/4" bolt and nyloc nut (57).

4) TRACK BAR ADJUSTMENT...

- ☐ Position a plumb bob or similar tool against the inside edge of the frame. Measure the distance between the line of the plumb bob and the brake backing plate. Record this measurement, then repeat the procedure on the other side.
- ☐ Compare the two measurements recorded in the previous step; the goal is to make them equal: If the driver side measurement is greater than the passenger side, the track bar

needs to be shortened. If the passenger side measurement is greater than the driver side, the track bar needs to be lengthened.

- ☐ ☐ Disconnect the heim end of the track bar from the vehicle and make the appropriate adjustments. Tighten the jam nut firmly, then reattach the bar to the axle and torque (57).
- ☐ ☐ Once installation is complete, test-drive the vehicle and repeat the measuring procedure to verify the adjustments made were correct.

NOTE: The maximum amount of adjustment is no more than 1-1/8" of exposed heim joint threads as measured from the end of the track bar.

IMPORTANT PRODUCT USE INFORMATION

As a general rule, the taller a vehicle is, the easier it will roll over. Offset, as much as possible, what is lost in roll over resistance by increasing tire track width. In other words, go "wide" as you go "tall". Many sportsmen remove their mud tires after winter / hunting season and install ones more appropriate for street driving; always use as wide a tire and wheel combination as possible to enhance vehicle stability.

We strongly recommend, because of roll over possibility, that the vehicle be equipped with a functional roll bar and cage system. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Generally, braking performances and capabilities are decreased when significantly larger / heavier tires and wheels are used. Take this into consideration while driving.

Do not add, alter, or fabricate any factory or aftermarket parts to increase vehicle height over the intended height of the Black Diamond product purchased. Mixing component brands is not recommended.

Most states have some type of law limiting vehicle height. The amount of lift allowed, and how the lift may be achieved, varies greatly. Several states offer exemptions for farm or commercially registered vehicles. It is the owner's responsibility to check state and local laws to ensure that their vehicle will be in compliance.

Black Diamond makes no claims regarding lifting devices and excludes any and all implied claims. Black Diamond will not be responsible for any altered product or any improper installation or use of our products.

We will be happy to answer any questions concerning the design, function, and correct use of our products.

IMPORTANT MAINTENANCE INFORMATION

It is the ultimate buyer's responsibility to have all bolts / nuts checked for tightness after the first 100 miles and then every 1000 miles. The steering, suspension and driveline systems, along with wheel alignment should be inspected by a qualified professional mechanic at least every 3000 miles.

NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with a Black Diamond lifting device must have the enclosed "Warning to Driver" decal installed on the inside of the windshield or on the vehicle's dash, within driver's view. The "Warning to Driver" decal is to act as a constant safety reminder for whoever may be operating the vehicle. The WARRANTY IS VOID unless this decal is in place. **INSTALLING DEALER...** It is your responsibility to install warning decal and forward these installation instructions to the vehicle owner for review of warnings, product use and maintenance information. Replacement warning decals are available free upon request. These instructions are to be kept with the vehicle registration papers and owners manual for the service life of the vehicle.

BLACK DIAMOND LIMITED LIFETIME WARRANTY

Suspension products bearing the Black Diamond (Woods Read Dist.) name are warranted for as long as the original purchaser owns the vehicle that the Woods Ready product was originally installed on. This warranty is non-transferable. Warranty covers only the product, no labor, time loss, or freight incurred. Any product that has been abused, altered, incorrectly installed, or used in competition is not covered. Product finish, spring bushings, Polyurethane products, and normal wear is not covered. The Woods Ready product is subject to replacement or repair. No other warranties are expressed or implied. An authorized Black Diamond dealer must inspect the part in question and confirm that the "Warning to Driver" decal is properly displayed. A copy of the sales invoice is required for warranty consideration.