

# Fat-Free HDL

## **ABSTRACT**

The Fat-Free HDL white paper has been written to provide coding guidelines to help produce re-useable, uniform, and synthesis friendly code. The paper covers issues such as uniform code, clocks and resets, coding for synthesis, partitioning for synthesis, and LEDA. Topics range from naming conventions to isolating special functions. Checklists are provided to aid a team in deciding which guidelines to follow. It is assumed by the author, readers of the paper are familiar with VHDL and/or Verilog.

# Table of Contents

<b>PURPOSE</b> .....	4
<b>INTRODUCTION</b> .....	4
<b>CHECKLISTS</b> .....	4
UNIFORM CODE.....	5
CLOCK AND RESETS .....	5
CODING FOR SYNTHESIS .....	5
SYNTHESIS PARTITIONING .....	6
LEDA .....	6
<b>HDL GUIDELINES</b> .....	7
UNIFORM CODE.....	7
<i>Naming Conventions</i> .....	7
<i>File Headers</i> .....	10
<i>File Comments</i> .....	11
<i>Line Length</i> .....	12
<i>VHDL- Entity, Architecture, and Configuration</i> .....	12
CLOCK AND RESETS .....	12
<i>Mixed Clock Edges</i> .....	12
<i>Clock buffers</i> .....	13
<i>Gated clocks</i> .....	13
<i>Internally generated clocks</i> .....	13
<i>Internally generated resets</i> .....	13
CODING FOR SYNTHESIS .....	14
<i>Sequential Logic</i> .....	14
<i>Synchronous vs. Asynchronous Reset</i> .....	18
<i>Combinatorial Logic</i> .....	19
<i>Sensitivity Lists</i> .....	20
<i>Block vs. Non-blocking</i> .....	21
<i>Signal vs. variable</i> .....	22
<i>Case vs. if-then-else</i> .....	22
<i>Case sensitivity</i> .....	22
<i>Bus Widths</i> .....	22
<i>Wait Until vs. If vs. Rising Edge</i> .....	23
PARTITIONING FOR SYNTHESIS .....	23
<i>Design Reuse</i> .....	24
<i>Related Combinatorial Logic</i> .....	24
<i>Register Block Outputs</i> .....	24
<i>Design goals</i> .....	25
<i>Sharable Resources</i> .....	25
<i>Isolating Special Functions</i> .....	25
LEDA .....	25
<i>What is LEDA?</i> .....	25

*How does LEDA Work?* ..... 26  
*LEDA Guidelines* ..... 26

# Purpose

Would you like to have HDL guidelines that help produce re-useable code? Wouldn't it be nice to see a team develop code that not only is functionally correct, but readable, and looks professional? What about having guidelines that may help reduce schedules, and improve synthesis? Providing you these guidelines is the purpose of this paper. Why fat-free you ask? Because the goal is to give you the information you're looking for without all the extra stuff you'll never need or use.

---

## Introduction

Okay, so you've been assigned a new project and the goal is to have functionally correct and re-useable code. And the same old same old speech: schedule is tight, work smarter not harder, and do it right the first time. Where do we start? I suggest with a meeting.

The goal of the meeting is to introduce the project and set the expectations: Re-useable code and schedule. Now in order to have re-useable code, HDL coding guidelines need to be established. If you can't read the code then how is someone else going to use it? Not to mention that poorly written or elaborate written code causes unnecessary synthesis headaches and schedule increases.

The entire team needs to be together at the meeting. This ensures that everyone has an opportunity to provide input to the guidelines. Rest assured that if guidelines are dictated someone will decide not to follow them. There's no guarantee this won't happen anyway but at least you can reduced the odds.

To help steer the meeting, checklists can be helpful. The checklists can be used to determine what guidelines you want to follow and ones you don't. Collecting and documenting these guidelines holds everyone accountable while producing uniform and professional looking code.

---

## Checklists

There are several books, articles, web pages, and etc. around that contain information on HDL coding guidelines. Most designers don't have the luxury of time to read the overwhelming amounts of material available. If you only have time to review a limited amount of material the HDL Compiler for Verilog and VHDL Reference Manuals come highly recommended. For this paper the areas that will be concentrated on are shown below:

1. Uniform Code

2. Clock and Reset
3. Coding for Synthesis
4. Synthesis Partitioning
5. LEDA

## Uniform Code

If you've ever had to pick up someone else's code and modify it or have been in lab trouble shooting cards with an ASIC on board then you have a good idea of the importance of coding conventions. There is nothing worse than looking at code where signal names are a single letter, and that letter changes throughout the hierarchy, or in lab, the schematic signal name doesn't match the name in the ASIC. Not to mention how annoying it is to have code with lines too long to read, no comments to tell you what the code does, or even a header to tell you what the file name is and who wrote the code. This can all be avoided by setting up some guidelines in the beginning of the program.

## Clock and Resets

Why guidelines for clocks and resets? Because a complicated clocking structure is harder to understand, analyze, and maintain. Using a simplified clocking scheme consistently produces better synthesis results. In this paper a simplified clocking scheme is defined as a single global clock and positive edge-triggered flops as the only sequential devices.

Decide early, before any code is written, what the reset methodology is going to be. Things to consider may include:

1. Is the reset synchronous or asynchronous?
2. Is there an internal or external power-on reset?
3. Is there more than one reset (hard vs. soft reset)?
4. Is each macro individually re-settable for debug purposes?

## Coding for Synthesis

Did you know that coding styles that are functionally equivalent might synthesize into hardware that has different timing and area results? Did you know that it is never a good idea to rely solely on the synthesis tool to fix a poorly coded design? This is why coding style plays a key role in generating the final synthesized hardware. The reason that coding styles need to be defined up front is because the coding style determines

the initial starting point for synthesis algorithms. Spending the time developing synthesis guidelines now can allow you to consistently generate better hardware results.

## Synthesis Partitioning

Design partitioning can help or hurt the time spent in synthesis. Thinking about how to break up the design in hierarchical blocks, how to register all the outputs, and where to place combinatorial logic now, before the design begins, can help produce better synthesis results and reduce run time.

## LEDA

In addition to developing HDL coding guidelines, the team needs to decide if LEDA is going to be used. LEDA is an HDL Specifier and checker, which contain sets of rules that you can use to check your HDL designs against coding standards that are important in the design and verification flow. Using LEDA or not decision needs to be made early since time and resources will be required to get LEDA ready to crunch prior to HDL being finished. Here are some items to be considered.

1. Use prepackaged rules that in general will meet most hardware design needs.
2. Use the Specifier to create your own custom rules.
3. Use the Specifier to configure prepackaged rules to meet your design teams needs.

---

# HDL Guidelines

Now that the team is together and checklists are at hand lets go deeper and develop guidelines to be used. The guidelines presented here are just that "guidelines." Every program and team needs to develop their own coding style to fit the requirements and goals of that particular program. Once the guidelines have been developed you'll be on your way to writing code that can be easily understood, looks professional, and synthesis friendly.

## Uniform Code

### Naming Conventions

In all programming languages including VHDL and Verilog it is important to use a specific naming style. Develop and document the naming style to be used for the entire design. This will produce consistent names throughout all the HDL and increase readability of the code.

1. Use lowercase letters for all signal names, variable names, and port names.

- a. *data\_in*

2. Use uppercase letters for names of constants and user-defined type.

- a. VHDL

- i. generic (WIDTH : integer);

- b. Verilog

- i. parameter WIDTH = 5;

3. Use an underscore ("\_") to separate parts of a name. But don't use the underscore as a first or last character.

- a. *data\_out*

4. Meaningful user defined names improve readability.

- a. Do not use *di* for a data input.

- b. Instead use *data\_input*.

5. Write compound names consistently to improve readability.

- a. *Ram\_Adder* Mixed upper and lower case not recommended.

- b. *RamAdder* Harder to read without underscore.

- c. *ram\_adder* Preferred method.
- 6. Choose to use either a noun-verb or verb-noun convention but not both.
  - a. Noun-verb format
    - i. *data\_requested*
  - b. Verb-noun format
    - i. *requested\_data*
- 7. Use the name *clk* for the clock signal. If there is more than one clock in the design, use *clk* as the prefix for all clock signals.
  - a. *clk1*
  - b. *ck2*
  - c. *clk\_10mhz*
- 8. Use the same name for all clock signals that are driven from the same source.
- 9. For active low signals, use the suffix “*\_n*”. Using the same suffix letter will allow someone to quickly identify signals that are active low.
  - a. *rst\_n*
- 10. Use the name *rst\_n* for reset signals. If the reset signal is active low, use the suffix “*\_n*” as shown above.
- 11. When describing multi-bit buses, use a consistent order of bits. The preference in this paper is for VHDL (y downto x) and Verilog (x:0). The recommendation is to establish a standard, and thus achieve some consistency across multiple design and design teams.
  - a. VHDL
    - i. (y downto x)
    - ii. (x to y)
  - b. Verilog
    - i. (y : 0)
    - ii. (0 : x)



12. Instead of using hard-coded numeric values use constants, generics for VHDL, and parameters for Verilog.

a. VHDL

```
constant CHIP_ID :std_logic_vector (7 downto 0) := "11110000";
```

...

```
if (decoded_addr == CHIP_ID)
```

b. Verilog

```
parameter CHIP_ID = 8'b11110000;
```

...

```
if (decoded_addr == CHIP_ID)
```

13. If the algorithm modeled by a VHDL *entity* or Verilog *module* can be generalized for arbitrary input and output bandwidths, then the ports may be declared with index ranges that are bounded by *generic* parameters for VHDL or use defined *parameter* for Verilog.

a. VHDL

```
entity interface is
```

```
generic (WIDTH : integer);
```

```
port (clk : in std_logic;
```

```
data_in : in std_logic_vector(WIDTH - 1 downto 0);
```

```
data_out : out std_logic_vector(WIDTH - 1 downto 0));
```

```
end interface;
```

b. Verilog

```
module interface (clk, data_in, data_out);
```

```
parameter WIDTH = 5;
```

```
input clk;
```

```
input [WIDTH - 1 : 0] data_in;
```

```
output [WIDTH - 1 : 0] data_out;
```

14. Ports should be listed in a specific order, alphabetized, and declared one port per line.

a. Inputs

i. Clocks alphabetized

ii. Resets alphabetized

- iii. Enables alphabetized
  - iv. Other control signals alphabetized
  - v. Data and address lines alphabetized
- b. Output
    - i. Clocks alphabetized
    - ii. Resets alphabetized
    - iii. Enables alphabetized
    - iv. Other control signals alphabetized
    - v. Data and address lines alphabetized
  - c. Bi-directional
    - i. Alphabetized ports

15. Always use explicit mapping for ports, and generics, using named association rather than positional association.

- a. VHDL
 

```
ram_addr => ram_addr;
data_in => data_in,
```
- b. Verilog
 

```
.ram_addr (ram_addr),
.data_in (data_in),
```

16. Consistent and well-defined indentation improves the visual understanding of a design's logic flow.

- a. Use indentation of 2 spaces.
- b. Avoid using tabs. Differences in editors and user setups make the positioning of tabs unpredictable and can corrupt the intended indentation.

## File Headers

A descriptive header should be written for every source file and script. Having a uniform header provides information about the file, and generates professional-looking code. This is especially important if the HDL code is going to be released to a customer. The header should include the following.

1. Company's copyright notification
2. Filename
3. Author
4. Date
5. Version number
6. Description of function
7. Modification history
  - a. Date
  - b. Modifier
    - i. Version number
    - ii. Modification description

## File Comments

One of the hardest tasks in designing is trying to reuse code from someone else. Why is this your manager wants to know? One reason is improper use of comments. Without the use of comments to describe the functionality it is sometimes impossible to figure out the contents of a program or module. The correct use of comments can help remove this problem and is useful for your own purposes.

1. Place comments logically near the code that they describe. Comments should be brief, concise, and explanatory.
2. Use comments appropriately to explain all process, functions, and declarations of types and subtypes.

```
--Create subtype INTEGER_256 for built-in error  
--checking of legal values
```

```
subtype INTEGER_256 is type integer range 0 to 255;
```

3. Use comments to explain ports, signals, and variables, or groups of signals or variables.

## Line Length

Have you ever looked at someone's code and had to keep scrolling to see the entire line? How annoying is that? Oh, lets not forget about those who like to have multiple commands on one line. These two habits make the code harder to read and maintain. Guidelines need to be established to prevent this from happening.

1. Use a separate line for each HDL statement.
2. For HDL code, use carriage returns to divide lines that exceed 72 characters and indent the next line to show that it is a continuation of the previous line.
3. Add blank lines when needed to improve readability. For example between input and output ports.

## VHDL- Entity, Architecture, and Configuration

VHDL gives you the flexibility to place entities, architectures and configurations in separate files. Splitting these up can make the code harder to read, understand, and maintain.

1. Place the entity, architecture, and configuration sections in the same file.

## Clock and Resets

The easier you can make your clocking scheme the happier you are going to be. A complicated clocking scheme makes everything more difficult: test insertion, writing constraints, static timing analysis, and simulations just to name a few. Here are some guidelines to consider.

### Mixed Clock Edges

If at all possible avoid using both positive and negative clock edges. Using both edges just makes life harder: design, functional simulations, writing timing constraints, DFT, and synthesis. If this can't be avoided, here are a couple of things to keep in mind.

1. Allow enough time in the schedule to thoroughly examine the timing using mixed clock edges.
2. For synthesis and timing analysis use the worst -case duty cycle.
3. Document the duty cycle.
4. Consider putting negative edge and positive edge flops into separate modules.

## Clock buffers

There is no need to worry about adding clock buffers during the initial design phase and synthesis. Adding clock buffers just adds fat to the code. Besides, clock buffers are normally taken care of during physical design and synthesis treats clocks as ideal nets.

1. Clocks are treated as ideal nets. Buffers are not needed.

## Gated clocks

Be careful using gated clocks. Improper timing of a gated clock can generate a glitch causing a flop to clock in the wrong data. In addition, testability can be limited because the logic clocked by the gated clock can't be made part of the scan chain. Here are some items to think about when using a gated clock.

1. Keep the gated clock generation in a separate module at the top level of the design.
2. Partition design so that all logic in a single module uses a single clock.
3. If possible add test circuitry to allow controllability of the gated clock.

## Internally generated clocks

Internally generated clocks can cause testability issues to rise. The reason is because the logic driven by the internally generated clock can't be made part of the scan chain. Writing timing constraints for generated clocks becomes more difficult as well. However in almost every design an internally generated clock is needed.

1. Add in test circuitry to bypass the internally generated clock. For example, if you have a divide-by-two, add in a mux to select a primary input clock over the internally generated one for test. The mux select line should be test\_mode signal coming from a primary input.
2. Autofix can be used during scan insertion to fix test violations for internally generated clock automatically. However for re-usable and test friendly code, go ahead and add the control yourself since the script enabling autofix may not be reused.

## Internally generated resets

Just like internally generated clocks, internally generated resets can cause test problems as well. But, I don't think I've seen a design that didn't require an internally generated reset so let's document a couple things to consider.

1. Add in test circuitry to bypass the internally generated reset.

2. Autofix can be used during synthesis to fix test violations for internally generated resets automatically.
3. If possible, have all registers in the macro be reset at the same time. By using this approach it makes analysis and design simpler and easier.
4. If a conditional reset is required, create a separate signal for the reset and isolate the reset logic into a separate module. This approach produces more readable code and improves synthesis results.

## Coding for Synthesis

When you start writing HDL think about the hardware you wish to produce. Draw a picture and sketch out a timing diagram so you'll know exactly what the hardware should look like when the HDL is synthesized.

1. When writing HDL code keep in mind the hardware intent.

## Sequential Logic

### Latches

1. If possible, avoid using latches in your design. Using latches can be more difficult to design correctly and to verify.
2. If latches are used, partition the logic in a separate module.
3. You can avoid inferred latches by using any of the following coding techniques. Assign default values at the beginning of a process
  - a. Assign outputs for all input conditions
  - b. Use *else* (instead of *elsif*) for the final priority branch
4. In VHDL, a latch is inferred during synthesis whenever an *if* statement satisfies all of the following conditions.
  - a. Conditional expressions are not completely specified
    - i. An *else* clause is omitted.
  - b. Objects conditionally assigned in an *if* statement are not assigned a value before this *if* statement.
  - c. The VHDL attribute *'event* is not present in the conditional if expression.

d. VHDL examples.

i. VHDL- latch inferred example

```
process (enable, data_in)
begin
    If enable = '1' then
        q <= data_in;
    end if;
end process;
```

ii. VHDL- latch avoidance example

```
process (enable, data_in)
begin
    If enable = '1' then
        data_out <= data_in;
    else
        data_out <= '0';
    end if;
end process;
```

5. In VHDL, latches are synthesized whenever a *case* statement satisfies all of the following conditions.

a. An expression is not assigned to a VHDL object (*signal* or *variable*) in every branch of *case* statement.

b. VHDL objects assigned an expression in any *case* branch are not assigned a value before the *case* statement is entered.

c. VHDL Examples.

i. VHDL- latch inferred example

```
process (data_in)
begin
    case data_in is
        when 0           => out_1 <= '1';
        when 1 | 3       => out_2 <= '1';
        when 4 to 7 | 2  => out_3 <= '1';
        when others      => out_4 <= '1';
    end case;
```

```
end process;
```

ii. VHDL- latch avoidance example

```
process (data_in)
begin
    out_1 <= '0';
    out_2 <= '0';
    out_3 <= '0';
    out_4 <= '0';

    case data_in is
        when 0           => out_1 <= '1';
        when 1 | 3       => out_2 <= '1';
        when 4 to 7 | 2  => out_3 <= '1';
        when others      => out_4 <= '1';
    end case;
end process;
```

6. In Verilog, latches are synthesized for a variable when all the following statements are true.
- Assignment to the variable occurs in at least one but not all of the branches of a Verilog control statement.
  - Assignment to the variable does not occur on a clock's edge.
  - Verilog Examples.

i. Verilog – latch inferred example

```
always @ (enable or data)
begin
    if (enable)
    begin
        Q= data;
    end
end
```

ii. Verilog – latch avoidance example

```
always @ (enable or ina or inb)
begin
    if (enable)
    begin
```



```

        data_out = ina;
    end
else
    begin
        data_out = inb;
    end
end
end

```

### iii. Verilog – latch inferred example

```

input [3:0] data_in;
always @ (data_in)
begin
    case (data_in)
        0           : out1 = 1'b1;
        1,3         : out2 = 1'b1;
        2,4,5,6,7   : out3 = 1'b1;
        default     : out  = 1'b1;
    endcase
end

```

### iv. Verilog – latch avoidance example

```

input [3:0] data_in;
always @ (data_in)
begin
    out1 = 1'b0;
    out2 = 1'b0;
    out3 = 1'b0;
    out4 = 1'b0;

    case (data_in)
        0           : out1 = 1'b1;
        1,3         : out2 = 1'b1;
        2,4,5,6,7   : out3 = 1'b1;
        default     : out  = 1'b1;
    endcase
end

```

## Flip-Flops

1. For VHDL, flip-flops are inferred when an *if* statement contains a *'event*, a *wait until* statement is used, or the function *rising\_edge* is used. Choose one and document it to produce uniform and professional looking code.

### a. VHDL- flip-flop inferred example

```

process (clock)
begin
    if (clock'event and clock = '1') then
        data_out <= data_in;
    end if;
end process;

```

2. For Verilog , flip-flops are inferred when edges occur in an event list of *posedge* clock or *negedge* clock.
3. For Verilog, non-blocking assignments should be used to model synchronous circuits.

a. Verilog – flip flop inferred example

```

always @ (posedge clock)
begin
    data_out <= data_in
end

```

## Synchronous vs. Asynchronous Reset

### Synchronous Reset

1. Is easy to synthesize.
2. Requires a free-running clock for reset to occur.
3. For VHDL, the synchronous reset does not have to be in the *process* sensitivity list.

a. VHDL- Flip Flop with synchronous Reset

```

process (clock)
begin
    if (clock'event and clock = '1') then
        if (reset_n = '0') then
            data_out <= '0';
        else
            data_out <= data_in;
        end if;
    end if;
end process;

```

b. Verilog- Flip Flop with synchronous Reset

```

always @ (posedge clock)
begin
    if (reset)
        data_out <= 1'b0;
    else
        data_out <= data_in;
end

```

### Asynchronous Reset

1. Does not require a free-running clock for a reset to occur
2. An asynchronous reset is harder to implement because it is a special signal like a clock. Usually, a tree of buffers is inserted at place and route.
3. Must be synchronously de-asserted in order to ensure that all flops exit the reset condition on the same clock. Otherwise, state machines can reset into invalid states.
4. For both VHDL and Verilog, the asynchronous signal must be in the *process* and *always* sensitivity list.

#### a. VHDL- Flip Flop with asynchronous Reset

```

process (clock, reset_n)
begin
    if (reset_n = '0') then
        data_out <= '0';
    elsif (clock'event and clock = '1') then
        data_out <= data_in;
    end if;
end process;

```

#### b. Verilog- Flip Flop with asynchronous Reset

```

always @ (posedge clock or negedge reset_n)
begin
    if (!reset)
        data_out <= 1'b0;
    else
        data_out <= data_in;
end

```

### Combinatorial Logic

1. For both VHDL and Verilog, envision the combinational circuit that will be synthesized.

2. For both VHDL and Verilog, avoid combinational feedback that is the looping of combinational processes.
3. For both VHDL and Verilog, when modeling purely combinational logic, ensure signals are assigned in every branch of conditional signal assignments.
4. For both VHDL and Verilog, ensure the sensitivity list of *process* statements in VHDL and the event list of *always* statements in Verilog are complete.
5. For VHDL, do not include the *after* clause in a signal assignment. This clutters the code and makes it harder to read.
  - a. VHDL – *after* clause used  
C <= a and b after 10ns;
  - b. VHDL – *after* clause removed  
C <= a and b;
6. For Verilog, do not include delays in assignment statements.
  - a. Verilog – Delay used  
assign #10 c = a & b;
  - b. Verilog – Delay not included  
assign c = a & b;
7. For Verilog, the *always* statement is supported by synthesis. The *initial* statement is not.

## Sensitivity Lists

1. Specify complete sensitivity lists in each of your *process* VHDL statements and Verilog *always* blocks. If you don't use a complete sensitivity list, the behavior of the pre-synthesis design may differ from the post-synthesis netlist.
2. For sequential blocks, the sensitivity list must include the clock signal that is read by the block. If the sequential block uses a reset signal, include the reset signal in the sensitivity list.
  - a. VHDL example  
seq\_example: process (clk)

```

begin
  if (clk'event and clk = '1') then
    a <= d;
  end if ;

```

b. Verilog example

```

always @ (posedge clk)
begin
  q <= d;
end

```

3. For combinational blocks, the sensitivity list must include every signal that is read by the process.

a. VHDL example

```

comb_ex: process (a, b)
begin
  if (b = '0') then
    sum <= a + 1;
  else
    sum <= a - 1;
  end if;
end process;

```

b. Verilog example

```

always @ (a or b)
begin
  if (b == 0)
    sum = a + 1;
  else
    sum = a - 1;
end

```

4. Verify that your process sensitivity lists contain only the necessary signals. Extra signals add fat to the code, makes the code harder to read, and can slow down simulations.

## Block vs. Non-blocking

1. Verilog only. Blocking assignments execute in sequential order, non-blocking assignments execute concurrently. When writing synthesizable code use non-

blocking assignments in *always @ (posedge clock)* blocks. Otherwise, the simulation behavior of the HDL and gate\_level designs may differ.

## Signal vs. variable

1. VHDL only. During simulations, signal assignments are scheduled for execution in the next simulation cycle. Variable assignments take effect immediately, and they take place in the order in which they appear in code. When writing synthesizable code, use signals instead of variables to ensure that the simulation behavior of the pre-synthesis design matches post-synthesis netlist.

## Case vs. if-then-else

1. For VHDL and Verilog, a *case* statement infers a single-level multiplexer while an *if-then-else* statement infers a priority-encoded, cascaded combination of multiplexers. A mux is a faster circuit. If the priority-encoding structure is not required use the *case* statement rather than *if-then-else* statement.
2. For VHDL and Verilog, for combinational logic from a *case* statement, ensure that either default outputs are assigned immediately before the *case* statement or that the outputs are always assigned regardless of which branch is taken through the *case* statement. This will avoid latches being inferred. The *others* in VHDL default *case* branch are optional to ensure all branch values are covered. The *default* in Verilog *case* branch is essential to ensure all branch values are covered and avoid inferring latches.
3. For VHDL, use *case* statements in preference to *if* statements containing *else-if* clauses where applicable for efficient synthesized circuits. The *if* statement operates on a priority encoded basis.

## Case sensitivity

1. Remember, Verilog is case sensitive while VHDL is not. So in Verilog "A" and "a" are different, while in VHDL they are treated as the same.

## Bus Widths

1. In Verilog you have the freedom of assigning signals of different width to each other. Therefore, be diligent to check this since Verilog compilers can't detect unintentional bit width mismatches. If widths do not match, either bits are chopped off or extra bits are filled with logic 0.

## Wait Until vs. If vs. Rising Edge

1. In VHDL, both the *'if'* and *'wait until'* statements will infer flops. The *'wait'* statement delays the execution of the whole process until its expression becomes true. This means that all other signal assignments in the process will infer one or more flops depending on the signal's bit width. The *'if'* statement does not stop the execution of the whole process so it does not prohibit separate purely combinational logic from also being modeled in the same process. For this reason the *'if'* statement is preferred over the *'wait'* statement. In addition, using the *'if'* statement provides greater control over the inferred registers.

- a. VHDL Example

```
wait until (clock'event and clock = '1');
```

```
if (clock'event and clock = '1') then
```

2. In VHDL, if you are using the IEEE *std\_logic\_1164* package, you can use the functions *rising\_edge* and *falling\_edge* to infer a flip-flop. The use of function calls can simplify a model slightly especially if you're using multi-valued data types, like for example *std\_logic*, that has nine possible values, (U, X, 0, 1, Z, W, L, H, -). The reason the model is simplified is that in order to detect a rising edge (logic 0 to 1 transition) for a signal type of *std\_logic*, it is necessary to ensure transitions like X to 1 are not detected.

- a. VHDL Example

```
Clock is of type std_logic.
```

```
-- Attribute 'event detects X to 0 and X to 1 transitions  
if (clock'event and clock = '1') then          -- Detects X to 1 transition
```

```
-- Detects only logic 0 to logic 1 transition  
if rising_edge(clock) then
```

## Partitioning for synthesis

I bet you're already partitioning your design and may not know it. Lets say you're getting ready for a design review. You start drawing block diagrams. You may have a top-level block showing all the I/O and inside the top-level block smaller blocks. These smaller blocks may represent design functions for example an interface to a processor, a clock generation block, or an encoding block. This is great for a design reviews. Each sub-block might represent a particular design requirement. As you start describing each block, the requirements as you have interpreted them are presented and perhaps modified. Most reviewers like this methodology because they are only interested in

knowing that you understand the requirements and how are you going to meet the requirements.

However, for synthesis, you might need to combine or break up these smaller blocks. This combining or breaking up of blocks is what I'm calling partitioning for synthesis.

Correct design partitioning can enhance the synthesis results, reduce compile time, and simplify the constraint and script files. Partitioning affects block size. If you make blocks too small, you can create artificial boundaries that restrict effective optimization. If you create very large blocks, compile runtimes can be lengthy. The following sections cover guidelines to help improve optimization and runtimes.

## Design Reuse

If you know some of your design may need to be reused consider the following items when you start partitioning the design.

1. Thoroughly define and document the design interface.
2. Standardize interfaces whenever possible.
3. Parameterize the HDL code.

## Related Combinatorial Logic

By default, Design Compiler can't move logic across hierarchical boundaries during compile. So if you separate related logic into different blocks you'll create artificial barriers that restrict logic optimization. By keeping related logic together Design Compiler will have more flexibility in optimizing the design. Follow these suggestions when partitioning your combinatorial logic.

1. Group related combinational logic and its destination register together.
2. Eliminate glue logic.

## Register Block Outputs

Take the time to think about the outputs of each of your blocks. If an output can't be registered consider moving the logic into the block so that it can be registered. Registering the output signals from each block simplifies the synthesis process.

1. For each block of a hierarchical design, register all output signals from the block.



## Design goals

If at all possible, separate modules that have different design goals (speed, area, etc). By doing so, Design Compiler can optimize critical path's logic for speed, while optimizing the non-critical path for logic area.

1. Keep critical path logic in a separate module from non-critical path logic.

## Sharable Resources

Design compiler has the capability to share resources. To take advantage of this feature, consider the following.

1. Place sharable resources in the same block. Design Compiler can share these resources but only if the resources belong to the same VHDL *process* or Verilog *always* block.

## Isolating Special Functions

Try to isolate different function like I/O pads, asynchronous logic, and clock generation circuitry. Isolation of the clock generation circuitry enables instantiation and careful simulation of this module. Isolation of the asynchronous logic helps confine testability problems and static timing analysis problems to a small area.

1. Isolate special functions (such as I/O pads, clock generation circuitry, boundary-scan logic, and asynchronous logic) from the core logic.

## LEDA

The program has decided to use LEDA. Now what! The first step is to get a copy of the LEDA user manual. This manual spells out in detail how to use LEDA. In this paper, I'll briefly describe what LEDA is, how does it work, and guidelines.

### What is LEDA?

The LEDA tool is a programmable HDL checker that verifies that HDL code complies with design rule and coding-style guidelines. By using the tool you can quickly verify that the team has followed all the guidelines you've put into place.

LEDA consists of two separate tools: Specifier and Checker. The Specifier tool is used to program/compile rules and exports policies to configure checkers. The checker tool is used to verify code against different policies and generate error reports.

## How does LEDA Work?

There are three types of rules in LEDA: language based, hardware based, and chip-level rules. The Language-based rules constrain different HDL constructs by ensuring that they correspond to acceptable values, ranges, or templates.

The hardware-based rules control the hardware semantics of VHDL and Verilog. Using hardware-based rules, you can check for the proper use of clocks, and inferred hardware such as latches, flip-flops, and finite state machines.

The chip-level rules work on the entire design hierarchy. For chip-level rules to work, you must specify a top module in the design hierarchy. You can write chip-level rules using templates (design, connectivity, test signal, and etc.).

Once you have programmed a set of rules, the LEDA Specifier compiles the rule source code into an object format readable by the LEDA Checker. The Checker then compares the input HDL code to the rules contained within the object files and outputs error messages depending on whether the comparisons pass or fail.

## LEDA Guidelines

### Getting Started

1. There are three flows available for using LEDA. Determine which flow best suits your team needs.
  - a. Configure the prepackage rules to meet all your needs.
  - b. Find a prepackage rule that is close to your needs. Copy the rules and modify them.
  - c. Write all new rules because none of the prepackage rules meet your needs.
2. Now that the flow has been selected you need to read in the design. For a VHDL design, you can specify the location of the design files and the checker will automatically figure out design dependencies and read the files in the right order. For a Verilog design, you can use your simulation setup file with some very minor changes.
3. If you need to modify the rules, the LEDA checkers include a rule-configuration wizard to aid in selecting and configuring the different rules you want to check. By using the GUI, you can turn rules on/off, set the severity-level, and configure different rule-parameters.

4. Before you can use LEDA to test your HDL source code against the prepackaged rules or new rules that you built, you must first create a project file. A project file organizes your VHDL or Verilog source files into easily managed units.
5. To execute the checker, all you have to do is click of a button in the GUI, or use a single command in the command-line.
6. After the checker is done you'll get a list of violations. Decide how you want to review the violations by complete design or individual units in the design. Once you have isolated the list of violations that you intend to work on, the checker's cross-linked browser will enable you to easily jump from error to the Verilog/VHDL code causing the violation or from the code back to the error.

### General Guidelines

1. VHDL code must respect one of two standards: VHDL 87 or VHDL 93.
2. For both VHDL and Verilog, make sure you can analyze or compile the code.
3. For mixed-language designs make sure to resolve naming issues, since VHDL is not case-sensitive and Verilog is case-sensitive. For example,
  - a. VHDL stores identifiers in upper case.
  - b. Verilog stores identifiers exactly as they appear in the source code, regardless of case.
4. You can instantiate a Verilog module inside a VHDL architecture using a component instantiation statement.
5. You can instantiate a VHDL entity, VHDL design entity, or VHDL configuration in a Verilog module using a module instantiation statement.
6. LEDA supports Verilog 2001 constructs. See the user guide for the constructs supported.
7. Be aware of the naming conventions for rule sets for VHDL and Verilog. Rule sets are stored as ASCII text in ruleset.rl files for VHDL or ruleset.sl files for Verilog.