# **TLL5000 Electronic System Design Base Module**

The Learning Labs, Inc. Copyright © 2007

Manual Revision 2007.12.28

#### Copyright Notice

The Learning Labs, Inc. ("TLL")
All rights reserved, 2007
Reproduction in any form without permission is prohibited.

#### Disclaimer

Information in this document is subject to change without notice and does not represent a commitment on the part of TLL.

TLL provides this document as is, without warranty of any kind, expressed or implied, including but not limited to the warranty of merchantability or fitness for a particular purpose. TLL may make improvements and/or changes in this manual or in the products(s) and/or the program(s) described in this manual at any time.

Information in this manual is intended to be accurate and reliable. However, TLL assumes no responsibility for its use, or for any infringements of rights of other parties, which may result from its use.

This document could include technical or typographical errors. Changes are periodically made to the information herein; these changes may be incorporated in new editions of the publication. This manual is provided solely and exclusively for educational use and this information or related products should not be used nor relied upon for any purpose except for education and training.

### Technical Support

Please contact your local TLL authorized product representative for questions regarding hardware, software, or applications issues. Any updates or patches will be sent to you as long as your registration is current. The TLL products are designed to be supported remotely by allowing viewing of the user desktop. It is highly recommended that the PC from which you are using TLL products is connected to an Internet link that allows Web browser access. In this way our technical support staff can view your desktop and work with you to understand and solve technical issues.

### **Table of Contents**

Chapter 1	4
Prerequisites	4
System Requirements	4
SOFTWARE REQUIREMENTS	4
HARDWARE REQUIREMENTS	4
CHAPTER 2	6
SETTING UP TLL5000 BASE MODULE	6
Power ON and TLL5000 Configuration using Hardware Manage	R.EXE7
SETUP FOR XILINX PLATFORM CABLE & TLL5000 BASE MODULE:	11
TLL5000 Interfaces and Peripherals	13
Chapter 3	14
DIGITAL DESIGN USING XILINX ISE	14
FUNCTIONAL TEST ON THE TLL5000	39
Chapter 4	4C
DIGITAL DESIGN USING VHDL	40
BEHAVIORAL SIMULATION OF THE DESIGN	48
SYNTHESIS OF THE DESIGN	53
IMPLEMENTATION OF THE DESIGN	54
Programming TLL5000	58
FUNCTIONAL TEST ON THE TLL 5000	63

## **Chapter 1**

# **Prerequisites**

## **System Requirements**

The following are the prerequisites for a computer to run the required software tools for doing basic digital designs on the TLL5000. Make sure that these components and minimum hardware are present.

- Personal Computer: Pentium 1 GHz or higher -- Although lower processors will run the software tools, the desired results are not guaranteed.
- 512MB RAM for average applications, larger designs a 1GB RAM or greater is useful.
- Minimum 5-GB on Hard Disk The Webpack ISE requires around 3.5 GB for all its components.
- SVGA Monitor with the resolution of 1024x768 -- Monitor resolutions has been kept at 1024x768, which is ideal.
- Windows 2000 or XP operating system with ServicePack-4 (for Windows 2000) & ServicePack-2 (for WinXP)
- Three USB2.0 ports
- One RS232 serial port
- Ethernet Network Interface Card (NIC) The network interface card should have been configured on your system. Make sure that you have configured the network card with a static IP address.

## Software requirements

The following software needs to be installed in the PC used for connecting to the TLL5000 Base Module.

- Xilinx Webpack ISE 9.x (our limited experience is that the Xilinx ISE version 8.x should also work, but we recommend that you use version 9.x). If you are using the previous versions of ISE, please update with the service packs for getting the drivers for the Xilinx Programming Cable. This tool is provided with, ISE simulator, XST synthesizer, PAR and downloads (iMPACT) applications.
- ModelSim-XE the Simulation software for behavioral simulation. One should also be able to do
  these exercises using the full ModelSim software from Mentor Graphics but there will be
  differences in methods and commands that this manual does not address.

## Hardware requirements

- The following items are required to start using the system.
- TLL5000 Base Module.
- Power supply for TLL5000 (18volts / 3.5 Amps)
- USB cables 2 Nos.
- Xilinx Platform Programming Cable newer versions use an USB interface, but parallel cables will also work.
- CDs with, User Documentations and Software.

The CDs provided with the TLL5000 will typically contain the following items. Please consult with your local TLL product partner for specific details as your configuration may be different from this table.

CD	Directory	Description	Remarks
1	TLL User Software and Manuals	Various application utilities and associated software and hardware manuals for the TLL5000.	Please check with your local TLL partner to verify that the manuals and software are the most current versions.
2	Web downloadable software tools	As a convenience for the user, this CD has the freely downloadable FPGA software from the Xilinx Website. The registration is done online by the user.	These tools will have a license duration determined by Xilinx and they will provide updates through their standard update mechanisms.

**Note1**: The installation of Xilinx tools are self guided. Click on the Setup.exe in the directory and the installation starts.

**Note2**: Choose the option of <u>cable drivers</u> during the installation of Webpack ISE. If these drivers are not chosen then the drivers for <u>Platform cable – USB</u> will not be installed in the System.

## Chapter 2

# **Setting up TLL5000 Base Module**

The following picture shows the connections to be made between the PC and TLL5000 Base Module. Please strictly follow the steps as per the manual to avoid any problems to the hardware. The wrong sequence of applying power and connection sequence can cause damage to the system.




Figure 2-1 TLL5000 platform setup.

# Power ON and TLL5000 Configuration using Hardware Manager

- Connect the power supply to the power supply connector **CON100**.
- Connect the USB cable1 between PC-USB port & CON801. This connection is used for communication and configuration of the TLL5000 from the PC using the TLL software provided with your system.
- Switch ON the power supply on the TLL5000 with POWER ON/OFF Switch.
- As the power is switched ON, the LEDs near the power connector will turn ON.
- Now use the TLL5000 Hardware Manager utility (typically included as a menu selection in the TLL Design Center software, please consult your local TLL partner for specific directions) to configure. This will bring up the following screen on the monitor.




Figure 2-2
Hardware Manager.

1. Click on the Choose device option in the step-5 screen, options will be displayed as shown below:




Figure 2-3
Selection of target platform.

In the options above we shall see "TLL5000 Development Board". This option will be enabled only by connecting USB cable between TLL5000 base module and PC.

appears on PC. **Ⅲ** TLL5000 - Monitor/Controler Board ID Connected Power Ethernet [ON] LL-5000 Development Board Board IP 192 . 168 . 0 . 0 Address Read C Write O Write 0x00000000 0x00000000 Read 0x00 Scan chain O Ok 1 C Write © Cik 2 100.0000 MHz Accessory Port Clk 1 100,0000 MHz (Divider Bypassed) Divider Bypassed Accessory Port Clk 2 100.0000 MHz (Divider Bypassed) 6 Divider Bypassed LVPECL Mezzanine A. 100.0000 MHz (Divider Bypassed) 🔻 Divider Bypassed 0.0 LVPECL Mezzanine B 100.0000 MHz (Divider Bypassed) V Divider Bypassed C 6 Mezzanine B 100.0000 MHz (Divider Bypassed) Divider Bypassed 6 C Mezzanine A 100.0000 MHz (Divider Bypassed) 6 FPGA 100.0000 MHz (Divider Bypassed). Divider Bypassed CPLD 33.3333 MHz (Divider 3) Status information

2. Now click on the "TLL5000 Development Board" option in Step-6. The following screen

Figure 2-4 Checking platform status.

Board Powered Down

- At this stage the screen displays the status as "Board Powered Down" (see the Status information marked in blue in the above screen). This means the platform is not powered up. Once the "Power ON" button is clicked then the platform will get powered up.
- The power supplies for the various TLL5000 elements (FPGA, memories, peripherals, etc) are started by clicking on POWER (marked in the red color) in the above screen. Now the power supply is enabled for all the parts of the board and the screen is shown as below.

3. The above screen provides monitoring of the TLL5000 onboard power supplies and configuration of the various user-settable parameters such as the system clocks shown in the lower tables. For example, the expected voltages and the actual voltages will be displayed in the "Power Values Monitor" section in the upper left of the display screen.




Figure 2-5
Platform power up.

10

# Setup for Xilinx Platform Cable & TLL5000 Base Module:

**Note:** Before connecting the Xilinx Platform Programming Cable from the PC to the target TLL5000, it is required to complete all the steps of **TLL5000 Power ON and Configuration using the TLL5000 Hardware Manager** as explained in the above section.

 When the Xilinx Platform Programming Cable is plugged into the system, the hardware is identified. This can be verified by right clicking on
 My Computer → Properties → Hardware → Device Manager → Programming cables.




Figure 2-6
Checking status of the platform USB cable.

Now observe the color of the status LED on the <u>Platform cable – USB</u> box. It will be **orange**.
The status will remain orange till the other end of <u>Platform cable – USB</u> (a 14-pin Flat ribbon connector) is connected to the TLL5000.




Figure 2-7
Checking status checking.

 Now connect the Xilinx Platform Programming Cable to the JTAG 14-pin FRC connector labeled CON1 on the lower right of the TLL5000 (this is non-reversible connector with a notch on the connector long side). Please refer to the following diagram for connections.



CON1

Figure 2-8
TLL5000 platform JTAG connector.

 When the Xilinx Platform Programming Cable is connected to the TLL5000 the status LED of the Platform Programming Cable will turn GREEN indicating that the JTAG communication is successful with target board.

**Note:** If the **TLL5000 Power ON and Configuration using the TLL5000 Hardware Manager** are not followed, then the reference voltage for JTAG will not be available on CON1 of TLL5000 and the status LED will remain <u>ORANGE</u>. Until the status LED turns GREEN, the bit file cannot be downloaded onto the target Platform.

# **TLL5000 Interfaces and Peripherals**




Figure 2-9
Various interfaces in TLL5000.

## **Chapter 3**

# Digital Design using Xilinx ISE

In this section we will introduce the steps needed to create a digital design with the schematic entry method of circuit design. Schematic entry is often a starting step in learning digital design prior to the Hardware Description Language approach to digital design, but can also be used concurrently with HDL approaches when a block diagram or circuit view is the most natural method of specifying the design. Now let us start with a basic design.

1. Run the ISE application by double clicking on the shortcut icon for the ISE tool or selecting it from your Programs menu.



Figure 3-1 Invoking Xilinx ISE.

2. When the tool is invoked the following windows will appear in the ISE tool.




Figure 3-2 XILINX welcome screen.

3. Now a new project has to be created. To create a new project, click on the "File" menu and select "New Project" option.





Figure 3-3
Creating a new project.

4. When the new project option is selected the following window is seen. In this window type a project name "buffer\_sch" and specify a location. Select "Schematic" as the Top-Level Source Type. And click "Next".



**Figure 3-4** *Entering the project name.* 

5. After these inputs the tool will go to the next window. Here select the target device and the tools that will be used in developing the design. Then click "Next".




Figure 3-5
Selecting of a device.

6. In the next window, click on "New Source" tab. In the "New Source Wizard" window give the file name and select the input file type as schematic.




Figure 3-6
Selecting a source type.

7. When the "Next" button is clicked, the "New Source Wizard" summary window will be seen. Click on "Finish" here.




Figure 3-7
Completing the new source wizard.

8. In the next window click "Yes", to create the new project directory.




Figure 3-8
Confirming the project creation.

9. Then click on "Next" in the "New Project Wizard".




Figure 3-9
Creating a project.

10. Again click on "Next" button on the "Add Existing Sources" window, since at this point of time there are no existing source designs.




Figure 3-10
Adding an existing file.

11. Click "Finish" on the "Project Summary" window, to create the project, or click "Back" to go back and make some changes, if any.




Figure 3-12 Viewing the project summary.

12. Once the finish button is clicked, the project is created and the design summary is also given in the ISE tool window, as shown below. And click on the file name tab to edit the file, as shown in the red circle on the figure.




Figure 3-13
Viewing project summary in HTML format.

13. Click on the "Float Window" button to get a better view of the schematic editor. This is the same as an undocking feature.



Figure 3-14
Undocking the window.

14. Once the schematic editor is undocked, i.e. the window is floated, the following window can be observed.




Figure 3-15
Selecting the components.

In this window click on "Symbols" tab in order to get the various components under different component categories, in the left side of the window.

15. From the "Categories" tab in left side of the window, select "buffer" and select the desired symbol from the "Symbols" tab and place in the editor window, as shown in the figure. The editor can be zoomed in / out as per the requirement. Notice the grid positions as guides to drawing a neat layout.




Figure 3-16
Placing the components.

16. After placing the components, the wire has to be connected. To connect the wires right click in the editor, select "Add" select "Wire".




Figure 3-17
Adding wires to the components.

17. Now as shown in the below given figure, add the wires to the components, in the editor window.




Figure 3-18 Placing wires.

18. After adding wires to the components, the IO markers are to be added to the wires, which should be used for applying the inputs and monitoring the outputs. To add IO markers again right click in the schematic editor, select "Add" and select "I/O Marker".




Figure 3-19
Adding I/O marker.

19. Place the IO markers as shown in the figure. While placing the input marker select "Add an input maker" and for the output marker "Add an output marker" in the options window on the left hand side of the window.




Figure 3-20 Renaming I/O markers.

20. To edit the object properties of the IO markers, in the name field delete the existing name and give the desired name, and click "OK".




Figure 3-21
Renaming the markers.

21. Repeat the same for all the ports. Save the schematic. Next perform a "Check Schematic" function has to be done. This same as check syntax process, in the text based design entries.




Figure 3-22 Checking the schematic.

22. Observe the "No error or warning is detected" message in the console window as shown below.




Figure 3-23
Observing console window.

23. Then dock the floating window by clicking on the "Dock Window" button.




Figure 3-24
Docking the window.

24. Then click on the "Sources" & "Process" tabs in the ISE tool window. Select the option as "Behavioral Simulation" in the "Sources for" window.




Figure 3-25
Selecting the simulation option.

25. By selecting the input file name in the "Sources for" window, expand the "ModelSim Simulator" window from the "Process for" window and run the process called "Simulate Behavioral Model". This will invoke the simulator that we use to simulate the design. Here ModelSim XE 6.2c is the simulator used.




Figure 3-26 Forcing the input signals.

26. Force the selected input signals with the desired values, and click on "OK".




Figure 3-27
Docking the window.

26

27. Then click on "Run" button, in order to view the simulated results.




Figure 3-28
Run simulation.

28. The simulated results can be seen in the wave form window. The vertical yellow bar is the cursor. Wherever the cursor is placed, the corresponding values will be displayed in the wave window, as marked in the below shown figure. Different inputs can be applied and the output can be viewed accordingly. Once the satisfied output is got the simulator may be quitted.




Figure 3-29 Viewing the simulated output.

- 29. The next step in the FPGA design flow is to synthesize the design. Synthesis is the process that generates the equivalent gate level netlist for the input design file. The netlist is a text based file that contains the details of the devices and the interconnection network that are used in the design.
- 30. In order to run the synthesize process, select "Synthesis/Implementation" option in the "Source for" tab, and right click on the "Synthesize XST" process, in "Process for" window and select "Run" from the pop-up menu. Once the synthesis is completed, expand the synthesis process to view the synthesis report, RTL Schematic & Technology view of the given design.

31. The above processes are shown below.




Figure 3-30 Synthesizing the design.

32. The next process is the implementation process. This process has three major steps under it. They are (a) Translate, (b) Map and (c) Place And Route.

#### **Translate:**

Translate is the process that merges all the input files and the constraint file into a single netlist.

#### Map:

Map is the process that maps the logical components to the physical components. Logical components are the ones which are there that according to the circuit diagram. And, the physical components are the ones that are physically present inside the FPGA.

#### Place And Route (PAR):

The map output file will be taken as the input file for the PAR process. The map file will contain how many CLBs & IOBs are required to implement the design. And also it will have the details of which are the CLBs & IOBs that are used in the design implementation. Based on that information, those particular CLBs and IOBs will be configured. This process is called as placing, and the routing is the process which makes the interconnection CLBs and/or IOBs.

33. Before going to the process of implementation, it is necessary to write the user constraints (ucf) file. This is the file where the designer can give the constraints for the design to be implemented.

Xilinx - ISE - F:\Menporul\Xilinx91\baru\_designs91\buffe 🔀 File Edit View Project Source Process Add Tools New Source... Add Source... abc Add Copy of Source... Sources for: Synthesis Cleanup Project Files - 🛅 buffer\_sch Toggle Paths 🖮 🎆 xc3s1500-4fg6 Archive... ····· 🗗 🛗 buffer\_s Take Snapshot... Make Snapshot Current Apply Project Properties... Source Control

34. To enter an ucf file, click on "Project" menu and select "New Source" option.

Ш

Figure 3-31
Creating a new source for constraints file.

35. Once the new source is selected, the "New Source Wizard" window gets opened. Here, enter the file name and select the input file type as "Implementation Constraints File" and click on "Next".




Figure 3-32 Synthesizing the design.

36. When the next button is clicked, the "Associate Source" window gets opened. Here select the appropriate entity/file name. If only one file is added to the project, then by default the same is selected. If more than one number files are there, only then we need to select the file/entity name.

37. Select the file (entity) name and click on "Next". Mew Source Wizard - Associate Source




Figure 3-33 Selecting an associated source.

38. Then again click on the "Finish" button. If any changes are to be made, click on "Back" and make the required changes.





Figure 3-34 File summary.

39. When this is completed, the ucf file is created and added to the project. To check this click on the + sign beside the input file name in the "Sources for" window. In this example design, the pin constraints will be in the ucf.



**Figure 3-35** *Assigning pin numbers.* 

- 40. To give the pin constraints, select the ucf file and expand the "User Constraints" in the "Process for" window, and run the process "Assign Package Pins". This will invoke another XILINX built in tool called PACE (Pinout Area Constraint Editor).
- 41. Enter the pin numbers, where the inputs and the outputs are supposed to be connected. The details of these pin numbers, may be found in the user manual.
- 42. After entering the pin numbers, the save the file and PACE tool may be exited.
- 43. Then again select the design file in the "Sources for" window.

44. The next step is to run the implementation process. So, right click on the "Implement Design" process and select "Run" from the pop-up menu.




Figure 3-36
Implementing design.

- 45. During the project design of a digital system each process can be found in some of the following states
- Running the process is in the running phase.
- Up-to-date Process is successfully executed without mistakes or warnings. If the rapport is in this condition it means that it's up to date although it could happen that the tasks covered with this process have mistakes and warnings.
- Warnings reported the process is successfully executed but there are warnings.
- Errors reported the process is finished with at least one error.
- Out-of-Date signifies that there have been made some changes and that the process needs to be done again.

No icon – In the case of, there is no any of these icons the process hasn't been started.

46. After the design implementation process is complete, the programming file needs to be created to download into the FPGA to correctly configure it. To generate the programming file, run the process called "Generate Programming File" from the "Process for" window.




Figure 3-37
Generating bit file.

This process will generate the programming file. i.e., the bit stream file will be generated. This is the file that will be downloaded onto the FPGA.

Once the file is generated, the next step is to make the communication between the host system and the target TLL5000.

47. Before starting this process, "Power ON" the board as given previously. To make the communication, expand the "Generate Programming File" process and select the "Configure Device (iMPACT) process.




Figure 3-38
Configuring the target device.

48. Before running the process "Generate Programming File" right click on "Generate Programming File" and select "Properties". In the properties window, select the "start up Options" and set the value as "JTAG Clock" in order to avoid the warning messages in the future.

iMPACT - Welcome to iMPACT

Please select an action from the list below

© Configure devices using Boundary-Scan (JTAG)

Automatically connect to a cable and identify Boundary-Scan chain

© Prepare a PROM File

© Prepare a System ACE File

© Prepare a Boundary-Scan File

SVF

© Configure devices

Using Slave Serial mode

C Back

Finish

C Cancel

49. This opens another software tool called iMPACT. Click on "Finish" button, in this window.

Figure 3-39

Checking for boundary scan devices.

50. This process detects three different devices that are present on TLL5000 target. The "xcf32p" is the flash device, "xc9572" is the CPLD device and "xc3s1500" is the FPGA device.




Figure 3-40 Selecting the target device.

51. The "Assign New Configuration File" is place where the programming file will be browsed to the location and selected, by clicking on the "Open" button. But, here DO NOT!! Select or configure the flash device and the CPLD. So, click on the "Bypass" button to bypass these components. And finally when the FPGA is highlighted, select the generated bit file, and click "Open".




Figure 3-41
Selecting the bit file.

52. After completing this process, the bit file will be selected for the FPGA, to be programmed.




Figure 3-42
Selecting the bit file.

53. Now right click on the FPGA, and select "Program" from the pop-up menu.




Figure 3-43
Programming the device.

54. In the "Programming Properties" window, just click on "OK". Programming Properties × Category 🖮 Programming Properties **Programming Properties** Advanced PROM Programming Properties General Programming Properties Revision Properties General CPLD And PROM Properties □ Erase Before Programming □ Read Protect PROM/CoolRunner-II Usercode (8 Hex Digits) CPLD Specific Properties— XPLA UES Enter up to 13 characters PROM Specific Properties-☐ Load FPGA ☐ Parallel Mode ☐ Use D4 for CF FPGA Device Specific Programming Properties ☐ Pulse PROG ☐ Program Key Spartan3AN Programming Properties ☐ Data Protect ☐ Data Lockdown Cancel Help Apply

Figure 3-44 Programming the device.

55. The program status can be observed by the viewing the "Progress Dialog" box.




Figure 3-45
Downloading the file.

56. Once the device is program is downloaded, the "Program Succeeded" message appears.




Figure 3-46 Viewing status message.

## **Functional Test on the TLL5000**

The design downloaded onto the TLL5000 is tested for correct functionality with the use of switches and LEDs available on the target TLL5000.




Figure 3-47
Observing the outputs.

As the switches are toggled to ON/OFF positions, if the design is functioning correctly then the corresponding output LEDs will turn ON/OFF to match the switch positions.

## **Chapter 4**

# **Digital Design Using VHDL**

1. To invoke the ISE 9.1 tool, double click on the below shown icon, on your desktop.



Figure 4-1
Invoking XILINX tool.

2. Once the tool is invoked the below shown window will open.




Figure 4-2
Tool welcome screen.

3. To start a new project, click on "File" tab and select "New Project". The same is shown in the below figure 4-3.




Figure 4-3
Creating new project.

4. When "New Project" is selected a new window is opened as shown in the figure. In the "Project Name" field enter the desired project name. Now, it can be observed that a folder is created with the same name in the "Project Location" field. This is for keeping track of all the input & output files in the same location.




Figure 4-4
Entering project name.

5. Let the "Top-Level Source Type" be as HDL itself. After giving the necessary inputs and clicking on "Next" the next window appears. This is the place where the target hardware & necessary tools are selected. Key in the inputs as per the requirements. Then click on "Next".




Figure 4-5
Selecting target hardware.

**Note 1**: The Simulator Chosen – ModelSim—XE, Synthesis Tool – XST (this is the built-in Webpack ISE)

**Note 2**: The device, Package and speed are chosen based on the details of an FPGA chip on the TLL5000.

### XC3S1500-4fq676

- **XC** Xilinx Component.
- **3S** Device Family, in this example, it is Spartan 3 Family.
- **1500** Device Gate density. As per this example, 1500 kilo gates are present in this chip.
- **-4** Speed Grade.
- **FG** Package type. Fine-pitch Ball Grid Array.
- **676** Number of I/Os on the chip.

Creating a new source to add to the project is optional. Only one new source can be created with the New Project Wizard.

Additional sources can be created and added to the project by using the "Project->New Source" command.

Existing sources can be added on the next page.

6. To create a new source, click on the "New Source" button.

Figure 4-6 Creating new source file.

7. When the "new source" button is clicked give a file name for the input source code, and select the file type, from the left hand side list. In this example it is a VHDL module.




Figure 4-7
Selecting file type.

8. After giving the file name & file type, the input and output port list of the design has to be given. Port list is the top level entity of the design. After giving the port names the directions of the ports can also be entered as per the design requirement. If the port is a type of bus, that can also be entered, along with the number of bits specifying the width of the bus.




Figure 4-8
Enter the port list.

**Note:** The Port names to be entered in the above window shall also be 1 bit for typical logical gate implementations. In the above design we have taken an input port of 8-bits (0 to 7) & output port of 8-bits (0 to 7).

9. After giving those details, click on "Next" & "Finish".




Figure 4-9
File summary.

10. After clicking on Next, the tool will ask for the confirmation of creating a new folder. Simply "Yes" can be clicked. This will create a folder named as the project name, in the specified location. And based on the information that is given, a skeleton of the VHDL file is created which will have all the declaration parts of the file. This is common for all the VHDL files.




Figure 4-10 Creating project directory.

11. Click on "Next" in this window.




Figure 4-11
Creating new source.

12. Since a new project is being created, it is not required to add any existing source at this point of time. So, click on "Next".




Figure 4-12
Adding existing file (if any).

🔤 New Project Wizard - Project Sur Project Navigator will create a new project with the following specifications Project: Project Name: test\_project Project Path: F:\menporul\Xilinx91\test\_project Top Level Source Type: HDL Device Family: Spartan3 Device: xc3s1500 Package: fg676 Speed: -4 Synthesis Tool: XST (VHDL/Verilog) Simulator: Modelsim-SE VHDL Preferred Language: VHDL Enhanced Design Summary: enabled ▼| Message Filtering: disabled

< Back

Finish

13. The summary is created based on the information that is given so far. Now click on "Finish".

Figure 4-13

Viewing project summary.

14. Figure 4-14 shows the VHDL file for, the given design. Normally, whenever the file is generated it will contain the library declaration, port declaration & architecture declaration. Only the functionality of the design has to be entered by the designer. This simplifies the job of the designer and time is also saved.

Cancel




Figure 4-14
Tool generated VHDL file.

In the above window the IEEE libraries are included by default, the design  $b \le a$ ; is entered by the user. This code will act as a buffer where the value of a is loaded to b (all the 8-bits).

15. As per the design flow, after design entry the 1<sup>st</sup> step is to simulate. So to simulate, the simulation option has to be selected. The steps for selecting it, is shown in figure 4-15.

### **Behavioral Simulation of the Design**

16. When the design is ready, choose the Behavioral Simulation option (This option is available on your top left hand corner of your ISE – near <u>Sources for</u>)




Figure 4-15
Selecting simulate operation.

17. Then select the VHDL file in the source for window and run the "Simulate Behavioral Model Function". To run any process, select the appropriate process and press enter or double click the process or right click on the process and select run option from the pop up menu.





Figure 4-16 Simulating the design.

18. The simulator used here is ModelSim-XE from Xilinx. Once the process is started, the simulator tool is invoked. The simulator main window and the wave window are opened. As, shown in the below figure.



**Figure 4-17** *Compiling and simulating.* 

19. Now maximize the wave window and right click on the input signal and select "Force" from the pop-up menu.




Figure 4-18
Selecting Force option.

20. When in the "Force Selected Signal" enter the desired value for the input signal(s) and click "OK".




Figure 4-19
Forcing the input signals.

21. After forcing the input signal, click on the run button. The shortcut to the run button is encircled in red color in the below shown figure.




Figure 4-20 Run simulation.

22. Once the simulation is run the output for the given input can be observed in the wave window. This is known as functional simulation in which only the software code is simulated prior to the design being implemented directly on the hardware.




Figure 4-21 Viewing the simulated waveform.

# Synthesis of the Design

23. The next step after simulation is to synthesize the design. Synthesis is the process which will generate the gate level netlist of the design. In order to run the synthesis process the selection has to be changed as "Synthesis/Implementation" in the sources for window. This netlist output file will be the input file for the implementation process.




Figure 4-22
Selecting synthesis option.

The progress of the Synthesis process will be shown in the console of the ISE (Left-down corner). In case of any errors, the details of the errors will be displayed. With any type of error, the design will not proceed to the Implementation stage. The synthesis generates the synthesis report, RTL schematic, Technology Schematics. The user should verify these reports in order to understand the actual logical circuitry that will be configured in the FPGA.

# Implementation of the Design

24. The implementation process has three different sub-processes in it. They are Translate, Map, and the third is Place & Route.

#### Translate:

This is the process that merges all the input files and the constraint file into a single netlist.

### Мар:

The process of mapping the logical components to the physical components is known as Map. Logical components are nothing but the components that we have as per the design circuit diagram. Physical components are the components that are there inside FPGA such as LUTs, gates, flip-flops.

#### **Place And Route:**

This is the process of configuring the appropriate CLBs & IOBs inside the FPGA and interconnecting them. Also known as, PAR.

25. To do the implementation process, the constraints file has to be given as another input file. To create a new user constraint file (ucf), click on project from the ISE software and select new source. Once that is completed the window shown below appears. Select implementation constraint file and give the desired file in the file name field. Then click on "Next", "Next" and "Finish".





Figure 4-23
Applying input constraints.

26. The above process will create an ucf file and automatically add it to the project. By selecting the ucf file in sources for window, "Run" "Assign Package Pins" process from Processes for window. The details of the pin locations are for switches and LEDs available on TLL5000 board.



**Figure 4-24** *Assigning package pins.* 

27. Once "Assign Package Pins" process is run another built-in tool from ISE will be opened called Pin-out Area Constraint Editor (PACE). Enter the pin numbers in the LOC field as shown in the figure. The pin number details in the figure below (bottom-left window labeled "Design Object List – I/O Pins") are as needed for the TLL5000 LEDs and Switches.




Figure 4-25
Applying pin numbers.

28. After entering the pin numbers in the LOC field save the file and exit the PACE tool. Then in the "Sources for" window in ISE select the VHD file and run the "Generating Programming File" process. This process will generate the bit file which can be downloaded onto the FPGA.

This process will run all the other processes that are there, before the generation of the programming file. An individual process may also be run separately.




Figure 4-26
Generating bit file.

# **Programming TLL5000**

29. After completing "Generating Programming File" process, expand "Generating Programming File" process tab in the "Process for" window and run "Configure Device iMPACT" process. When this process is executed the target board has to be connected, with the appropriate cable connections.




Figure 4-27
Configuring the target platform.

30. Once the "Configure Device iMPACT" process is run, the below shown below appears. In this window, just click on "Finish".




Figure 4-28
Welcome screen of iMPACT.

31. Once the "Finish" is clicked the iMPACT tool will detect the boundary scan devices on the target TLL5000. Here "xcf32p" is a flash prom & "xc9572" is a CPLD. These devices will NOT!! be programmed. Click "Bypass" on the following window.




Figure 4-29
Detecting boundary scan devices.

32. This window is to select the programming file for the CPLD. Since we are not going to program that this can also be bypassed.




Figure 4-30 Selecting programming file.

33. The third window is for the FPGA. Please ensure that the FPGA is selected by being highlighted. Then select the appropriate bit file and click on "Open".




Figure 4-31 Selecting bit file.

34. Now it can be observed that the FPGA is selected with the given bit file.




Figure 4-32
Programming selection.

7. Right click on the FPGA that is "xc3s1500" and select program from the pop-up menu. Then the below shown window appears. Click on "OK" in this window. This will download the bit file onto the target device.




Figure 4-33 Viewing programming properties.

35. Once programming is successfully completed, the "Program Succeeded" message appears as shown in the given figure.




Figure 4-34
Programming status.

## **Functional Test on the TLL5000**

36. The design downloaded onto the TLL5000 is tested for correct functionality with the use of switches and LEDs available on the target TLL5000.




Figure 4-35
Observing outputs.

As the switches are toggled to ON/OFF positions, if the design is functioning correctly then the corresponding output LEDs will turn ON/OFF to match the switch positions.

\*END\*