



SRV02-Series

Rotary Experiment # 1

Position Control



Student Handout



SRV02-Series

Rotary Experiment # 1

Position Control

Student Handout

1. Objectives

The objective in this experiment is to introduce the student to the fundamentals of control using the PID family of compensators.

At the end of this session, you should know the following:

- How to mathematically model the servo plant from first principles.
- An understanding of the different tuning parameters in the controller.
- To design and simulate a PV controller to meet the required specifications.
- To implement your controller and evaluate its performance.

2. System Requirements

To complete this lab, the following hardware is required:

[1] Quanser UPM 2405/1503 Power Module or equivalent.

[1] Quanser MultiQ PCI / MQ3 or equivalent.

[1] Quanser SRVO2-(E) servo plant.

[1] PC equipped with the required software as stated in the WinCon user manual.

- The suggested configuration for this experiment is the **SRV02-E(T)** in the **High-Gear** configuration with a **UPM 2405** power module and a **gain cable** of **5**.
- *It is assumed that the student has successfully completed Experiment #0 of the SRVO2 and is familiar in using WinCon to control the plant through Simulink.*
- *It is also assumed that all the sensors and actuators are connected as per dictated in the Experiment #0 as well as the SRVO2 User's Manual.*

3. Mathematical Model

This section of the lab should be read over and completely understood before attending the lab. It is encouraged for the student to work through the derivations as well as to get a thorough understanding of the underlying mechanics. For a complete listing of the symbols used in this derivation as well as the model, refer to **Appendix A - SRV02 Nomenclature** at the back of this handout.

We shall begin by examining the electrical component of the motor first. In **Figure 1**, you see the electrical schematic of the armature circuit.




Figure 1 - Armature circuit in the time-domain

Using Kirchhoff's voltage law, we obtain the following equation:

$$V_m - R_m I_m - L_m \frac{dI_m}{dt} - E_{emf} = 0 \quad [3.1]$$

Since $L_m \ll R_m$, we can disregard the motor inductance leaving us with:

$$I_m = \frac{V_m - E_{emf}}{R_m} \quad [3.2]$$

We know that the back emf created by the motor is proportional to the motor shaft velocity ω_m such that:

$$I_m = \frac{V_m - K_m \dot{\theta}_m}{R_m} \quad (\dot{\theta}_m = \omega_m) \quad [3.3]$$

We now shift over to the mechanical aspect of the motor and begin by applying Newton's 2nd law of motion to the motor shaft:

$$J_m \ddot{\theta}_m = T_m - \frac{T_l}{\eta_g K_g} \quad [3.4]$$

Where $\frac{T_l}{\eta_g K_g}$ is the load torque seen thru the gears. And η_g is the efficiency of the gearbox.

We now apply the 2nd law of motion at the load of the motor:

$$J_l \ddot{\theta}_l = T_l - B_{eq} \dot{\theta}_l \quad [3.5]$$

Where B_{eq} is the viscous damping coefficient as seen at the output.

Substituting [3.4] into [3.5], we are left with:

$$J_l \ddot{\theta}_l = \eta_g K_g T_m - \eta_g K_g J_m \ddot{\theta}_m - B_{eq} \dot{\theta}_l \quad [3.6]$$

We know that $\theta_m = K_g \theta_l$ and $T_m = \eta_m K_t I_m$ (where η_m is the motor efficiency), we can re-write [3.6] as:

$$J_l \ddot{\theta}_l + \eta_g K_g^2 J_m \ddot{\theta}_l + B_{eq} \dot{\theta}_l = \eta_g \eta_m K_g K_t I_m \quad [3.7]$$

Finally, we can combine the electrical and mechanical equations by substituting [3.3] into [3.7], yielding our desired transfer function:

$$\frac{\theta_l(s)}{V_m(s)} = \frac{\eta_g \eta_m K_t K_g}{J_{eq} R_m s^2 + (B_{eq} R_m + \eta_g \eta_m K_m K_t K_g^2) s} \quad [3.8]$$

Where:

$$J_{eq} = J_l + \eta_g J_m K_g^2$$

This can be interpreted as the being the equivalent moment of inertia of the motor system as seen at the output.

3.1 Pre-Lab Assignment

This lab involves designing a PV controller for the servo plant. We have omitted the integral gain (**PID**), as the main purpose of the integral gain is to reduce the steady state error by introducing a pole located at $s = 0$ in the open loop. Looking back at the derived equation [3.8], we can clearly see that the plant already has a pole at $s = 0$. For this reason, and for the sake of simplicity, the required specifications will be met using only a proportional (**P**) and velocity/derivative (**V**) controller.

In the classical sense, a PD controller would have the form: $C(s) = K_p + K_d s$. Placing this controller into the forward path would result in introducing an unwanted 'zero' in the closed loop transfer function. As a result of the 'zero', the closed loop transfer function no longer fits equation [3.10] and it becomes increasingly difficult to design the controller to meet time specifications.

With this limitation in mind, we can now make the transition to use a state-feedback (**PV**) approach that can meet our requirements and results in a closed loop transfer function of the form seen in equation [3.10]. The **PV** controller that will be implemented in this lab can be seen in **Figure 2** below and has the form:

$$V_m = -K_p(\theta - \theta_d) - K_v \dot{\theta} \tag{3.9}$$




Figure 2 - PV Controller for the SRV02 Plant

The purpose of this lab is to design a controller using the 2nd order transfer function representation of the form:

$$\frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2} \quad [3.10]$$

with characteristic equation:

$$s^2 + 2\zeta\omega_n s + \omega_n^2 \quad [3.11]$$

Coincidentally, the **characteristic equations of the **PV** and **PD** controller closed loop transfer functions are **equal**. A PV controller in essence is a PD controller without the unwanted 'zero', allowing the designer to meet the required specifications using only the characteristic equation.*

- 1) Obtain the transfer function of the closed loop model in **Figure 2**. Extract the characteristic equation and fit it to the form seen in equation [3.11]. Obtain 2 equations expressing ω_n and ζ as functions of K_p and K_v as these are the only 2 variables in your system. Using your newly obtained formulas and referring to your in-class notes, what changes to your response would you expect to see by varying the values of K_p and K_v ?

(What happens to ω_n when you increase/decrease K_p ?)

(What happens to ζ when you increase/decrease K_v and/or K_p ?)

Keep your answers simple. (i.e. will ω_n and ζ increase or decrease?)

- 2) For the in-lab portion of this experiment, you are required to design a PV controller that will yield the following time requirements:

- The Overshoot should be less than 5% ($\zeta \geq 0.707$).
- The time to first peak should be 100ms ($T_p = 0.100$).

Using the formulas from Question 1, choose values for K_p and K_v to meet the requirements.

**Hint:*

$$T_p = \frac{\pi}{\omega_n \sqrt{1 - \zeta^2}} \quad \%OS = e^{\frac{-\zeta\pi}{\sqrt{1 - \zeta^2}}} \quad [3.12]$$

4. Lab Procedure

4.1 Wiring and Connections

The first task upon entering the lab is to ensure that the complete system is wired as described in the *SRV02 Experiment #0 - Introduction*. If you are unsure of the wiring, please refer to the *SRV02 User Manual* or ask for assistance from a TA assigned to the lab. Now that all the signals are connected properly, start-up MATLAB and start Simulink. You are now ready to begin the lab.

4.2 Controller Specifications

This lab requires you to design a Proportional + Velocity (**PV**) controller to control the position of the load shaft with the following specifications:

1. The Overshoot should be less than 5% ($\zeta \geq 0.707$).
2. The time to first peak should be 100ms ($T_p = 0.100$).

4.3 Simulation of the Plant

In Simulink, open a model called “*s_position_pv.mdl*”. This model includes the modeled plant (SRV-02 Plant Model), as well as the PV controller. K_p and K_v are both set by slider gains. Before you begin, you must run an M-File called “*Setup_SRV02_Exp1.m*”. This file initializes all the motor parameters and gear ratios. Click on *Simulation->Start*, and bring up the *Simulated Position* scope. As you monitor the response, adjust K_p and K_v using the slider gains. Try a variety of combinations, and note the effects of varying each parameter.

- Make a table of system characteristics (ω_n and ζ) with respect to changes in K_p and K_v . (Hold one variable constant while adjusting the other).
- Does the system response react to how you had theorized in section 3.1?

Now that you are familiar with the actions of each parameter, enter in the designed K_p and K_v that you had calculated to meet the system requirements. **Note: the values should fall within the slider limits.*

- Does the response look like you had expected? What is your percent overshoot?
- Calculate your T_p . Does it match the requirements?

**Hint: To get a better resolution when calculating T_p , decrease the time range under the parameters option of the scope.*

If the simulated response is as expected, you can move on and implement your controller, if you are close to meeting the requirements, try fine-tuning your parameters to achieve the desired response. If the response is far from the specifications, you should re-iterate your design process and re-calculate your controller gains.

4.4 Implementation of the Controller

After successfully simulating your controller and achieving your desired response, you are now ready to implement your controller and observe its effect on the physical plant.

Open a Simulink model called “*q_position_pv_e.mdl*” or “*q_position_pv_pot*” - ask a TA assigned to this lab if you are unsure which model is to be used in the lab. The model has 2 identical closed loops; one is connected similar to the simulation block of the previous section, and the other loop has the actual plant in it. To better familiarize yourself with the model, it is suggested that you open both sub-systems to get a better idea of the systems as well as take note of the I/O connections. In the SRV02 plant block (blue), you will see a gain of $1/K_{\text{Cable}}$ to normalize the system due to our use of a gain cable (to enable a greater control signal being fed into the plant).

Note: In place of a standard derivative block in the **PV controller, we have placed a derivative with a filter in order to eliminate any high frequencies from reaching the plant as high frequencies will in the long term damage the motor.*

Before running the model, you must set your final values of K_p and K_v in the MATLAB workspace (type it in MATLAB). You can now build the system using the *WinCon->Build* menu. You will see the model compile, and then you can use the WinCon Server to run the system (click on the start button). Your plant should now be responding and tracking a square wave to the commanded angle (*Setpoint Amplitude (deg)*).

Plot the *Measured Theta (deg)* as well as the *Setpoint Amplitude (deg)* and the *Simulated Theta (deg)*. This is done by clicking on the scope button in WinCon and choosing *Measured Theta (deg)*. Now you must choose the *Setpoint Amplitude (deg)* and the *Simulated Theta (deg)* signals thru the *Scope->File->Variables* menu.

- How does your actual plant response compare to the simulated response?
- Is there a discrepancy in the results? If so, why?
- Calculate your system T_p and %OS. Are the values what you had expected?

**You can calculate these parameters by saving these traces as an m-file and making our calculations in MATLAB. You could also make your calculations directly from the WinCon scope by zooming in on the signals. It is suggested to make these calculations thru MATLAB as this method will provide greater accuracy.*

If you are sufficiently happy with your results and your response looks similar to **Figure 3** below, you can move on and begin the report for this lab. Remember, there is no such thing as a perfect model, and your calculated parameters were based on the plant model. A control design will usually involve some form of fine-tuning, and will more than likely be an iterative process.

At this point, you should be fine-tuning your K_p and K_v based on your findings from above (*use the table created in section 4.3 of this lab as a guide*) to ensure your response matches the system requirements as seen in **Figure 3**.




Figure 3 - Step Response to a Command of 30 degrees

We can see by looking at **Figure 3**, that the position response has a **100ms** time to peak and an overshoot of less than **5%**. The system requirements have been met and implemented using a **PV** controller.

5. Post Lab Questions and Report

After successfully designing and implementing your controller, you should now begin to document your report. This report should include:

- I. Your solutions to the pre-lab assignment of section **3.1**. Included should be the characteristic equation of the system, formulas relating ω_n and ζ to K_p and K_v , and your expected changes in response to variations of K_p and K_v .
- II. Your designed K_p and K_v to meet the system specifications and your steps at calculating the results.
- III. A table relating changes in ω_n and ζ to changes in K_p and K_v as described in section **4.3**. Did these changes reflect what you had theorized in the pre-lab? Explain.
- IV. After simulating your controller with your calculated K_p and K_v , did the response match what you had expected? What was the percentage overshoot? What was your T_p ? If you had to re-iterate your design, also include your iterations and why you believe your initial solution did not yield a desired response.
- V. In section **4.4**, you implemented your controller. Did the actual system response match your simulated results? If not, what reasons could you conclude were responsible for the discrepancies?
- VI. Include your final K_p and K_v after fine-tuning the controller. You should also present a plot of your final system response with the actual, simulated and setpoint signals. this graph should look similar to **Figure 3**.

5.1 Post Lab Questions

- 1) During the course of this lab, were there any problems or limitations encountered? If so, what were they and how were you able to overcome them?
- 2) After completion of this lab, you should be confident in tuning this type of controller to achieve a desired response. Do you feel this controller can meet any arbitrary system requirement? Explain.
- 3) Most controller of this form also introduce an integral action into the system (PID), do you see any benefits to introducing an integral gain in this experiment?

Appendix - A: SRV02 Nomenclature

Symbol	Description	MATLAB Variable	Nominal Value SI Units
V_m	Armature circuit input voltage		
I_m	Armature circuit current		
R_m	Armature resistance	Rm	2.6
L_m	Armature inductance		
E_{emf}	Motor back-emf voltage		
θ_m	Motor shaft position		
ω_m	Motor shaft angular velocity		
θ_l	Load shaft position		
ω_l	Load shaft angular velocity		
T_m	Torque generated by the motor		
T_l	Torque applied at the load		
K_m	Back-emf constant	Km	0.00767
K_t	Motor-torque constant	Kt	0.00767
J_m	Motor moment of inertia	Jmotor	3.87 e-7
J_{eq}	Equivalent moment of inertia at the load	Jeq	2.0 e-3
B_{eq}	Equivalent viscous damping coefficient	Beq	4.0 e-3
K_g	SRV02 system gear ratio (motor->load)	Kg	70 (14x5)
η_g	Gearbox efficiency	Eff_G	0.9
η_m	Motor efficiency	Eff_M	0.69
ω_n	Undamped natural frequency	Wn	
ζ	Damping ratio	zeta	
K_p	Proportional gain	Kp	
K_v	Velocity gain	Kv	
T_p	Time to peak	Tp	