Installation and User Manual

Always have a qualified bicycle technician install **the Plug II** on your bicycle. Please visit www.tout-terrain.de for a video intallation tutorial.

General use and features:

- the Plug II consumes almost no power if no device is connected. If 5V (+/-0.2V) are supplied the green LED will turn on, regardless if there is a device connected or not. If there is no device connected and the internal voltage is too high (at high speeds), the Plug II switches off automatically.
- the Plug II has been optimized to power devices that use USB standard as interface. Please note that the actual use and performance of a device in combination with the Plug II depends on the device's individual charging and operating characteristic. the Plug II generally provides a power interface according to USB-specifcation type A. This means that the USB wire 1 and 4 provide constant power of 5V.



the Plug II does only supply power once a constant output of 5V can be supplied. The actual
riding speed in order to provide 5V output depends on your device's individual charging and
operating characteristic. Please check with your device's manufacturer for compatibility and
requirements. The following chart shows a basic overview of output current depending on your
speed. This however also depends on the hub dynamo used.



- the Plug II has been designed for parallel use with a light system. Thus there is no need to dismount any cable after its initial installation. Please also see the light and dynamo manufacturer's instructions for cable installation details. However please note that if the Plug II and a light system are used at the same time, both light and the Plug II 's output performance will decrease based on the limitation of the hub dynamo. Thus we recommend to use "either/or".
- **the Plug II** 's electronics have been designed to be water-resistant. However depending on the conditions of use, the USB outlet might show some initial rust corrosion over time. This rust film can be easily removed using a Q-tip with some alcohol.
- Please note: Never rotate the USB-Top-Cap (1) after installation, as this might damage the connector cable.

INSTALLATION

Please read carefully. If the instructions are not followed carefully you might void your warranty! Also make sure that the steer tube end is de-burred on in and outside.

For installation (Hex) Allen keys size 4mm and 5mm are required.

a) check of star-fangled nut and installation of cable

The cable (4) can be wired through the "claws" of a standard star-fangled nut. Please see Fig.1 for details. **Please make sure to not damage the cable!** If this is not an option continue with b).



b) alternative to a): Installation of expander nut with integrated cable channel (3)

- 1. Insert the expander nut (3) in the steer shaft with the cable (4) already inserted in the channel. Tighten the expander nut using a Hex 5 Allen Key. Make sure to leave a 5mm gap between the top of the steer shaft and the top of the stem. You might need to add a spacer.
- 2. In case you already have a star-fangled nut installed you will need to remove it using the following steps. You can either remove the star-fangled nut by forcing it out using a hammer or by using a drilling technique. The drilling technique requires to repeat a drill sequence through the center of the star-fangled nut by using a 6-8-10-11-12 mm drills one after the other, until the star-fangled nut collapses.

c) connecting of cable and adjustment of headset:

- 1. Connect the cable (4) with the connector at the bottom of the Top Cap (1). If needed, the cable can be disengaged using slight force.
- Use your existing aheadset cap to adjust the headset. Torque the stem according to the manufacturer's specifications. Depending on your headset you might need a shorter M6 bolt.
- 3. There is no need to pay attention to polarity of the cables as the dynamo hub has AC output. However please also see the light and dynamo manufacturer's instructions for cable installation details.

d) Assembly of USB cover (2)

Slide the plastic ring of the USB cover assembly (2) over the Top Cap (1) with the pin that fixes the silicone part facing upwards.

e) Top Cap installation

Install the Top Cap (1) like a regular Ahead-Set Cap using the M6 bolt.

NOTE: You can also the bolt of the top cap (1) to adjust the headset. In this case pay attention that the cable does not get damaged!