

Implementing low-cost TTCS systems using assembly language

Simon Key, Michael J. Pont and Simon Edwards¹

Embedded Systems Laboratory², University of Leicester, LEICESTER LE1 7RH, UK.

Introduction

We have previously described a “pattern language” consisting of nearly eighty components, which will be referred to here as the “PTTES Collection” (see Pont, 2001; Pont and Ong, in press). This language is intended to support the development of reliable embedded systems: the particular focus of the collection is on systems with a time triggered, co-operatively scheduled (TTCS) system architecture.

In this paper, we present a new pattern – TTCo SCHEDULER (ASSEMBLY LANGUAGE) – which describes how to implement TTCS architectures using small, memory-limited, microcontrollers (such as 8051s, PICs, AVRs or similar devices).

Acknowledgements

We are grateful to Jorge Ortega-Arjona (our ‘shepherd’ at EuroPLoP 2003) for comments and suggestions on the first drafts of this paper.

Copyright

Copyright © 2003-2004 by Simon Key, Michael J. Pont and Simon Edwards. Permission is granted to copy this paper for the purposes of EuroPLoP 2003. All other rights reserved.

¹ The first phase of the work described in this paper was carried out while Simon Edwards was a Final-Year student at the University of Leicester. Present address: MIRA Ltd, Watling Street, Nuneaton, Warwickshire CV10 0TU,UK

² <http://www.le.ac.uk/eg/embedded>

TTCo SCHEDULER (ASSEMBLY LANGUAGE)

Context

- You are developing an embedded application.
- You wish to use a time-triggered (software) architecture, based on some form of co-operative scheduler.
- Your chosen hardware platform (microcontroller) has very limited data memory and/or code memory.

Problem

How can you create a co-operative scheduler with minimal memory and CPU requirements?

Background

There are two ways of viewing a (co-operative) scheduler:

- At one level, a scheduler can be viewed as a simple operating system that allows tasks (functions) to be called periodically, or - less commonly - on a one-shot basis.
- At a lower level, a scheduler can be viewed as a single timer interrupt service routine that is shared between many different tasks. As a result, only one timer needs to be initialised, and any change to the timing generally requires only one function to be altered.
Furthermore, we can generally use the same scheduler whether we need to execute 1, 10 or 100 different tasks.

Using such a scheduler, we can co-ordinate the execution and interaction of tasks in a highly deterministic manner. By making the scheduler co-operative (that is, only one task is active at any point in time), we simplify the design³ and greatly reduce the potential for task conflicts.

Solution

We have previously described, in detail, how to create a flexible scheduler using the C programming language (see CO-OPERATIVE SCHEDULER [Pont, 2001, p.255]). In the present pattern, we describe how to create a similar scheduler, using assembly language. By using assembly language, we can significantly reduce the system resource requirements.

In the examples, we will use code fragments taken from an 8051-based system. However, the techniques can be applied with virtually any microcontroller.

³ Compared with an equivalent pre-emptive scheduler.

Key components

An implementation of TTCo SCHEDULER (ASSEMBLY LANGUAGE) has the following key components:

1. The scheduler data structure.
2. An initialisation function.
3. A single interrupt service routine (ISR), used to update the scheduler at regular time intervals.
4. A dispatcher function that causes tasks to be executed when they are due to run.
5. One or more tasks.

The links between these components during the program execution are shown schematically in Figure 1.




Figure 1: Links between the different scheduler components during the program run.

We consider each of these components in the sections that follow.

The scheduler data structure

To control a task we need to know three basic pieces of information:

1. The location of the task in program memory
2. The initial delay value (when should the task be run for the first time?)
3. The Reload value (if the task is periodic, what is the interval between runs?)

The location of the tasks is given in the task list. This is a ‘jump table’ (see Listing 1).

```

; *** This is where the scheduled tasks go list below in order (1 to 8)
TASK_LIST:
    ajmp TASK1          ; Jump to Task 1
    ajmp TASK2          ; Jump to Task 2
    ajmp TASK3          ; Jump to Task 3
    ajmp TASK4          ; Jump to Task 4
    ajmp TASK5          ; Jump to Task 5
    ajmp TASK6          ; Jump to Task 6
    ajmp TASK7          ; Jump to Task 7
    ajmp TASK8          ; Jump to Task 8
SCH_NO_TASK_HERE:      ; DO NOT MOVE OR RENAME THIS LINE

```

Listing 1 Task list (file: 8051SCH.ASM)

Each task has its own delay and reload values which are entered directly by the programmer into the appropriate task slot (Listing 2). These values are then copied at runtime into RAM memory locations.

```

;*****cseg*****
; Scheduled Task Delay and Reload Values
;*****cseg*****
SCH_Delay_Values:
    db 0x00          ; Delay value for Task 1
    db 0x00          ; Delay value for Task 2
    db 0x00          ; Delay value for Task 3
    db 0x00          ; Delay value for Task 4
    db 0x00          ; Delay value for Task 5
    db 0x00          ; Delay value for Task 6
    db 0x00          ; Delay value for Task 7
    db 0x00          ; Delay value for Task 8

SCH_Reload_Values:
    db 0x63          ; Reload value for Task 1
    db 0x00          ; Reload value for Task 2
    db 0x00          ; Reload value for Task 3
    db 0x00          ; Reload value for Task 4
    db 0x00          ; Reload value for Task 5
    db 0x00          ; Reload value for Task 6
    db 0x00          ; Reload value for Task 7
    db 0x00          ; Reload value for Task 8

```

Listing 2 Delay and reload Values (file: TASK_PERIODS.INC)

An initialisation function

As with most programs the system requires some initialisation. In the case of assembly language programs we are also required to initialise vectors and memory allocations.

Vectors

When an interrupt occurs the CPU finishes the instruction that it is currently processing and jumps to an area of memory known as a vector. This vector contains a pointer to the relevant ISR.

In this case we are considering only one vector, linked to the timer overflow. When the timer reaches its maximum count and ‘overflows’, the ISR “SCH_Update” is called.

```

; ****
;  Vectors
; ****
    CSEG  AT      0x0000          ; absolute Segment at Address 0
    LJMP  MAIN           ; reset location (jump to start)
    CSEG  AT      0x002b          ; interrupt vector
; *** There is only one interrupt in this program ...
    LJMP  SCH_Update       ; timer overflow -> update scheduler
    CSEG  AT      0x0043          ; after all interrupt vectors
                                ; start of main program.

```

Listing 3 Interrupt vectors (file: VECTORS.INC)

Memory Allocation

In assembly language the location of variables used within the program has to be specified manually. This is done by allocating a name to a section of memory; this name can then be referred to throughout the program (this is similar to variable initialisation in a high-level language).

```

; ****
;  Scheduler Memory Allocation
; ****
    START_OF_DATA_MEMORY      EQU      (00h)
    START_OF_USER_MEMORY      EQU      (SCH_rloads + SCH_MAX_TASKS)
;scheduler status register
    SCH_STATUS     DATA      (START_OF_DATA_MEMORY)
;temp register for Scheduler
    SCH_temp       DATA      (START_OF_DATA_MEMORY + 01h)
;general temp register
    temp          DATA      (START_OF_DATA_MEMORY + 02h)
; ***Scheduler variables
;Run flags for scheduled tasks
    SCH_run_f      DATA      (START_OF_DATA_MEMORY + 04h)
;Run flag mask
    SCH_run_mask   DATA      (START_OF_DATA_MEMORY + 05h)
;Current task index
    SCH_index      DATA      (START_OF_DATA_MEMORY + 06h)
;Task Dispatcher run flag mask
    SCH_dis_mask   DATA      (START_OF_DATA_MEMORY + 07h)
;Task Dispatcher task index
    SCH_dis_index  DATA      (START_OF_DATA_MEMORY + 08h)
;Delay values for scheduled tasks
; put in ram comments to the size of the number of tasks -> SCH_MAX_TASKS
    SCH_delays     DATA      (START_OF_DATA_MEMORY + 09h)
;Delay values for scheduled tasks
; put in ram comments to the size of the number of tasks -> SCH_MAX_TASKS
    SCH_rloads    DATA      (SCH_delays + SCH_MAX_TASKS)

```

Listing 4 Memory allocation (file: MEMORY_ALLOCATION.INC)

Device initialisation

To ensure correct operation of the scheduler we have to initialise run time variables, prepare the system timer and prepare any ports used for IO operations. The initialisation of runtime variables consists of copying the task delay and task reload values from non changeable ROM to RAM. Listing 5, shows general configuration settings for the device.

```

initialise:
; *** General Initialisation
    mov     SP,#0x30           ; Set Stack Pointer
    clr     SWDT              ; Clear Watchdog timer

```

Listing 5 Initialisation (file: 8051SCH.ASM)

Timer initialisation

The scheduler is driven by timer “ticks”. These are interrupts generated when a timer register overflows. Listing 6 shows a possible timer initialisation using Timer 2 in an 8051 device. With the timer reload values used here we have a 10 ms period between interrupts.

```

; *** Initialise timer for scheduler (using TMR2)
    mov     T2CON,#0x10
    mov     CCEN,#0x00

; *** The timer preload values
    mov     TH2, #PRELOAD10H      ; Pre-defined values giving 10ms tick
    mov     CRCH, #PRELOAD10H
    mov     TL2, #PRELOAD10L
    mov     CRCL, #PRELOAD10L

; *** Enable Timer 2 interrupt, but not the external one.
    setb   ET2
    setb   EXEN2

```

Listing 6 Timer initialisation (file: 8051SCH.ASM)

In general, the initial task delays and reload values are stored directly in program memory using assembler directives, such as db. If these memory locations are referenced using a label a simple routine to move these fixed values from code memory to RAM can be used. Listing 7 shows the routine used to copy the data code section (scheduler data structure) from ROM to RAM.

```

; *** Initialise scheduler variables
    mov     SCH_run_f,#0x00      ; Clear all run flags
    mov     SCH_index,#0          ; Reset index counter
    mov     R1,#(SCH_rloads)     ; Get address of delay values
    mov     R0,#(SCH_delays)     ; Initialise indirect pointer

SCH_init_lp:
    mov     DPTR,#SCH_Delay_Values ; Get delay value for task[index]
    mov     A,SCH_index           ; Get task index value
    movc   A,@A+DPTR             ; Store in array
    inc    R0
    mov     DPTR,#SCH_Reload_Values ; Get reload value for task[index]
    mov     A,SCH_index           ; Offset pointer by number of tasks
    movc   A,@A+DPTR             ; Get task index value
    mov     @R1,A                 ; Store in array
    inc    R1
    inc    SCH_index
    mov     A,SCH_index

; decrease index value, if not zero, loop
    cjne   A,#SCH_MAX_TASKS,SCH_init_lp

```

Listing 7 ROM to RAM copy (file: 8051SCH.ASM)

To conclude the initialisation, Timer 2 is started and the associated interrupt is enabled (Listing 8).

```

; *** Enable interrupts and reset TMR0
setb  T2I0          ; Set the timer running
setb  EAL           ; Enable interrupts

```

Listing 8 Concluding the scheduler initialisation (file: 8051SCH.ASM)

An ISR

When the scheduler timer (discussed above) ‘overflows’, the scheduler interrupt service routine (ISR) is executed. The first action taken in the ISR is to clear the timer interrupt flag and save any registers that will be altered within this routine (Listing 9); these registers will be restored at the exit from the function.

```

SCH_Update:
    clr  TF2          ; Clear Timer 2 interrupt flag
    push ACC          ; Save registers that might be needed
    push PSW
    push 01h
    push 00h

```

Listing 9 Performing a context save (file: 8051SCH.ASM)

Each of the possible tasks is then checked. A non-zero delay time is decreased by one, and the update function then checks the next task. A zero delay time results in the delay time been re-initialised with the associated reload value, and the run flag for that task is set (Listing 10).

```

; *** Setup loop counter and run flag mask
    mov  SCH_run_mask,#00000001b    ; Init value for run flag mask
    mov  SCH_index,#SCH_MAX_TASKS  ; Reset index value to number of tasks
                                    ; in scheduler
    mov  A,#SCH_delays
    mov  R0,A          ; Get address of SCH_delays
    mov  A,#SCH_rloads    ; Get location of first reload ram
                          ; location
    mov  R1,A

SCH_Update_lp:
    mov  A,SCH_run_mask      ; Get run flag mask
    cjne @R0,#0,SCH_Task_notready ; Test delay time if not zero task not
                                    ; ready
; *** Current task is ready to be run, so set run flag and reload delay
; value
SCH_Task_ready:
    orl  SCH_run_f,A        ; Set appropriate run flag
    mov  A,@R1          ; Get value being pointed to
    mov  @R0,A          ; Store in delay value (task period)
    AJMP SCH_Update_lp_end ; Jump to end of loop

SCH_Task_notready:           ; Task isn't ready to run
    dec  @R0           ; Decrease delay value by 1

SCH_Update_lp_end:
    inc  R0            ; Increase pointer value by 1
    inc  R1
    mov  A,SCH_run_mask ; Roll run mask one place to left
    rl   A
    mov  SCH_run_mask,A
    djnz SCH_index,SCH_Update_lp ; Decrease index value, not zero, so
                                ; Loop still tasks to look at

```

Listing 10 The core scheduler “update” code (file: 8051SCH.ASM)

Finally, the pre-ISR program context is restored, and system resumes “normal” operation (Listing 11).

```

pop    00h          ; Restore registers
pop    01h
pop    PSW
pop    ACC
reti           ; Return from interrupt

```

Listing 11 Restoring the pre-ISR context (file: 8051SCH.ASM)

A dispatch function

We have seen that a run flag is set for a given task to be performed in the SCH_Update function. In this section we see how the flag is used to activate the task that it relates to.

Until an interrupt occurs and a run flag is set, the dispatch function sits in an endless loop, ‘sleeping’ between timer ‘ticks’. When a run flag has been set, checks are performed and the associated task is called (Listing 12).

```

; *** This is the main task dispatcher process. If a task is ready to be run
;      then the dispatcher will run it and clear its run flag.

orl    PCON,#0x01          ; Enter idle mode (#1)
orl    PCON,#0x20          ; Enter idle mode (#2) goto sleep
mov    A,SCH_run_f         ; Test run flags
jz    SCH_Dispatch_Tasks ; No tick -> loop

; initial value for mask, load dispatcher run flag mask
mov    SCH_dis_mask,#00000001b
; get number of tasks in scheduler, load dispatcher task index
mov    SCH_dis_index,#SCH_MAX_TASKS

SCH_Dispatch_Tasks_lp:
    mov    A,SCH_dis_mask          ; Get run flag mask
    anl    A,SCH_run_f            ; Logical AND with run flags
; if result was zero, so no run flag there, go back to loop
    jz    SCH_Dispatch_Tasks_end

; *** Task needs to be run, so clear run flag and jump to task
    mov    A,SCH_dis_mask          ; Get inverse of run flag mask
    cpl    A
    anl    SCH_run_f,A           ; Clear appropriate run flag
    mov    DPTR,#TASK_LIST        ; Load start of task lists
    mov    A,#SCH_MAX_TASKS
    subb   A,SCH_dis_index        ; Add current task no
    clr    C                      ; Clear carry
    rlc    A                      ; x2 to get 'real' code location
    jmp    @A+DPTR               ; Jmp to task

```

Listing 12 A possible dispatch function (file: 8051SCH.ASM)

The tasks have been stored in a jump table, and the relevant task number is added to the base address of this table (TASK_LIST). The resulting value is then stored in the program counter, causing a ‘jump’ to the task (Listing 13).

```

; *** This is where the scheduled tasks go.
;       the list below in order (1 to 8)
TASK_LIST:
    ajmp  TASK1          ; Jump to Task 1
    ajmp  TASK2          ; Jump to Task 2
    ajmp  TASK3          ; Jump to Task 3
    ajmp  TASK4          ; Jump to Task 4
    ajmp  TASK5          ; Jump to Task 5
    ajmp  TASK6          ; Jump to Task 6
    ajmp  TASK7          ; Jump to Task 7
    ajmp  TASK8          ; Jump to Task 8

SCH_NO_TASK_HERE:           ; DO NOT MOVE OR RENAME THIS LINE

```

Listing 13 A possible implementation of the task list jump table (file: 8051SCH.ASM)

Having checked (and, if necessary, run) all possible tasks, the whole process starts again (Listing 14).

```

SCH_Dispatch_Tasks_end:
    mov   A,SCH_dis_mask      ; Roll run flag mask one place left
    clr   C
    rlc   A
    mov   SCH_dis_mask,A
; decrease task index , if not zero more tasks to do
    djnz  SCH_dis_index,SCH_Dispatch_Tasks_lp
    ajmp  SCH_Dispatch_Tasks ; Super loop!

```

Listing 14 A dispatch loop (file: 8051SCH.ASM)

Tasks

For demonstration purposes, we include a simple task that will flash an LED connected to an external pin (50% duty cycle, 0.5 Hz).

```

; ****
; Function:      LED_Flash
; Description:   Flashes LED on port0 pin0 on and off
; Pre:           None
; Post:          None
; ****
TASK1:
LED_Flash:
    mov   A,LED_Status        ; Is the led on?
    jz    LED_on              ; No - jump to turn it on
    clr   LED_PORT            ; Yes - turn it off
    mov   LED_Status,#00        ; Update the LED status
    ajmp  SCH_Dispatch_Tasks_end

LED_on:
    setb  LED_PORT            ; Turn LED on
    mov   LED_Status,#01        ; Update the LED status
    ajmp  SCH_Dispatch_Tasks_end ; Return from scheduled task

```

Listing 15 Flash LED Task (file: TASK1.ASM)

Reliability and safety implications

Many questions have been raised about the suitability of assembly language⁴ for use in applications which are safety-related or safety critical (see, for example, Cullyer et al., 1991; Cooling, 2003).

⁴ It should also be noted that C is rarely considered to be an ideal language for safety-critical systems.

It is undoubtedly the case that implementing – say – a very large and complex air-traffic control system entirely in assembly language would probably not be sensible. However, in the present pattern, we focus on systems implemented using microcontrollers with very limited memory. A consequence of this is that the code size is (compared with many real-time and embedded systems) very small. What is not clear is whether – in such small systems, where the code can be carefully and completely checked – there are significant safety implications resulting from the use of assembly language vs. C. Further studies are required in order to clarify this issue.

Hardware resource implications

Embedded systems implemented using assembly language generally require significantly less memory than those implemented in high-level languages. To illustrate the likely savings in memory when using this pattern, please consider the results shown in Table 1.

Microcontroller	Manufacturer	Size of assembly compared to C (ROM)	Size of assembly compared to C (RAM)	
			One task	Five tasks
16F877	Microchip	20%	39%	27%
AT90s2343	Atmel	26%	35%	31%
C515C	Infineon	32%	76%	46%

Table 1: A comparison of the memory requirements for schedulers implemented in assembly language and C, for a range of different microcontrollers (all figures are approximate).

In this table, the comparison is between an implementation of Co-operative scheduler (Pont, 2001, p.255), implemented in C, and the assembly-language scheduler described in the present pattern. Overall, these figures illustrate that the assembly-language implementations require around a third (or less) of the code memory than is required in the C-language implementation. Savings in code memory are more variable (in this table), but are still substantial.

These memory savings (particularly code-memory reductions) translate directly into reduced costs. This is illustrated in Figure 2, which shows the cost per device for a family of 8051 microcontrollers. The only difference between these microcontrollers is the (code) memory size.




Figure 2 Relating memory size to device costs

When considering the resource implications of this approach to scheduling, please note that the scheduler presented in this paper is divided into multiple source files. This has been done because, when compared with a single-source version, we find this version much easier to use. Please bear in mind that this approach increases the code memory requirements (when using a single task) by 42 bytes (the increase is much less as subsequent tasks are added).

Portability

Assembly language is not a portable language, when compared to any high level language. For example porting the scheduler code from a Microchip 16F877 to an AVR 90S2323 generally requires a complete rewrite.

However within product families, manufacturers maintain compatibility of instruction sets. For example the 8051 or AVR allows quick porting of this scheduler between chips within the same range. Similar observations are noted in other families.

Related patterns and alternative solutions

CO-OPERATIVE SCHEDULER [Pont, 2001, p.255] describes a similar architecture, implemented using the C programming language.

Overall strengths and weaknesses

From previous work we have the following strengths for a co-operative scheduler:

- ☺ The scheduler behaviour is highly predictable.
- ☺ The scheduler is much simpler than pre-emptive alternatives.
- ☺ The scheduler is an integral part of the developed application.

Additionally for the assembly scheduler (compared with an implementation in “C”), we have one key strength:

- ☺ By using this scheduler we can reduce costs, through the use of a microcontroller with less code memory.

General weaknesses of co-operative scheduling:

- ☹ External events have to be polled, which may delay response times under some circumstances.
- ☹ Tasks that exceed the system tick interval can greatly disrupt the system performance.

Specifically for the assembly scheduler:

- ☹ Knowledge of the individual of microcontroller is required in order to write effective code.
- ☹ In the implementation presented here, a maximum of eight tasks that can be scheduled.
- ☹ The assembly-language scheduler is not as straightforward to use as the C-language scheduler and some “hand crafting” is required.

Example: An 8051 assembly scheduler

We present a complete listing of an assembly-language scheduler for the 8051 microcontroller in this section. It is targeted at an Infineon C515C microcontroller running at 10 MHz, and produces a 1ms tick. An example “flashing LED” task is included.

Please note that, as discussed in “Hardware resource implications”, this scheduler is split across multiple source files. This is intended to make the use of the program more straightforward. We can illustrate the use of these various files by outlining how we would add a simple “flashing LED” task to the scheduler:

- Create the ‘flashing LED’ task (TASK1.ASM, Listing 22)
- Modify the task’s delay and reload values as required (TASK_PERIODS.INC, Listing 21)
- Specify the port pin to be used (PORTS.INC, Listing 20)
- Modify the number of tasks and - if required - the scheduler timing (TIMING.INC, Listing 17)
- Allocate memory for the task variables (file: MEMORY_ALLOCATION.INC, Listing 18)

```
; ****
; ****
; Description      8051 Assembler scheduler
; ****
; ****
; ****
; Filename:      8051SCH.ASM
; Company:
; Version:       Author:      Date:      Modification:
; 1.0            S Key       09/12/02   Created
; 1.1            S Key       30/05/03   separate files for easy of use
; ****
; ****
; Files required:
;      REG515C.H, TIMING.INC, MEMORY_ALLOCATION.INC, vectors.inc
;      ports.inc, task_periods.inc, TASK1.ASM, task2.asm, task3.asm
;      task4.asm, task5.asm, task6.asm, task7.asm, task8.asm
; ****
; ****
; Notes:
; Base scheduler for 8051
; THIS FILE DOES NOT REQUIRE MODIFICATION
; ****
; ****
$NOMOD51                                ; disable predefined 8051 registers
$INCLUDE (REG515C.H)
```

```

; **** Sample prescale and reload values ****
; **** Memory Allocation ****
$include (TIMING.INC)

; **** Vectors ****
; **** Main Program ****
$include (MEMORY_ALLOCATION.INC)

$include (vectors.inc)

MAIN:
; **** Initialise Ports ****
$include (ports.inc)

; *** Initialise Ports
    mov     SP      ,#0x30
    clr     SWDT
; *** Initialise timer for scheduler (using TMR2)
    mov     T2CON   ,#0x10
    mov     CCEN    ,#0x00
; *** The timer preload values.
    mov     TH2     , #PRELOAD10H
    mov     CRCH    , #PRELOAD10H
    mov     TL2     , #PRELOAD10L
    mov     CRCL    , #PRELOAD10L

; *** Enable Timer 2 interrupt, but not the external one.
    setb   ET2
    setb   EXEN2

; *** Initialise scheduler variables
    mov     SCH_run_f, #0x00          ;clear all run flags
    mov     SCH_index, #0             ;reset index counter
    mov     R1, #(SCH_rloads)        ;get address of delay values
    mov     R0, #(SCH_delays)        ;initialise indirect pointer

SCH_init_lp:
    mov     DPTR, #SCH_Delay_Values  ;get delay value for task[index]
    mov     A, SCH_index            ;get task index value
    movc   A, @A+DPTR              ;store in array
    mov     @R0, A
    inc    R0
    mov     DPTR, #SCH_Reload_Values ;get reload value for task[index]
    mov     A, SCH_index            ;offset pointer by number of tasks
    movc   A, @A+DPTR              ;get task index value
    mov     @R1, A
    inc    R1
    inc    SCH_index
    mov     A, SCH_index
    cjne   A, #SCH_MAX_TASKS, SCH_init_lp ; decrease index, if not 0, loop

; *** Enable interrupts and reset TMR2
    setb   T2I0                  ; Set the timer running
    setb   EAL                   ; enable interrupts

```

```

SCH_Dispatch_Tasks:
; *** This is the main task dispatcher process. If a task is ready to be run
;     then the dispatcher will run it and clear its run flag.
    ORL    PCON,#0x01          ; Enter idle mode (#1)
    ORL    PCON,#0x20          ; Enter idle mode (#2)
    mov    A,SCH_run_f         ; test run flags
    jz    SCH_Dispatch_Tasks  ; no tick so loop

    mov    SCH_dis_mask,#00000001b ; init value for mask, load
                                    ; dispatcher run flag mask

    mov    SCH_dis_index,#SCH_MAX_TASKS ; get number of tasks in scheduler,
                                    ; load dispatcher task index

SCH_Dispatch_Tasks_lp:
    mov    A,SCH_dis_mask      ; Get run flag mask
    anl    A,SCH_run_f         ; AND with run flags
    jz    SCH_Dispatch_Tasks_end ; if result is 0, run flag is clear
                                ; go back to loop

; *** Task needs to be run, so clear run flag and jump to task
    mov    A,SCH_dis_mask      ; Get inverse of run flag mask
    cpl    A                   ; Clear appropriate run flag

    mov    DPTR,#TASK_LIST      ; Load start of task lists
    mov    A,#SCH_MAX_TASKS    ; Add current task number
    subb   A,SCH_dis_index     ; Clear carry
    rlc    A                   ; x2 to get 'real' code location
    jmp    @A+DPTR             ; Jump to task

```

```

; *** This is where the scheduled tasks go list below in order (1 to 8)
TASK_LIST:
    ajmp  TASK1          ; Jump to Task 1
    ajmp  TASK2          ; Jump to Task 2
    ajmp  TASK3          ; Jump to Task 3
    ajmp  TASK4          ; Jump to Task 4
    ajmp  TASK5          ; Jump to Task 5
    ajmp  TASK6          ; Jump to Task 6
    ajmp  TASK7          ; Jump to Task 7
    ajmp  TASK8          ; Jump to Task 8

    SCH_NO_TASK_HERE:      ; DO NOT MOVE OR RENAME THIS LINE

SCH_Dispatch_Tasks_end:
    mov   A,SCH_dis_mask      ; Roll run flag mask one place left
    clr   C
    rlc   A
    mov   SCH_dis_mask,A
    djnz SCH_dis_index,SCH_Dispatch_Tasks_lp      ; decrease task index,
; - if not zero,
; more task to do
    ajmp  SCH_Dispatch_Tasks      ; Super loop!

; *****
; Scheduler Functions
; *****

; *****
; Function:      SCH_Update
; Description:   Services TMR2 overflow interrupt and processes all tasks
; Pre:           None
; Post:          None
; *****

SCH_Update:
    clr   TF2          ; Clear Timer 2 interrupt flag
    push  ACC          ; Save registers that might be needed
    push  PSW
    push  01h
    push  00h

; *** Setup loop counter and run flag mask
    mov   SCH_run_mask,#00000001b      ; Init value for run flag mask
    mov   SCH_index,#SCH_MAX_TASKS    ; Reset index value to number of tasks
    mov   A,#SCH_delays
    mov   R0,A          ; Get address of SCH_delays
    mov   A,#SCH_rloads      ; Get location of first reload ram location
    mov   R1,A

SCH_Update_lp:
    mov   A,SCH_run_mask      ; Get run flag mask
    cjne @R0,#0,SCH_Task_notready ; Test delay time

```

```

; *** Current task is ready to be run, so set run flag and reload delay value
SCH_Task_ready:
    orl    SCH_run_f,A          ; Set appropriate run flag
    mov    A,@R1                ; Get value being pointed to
    mov    @R0,A                ; Store in delay value (task period)
    AJMP   SCH_Update_lp_end   ; Jump to end of loop

SCH_Task_notready:
    dec    @R0                ; Task isn't ready to be run
                                ; Decrease delay value by one

SCH_Update_lp_end:
    inc    R0                  ; Increase pointer value by one
    inc    R1                  ; Roll run mask one place to left
    mov    A,SCH_run_mask
    rl     A
    mov    SCH_run_mask,A
    djnz   SCH_index,SCH_Update_lp   ; Decrease index value,
                                    ; not zero, so more to check
    pop    00h                 ; Restore registers
    pop    01h
    pop    PSW
    pop    ACC

    reti                      ; Return from interrupt

; *****
; Task Name, Scheduled Task Delay and Reload Values
; *****

$include (task_periods.inc)

; *****
; Scheduled Tasks
; *****

$include (TASK1.ASM)
$include (task2.asm)
$include (task3.asm)
$include (task4.asm)
$include (task5.asm)
$include (task6.asm)
$include (task7.asm)
$include (task8.asm)

end

; *****
; End of Program
; *****

```

Listing 16 Assembly-language scheduler for the 8051 microcontroller, main program (file: 8501SCH.ASM)

```

; ****
; Description      8051 c515c Assembler scheduler
; ****
;
; Filename:      TIMING.INC
; Company:
; Version:       Author:      Date:      Modification:
; 1.0           S Key       09/12/02 Created
; 1.1           S Key       30/05/03 separate files for easy of use
;
; ****
;
; Files required:
;
;
; ****
;
; Notes:
; This section deals with the timing of the scheduler, As set the
; tick is 1 ms vary these according to the settings below or work
; out your own. note some ACCURATE timings are not possible.
;
; *****/
;
; ****
; Sample prescale and reload values
;
;
+-----+-----+-----+
| PRELOAD10h | PRELOAD10l | time generated |
+-----+-----+-----+
| 0xBE      | 0xE5      | ~1ms @ 10 MHz   |
+-----+-----+-----+
| 0xB1      | 0xE0      | 1ms @ 12 MHz   |
+-----+-----+-----+
;
; ****
;
SCH_MAX_TASKS    equ      (01h) ;Maximum number of tasks (MIN = 1)
;MIN = 1, MAX = 7 (depends on task variables)

; Oscillator / resonator frequency (in Hz) e.g. (11059200UL)
OSC_FREQ equ      (10000000)
; Number of oscillations per instruction (6 or 12)
;OSC_PER_INST equ      (6)
;PRELOAD10 equ      (65536 - (OSC_FREQ / (OSC_PER_INST * 100)))
;PRELOAD10H equ      (PRELOAD10 / 256) ;0xd7
PRELOAD10H equ      (0xbe)
;PRELOAD10L equ      (PRELOAD10 % 256) ; 0xd1
PRELOAD10L equ      (0xe5)

; ****
; End of File
; ****

```

Listing 17 Scheduler 'tick' definition (file: TIMING.INC)

```

; ****
; Description      8051 c515c Assembler scheduler
; ****
;
; Filename:      MEMORY_ALLOCATION.INC
; Company:
; Version:       Author:      Date:      Modification:
; 1.0           S Key       09/12/02 Created
; 1.1           S Key       30/05/03 separate files for easy of use
;
; ****
;
; Files required:
;
;
; ****
;
; Notes:
; This section deals with the allocation of memory to scheduler
; and user variables. do not modify the scheduler variables,
; unless REALLY necessary.
;
; **** */
;

; DO NOT MODIFY THIS SECTION
; ****
; Scheduler Memory Allocation
; ****

START_OF_DATA_MEMORY      EQU      (00h)
START_OF_USER_MEMORY      EQU      (SCH_rloads + SCH_MAX_TASKS)

; Misc variables

SCH_STATUS    DATA  (START_OF_DATA_MEMORY)      ; sched status reg
SCH_temp      DATA  (START_OF_DATA_MEMORY + 01h)   ; temp reg for sched
temp          DATA  (START_OF_DATA_MEMORY + 02h)   ; general temp reg

; Scheduler variables

SCH_run_f     DATA  (START_OF_DATA_MEMORY + 04h)      ; Run flags for tasks
SCH_run_mask   DATA  (START_OF_DATA_MEMORY + 05h)      ; Run flag mask
SCH_index     DATA  (START_OF_DATA_MEMORY + 06h)      ; Current task index
SCH_dis_mask   DATA  (START_OF_DATA_MEMORY + 07h)      ; Dispatch run flag msk
SCH_dis_index  DATA  (START_OF_DATA_MEMORY + 08h)      ; Dispatch task index

; Delay values for scheduled tasks
; put in RAM comments to the size of the num of tasks -> SCH_MAX_TASKS
SCH_delays    DATA  (START_OF_DATA_MEMORY + 09h)

; Delay values for scheduled tasks
; put in RAM comments to the size of the num of tasks -> SCH_MAX_TASKS
SCH_rloads    DATA  (SCH_delays + SCH_MAX_TASKS)

; ****

; END OF DO NOT MODIFY

; user variables;
; define all user variables for start of user memory

;Scheduled Task One Variables
LED_Status    DATA  (START_OF_USER_MEMORY)      ;led status register

;Scheduled Task Two Variables
; task_two_variable DATA (START_OF_USER_MEMORY + 01h)      ;example

```

```
;Scheduled Task Three Variables
;Scheduled Task Four Variables
;Scheduled Task Five Variables
;Scheduled Task Six Variables
;Scheduled Task Seven Variables
;Scheduled Task Eight Variables
```

```
;*****
; End of File
*****
```

Listing 18 Memory and register allocation (file: MEMORY_ALLOCATION.INC)

```
;*****
;
; Description      8051 c515c Assembler scheduler
;
*****
```

*

```
;
; Filename:    vectors.inc
; Company:
; Version:     Author:      Date:      Modification:
; 1.0          S Key       09/12/02 Created
; 1.1          S Key       30/05/03 separate files for easy of use
;
*****
```

*

```
;
; Files required:
;
*****
```

*

```
;
; Notes:
;
*****
```

*

```
;
*****
```

*

```
;
; Vectors
*****
```

*

```
CSEG   AT      0x0000      ; reset
LJMP   MAIN      ; reset location (jump to start)

CSEG   AT      0x002b      ; timer 2 overflow
; *** There is only one interrupt in this
program....
ljmp   SCH_Update    ;timer has overflowed, so update scheduler
CSEG   AT      0x0043      ; after all interrupt vectors
; start of main program.

*****
```

```
; End of File
*****
```

Listing 19 8051 C515C Vector table (file: VECTORS.INC)

```

;*****
; Description      8051 c515c Assembler scheduler
;
;*****
;
; Filename:      ports.inc
; Company:
; Version:       Author:      Date:      Modification:
; 1.0           S Key       09/12/02 Created
; 1.1           S Key       30/05/03 separate files for easy of use
;
;*****
;
; Files required:
;
;
;*****
;
; Notes:
; This section deals with the port settings. I find it easier to
; give the port a name such as LED_PORT. Then if you port to a
; different device you only need to change the port description
; in this file
;
;*****
;
; *** Initialise Ports
;
LED_PORT equ      (P0.0)
;
;*****
; End of File
;*****

```

Listing 20 Port definition file (file: PORTS.INC)

```

;***** ****
;
; Description      8051 c515c Assembler scheduler
;
;***** ****
;
; Filename:    task_periods.inc
; Company:
; Version:     Author:      Date:      Modification:
; 1.0          S Key       09/12/02 Created
; 1.1          S Key       30/05/03 separate files for easy of use
;
;***** ****
;
; Files required:
;
;
;***** ****
;
; Notes:
; This section deals with the periods of all the task, enter the
; start delay and interval between the repeat of the tasks below
;
;***** **** */
;
;***** ****
; Scheduled Task Delay and Reload Values
;***** ****
cseg
SCH_Delay_Values:
    db    0x00      ; Delay value for Task 1
    db    0x00      ; Delay value for Task 2
    db    0x00      ; Delay value for Task 3
    db    0x00      ; Delay value for Task 4
    db    0x00      ; Delay value for Task 5
    db    0x00      ; Delay value for Task 6
    db    0x00      ; Delay value for Task 7
    db    0x00      ; Delay value for Task 8

SCH_Reload_Values:
    db    0x31      ; Reload value for Task 1
    db    0x00      ; Reload value for Task 2
    db    0x00      ; Reload value for Task 3
    db    0x00      ; Reload value for Task 4
    db    0x00      ; Reload value for Task 5
    db    0x00      ; Reload value for Task 6
    db    0x00      ; Reload value for Task 7
    db    0x00      ; Reload value for Task 8

;***** ****
; End of File
;***** ****

```

Listing 21 Scheduler task period definitions (file: TASK_PERIODS.IN)

```

; *****
;  Scheduled Tasks
; *****

; *****
;  Function:      LED_Flash
;  Description:   Flashes LED on port0 pin0 on and off
;  Pre:           None
;  Post:          None
; *****

TASK1:

LED_Flash:
    mov     A,LED_Status           ; is led on?
    jz      LED_on                ; no got turn it on
    clr     LED_PORT              ; turn off
    mov     LED_Status,#00         ; set status
    ajmp   SCH_Dispatch_Tasks_end

LED_on:
    setb   LED_PORT              ;turn LED on
    mov    LED_Status,#01          ;set status
    ajmp   SCH_Dispatch_Tasks_end ;Return from scheduled task

; *****
; End of File
; *****

```

Listing 22 Task1: Flashing LED (file: TASK1.ASM)

```

; *****
;  Scheduled Tasks
; *****

; *****
;  Function:
;  Description:
;  Pre:           None
;  Post:          None
; *****

TASK2:
    ajmp   SCH_Dispatch_Tasks_end ;Return from scheduled task

; *****
; End of File
; *****

```

Listing 23 Task2: Empty task file (file: TASK2.ASM - TASK8.ASM)

References and further reading

- Allworth, S.T. (1981) "An Introduction to Real-Time Software Design", Macmillan, London.
- Atmel (2002) "AVR Instruction Set",
http://www.atmel.com/dyn/resources/prod_documents/DOC0856.PDF
- Bate, I. (2000) "Introduction to scheduling and timing analysis", in "The Use of Ada in Real-Time Systems" (6 April, 2000). IEE Conference Publication 00/034.
- Cooling, J. (2003) "Software engineering for real-time systems", Addison-Wesley, UK
- Cullyer, W J, Goodenough, S J and Wichmann, B A "The choice of computer language for use in safety-critical systems," Software Engineering Journal, Vol. 6, No. 2, March 1991.
- Infineon (1997) "C515C 8-Bit CMOS Microcontroller User's Manual 11.97",
http://www.infineon.com/cgi/ecrm.dll/ecrm/scripts/public_download.jsp?oid=8031&parent_oid=13734
- Infineon (2000) "C500 Architecture and Instruction Set",
http://www.infineon.com/cgi/ecrm.dll/ecrm/scripts/public_download.jsp?oid=27537&parent_oid=-8136
- Kopetz, H. (1995) "The Time-Triggered Approach to Real-Time System Design", in Predictably Dependable Computing Systems, Springer, Berlin, 1995
- Microchip (1997) "PICmicro® Mid-Range MCU Family Reference Manual",
<http://www.microchip.com/download/lit/suppdoc/refernce/midrange/33023a.pdf>
- Nissanke, N. (1997) "Realtime Systems", Prentice-Hall.
- Pont, M.J. (2001) "Patterns for time-triggered embedded systems: Building reliable applications with the 8051 family of microcontrollers", ACM Press / Addison-Wesley, UK
- Pont, M.J. (2002) "Embedded C", Addison-Wesley, UK.
- Storey, N. (1996) "Safety-critical computer systems", Prentice Hall, UK
- Styger, E. "The Usage of C++ for 8 Bit, 16 Bit and 32 Bit MCU's Compared with C and Assembly", Embedded Systems Conference Europe in 1999 (Spring)
- Ward, N. J. (1991) "The static analysis of a safety-critical avionics control system", in Corbyn, D.E. and Bray, N. P. (Eds.) "Air Transport Safety: Proceedings of the Safety and Reliability Society Spring Conference, 1991" Published by SaRS, Ltd.