Getting Started with PEST

Zhulu Lin Dept. of Crop and Soil Sciences The University of Georgia, Athens, GA 30602 linzhulu@uga.edu

This note is by no means to try to replace the extensive PEST User's Manual (http://www.sspa.com/pest/) and Surface Water Utilities Manual (http://www.sspa.com/pest/utilities.html). It only serves as a rudimentary guide for PEST novices of using PEST as a parameter estimation tool. In order to use PEST more efficiently, one is encouraged to read those two manuals very carefully. PEST is a modelindependent parameter estimation program. It can be used to calibrate any model and conduct uncertainty analysis as long as the model reads in and prints out in ASCII format. But, in this note, we will only describe basic procedures of how to use PEST to calibrate SWAT model's parameters. Regularization parameter estimation, predictive uncertainty analysis and parameter sensitivity analysis are not included in this note. After setting up SWAT simulation run in BASINS or AVSWAT interface, copy the entire txtinout directory into your working directory and keep the original txtinout directory intact so that if anything goes wrong, you will have backups to restore the damaged model input files. PEST carry out all the calibration or uncertainty analysis tasks by itself, it normally takes a few hours depending on model's runtime and computer's speed. User's jobs involve (1) selecting adjustable parameters; (2) preparing initial and boundary values for the selected parameters; (3) preparing PEST files; and (4) running PEST and interpreting or utilizing PEST outputs. The first two tasks require the user's knowledge about the model and they are implicitly included the task of preparing PEST files.

1. Preparing PEST files

In order to run PEST properly, at least four types of file need to be provided: (1) model batch file; (2) model input template files; (3) model output reading instruction files; and (4) PEST control file. Figure 1 is a schematic diagram that shows how PEST works with a model to calibrate its parameters. PEST control file is a master file, which contains central information pertaining to PEST optimization algorithm, initial and boundary values of model parameters, observations that the model output is going to be calibrated against, and other information depending on the use of PEST. Although PEST control file is the most importance file, it is not difficult to prepare if TSPROC (Time Series Processor, a PEST utility program) is used to do such a job. We shall cover using TSPROC to prepare PEST control file later on. At each iteration of a PEST run, the PEST optimization algorithm (with Levenberg-Marquart method as its core) adjusts the values for model parameters to lessen the objective function's value. The newly updated model parameter values are then written to model input files using input template files. The process involves deleting the old set of model input files and generating a new set of

model input files using the input template files. Then the model (batch file) is called. If the model runs successfully, the model will generate a set of output files. The modelgenerated outputs in the model output files, which will be compared against the corresponding observations, are then read by PEST through using model output instruction file. At this stage, the objective function and Jacobian matrix are calculated, based on which the PEST will make its decision for next iteration until one of its stopping criteria is met. The stop criteria are specified in PEST control file as you may suspect.



Figure 1. Schematic diagram of PEST optimization process

1.1 Model batch file

Model batch file is simple. It can be as short as one line – the model DOS command. But if the model output files are not text format files; or you plan to use TSPROC as your model post-processor, the model batch file will get slightly longer, like in Example 1. The purpose of each command in Example 1 is briefly explained as follows. The first line of Example 1 (@echo off) is to tell the computer system not to display the commands while executing them. The second line (del basins.rch > nul) is to delete the SWAT output file basins.rch that has been generated by previous modeling run. If it had not been deleted, even though the following SWAT run is not successful, PEST would still have read model outputs from the existing basins.rch file, which obviously should be avoided. The suffix of the second line (> nul) is to suppress the deleting command to be displayed in screen so that the messages issued by ysstem commands (or model) will not interfered with the messages issued by PEST. The third line is a SWAT model command line. The fourth line is a short Fortran program I coded to convert partial information contained in the SWAT basins.rch file to a Site Sample File (SSF), a file format that the TSPROC can read. The information of what water quantity or quality time series (e.g., FLOW_OUT) in what reach segment (e.g., Reach 6) will be converted is provided in rch2ssf.dat file. The fifth line shows that TSPROC is used as model post-processor, which is almost a standard when using PEST to calibrate a surface water model. Otherwise, the task of preparing model output reading instruction files (see above) is insurmountable. Example 1 is a simplest version of model batch file for SWAT automatic calibration. We suppose it has been given a file name called swat.bat. Batch file name must have .bat as its extension name. A few lines may be added in front of SWAT model command to serve as a model pre-processor (for example, par2par par2par.dat > nul). To know more information about batch files, please go to website <u>http://www.computerhope.com/batch.htm</u>.

```
1 @echo off
2 del basins.rch > nul
3 swat2000 > nul
4 rch2ssf rch2ssf.dat
5 tsproc < tsproc.in > nul
```

Example 1. Model batch file for SWAT calibration (The numbers in left column are line labels; they are not contained in the model batch file)

1.2 SWAT input template files

Usually, it is easy to prepare a model input template file. But, since SWAT requires hundreds of input files, this job could become very tedious and error-prone. Before you start to edit input template files, you should have decided what model parameters you want PEST to calibrate. Then you need to find out which model input file contains the tobe-calibrated parameters and to build the corresponding template file based on that model input file. For example, if I want to calibrate CN2 parameter in all .mgt (management) files¹, then I carry out the following steps for each .mgt file:

Step 1: use any text editor, such as Notepad, Wordpad, or NoteTab (www.notetab.com) to open a .mgt file; Example 2 is the .mgt file for the first HRU in the first sub-basin (i.e., 000010001). Notice that this .mgt file only contains planting and havest/kill operations.

```
0
             2
                    3
                           4
                                  5
                                         6
      1
.mgt file Subbasin:1 HRU:1 Luse:PAST Soil:GA028 Fri Apr 23 15:42:28 2004
0 1
   0
      0 0.00 0.00 0.00 0.00
                                 0.2074.00000
                                            1.00
             11904.348 12 0.000
                             0.000
                                   0.000
                                          0.000 0.000
       0.150
       1.200
             5
                                              0.000
```

Example 2. 000010001.mgt file for HRU 000010001 (The first two lines contain column labels; they are not actual lines in .mgt file which should begin with ".mgt file ..." in third line).

¹ In this note, SWAT model is treated as a lumped model. That is, all model parameters in different subbasins or HRU's take same values across entire watershed except those topographic and morphologic parameters such as area, length, slope, depth, etc.

Step 2: Save the opened .mgt file as mgt010001.tpl file. The extension .tpl stands for PEST template file, which is mandated. That is to say, all PEST template files must have .tpl as their extension names. But the first three letters that replaced the first three zeros in the file name are arbitrary. They can be any other combination of letters or numbers. They even can be three zeros. But I used "mgt" to tell myself that these .tpl files are template files for .mgt SWAT input files so that they can be easily distinguished from any other .tpl files such as template files for .hru SWAT input files, etc. It is worth reiterating that preparing template files for SWAT input files is a very tedious work since SWAT reads too many input files². If you want to automatically calibrate hydrology and water quality in the same time, you almost need to go through all the SWAT input files, which could be more than several hundreds. Therefore, the following two advices may be helpful: First, at the stages of watershed delineation and HRU distribution, keep the number of sub-basins and HRU's as small as possible. The total SWAT input files is approximately equal to $8 + 6 \times$ (the number of subbasins) + 5 \times (the number of HRU's). Second, start with a simple problem with less than five adjustable parameters; then progress to a more sophisticate problem step by step.

Step 3: Insert one line in the beginning of the newly saved (mgt010001).mgt file. The line added is as simple as follows:

12345 ptf #

It merely contains 5 characters – ptf, which stands for PEST Template File, followed by a space (blank), which, in turn, followed by a special character. This special character can be any other ASCII character such as #, \$, etc, as long as it is so special that it is not used by the pre-existing model input file. This simple rule should be followed strictly.

Step 4: Change the parameter value for CN2 that you wanted to calibrate to a string that is delimited by the special character you specified in the inserted first line. For example, in our mgt010001.mgt file, the parameter value for CN2 is 74.00000 in line 2 (highlighted in pink color). You need to change it to #cn2 # as shown in Example 3.

```
0
             2
                           4
                                  5
      1
                    3
                                         6
ptf #
.mgt file Subbasin:1 HRU:1 Luse:PAST Soil:GA028 Fri Apr 23 15:42:28 2004
                    0.00 0.00 0.20#cn2 #
0 1 0
      0 0.00
               0.00
                                            1.00
       0.150
             11904.348 12
                       0.000
                            0.000
                                   0.000
                                          0.000 0.000
       1.200
             5
                                              0.000
```

Example 3. mgt010001.mgt file for HRU 000010001

² If a SWAT input interface developed by Jing Yang (jing.yang@eawag.ch) in Swiss Federal Institute for Environmental Science and Technology (EAWAG) is used, the task of preparing the SWAT input template file will become very easy. Only one input template file is needed. How to use the SWAT input interface will be briefly discussed in the note entitled "Running SWAT in A Breeze".

In this step, there are two places that need special attention. First, if the model input file adopts fix format rather than free format for model parameter values, you should consult SWAT User's Manual to find out how many and what spaces are reserved for your parameter of interest. For example, in .mgt file, SWAT uses fix format. In page 192 of SWAT User's Manual, it's been specified that CN2 parameter takes the value from Columns 53 to 60 in Line 2. Therefore, in the corresponding PEST input template file, the to-be-calibrated parameter's name (cn2) plus the two delimiters (#) should not be placed outside the specified spaces (Columns 53-60 in Line 2). But, if the input file takes free format, the absolute position for model parameters is not critical, as long as they are separated by standard delimiters such as spaces, commas, tabs etc. Second, since PEST employs finite-definite methods to calculate Jacobian matrix, it is important to have high precisions for both model outputs and model parameters. Therefore, the reserved spaces for adjustable parameters in PEST input template file should be as longer as possible. I normally use 12-16 spaces for free-format parameters, and use all allowable spaces for fix format parameters. Please note that the parameter spaces include parameter names, two special characters, and the white spaces that are used to fill the rest of reserved parameter spaces. It is important to use white spaces (blanks) rather than tabs to fill the vacancies. If tabs are used, PEST will issue error messages.

1.3 Model output reading instruction files

As briefly discussed above, model output reading instruction files are used by PEST to read, through model output files, the model-generated outputs that will be compared against measured observations. They should be constructed based on model output files (in ASCII text format); and their preparation could be very time-consuming if there are many observations you want to incorporate in the automatic calibration process. For example, if you want to calibrate 10-year SWAT model-generated daily flows against 10year daily flow observations, you will have to write an instruction file with more than 3650 lines. But if you use TSPROC as model postprocessor, the task of preparing model output reading instruction files is trivial. You don't even have to care about preparing instruction files. All you need is to ask TSPROC to prepare them for you. TSPROC has multiple purposes. It can be used not only as a model postprocessor, but also as a tool to automatically generate instruction files and PEST control file. The usage of TSPROC will be discussed later. It is important to note that the extension name for all model output reading instruction files has to be .ins and that all instruction file must begin with pif and a special character letter as its first line as shown below. As in model input template files, pif standards for PEST Instruction File. The special letter (e.g., #, \$, etc) may not be used in the file but has to be present.

12345 pif #

1.4 PEST control file

As for model output reading instruction files, PEST control file may be prepared using TSPROC program. Because all observations will be included in the PEST control file, if there are more than scores of measured data, TSPROC will inevitably be used for preparing PEST control file. Unlike model input template files and model output reading instruction files, which can be many, there is only one PEST control file for one PEST run. The PEST control file must begin with pcf as its first line (guess what pcf stands for!). Example 4 displayed a basic PEST control file. A basic PEST control file is designed for the purpose of simple parameter estimation only. In other words, it does not include any prior information, or employ Tikhonov or singular value decomposition (SVD) regularization methods, or SVD-assist scheme in automatic parameter estimation of the contents of such a file is presented in the following paragraphs.

With the exclusion of first line, this PEST control file consists of 7 zones, with each zone starting with an asterisk (*) followed by a space (blank) and zone name. The first zone is "control data" zone. The first line in this zone (i.e., Line 3) only has two control variables. In this file, it is shown that the values for these two control variables are "norestart" and "estimation", respectively. The first variable tells PEST that you want to turn off the restart function so that PEST will not generate some output files that are used for restarting. The alternative value is "restart". I usually use "norestart". The second variable in this line tells PEST to run parameter estimation, rather than regularization or predictive analysis, for which the variable value should be "regularisation" or "prediction". In this note, we only use PEST for parameter estimation.

Line 4 has 5 variables. The variable in Column 1 (C1) is the number of all parameters listed in "parameter data" zone; therefore its value should be equal to the number of lines in "parameter data" zone. The variable in Column 2 (C2) is the number of all observations listed in "observation data" zone; therefore, its value should be equal to the number of lines in "observation data" zone. The variable in Column 3 (C3) is the number of all parameter groups listed in "parameter groups" zone; therefore, its value should be equal to the number of lines in "parameter groups" zone; therefore, its value should be equal to the number of lines in "parameter groups" zone. The variable in Column 4 (C4) is the number of all prior information incorporated in parameter estimation process, which should be listed in "prior information" zone, if there is any. Since we will not use any prior information, therefore its value is always zero. Otherwise, its value is equal to the number of lines in "prior information" zone (not shown in Example 4). The variable in Column 5 (C5) is the number of all observation groups listed in "observation group" zone; therefore, its value should be equal to the number of all observation groups listed in "observation group" zone; therefore, its value should be equal to the number of lines in "prior information" zone (not shown in Example 4). The variable

Line 5 consists of 7 variables. The variable in Column 1 (C1) is the number of pairs of model input template files and their corresponding model input files; and the variable in Column 2 (C2) is the number of pairs of model output reading instruction files and the corresponding model output files; therefore, the sum of the values of these two variables

should be equal to the number of lines in "model input/output" zone. Don't worry about the rest of variables in this line, just leave what they are.

Don't worry about the rest of variables in this zone, except for the first variable (C1) in Line 9. Each variable in Line 9 is a stopping criterion. When any one of these criteria has been met, PEST will stop the parameter estimation process and write its estimation results into several files. The first variable is the maximum number of iterations that a PEST run is allowed. Usually 30 iterations are sufficient for any PEST run. But there are a couple of other options that have special meanings. If this variable is set to zero, the PEST only requests one model run³ using the initial (default) parameter values. Then it calculates the value of objective function and writes PEST output files. Usually, after I've finished composing all files that are needed for running PEST, I then set this variable to be zero and run PEST control file once before being engaged in a full PEST optimization process. If this variable is set to minus one (-1), PEST will terminate execution immediately after it has calculated the Jacobian matrix for the first time. Since Jacobian matrix has been calculated, PEST output files may contain more information about your estimation problem in the neighborhood of initial condition. For example, you may be able to obtain parameter variance-covariance or correlation coefficient matrices in the locality of initial condition if $\mathbf{J}^T \mathbf{J}$ is not singular. The parameter sensitivities will also be written to the sensitivity file.

Next two zones are "parameter groups" and "parameter data". It is easier to understand why PEST control file contains "parameter data" (i.e., data about parameters) since we at least need provide PEST with information such as what parameters are to be estimated by PEST; what their initial values are, and what their lower and upper boundaries are, etc. The parameter names are listed in C1 of "parameter data" zone. Their initial values are listed in C4 while lower and upper boundary values are listed in C5 and C6 respectively. If you want PEST to find a best (optimal) value for a parameter, you should assign "none" or "log" to C2 for that parameter, otherwise assign "fixed" or "tied". I suggest you use "none" or "fixed" only and refer PEST User's Manual if you want to try "log" and "tied". For C3, I always fill it with "factor" unless one of the following two situations occurred: 1) One of the initial, lower or upper boundary values is zero; (2) lower and upper boundary values have opposite signs. For example, in Line 20, initial value for parameter "awc" is "0"; and its lower bounds is less than zero while its upper bounds is greater than zero. Hence, I used "relative" for "awc" in C3. You may always assign "1.0" for C8, "0.0" for C9, and "1" for C10. Don't worry about what they mean by now. The string values for C7 are the names from "parameter groups". Each parameter should be assigned to one parameter group. And one parameter group must have at least one parameter assigned. Therefore, the number of parameter groups is less or equal to the number of parameters.

³ Please note the difference between PEST run, iterations and model runs. A PEST run means that PEST is used to estimate model parameters. An (optimization) iteration means that PEST has found a best λ , then PEST updated model parameter values, run the model once, and updated (reduced) the objective function. A model run means that the model has been run once. In one PEST run, the number of iterations is usually substantially less than the number of runs since in each iteration it requires many model runs to find a best λ , which will result in the most efficient objective function.

In contrast, it is not very easy to understand why PEST requires all the parameters be classified into different parameter groups. The classification of parameters into groups is for the purpose of calculation of derivatives (Jacobian matrix). Actually, if you wish, you can define a unique group for each individual parameter and set the derivative variables for each parameter separately. But in many cases, parameters fall nicely into different groups which can be treated similarly in terms of calculating derivatives so as to save time for you. In calculating derivatives, PEST uses 2-point forward-difference or 3-point central-difference numerical methods. The former is less accurate but requires less model runs, while the latter is more accurate with more model runs. Therefore, normally, we adopt a composite strategy – using 2-piont method in the beginning and then switching to 3-point method when parameter values are getting close to the optimal ones. In C6-7, the string value "switch" means that we are using this very composite strategy. The other two alternatives are "always_2" and "always_3". The following two derivative variables are relevant to 3-point methods. I respectively use "2" and "parabolic" for them.

In addition to this, there is other information we should provide PEST with regard to how to increment parameter values in order to calculate their derivatives. First option you have to face is HOW to increase a parameter's value – increasing relatively based on parameter's current value or increasing by an absolute amount. I normally use "relative" in C3 to increase parameter values relatively. The other two options are "absolute" and "rel to max". The meaning of the variable's value in C4 depends on what value in C3. If C3 is "relative", the increment used for forward-difference calculation of derivatives with respect to any parameter belonging to the group is calculated as a fraction of the current value of that parameter; that fraction is provided as the real variable in C4. However, if C3 is "absolute" the parameter increment for parameters belonging to the group is fixed, being again provided as the variable in C4. Alternatively, if C3 is "rel to max", the increment for any group member is calculated as a fraction of the group member with highest absolute value, that fraction again being the variable in C4. If a parameter increment is calculated as "relative" or "rel to max", it is possible that it may become too low if the parameter becomes very small. If a parameter increment becomes too low, it does not allow reliable derivatives to be calculated with respect to that parameter because of round-off errors incurred in the subtraction of nearly equal model-generated values. To circumvent this possibility, an absolute lower bound can be placed on parameter increments; this lower bound will be the same for all group members, and is provided as that variable in C5. Note that if C3 is "absolute", the value in C5 is ignored.

I usually like to classify the parameter into different groups in terms of their magnitudes. For example, if parameters are kinetic reaction coefficients, they are usually less than one; but if parameters are concentrations, they are normally larger than one. Therefore, I put all parameters that are less than one into one group, say "leone", and those that are greater than one but less than ten into another group, say "leten", etc. Then, I like to increase parameters by an absolute amount for group "leone"; and increase parameter by a relative amount for the rest of groups. Variables C4 are set according to the average magnitudes of the parameters in that group. I usually use "0.001" for C5. If you have a very wide range of parameter values, you should pay more attention to assign values for

C4 and C5. It is wise to use PESTCHEK to check for this type of errors before you run PEST (PESTCHEK will be discussed in the other PEST utilities section).

The next two zones – "observation groups" and "observation data" – are related to observations (measured data). The sum of squares of the weighted mismatches between these observations and model-generated counterparts will usually be defined as the objective function that PEST is trying to minimize. If you want to calibrate stream discharges and water quality altogether, the components of the objective function could be diverse. For example, we want to calibrate flow, sediment and total phosphorus concentrations simultaneously. The values of flow rate are usually much larger than those of the total phosphorus concentration (in mg/l); and the measured points for flow are a lot more than those of sediment or total phosphorus concentrations. If you did not differentiate them in the objective function, PEST may not pay any respect to the mismatches from water quality components because both the number of measurement and magnitudes of the flow component dominate the total objective function. Therefore, we need divide the observations into different groups, for example, "mflow", "mtss", and "mtp", which are listed in "observation groups". Then assign each individual observation to an observation group in C4 of the "observation data" zone. The name for each observation should be unique but could be anything as long as it is a string of character and number's combination with a length of 12 at most. The observation names are listed in C1 and the observed values are listed in C2. Values in C3 are weights that you assigned to the observations. The weight for each observation could be different such as those in group "mflow"; or all weights for the observations in an observation group could be the same such as those in groups "mtss" and "mtp". The weights are determined so that the sum of squares from one observation group should be approximately equal to that from any other observation group. The sum of squares that contributes to the total objective function from each observation group will be printed out to screen (and PEST run record file) along with the total objective function. Before you run a formal PEST optimization, adjust the weights for different observations to make sure that the contributions to the total objective function from all different observation groups are approximately equal. Relevant discussions have been given in the early of this section on setting the variable in C1 of Line 9 to zero to do this job; while how to adjust weights for observations will be discussed in TSPROC data file section.

The sixth zone is the simplest one called "model command line". It only contains one line with the model batch file's name (swat.bat is shown in Example 1). The last zone is "model input/output". Each line in this zone lists either a pair of model input template file (C1-C2) with correspondent model input file (C3-C4), or a pair of model output reading instruction file (C1-C2) with correspondent model output file (C3-C4). In this example, Lines 44-49 are model input file pairs while Line 50 is a model output file pair. Chapter 4 in PEST User's Manual can be referred to understand PEST control file more extensively.

Ln	C1	C2	C3	C4	C5	C6	C7	C8	C9	C10
1	pci * control	data								
∠ २	norestart	uala	a estimation							
4	8	950	3	0	3					
5	50	1	single	Ū.	point	1	0	0		
6	5.0	2.0	0.3	0.03	10					
7	5.0	5.0	0.001							
8	0.1	aui								
9	30	0.005	4	4	0.005	4				
10	1	1	1							
11	* paramete	er group	S							
12	leone	leone absolute 0.001 .001 switch				2	parab	olic		
13	leten	relativ	e	0.01	.001	switc	h	2	parab	olic
14	lehun	relativ	e	0.1	.001	switc	h	2	parab	olic
15	* paramet	er data	с ,	4 0	0 0	0 0	- .	1 0	0 0	1
10 17	surlg	none	factor	4.0	2.0	8.0	leten	1.0	0.0	1
⊥/ 10	CIIZ	none	factor	70.0	55.U 0 01	80.0 0 6	leenun	1.0	0.0	1
10 10	0000	none	factor	0.14		1 0	loono	1.0	0.0	⊥ 1
20	awc	none	relative	0.95	-0.1	1.0	leone	1 0	0.0	⊥ 1
20	alphabf	none	factor	0.0	0 01	0.1	leone	1.0	0.0	1 1
22	slope	fixed	factor	0.10	0.001	0.3	leone	1.0	0.0	1
23	slsbsn	fixed	factor	60.0	40.0	90.0	lehun	1.0	0.0	1
24	* observa	tion gro	ups							
25	mflow	-	-							
26	mtss									
27	mtp									
28	* observa	tion dat	a							
29	mflow1	41.06	0.0312	mflow						
30	mflow2	57.49	0.0264	mflow						
31		•••								
32	m±low900	44.75	0.0990	m±⊥ow						
33	mtss1	12.5	150.0	mtss						
34 25	mtss2	40.8	150.0	mtss						
36	••• mtgg25	••• 100 3	150 0	 mtgg						
37	mtp 1	0 02	200 0	mtp						
38	mtp 2	0.01	200.0	mtp						
39			200.0							
40	mtp 25	0.90	200.0	mtp						
41	* model co	ommand l	ine	÷						
42	swat.bat									
43	* model input/output									
44	mgt010001.tpl 000010001.mgt									
45	mgt010002.tpl 000010002.mgt									
46		_		_						
47	hru010001	.tpl	000010001	.hru						
48										
49 50	par_par.t	ing ing	parzpar.d	at tvt						
50	moderout.	T112	moderout.	LĂL						

Example 4. A basic PEST control file

1.5 Parameter group file and parameter data file

In order to use TSPROC to automatically prepare a PEST control file, two more files should be provided – parameter group file and parameter data file. The parameter group file contains the same information with the same format as those in the "parameter groups" zone in the PEST control file. When TSPROC is asked to write PEST control file, it simply copies all information in the parameter group file into "parameter groups" zone in the PEST control file. For example, in order to write a PEST control file shown in Example 4, a parameter group file named parmgrp.dat (can be any name) must look like the following (Example 5).

leone	absolute	0.001	0.001	switch	2	parabolic
leten	relative	0.01	0.001	switch	2	parabolic
lehun	relative	0.1	0.001	switch	2	parabolic

Example 5. A parameter group file

Meanwhile, a parameter data file should also be provided in order to use TSPROC to prepare a PEST control file. As for parameter group file, the parameter data file contains the same information and the same format as those in the "parameter data" zone in the PEST control file, except that in the parameter data file, the one's in the last column in the "parameter data" zone are omitted. For example, the parameter data file named as parmdata.dat (can be any name) used for preparing the PEST control file shown in Example 4 should look like the following (Example 6).

surlg	none	factor	4.0	2.0	8.0	leten	1.0	0.0
cn2	none	factor	70.0	55.0	80.0	lehun	1.0	0.0
ovn	none	factor	0.14	0.01	0.6	leone	1.0	0.0
esco	none	factor	0.95	0.01	1.0	leone	1.0	0.0
awc	none	relative	0.0	-0.1	0.1	leone	1.0	0.0
alphabf	none	factor	0.048	0.01	0.3	leone	1.0	0.0
slope	fixed	factor	0.10	0.001	0.3	leone	1.0	0.0
slsbsn	fixed	factor	60.0	40.0	90.0	lehun	1.0	0.0

Example 6. A parameter data file

1.6 TSPROC data file

TSPROC is a very useful time series processing tool. Even if it is not used for PEST optimization, it can also be used for some other basic time series computations. However, I must admit that it is not an easy task to describe the usage of TSPROC clearly in a short length. The Surface Water Utilities User's Manual should always be referred when detail information is needed with regard to constructing TSPROC blocks in TSPROC data file. But, it is simple to use TSPROC in DOS command line. At DOS command prompt, write the following line:

tsproc < tsproc.in

The tsproc before "<" is the TSPROC command, while tsproc.in behind "<" is TSPROC input file, which is usually contains two or four lines depending on what purpose TSPROC is serving. Note that the TSPROC *input* file is different from TSPROC *data* file. Actually, the former contains the latter. The names for the TSPROC file could be any legitimate file names. For convenience, I usually name it as tsproc.in. In terms of using it for PEST optimization, TSPROC has two usages: 1) being used as a model post-processor; 2) being used to prepare PEST control file and model output reading instruction file when TSPROC is used as a model post-processor. If TSPROC is used as a model post-processor, tsproc.in should have four lines as shown in Example 7.

tsproc.tsp tsproc.rec n n

Example 7. A typical TSPROC input file as TSPROC serving as postprocessor

The first line contains a TSPROC data file, which is the essence of TSPROC input file; while the second line contains a TSPROC record file, which records some information when TSPROC is processing TSPROC data file, for example, tsproc.tsp. But I never looked at it. The last two lines are two n's. They are answers for two potential TSPROC prompting questions. However, if TSPROC is used to prepare a PEST control file, tsproc.in only has to have the previous two lines shown in Example 7. Had any questions been prompted for answers, you normally will answer them with "y"⁴. However, this is not the only difference between the two TSPROC input files (tsproc.in). Instead, the major difference comes from what it is contained in the TSPROC data file (tsproc.tsp). How to construct such a TSPROC data file will become the major topic of the following paragraphs.

1.6.1 TSPROC data file for model post-processor

An example of TSPROC data file used as model post-processor is shown in Example 9. This simple TSPROC data file contains 10 blocks, each with a similar format. For each block, first line begins with key word START followed by a space which in turn is followed by the block's name; while the last line begin with key word END followed by a space which again is followed by the block's name. Usually, from the name of block you can tell which task the block is designed for. Each block with different name has different task; and it has different key words within the block. There are 21 different blocks available for 21 different tasks. Please go to the Surface Water Utilities User's Manual for their references. But all blocks have one common key word – CONTEXT, which is always the second key word in the block. This CONTEXT statement (CONTEXT followed by a space and a string variable) serves like an on/off switch. The CONTEXT statement in SETTINGS block determines the "theme" of the entire TSPROC data file (for example,

⁴ Don't worry about what kind of questions they are so far. We'll come back for this.

in tsproc.tsp file). For each of the following blocks, if the string variable in the CONTEXT statement is the same as the string variable in the CONTEXT statement in the SETTINGS block, then the block is on, which means its specified task will be processed by TSPROC and will be accomplished. While if the string variable in the CONTEXT statement is different from the string variable in the CONTEXT statement in the SETTINGS block, then the tasks specified in this block will not be executed.. For this reason, it should be noted that SETTINGS block always has to be the first block in a TSPROC data file and only one CONTEXT can be specified at one time. But if the string variable in the CONTEXT statement of a block is "all", then that block will always be executed regardless what is in the CONTEXT statement in the SETTINGS block. For example, Block 10 in Example 9 will always be executed.

If a line in the TSPROC data file begins with "#" then the line is a comment line that will not be processed by TSPROC. You should always set DATE_FORMAT to mm/dd/yyyy as shown in Example 9. The files FLOW_OUT.ssf, SEDCONC.ssf, MINP_OUT.ssf and ORGP_OUT.ssf in Blocks 2-5 are so-called Sample Site Files. The time series contained in these files were converted from basins.rch file (a SWAT output file) through using a short Fortran program – RCH2SSF whose usages will be covered in the other PEST utilities section. A typical Sample Site Files is shown in Example 8. In brief, the task that has been achieved by this TSPROC data file (Example 9) is to convert all these four Sample Site Files into modelout.txt file that is written in Block 10. Therefore, this TSPROC data file is used as model post-processor. Based on this generated modelout.txt, a TSPROC data file, which will serve to prepare the PEST control file, can write a model output instruction file automatically.

REACH06	01/01/1985	00:00:00	0.708103E+01
REACH06	01/02/1985	00:00:00	0.123626E+02
REACH06	01/03/1985	00:00:00	0.475176E+02
REACH06	01/04/1985	00:00:00	0.818826E+02
REACH06	01/05/1985	00:00:00	0.105300E+03
REACH06	01/06/1985	00:00:00	0.679745E+02
REACH06	01/07/1985	00:00:00	0.697458E+02
REACH06	01/08/1985	00:00:00	0.359467E+02
REACH06	01/09/1985	00:00:00	0.360293E+02

Example 8. A typical Sample Site File

Block 1
START SETTINGS
 CONTEXT model_post
 DATE_FORMAT mm/dd/yyyy
END SETTINGS
Block 2
START GET_SERIES_SSF
 CONTEXT model_post
 FILE FLOW_OUT.ssf
 SITE reach06
 NEW_SERIES_NAME mflow
 DATE_1 01/01/1983

TIME_1 00:00:00 DATE_2 12/31/1992 TIME_2 00:00:00 END GET_SERIES_SSF # Block 3 START GET_SERIES_SSF CONTEXT model_post FILE SEDCONC.ssf SITE reach06 NEW_SERIES_NAME mtss1 END GET_SERIES_SSF # Block 4 START GET_SERIES_SSF CONTEXT model_post FILE MINP_OUT.ssf SITE reach06 NEW_SERIES_NAME minp1 END GET_SERIES_SSF # Block 5 START GET_SERIES_SSF CONTEXT model_post FILE ORGP_OUT.ssf SITE reach06 NEW_SERIES_NAME orgp1 END GET_SERIES_SSF # Block 6 START NEW_TIME_BASE CONTEXT model_post SERIES_NAME mtss1 TB_SERIES_NAME mflow NEW_SERIES_NAME mtss END NEW_TIME_BASE # Block 7 START NEW_TIME_BASE CONTEXT model_post SERIES_NAME minp1 TB_SERIES_NAME mflow NEW_SERIES_NAME minp END NEW_TIME_BASE # Block 8 START NEW_TIME_BASE CONTEXT model_post SERIES_NAME orgp1 TB_SERIES_NAME mflow NEW_SERIES_NAME orgp END NEW_TIME_BASE # Block 9 START SERIES_EQUATION CONTEXT model_post NEW_SERIES_NAME mtp EQUATION 0.01157 * (minp + orgp) / (mflow + 0.001) END SERIES_EQUATION # Block 10 START LIST_OUTPUT CONTEXT all

```
FILE modelout.txt
SERIES_NAME mflow
SERIES_NAME mtss
SERIES_NAME mtp
SERIES_FORMAT short
END LIST_OUTPUT
```

Example 9. A simple TSPROC data file for model post-processor

1.6.2 TSPROC data file for preparing PEST control file

An example of TSPROC data file used for PEST control file preparation is shown in Example 10. Blocks 1-9 in Example 10 have the same function of those blocks in Example 9 – reading model-generated outputs from the Sample Site Files (FLOW_OUT.ssf, SEDCONC.ssf, MINP_OUT.ssf, and ORGP_OUT.ssf). Blocks 10-12 read observed stream flow, sediment and total phosphorus concentration data at Canton, GA. These observations had also been stored in Sample Site File format. In general, water quality parameters are observed once a month or once two months, while the model outputs are in daily frequency. Therefore, Blocks 13-15 are used to match the model-generated time series with the observed time series in one-to-one mapping. Note that, Block 16 in Example 10 is slightly different from Block 10 in Example 9. The former only prints out the model-generated time series at the dates when the corresponding flow or water quality parameters have been observed.

Immediately following the LIST_OUTPUT block, it is WRITE_PEST_FILES block which will generate PEST control file and model output instruction file based on the supplied information. It should be reiterated that the WRITE PEST FILES block must immediately follow LIST_OUTPUT block that generates the model output file. The first two statements behind the CONTEXT statement produce PEST control file that is named as etowah.pst and model output reading instruction file that is named as modelout.ins. The next three statements supply parameter group file, parameter data file, and model batch file that have been discussed (prepared) before. These files contain the information needed in the zones of "parameter groups", "parameter data", and "model command line" in a PEST control file. Similarly, in the subsequent lines, the pairs of model input template files and model input files have been provided to write information in the "model input/output" zone; while the information supplied in the next three subblocks will be used to write the zones of "observation groups" and "observation data". The information needed to write the "control data" zone will be either calculated from the existing data or using default values. It should be mentioned that if the any of the two tobe-generated files already exist in the current directory, one or both of the following questions will be prompted to answer. Type "y" or "n" to proceed.

Question 1: File modelout.ins already exist. Overwrite it? [y/n]

Question 2: File etowah.pst already exist. Overwrite it? [y/n]

```
# Block 1
START SETTINGS
   CONTEXT pest_prep
   DATE_FORMAT mm/dd/yyyy
END SETTINGS
# Block 2
START GET_SERIES_SSF
   CONTEXT pest_prep
   FILE FLOW_OUT.ssf
   SITE reach06
   NEW_SERIES_NAME mflow
   DATE_1 01/01/1983
   TIME_1 00:00:00
   DATE_2 12/31/1992
   TIME_2 00:00:00
END GET_SERIES_SSF
# Block 3
START GET_SERIES_SSF
   CONTEXT pest_prep
   FILE SEDCONC.ssf
   SITE reach06
   NEW_SERIES_NAME mtss1
END GET_SERIES_SSF
# Block 4
START GET_SERIES_SSF
   CONTEXT pest_prep
   FILE MINP_OUT.ssf
   SITE reach06
   NEW_SERIES_NAME minpl
END GET_SERIES_SSF
# Block 5
START GET_SERIES_SSF
   CONTEXT pest_prep
   FILE ORGP_OUT.ssf
   SITE reach06
   NEW_SERIES_NAME orgp1
END GET_SERIES_SSF
# Block 6
START NEW_TIME_BASE
   CONTEXT pest_prep
   SERIES_NAME mtss1
   TB_SERIES_NAME mflow
   NEW_SERIES_NAME mtss
END NEW_TIME_BASE
# Block 7
START NEW TIME BASE
   CONTEXT pest_prep
   SERIES_NAME minpl
   TB_SERIES_NAME mflow
   NEW_SERIES_NAME minp
END NEW_TIME_BASE
# Block 8
START NEW_TIME_BASE
   CONTEXT pest_prep
   SERIES_NAME orgp1
   TB_SERIES_NAME mflow
```

```
NEW_SERIES_NAME orgp
END NEW_TIME_BASE
# Block 9
START SERIES_EQUATION
   CONTEXT pest_prep
   NEW_SERIES_NAME mtp
   EQUATION 0.01157 * (minp + orgp) / (mflow + 0.001)
END SERIES_EQUATION
# Block 10
START GET_SERIES_SSF
   CONTEXT pest_prep
   FILE canton_FLOW.ssf
   SITE Canton
   NEW_SERIES_NAME oflow1
END GET_SERIES_SSF
# Block 11
START GET_SERIES_SSF
   CONTEXT pest_prep
   FILE Canton_SS.ssf
   SITE Canton
   NEW_SERIES_NAME otss
   DATE_1 10/15/1983
   TIME_1 00:00:00
   DATE_2 12/21/1992
   TIME_2 00:00:00
END GET_SERIES_SSF
# Block 12
START GET_SERIES_SSF
   CONTEXT pest_prep
   FILE Canton_TP.ssf
   SITE Canton
   NEW_SERIES_NAME otp
   DATE_1 1/25/1983
   TIME_1 00:00:00
   DATE_2 12/21/1992
   TIME_2 00:00:00
END GET_SERIES_SSF
# Block 13
START NEW_TIME_BASE
   CONTEXT pest_prep
   SERIES_NAME oflow1
   TB_SERIES_NAME mflow
   NEW_SERIES_NAME oflow
END NEW_TIME_BASE
# Block 14
START NEW TIME BASE
   CONTEXT pest_prep
   SERIES_NAME mtss1
   TB_SERIES_NAME otss
   NEW_SERIES_NAME mtsso
END NEW_TIME_BASE
# Block 15
START NEW_TIME_BASE
   CONTEXT pest_prep
   SERIES_NAME mtpl
   TB_SERIES_NAME otp
```

```
NEW_SERIES_NAME mtpo
END NEW_TIME_BASE
# Block 16
START LIST_OUTPUT
   CONTEXT pest_prep
   FILE modelout.txt
   SERIES NAME mflow
   SERIES_NAME mtsso
   SERIES_NAME mtpo
   SERIES_FORMAT short
END LIST_OUTPUT
# Block 17
START WRITE_PEST_FILES
   CONTEXT pest_prep
   NEW_PEST_CONTROL_FILE etowah.pst
   NEW_INSTRUCTION_FILE modelout.ins
# Information pertaining to general files.
   PARAMETER_GROUP_FILE parmgrp.dat
   PARAMETER_DATA_FILE parmdata.dat
   MODEL_COMMAND_LINE swat.bat
# Information pertaining to template and model input files.
   TEMPLATE_FILE mgt010001.tpl
   MODEL_INPUT_FILE 000010001.mgt
   TEMPLATE_FILE mgt010002.tpl
   MODEL_INPUT_FILE 000010002.mgt
   TEMPLATE_FILE hru010001.tpl
   MODEL_INPUT_FILE 000010001.dat
   . . . . . . . . . . . . .
   TEMPLATE_FILE par2par.tpl
   MODEL_INPUT_FILE par2par.dat
# Information pertaining to flow time series.
   OBSERVATION_SERIES_NAME oflow
   MODEL_SERIES_NAME mflowb
   SERIES_WEIGHTS_EQUATION 1.5 / (@_abs_value+0.0001)
   SERIES_WEIGHTS_MIN_MAX 1e-4 1e+4
# Information pertaining to sediment time series.
   OBSERVATION_SERIES_NAME otss
   MODEL_SERIES_NAME mtss
   SERIES_WEIGHTS_EQUATION 0.1
# Information pertaining to phosphorus time series.
   OBSERVATION_SERIES_NAME otp
   MODEL SERIES NAME mtp
   SERIES_WEIGHTS_EQUATION 50
END WRITE_PEST_FILES
```

Example 10. A simple TSPROC data file for PEST files preparation

A vigilant reader will find that Example 9 and Example 10 have many blocks in common. It is possible to use only one TSPROC data file (tsproc.tsp) to carry out two tasks – being a model post-processor and preparing PEST files. Actually this is the very reason why each block has a CONTEXT statement in the previous examples. The two files can be combined together with a little modification to serve both tasks with the aide of CONTEXT statement. The combined TSPROC data file is shown Example 11. Only one CONTEXT statement is allowed in one block, therefore, the other CONTEXT statement should be commented out when the TSPROC data file is used to conduct one specific

task. It should be noted that TSPROC is not limited to these two tasks. I also used it to separate base flow from storm flow, compare two time series, etc.

Block 1 START SETTINGS CONTEXT pest_prep # CONTEXT model_post DATE_FORMAT mm/dd/yyyy END SETTINGS # Block 2 START GET_SERIES_SSF CONTEXT all FILE FLOW_OUT.ssf SITE reach06 NEW SERIES NAME mflow DATE_1 01/01/1983 TIME_1 00:00:00 DATE_2 12/31/1992 TIME_2 00:00:00 END GET_SERIES_SSF # Block 3 START GET SERIES SSF CONTEXT all FILE SEDCONC.ssf SITE reach06 NEW_SERIES_NAME mtss1 END GET_SERIES_SSF # Block 4 START GET_SERIES_SSF CONTEXT all FILE MINP_OUT.ssf SITE reach06 NEW_SERIES_NAME minp1 END GET_SERIES_SSF # Block 5 START GET_SERIES_SSF CONTEXT all FILE ORGP_OUT.ssf SITE reach06 NEW_SERIES_NAME orgp1 END GET_SERIES_SSF # Block 6 START NEW_TIME_BASE CONTEXT all SERIES_NAME mtss1 TB_SERIES_NAME mflow NEW_SERIES_NAME mtss END NEW_TIME_BASE # Block 7 START NEW_TIME_BASE CONTEXT all SERIES_NAME minpl TB_SERIES_NAME mflow NEW_SERIES_NAME minp END NEW_TIME_BASE

Block 8 START NEW_TIME_BASE CONTEXT all SERIES_NAME orgp1 TB_SERIES_NAME mflow NEW_SERIES_NAME orgp END NEW_TIME_BASE # Block 9 START SERIES_EQUATION CONTEXT all NEW_SERIES_NAME mtp EQUATION 0.01157 * (minp + orgp) / (mflow + 0.001) END SERIES_EQUATION # Block 10 START LIST_OUTPUT CONTEXT model_post FILE generated.txt SERIES_NAME mflow SERIES_NAME mtss SERIES_NAME mtp SERIES_FORMAT short END LIST_OUTPUT # Block 11 START GET_SERIES_SSF CONTEXT all FILE canton_FLOW.ssf SITE Canton NEW_SERIES_NAME oflow1 END GET_SERIES_SSF # Block 12 START GET_SERIES_SSF CONTEXT all FILE Canton_SS.ssf SITE Canton NEW_SERIES_NAME otss DATE_1 10/15/1983 TIME_1 00:00:00 DATE_2 12/21/1992 TIME_2 00:00:00 END GET_SERIES_SSF # Block 13 START GET_SERIES_SSF CONTEXT all FILE Canton_TP.ssf SITE Canton NEW_SERIES_NAME otp DATE_1 1/25/1983 TIME_1 00:00:00 DATE_2 12/21/1992 TIME_2 00:00:00 END GET_SERIES_SSF # Block 14 START NEW TIME BASE CONTEXT all SERIES_NAME oflow1 TB_SERIES_NAME mflow NEW_SERIES_NAME oflow

Block 15 START NEW_TIME_BASE CONTEXT all SERIES_NAME mtss1 TB_SERIES_NAME otss NEW_SERIES_NAME mtsso END NEW_TIME_BASE # Block 16 START NEW_TIME_BASE CONTEXT all SERIES_NAME mtpl TB_SERIES_NAME otp NEW_SERIES_NAME mtpo END NEW_TIME_BASE # Block 17 START LIST_OUTPUT CONTEXT all FILE modelout.txt SERIES_NAME mflow SERIES_NAME mtsso SERIES_NAME mtpo SERIES_FORMAT short END LIST_OUTPUT # Block 18 START WRITE_PEST_FILES CONTEXT pest_prep NEW_PEST_CONTROL_FILE etowah.pst NEW_INSTRUCTION_FILE modelout.ins # Information pertaining to general files. PARAMETER_GROUP_FILE parmgrp.dat PARAMETER_DATA_FILE parmdata.dat MODEL COMMAND LINE swat.bat # Information pertaining to template and model input files. TEMPLATE_FILE mgt010001.tpl MODEL_INPUT_FILE 000010001.mgt TEMPLATE_FILE mgt010002.tpl MODEL_INPUT_FILE 000010002.mgt TEMPLATE_FILE hru010001.tpl MODEL_INPUT_FILE 000010001.dat TEMPLATE_FILE par2par.tpl MODEL_INPUT_FILE par2par.dat # Information pertaining to flow time series. OBSERVATION_SERIES_NAME oflow MODEL_SERIES_NAME mflowb SERIES_WEIGHTS_EQUATION 1.5 / (@_abs_value+0.0001) SERIES_WEIGHTS_MIN_MAX 1e-4 1e+4 # Information pertaining to sediment time series. OBSERVATION SERIES NAME otss MODEL_SERIES_NAME mtss SERIES_WEIGHTS_EQUATION 0.1

END NEW_TIME_BASE

Information pertaining to phosphorus time series.

```
OBSERVATION_SERIES_NAME otp
MODEL_SERIES_NAME mtp
SERIES_WEIGHTS_EQUATION 50
END WRITE_PEST_FILES
```

Example 11. A combined TSPROC data file used for both tasks

1.7 Other PEST utility programs

1.7.1 TEMPCHEK, INSCHEK and PESTCHEK

After the model template files, model output instruction file(s), and the PEST control file have been prepared, it is recommended to use TEMPCHEK, INSCHEK and PESTCHEK PEST utility programs to check the syntax of these files. If the model output instruction files are prepared using TSPROC program, INSCHEK is rarely used. But TEMPCHEK and PESTCHEK are always very helpful to find syntax or human errors. The DOS commands for TEMPCHEK and PESTCHEK are the same, that is,

tempchek template_file_name (extension name can be omitted), or
pestchek pest_control_file_name (extension name can be omitted)

It should be noted that each of these utilities checks one error at a time. Therefore, after you fixed one error, you need to run the check utility program again. In the other words, for one file (either template file or control file) you should run the check utility program again and again until it does not issue any errors any more.

1.7.2 PARREP

I guess PARREP is a short for PARameter REPlication. It is usually used to generate a new PEST control file from an old PEST control file and the correspondent optimal parameter file that is written after the PEST optimization process of the old PEST control is finished. Its DOS command is as follows.

parrep parameter_file old_control_file new_control_file

1.7.3 PSTOP

It is quite often when you find yourself have made some nonfatal mistakes that could defer the whole optimization process or lead to undesirable results after you've commenced PEST optimization. At situations like this, you don't have to wait until the undesired PEST run to finish or need to use Control-C command. You may open another DOS command window, and type PSTOP at the DOS prompt in the current working directory. Then PEST will stop after it finishes the current model run.

1.7.4 PAR2PAR

PAR2PAR is one of most frequently used PEST utility program. It is used to make generic parameter transformations. If you only want to make a logarithmic transformation for one of the adjustable parameters, you can do it within the PEST control file. You just need to specify the variable of C2 in "parameter data" zone in Example 4 to "log" instead of "none". But if you want to make a parameter transformation other than a logarithmic one, PAR2PAR has to be employed. However, it is confusing to include it into your PEST optimization process if you haven't used PEST before. Therefore, I suggest you postpone its usage until you feel comfortable with a regular PEST run.

1.7.5 RCH2SSF

Strictly, this is not a PEST utility program. It was programmed by myself to convert a SWAT-printed basins.rch to a series of Sample Site Files that will be read in TSPROC no matter what role TSPROC plays. This is why it is called RCH2SSF (RCH file to SSF files). The DOS command for RCH2SSF is as follows.

rch2ssf RCH2SSF_data_file

The text file of RCH2SSF_data_file can be any name with a format shown in Example 12.

6 FLOW_OUT SEDCONC ORGP_OUT MINP_OUT

Example 12. An RCH2SSF data file

The first line is the number of the sub-basin where the stream flow and water quality parameters in the reach are of interest. The following lines are variables that are printed in the SWAT basins.rch file. If they are listed in this RCH2SSF data file (called rch2ssf.dat), one Sample Site File will be generated for each of them. The Sample Site File will be named after the variable's name followed by .ssf. For example, according to Example 12, a Sample Site File will be generated for the downstream flow for reach 6 and after⁵, whose name will be FLOW_OUT.ssf. Similarly, another three Sample Site Files will be produced for sediment concentration, organic phosphorus load, and mineral phosphorus load in reach 6 and after, which will be named as SEDCONC.ssf, ORGP_OUT.ssf, and MINP_OUT.ssf, respectively. All eligible variable's names in basins.rch file include FLOW_IN, FLOW_OUT, EVAP, TLOSS, SED_IN, SED_OUT, SEDCONC, ORGN_IN, ORGN_OUT, ORGP_IN,

⁵ If we want the downstream data for reach 6 only, then run rch2ssf1.exe instead of rch2ssf.exe.

ORGP_OUT, NO3_IN, NO3_OUT, NH4_IN, NH4_OUT, NO2_IN, NO2_OUT, MINP_IN, MINP_OUT, CHLA_IN, CHLA_OUT, CBOD_IN, CBOD_OUT, DISOX_IN, DISOX_OUT, SOLPST_IN, SOLPST_OUT, SORPST_IN, SORPST_OUT, REACTPST, VOLPST, SETTLPST, RESUSP_PST, DIFFUSEPST, REACBEDPST, BURYPST, BED_PST, BACTP_OUT, BACTLP_OUT, CMETAL_1, CMETAL_2, CMETAL_3.

2. Running PEST and reading PEST output files

Running PEST is simple. After having PEST control file prepared and successfully checked by PESTCHEK program, you just need to type the following command line at DOS prompt.

pest pest_control_file (extension name can be omitted)

Before turning our attention to PEST output files, let's summarize the whole process of preparing PEST files that have been extensively discussed in the previous section. They are outcomes of my personal experiences and don't have to be followed stringently.

Step 1: Having set up the SWAT model and made a successful run of the SWAT model, copy the txtinout directory to your working directory and rename it;

Step 2: Select adjustable parameters based on your goal for model calibration;

Step 3: Set initial, boundary values for the selected parameters;

Step 4: Write a parameter data file and a parameter group file;

Step 5: Write all appropriate model input template files, checking with TEMPCHEK after each template file having been written;

Step 6: Convert any available measured data into SSF or WDM format which can be read by TSPROC;

Step 7: Write model batch file if necessary;

Step 8: Prepare TSPROC data file for PEST file preparation;

Step 9: Run TSPROC to generate PEST control file;

Step 10: Prepare (or Reform) TSPROC data file as model post-processor;

Step 11: Run PESTCHEK to check the newly generated PEST control file;

Step 12: Adjust C1 in Line 9 of the PEST control file (shown in Example 4) to 0, and run PEST once;

Step 13: If the values for all components of the total objective function are not equivalent in magnitude, adjust the weights in the TSPROC data file prepared in Step 8;

Step 14: Repeat Step 8 through Step 13 until all components of the total objective function have similar values;

Step 15: Change C1 in Line 9 of the PEST control file (shown in Example 4) to 30;

Step 16: Run PEST optimization.

After PEST having been stopped by one of its criteria, a set of PEST output files will be written to disk immediately. The base names of these files are the same as that of the PEST control file, but they differ from each other by their extension names. For example, if the PEST control file name is test.pst, then all PEST output files resulted from the PEST optimization for this case will be test.*, where the asterisk (*) represents different extension names. The PEST output files were described in Chapter 5 in PEST User's Manual. A summary of these files is given in the following.

The most comprehensive output file is PEST record file (*.rec). It has a detailed record of the parameter estimation process from the beginning to the end. But I found it has too much information to be helpful. Sometimes, it may have more than 10,000 lines of materials. It is difficult to find what you want. Furthermore, except for the detailed record of the estimation process, many of the rest recordings are also written into other different files⁶, which have specific purposes and are easy to be converted into spreadsheet.

For example, a parameter sensitivity file (*.sen) contains the "composite sensitivity" of each parameter with respect to all observations (with the latter weighted by the user-assigned weights). Recall that each column of the Jacobian matrix lists the derivatives of all model-generated observations with respect to a particular parameter. Thus the composite sensitivity of a parameter is the normalized (with respect to the number of observations) magnitude of the column of the Jacobian matrix pertaining to that parameter, with each element of that column multiplied by the weight pertaining to the respective observation. The *relative* composite sensitivity of a parameter. It is thus a measure of the composite changes in model outputs that are incurred by a fractional change in the value of the parameter. Composite parameter sensitivities are useful in identifying those parameters which may be degrading the performance of the parameter estimation process through lack of sensitivity to model outcomes. The use of relative composite sensitivity is assists in comparing the

⁶ There is slight discrepancy between some information recorded in the record file and that recorded in other files. But it is an easy matter to overcome it.

effects that different parameters have one the parameter estimation process when these parameters are of different type, and possibly of very different magnitudes.

A similar PEST output file is the observation sensitivity file (*.seo) that contains the composite sensitivity of an observation with respect to all parameters involved in the parameter estimation process. The composite sensitivity of observation *j* is the magnitude of the *j*th row of the Jacobian matrix multiplied by the weight associated with that observation; this magnitude is then divided by the number of adjustable parameters. Though composite observation sensitivities can be of some use, they do not, in general, convey as much useful information as composite parameter sensitivities. Therefore, I rarely looked at the observation sensitivity file.

During each optimization iteration, immediately after it has calculated the Jacobian matrix, PEST records composite parameter sensitivities to a parameter sensitivity file (*.sen) for each iteration. But PEST only write the current composite observation sensitivities to an observation sensitivity file (*.seo). The another file that will be written after PEST calculates the Jacobian matrix is the matrix file (*.mtt), if any of the three variables of Line 10 in the PEST control file (Example 4) are set to 1. The variable in C1 indicates whether the parameter variance-covariance matrix is written or not; the variable in C2 indicates for parameter correlation coefficient matrix; and the variable in C3 indicates for the eigenvalues and normalized eigenvectors of the variance-covariance matrix. If any of the three variables are set to zero, the corresponding matrix is not written to the matrix file. Although all of these three matrices are useful, I used the parameter correlation coefficient matrix most often. It tells me which two parameters might be linearly dependent so that it should be avoided estimating both of them simultaneously. One of my statistics teachers once told us that if the (Pearson's) correlation coefficient is greater than 0.8, the two random variables may be considered linearly dependent. I used to use the eigenvalues printed in the matrix file to calcuate the condition number for the variance-covariance matrix, but in the later versions of PEST, the condition numbers for each iteration are given in the condition number file (*.cnd). Don't worry about this file if you don't know what condition number is for it is more useful, along with the singular value file (*.svd), when SVD-assist is employed in the future.

Like the observation sensitivity file (*.seo), the matrix file (*.mtt) only contains the information with regard to the current set of parameter values. Each time this file is written, the previous file of the same name is overwritten. Because the optimal parameter set does not necessarily result from the last optimization iteration, cautions should be exercised if you want to check for the above-mentioned information pertaining to the optimal parameter set. Usually, a small remedy should be done in this respect. We'll come back for this remedy shortly.

Besides the record file (*.rec), the other two important files that store the information for the best achievement of the PEST optimization are the parameter value file (*.par) and the residual file (*.res). At the end of its execution, PEST writes the residual file listing in tabular form observation names, the groups to which various observations belong, measured and modeled observation values, differences between these two (i.e., residuals), measured and model observation values multiplied by respective weights, weighted residuals, measurement standard deviations and "natural weights". While the meanings for the rest of columns are apparent from their names, the last two data types require a word of explanation. The measurement standard deviation is calculated as the inverse of its weight multiplied by the square root of the reference variance (σ^2) which is calculated by the minimum objective function value being divided by the degrees of freedom (the difference between the number of observations and the number of adjustable parameters). It can serve as a valid measure of observation uncertainty only if the model is a valid simulation the process that it is intended to represent. The "natural weights" are the inverse of measurement standard deviations as determined above. It is obvious that if these weights were used in the parameter estimation process, the reference variance would be unity. Normally, I only used the measured and modeled observation columns to plot graphs for visual comparisons between them.

The parameter value file (*.par) records the optimal parameter set of the PEST optimization process. As discussed above, the last iteration does not necessarily result in the optimal parameter set, therefore, if I want to look at the parameter sensitivities and parameter correlation coefficients pertaining to the optimal parameter set, I will do the following: (1) I use the PEST utility program PARREP to make a new PEST control file based on the optimal parameter set and the old PEST control file; (2) change the variable of C1 in Line 9 in the new PEST control file to -1; (3) run the new PEST control file. Then the information contained in the PEST output files correspondent to the new PEST control file is correct information.

In addition, the Jacobian matrix corresponding to the optimized parameter values is recorded in a binary file (*.jco) that can be accessible by the JACWRIT utility program for recording of the Jacobian matrix in text format. A residual file for each iteration (*.rei) temporarily stores the measured and modeled observations for current iteration. The information in this file may be used by PEST itself during the parameter estimation process. I haven't seen any usefulness of it. If the string variable of C1 in Line 3 is set to "restart", then another three files (*.rst, *.jac, *.jst) may be generated by PEST for its restart features, although I never felt the need to use them.

3. Editing AUTOEXC.BAT file

In order to use PEST to calibrate the SWAT model, we need to do one more thing – adding the directories where the SWAT executable file and PEST command files are located into the autoexec.bat file. The autoexec.bat file is located in the root drive of your computer. Since the autoexec.bat file is a system file, you shouldn't tamper with it if you don't know what it is. Normally, the autoexec.bat is hidden under the Windows Explorer. The following line can be added into the autoexec.bat file if the SWAT executable file (swat2000.exe) and the swat.bat (described in Section 1.1), together with those executable files contained in the swat.bat batch file are located in C:\AVSWAT\AVSWATPR\ and PEST command files are located in C:\PEST. SET PATH = C:\AVSWAT\AVSWATPR\; C:\PEST\