

Dali Racing's NSX Audio System

System Overview

Our design objectives were.....

- to maintain the cosmetic integrity and aesthetics of the vehicle
- to enable the vehicle to return to stock with little work and expense
- to utilize the factory head unit and changer, thus eliminating the need to modify the dash
- □ to conserve trunk space
- to have a basic framework that leaves room for budgetary and listening habit variances of different drivers
- to design a system that in no way compromised the performance or reliability of the car, even when the car is being driven like it is a rental!

Equipment used in the system

- Soundgate LOC Audiophile interface
- □ EarthQuake 120.2 4 channel amplifier with built-in crossover
- Diamond Audio Motorsports 6.5" 2-way separate speakers
- □ Eclipse 8708.4 Cast magnesium frame, long-excursion subwoofer

Installation Overview

The audio signal from the factory head unit, and the factory speaker wires are sent to the trunk via a pre-manufactured harness to a Soundgate interface mounted in the trunk that massages the signal. Then the signal heads through twisted pair, gold connector signal cables to the Earthquake 120.2 amplifier mounted in the area formerly holding the jack and tool kit. The amp is protected underneath a perforated shroud that is powder-coated black. The amplifier is configured to send 85 watts to each of the Diamond Audio speaker modules mounted in the factory door speaker locations. These modules house the 1" aluminum dome tweeter, a 6.5" cast frame mid-bass/mid-range driver, and the very sophisticated crossover network that divides the frequencies and sends them to their respective speakers. The Eclipse 8708.4 subwoofer is mounted in a CF & fiberglass enclosure that occupies approximately the same space that once held the little spindly plastic bag referred to as a subwoofer by the fine folks at Bose/Acura.

This subwoofer receives 200 watts from the amplifier. No NSXs were harmed during this installation. All scenes involving NSXs were closely monitored by the Society to Prevent People From Destroying Their NSX.

So, how does it sound?

Many NSXs **have** been destroyed at the hands of the technically challenged to achieve sound quality and volume that isn't even close to this system. It is well engineered, sonically accurate, capable of very high, undistorted output, and is invisible to all but the very trained eye. It is rare to have something this simple, sound and function so well!



Dali Racing's NSX Audio System

Installation Instructions

Given the proper tools, some degree of mechanical aptitude and a little patience, this system should be able to be installed over a weekend. Take your time, follow the directions carefully, and be thorough and you should have no problems. If you have any doubts about your ability to do a good job, **STOP** and contact your local high-end car stereo shop to schedule an appointment.

The following tools are recommended for the installation.

-electric or cordless drill
#2 phillips screwdriver
-a set of drill bits
-8mm, 10mm, 12mm sockets
-pick tool set
-diagonal cutters (dykes)

Start your installation by reading through the entire installation instructions to mentally get a picture of the entire process. Next, unpack the entire system and familiarize yourself with all of the different components. Now you're ready to start the installation. This is the recommended sequence for performing the installation.

Remove the passenger seat

Set the climate control system to "Floor/Defrost"

Remove the negative battery terminal

Disassembly Instructions

The next step is the disassembly of all areas

Next, remove the following interior trim pieces by following **diagram A**, reprinted from the NSX service manual. (Bottom of page 20-38)

- 1. Side sill pad
- 2. Side sill trim
- 3. Rear trim panel
- 4. Right rear trim panel
- 5. Rear upper trim panel

Pull the floorboard carpet kit on passenger side.

Pull carpeted panel on side of console back far enough to access back of radio. To accomplish this, remove the screw from the floor heater vent located at the top of the panel and shown in **photos A & E.**

Next, remove the aluminum panel covering the subwoofer, and then the subwoofer and mounting bracket by following **diagram B.** (Right side of page 23-238) (Photos B, C, D)

Remove the 3-piece carpet kit in the trunk by following **diagram C.** Make sure not to misplace any of the plastic retainer clips. **(Page 20-66)**

Remove the factory tool and jack kit

Harness installation

Remove the factory radio plug from back of radio. There are 2 methods of accomplishing this. The first, follow the service manual instructions and remove the dash and the radio. If choosing this painful route, follow (diagram D) Pages 23-232-233) This is NOT recommended, as it is time consuming, and quite often leads to a scratched dash bezel. The second, and preferred method will take a little patience and finesse. To accomplish this, grab a flashlight and your pick tool set and position yourself on the passenger side of the console.

Locate the plastic connector on the back of the factory radio, use your pick tool to depress the locking tab, and slide plug towards front of vehicle, and pull out to the passenger side of the console. (Photo E)

Next, insert plug of the new harness that is the same as the factory plug, into the radio, and plug the factory radio harness into the female jack.

Next, it's time to route the harness to the trunk. Follow the route pictured in **(photos: F, G)** The harness will pass through the front firewall in the right corner, in the large, oval grommet pictured in **photo H.** The grommet would be over your right shoulder if seated in the passenger seat. Make sure to run the harness through the top of the grommet, over the factory harness. Be careful when cutting a slice in the grommet to pass the wires through. It is very easy to cut in to the harness, or your fingers!

Once inside the engine compartment, route the harness over the top of the fan, securing it to the fan bracket, and tie wrap wire securely out of harms way, while routing towards the rubber grommet located at the upper right side of rear firewall. You can see the trunk side of this grommet in **photo I**. Once inside the rear trunk compartment, secure the harness under the top trunk lip as detailed in **photo I**. Note that the end of the harness ends up passing behind the trunk latch support as shown in **photo J**.

Power cable harness

Prior to routing the harness, make the following connections.

Connect the positive cable (Red) to the power distribution center by removing the nut on the farthest forward, large distribution stud shown in **photo K**. Make sure this connection is tight before moving on.

Connect the ground cable (black) to the bolt on the block that holds the engine ground, shown in **photo K**.

Now that your connections are made, secure your harness with tie wraps and follow the route detailed in **photo L**. Your harness will pass through the unused rubber grommet at the top left side of the front wall of the trunk, detailed in **photo M**. Next, route the harness following the route shown in **photo N**.

Wire and mounting of Soundgate interface

Wire the Soundgate EXACTLY according to the following legend. Incorrect connections can result in damage to your factory radio and/or the amplifier.

Harness wire colors	Soundgate LOC connections
Unused	Left positive lo input
Blue w/white	Left positive high input
Green w/white	Left negative input
Black (Connected)	Left ground
Black (Connected)	Right ground
Green w/black	Right negative input
Blue w/black	Right positive high input
Unused	Right positive lo input

The 18 gauge black wire connected to the two ground terminals on the interface must be connected to chassis ground. This can be accomplished by securing them via the bolt on the trunk latch support strut. Failure to connect this can result in severe engine whine through your system.

The Soundgate interface can be mounted either by screwing to the rear wall, (not recommended), or by pushing it between the trunk latch support strut, and the rear wall of the trunk, and securing with the enclosed, long tie-wrap.

Installation of black carpet underneath amplifier

The carpet's purpose is to conceal the wiring to the amplifier, and make it look pretty when showing your friends your new system. It can be secured in place with spray adhesive, or left loose, as it can't go anywhere. If using the spray adhesive method, spray both the carpet, and the trunk floor with an even coating, allow to set-up for several minutes or until dry to the touch, and then press the carpet to the floor. It is important to make sure you have the wires routed through the opening first.

Insert the remaining wires from the main harness as well as the RCA cables from Soundgate through the hole in center of carpet as shown in **photo O**.

Amplifier wiring and mounting

Next insert the speaker wires into their plugs according to the following legend. Make sure to carefully confirm the orientation of the plug into the amp prior to installing wires. **Incorrect connections can result in damage to your factory radio and/or the amplifier.**

Harness wire colors	Amplifier speaker plug connections
White	Left positive on front plug
Orange	Left negative on front plug
White w/black	Right positive on front plug
Orange w/black	Right negative on front plug
Blue	REM on front plug
Red w/white & red w/black	Left positive on rear plug
Black w/white & green	Right negative on rear plug

Next insert the power cables into their plug according to the following legend Red: +

Black: --

Next insert the RCA signal cable into the "Front" inputs

Position the amplifier in the center of the well and secure using the provided screws as shown in **photo P.**

The amplifier will arrive at your door with the crossover, gain and switch settings in the optimum positions, however, some of us like to play, so read the instructions provided with your amplifier very carefully before touching the adjustments. Incorrect settings can damage speakers and the amplifier, and make your new system sound very bad! After you have gotten the urge to experiment out of your system, and the frustration with how bad you have made your new system sound has really set in, use the following legend to return it to the optimum settings.

Function/Control	Setting	Notes
Rear xover Freq.	18 clicks from full counter- clockwise	This is the lowpass frequency of your subwoofers. The optimum setting for most styles of music is 73hz. Lowering it can mean less output, and poor system frequency response. Raising it, can mean boomy, directional sub bass that will not help create a realistic sound stage.
Rear HP/LP	Switch out	This switch determines whether your subwoofer is low pass or high pass.
Rear gain	90% clockwise	This is the level control for the subwoofer. Adjust sparingly. Too much gain can cause distortion and possibly damage the subwoofer and/or amp.
Q-bass	Fully counter- clockwise	This dangerous control serves no purpose in your system. DON'T TOUCH UNLESS OTHERWISE INSTRUCTED.
Front gain	45% clockwise	This is the level control of the door speakers. Adjust sparingly. Too much gain can induce noise and distortion.
-12db	Out	This is used when running a speaker level input to the amplifier.
Combine	In	This sends the output of the Soundgate to all four channels of the amp
Front HP freq.	19 clicks from full	This is the high-pass frequency of your Diamond Audio door speakers. They are set to 80 hz. Lowering this frequency can cause distortion and

counter-	possibly damage the speakers.	Raising it will make the sound thinner and
clockwise	less detailed.	

Subwoofer installation

Next, install the subwoofer enclosure and connect its harness into the 2 pin connector on main harness that mates with the sub connector. Attach the enclosure using the supplied blots, and the lower two factory mounting holes.

Door speaker installation (This applies to both doors)

Remove the door panel and factory speaker units by following diagrams E-1, 2. (Pages 20-7-8)

On the speaker unit harness that remains in the door, cut the orange and white wires 1.5" from the plug.

Next, screw the new speaker module into the door using the supplied (6) 3'' long sheet metal screws. Use the factory $\frac{1}{2}''$ sheet metal screws to align the unit via the factory mounting locations, and then use the 3'' screws to secure the pod as shown in **photo Q**.

Strip 1/4" of insulation from the orange and white wires and connect to crossover mounted on door pod according to the following diagram

Wire	Connect to
Orange	Negative input
White	Positive input

Incorrect connections will cause phase cancellation and negatively impact the sound quality of the system.

Repeat on other door.

Turn on procedures

Reconnect the negative battery cable.

Verify amplifier settings according to the legend to make sure no buttons were accidentally depressed.

Insert the supplied Maxi-fuse into fuse holder on main power harness

Turn the system on and proceed through the following tests.

-balance test: verify that left is left and right is right. If incorrect, reverse the RCA cables into the amplifier.

-engine noise test: Roll up the windows, shut the doors, start the engine, and listen for any type of whine, squeal or tic through the system. If present, make sure battery connections are tight. If still present, contact the ThunderWorks Technical Support Hotline at (619) 596-1925.

-volume test: Turn the system on and with the bass and treble controls set to flat, and a well recorded CD playing, turn the volume up and listen for adequate volume, good relationship between the subwoofer and door speakers, and distortion. If needed, make adjustments, and re-evaluate.

If all tests are positive, mount the perforated amplifier shroud with the $\frac{1}{2}$ " self-tapping screws as shown in **photo R**.

Finally, reinstall the door panels, trunk carpet kit, and interior and go for a drive.