

"Setting the World's Performance Standards!"

743 Iona Rd. Idaho Falls, ID 83401, (208)529-0244 Fax (208)529-9000

Performance Edition Kit for 2008-10 Polaris 800 H.O. RMK CFI

Congratulations! You have just purchased one of the best modifications available for your snowmobile. Please follow the recommendations below for the best results from this modification.

Customer Name and ID #_____

Porting Serial #_____

Minimum elevation recommended for this combination _____

Parts Required for Performance Edition Package

- Single Pipe (Part #09-878 or #09-888 depending on year)
- Performance Edition Porting
- SLP Cheater Heads
- High Flow Intake Kit (Part #14-140)
- Clutch Kit Depending on Elevation
- ECU Modification for SLP Performance Edition
- Air box modification required (see instructions)



TORQUE SPECIFICATIONS:

A = 70 In.Lbs. (8Nm) B = 9 Ft.Lbs. (12 Nm) - Apply Loctite 242 C = 25 Ft.Lbs. (34 Nm) - Apply Loctite 242 D = 18 Ft.Lbs. (24 Nm) - Apply Pipe Sealant E = 168 In.Lbs. (19 Nm) - Clean and Dry F = 42 Ft.Lbs. (57Nm)



NOTE: Engines with serial number beginning with S3489 Feature a bypass nozzle. Engines with serial number beginning with S3471 feature a plug.



Disassembly / Assembly Pricess - 800 CFI Cylinder Head / Cylinder / Pistons

1. Remove the coolant from the engine using a syphon, wet/dry vac, or drain pan.

2. Remove the air box, exhaust pipe and resonator from the engine compartment.

3. Remove the high tension wires and spark plugs from the cylinder head.

4. Remove the thermostat housing outlet cooling hose from the housing.

5. Loosen all, then remove all hea cover fasteners. Clean the fastener threads to remove any thread locking residue.

6. Discard the head cover and cylinder head o-rings. Always use new o-rings during assembly.

7. Inspect the cylinder head / combustion domes for any damage. Measure cylinder flatness. Replace cylinder head if required.

8. If only hte cylinder is going to be removed, remove the fuel rail from the upper fuel injectors. See "CFI Fuel Rail/Injector(s) Removal/Installation" on page 4.30 in the Polaris Service Manual.

9. Loosen all, then remove the cylinder bolts. Clean the bolt threads to remove any thread locking residue.

10. Carefully pull the cylinder upwards taking care not to drop the pistons and rods abruptly against the crankcase.

11. Remove the cylinder base gaske. Use a gasket scraper to clean the gasket residue form the crankcase and cylinder base.

12. Inspect the cylinder walls. Nicasil cylinders can only be lightly honed. Damage that cannot be removed with a light hone requires cylinder replacement or re-choromed.

13. Inspect the crankcase and clylinder mating surface for warping.

14. The assembly process is the reverse dissasembly.

15. Always use new gaskets asnd o-rings during assembly. Liberally coat the inside of each cylinder bore adn the outside of each piston with Polaris two-stroke enigne oil.

16. When installing a piston into a cylinder, verify each piston ring opening is located at each piston ring locating pin. Squeeze the top ring, then carefully slide the cylinder over the compressed ring. Do the same with the bottom ring.

17. Follow the torque specification and torque sequences located at beginning of chapter when tightening fasteners.

Stock Air Box Modification



Remove the air box, using a 7/8" hole saw drill out 4 holes in the front of the shelf in the air box. Remove any plastic shavings in the air box. Reinstall air box.

800 H.O. RMK Performance Edition Clutching Chart using stock TEAM TSS-04 Driven Clutch

Altitude (feet)	Drive Clutch		TEAM TSS-04 Driven Clutch (Stock)	
	Clutch Spring	Shift Weight	Cluch Spring	Driven Helix
0-3000 ft	SLP Blue / Pink #40-76	SLP MTX 71g #40-84 2g rivet outer hole 2g inner hole	TEAM Ind. Black/Purple (Stock)	TEAM Ind. 58/40.36 #50-121
3000-6000 ft	SLP Blue / Pink #40-76	SLP MTX 68g #40-83 3g rivet outer hole 2g inner hole	TEAM Ind. Black/Purple (Stock)	TEAM Ind. 58/40.36 #50-121
6000-8000 ft	SLP Blue / Pink #40-76	SLP MTX 68g #40-83 2 g rivet outer hole 1g inner hole	TEAM Ind. Black/Purple (Stock)	TEAM Ind. 58/40.36 #50-121
8000-10000 ft	SLP Blue / Pink #40-76	SLP MTX 68g #40-83 1g rivet outer hole 1g inner hole	TEAM Ind. Black/Purple (Stock)	TEAM Ind. 58/38.36 #50-121

Running RPM 8100-8250 ECU Modification Required. For proper performance ECU <u>must</u> be sent to SLP for modification. See next page for additional information.

800 H.O. RMK Performance Edition Clutching Chart using TEAM Tied Driven Clutch

Altitude (feet)	Drive Clutch		TEAM Tied Driven Clutch	
	Clutch Spring	Shift Weight	Cluch Spring	Driven Helix
0-3000 ft	SLP Blue / Pink #40-76	SLP MTX 74g #40-84 2g rivet outer hole 2g inner hole	TEAM Ind. Red/Blue #50-4	TEAM Ind. 73/59.46 #50-214
3000-6000 ft	SLP Blue / Pink #40-76	SLP MTX 74g #40-84 1g rivet outer hole 1g inner hole	TEAM Ind. Red/Blue #50-4	TEAM Ind. 73/59.46 #50-214
6000-8000 ft	SLP Blue / Pink #40-76	SLP MTX 68g #40-83 2 g rivet outer hole 1g inner hole	TEAM Ind. Red/Green #50-2	TEAM Ind. 75/57.46 #50-218
8000-10000 ft	SLP Blue / Pink #40-76	SLP MTX 68g #40-83 1g rivet outer hole 1g inner hole	TEAM Ind. Red/Green #50-2	TEAM Ind. 75/57.46 #50-218

Running RPM 8100-8250

ECU Modification Required. For proper performance ECU <u>must</u> be sent to SLP for modification. See next page for additional information.

Oil Recoomendation: For best performance and dependability on the 800 be sure to run very high quality oil like Red Line full synthetic Racing oil which is the first choice. The second choice would be the new Polaris "VES Gold Plus" oil that we understand is good. No other oils are acceptable.

Octane: Minimum 91 octane pump fuel. Fuels containing ethanol or oxygen carrying additives will require more fuel than non oxygen carrying fuels and may require use of an EFI Control Box.

General Fuel Note: Due to inconsistencies in quality of fuel available today the following are a few tips to prevent issues that may arise due to fuel.

- When riding in midrange throttle positions periodically vary throttle position, do not hold in constant position for extended periods of time.

- Make sure that the premium/ethanol jumper wires are set proper for the fuel being used.

- A good practice and cheap insurance is to add a 1 oz of Lucas Octane Booster to every gallon of fuel this can be found at most automotive stores.

MODIFIED ECU

This ECU will function with the Ethanol fuel wires.

<u>Unlike</u> the stock connection procedure, this ECU is opposite connection and will be set for Ethanol use when the wires are <u>connected</u> together.

Disconnect for Non Ethanol fuel use.

Please install included sticker to the rear of the clutch cover. See picture below.



6