

TI-84 Plus TI-84 Plus Silver Edition



Important Information

Texas Instruments makes no warranty, either express or implied, including but not limited to any implied warranties of merchantability and fitness for a particular purpose, regarding any programs or book materials and makes such materials available solely on an "as-is" basis. In no event shall Texas Instruments be liable to anyone for special, collateral, incidental, or consequential damages in connection with or arising out of the purchase or use of these materials, and the sole and exclusive liability of Texas Instruments, regardless of the form of action, shall not exceed the purchase price of this product. Moreover, Texas Instruments shall not be liable for any claim of any kind whatsoever against the use of these materials by any other party.

USA FCC Information Concerning Radio Frequency Interference

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference with radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, you can try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

Caution: Any changes or modifications to this equipment not expressly approved by Texas Instruments may void your authority to operate the equipment.

About the TI-84 Plus and TI-84 Plus Silver Edition

The TI-84 Plus Silver Edition is the same as the TI-84 Plus except:

- it has more memory, and thus more spaces for graphing handheld software applications (Apps).
- it has interchangeable faceplates that let you customize the appearance of your TI-84 Plus Silver Edition.

Since all the functions of the TI-84 Plus Silver Edition and the TI-84 Plus are the same, this guidebook can be used for either the TI-84 Plus or the TI-84 Plus Silver Edition.

The CD included with your TI-84 Plus / TI-84 Plus Silver Edition package also includes an electronic guidebook, which is a complete reference manual for the TI-84 Plus / TI-84 Plus Silver Edition. If the CD is not available, you can download a copy of the electronic guidebook from the Texas Instruments web page at:

education.ti.com/quides

The TI-84 Plus / TI-84 Plus Silver Edition has some graphing handheld software applications (Apps) preinstalled. For information about these Apps, see the electronic documentation files on the Texas Instrument web page at:

education.ti.com/quides

About this book

This guidebook gives a quick overview of each topic, along with keystroke instructions for easy examples. All examples assume that the TI-84 Plus is using default settings. For complete information on any topic, see the electronic guidebook on the CD that came with your graphing handheld.


Table of Contents

1	Getting Started1
	TI-84 Plus keys1
	Turning the TI-84 Plus on and off
	Home screen
	2nd and [ALPHA] keys
	CLEAR and 2nd [QUIT]
	Entering an expression
	Interchangeable Faceplates
	Using the Clock6
	TI-84 Plus menus
	Editing and deleting11
	Using - and
	Using parentheses
	Storing a value
	Graphing a function
	Changing mode settings18
	Setting the graphing window21
	Using
	Building a table23
	Using the CATALOG25
	Performing simple calculations
	Using the equation solver28
	Entering data into lists
	Plotting data32
	Calculating a linear regression35
	Calculating statistical variables
	Using the MATRIX Editor
	Grouping
	Ungrouping 41
	Error messages
	Resetting defaults43
	Installing applications44
	Running applications45
	Quick reference46
	Battery precautions
2	Activities47
2	
	The Quadratic Formula47
	Box with Lid 50
	Comparing Test Results Using Box Plots57
	Graphing Piecewise Functions 59
	Graphing Inequalities60

	Solving a System of Nonlinear Equations	
	Using a Program to Create the Sierpinski Triangle	
	Graphing Cobweb Attractors	
	Using a Program to Guess the Coefficients	
	Graphing the Unit Circle and Trigonometric Curves	
	Finding the Area between Curves	
	Using Parametric Equations: Ferris Wheel Problem	
	Demonstrating the Fundamental Theorem of Calculus	
	Computing Areas of Regular N-Sided Polygons	
	Computing and Graphing Mortgage Payments	75
3	Memory and Variable Management	79
	Checking Available Memory	79
	Deleting Items from Memory	
	Clearing Entries and List Elements	
	Archiving and UnArchiving Variables	83
	Resetting the TI-84 Plus	87
	Grouping and Ungrouping Variables	90
	Garbage Collection	
	ERR:ARCHIVE FULL Message	
4	Communication Link	99
	Getting Started: Sending Variables	99
	TI-84 Plus LINK	
	Selecting Items to Send	
	Receiving Items	106
	Backing Up RAM Memory	
	Error Conditions	108
Α	Appendix A: Tables and Reference Information	. 111
	Table of Functions and Instructions	111
	Variables	
	Statistics Formulas	
	Financial Formulas	
В	Appendix B: General Information	. 163
	Battery Information	
	Important Things You Need to Know About Your TI-84 Plus	165
	In Case of Difficulty	
	Error Conditions	
	Accuracy Information	
	Texas Instruments (TI) Support and Service	
	Texas Instruments (TI) Warranty Information	

Getting Started

TI-84 Plus keys



Turning the TI-84 Plus on and off

To turn on the TI-84 Plus, press ON. The ON key is located at the lower left corner of the TI-84 Plus.

To turn off the TI-84 Plus, press the 2nd key followed by the ON key. OFF is the second function of ON.

When you turn off the TI-84 Plus, all settings and memory contents are retained. The next time you turn on the TI-84 Plus, the home screen displays as it was when you last used it.

Automatic Power Down™

To prolong the life of the batteries, Automatic Power Down™ (APD™) turns off the TI-84 Plus automatically after about five minutes without any activity. The next time you turn o?n the TI-84 Plus, it is exactly as you left it.

Home screen

When you turn on your TI-84 Plus the first time, you should see this screen:



To clear this text from your screen, press <u>CLEAR</u> twice. You should now see the home screen, a blank screen with a flashing cursor. The home screen is where you enter problems and see results.




If you pressed <u>CLEAR</u> above and you still do not see a blank home screen, press the <u>[2nd]</u> key followed by the <u>[MODE]</u> key (to select QUIT).

Example: Add 2 + 3 on the home screen.

Press	Result
2 + 3	2+3■
ENTER	2+3 Entry line 5 Answer line

Note: Results are displayed on the next line (the answer line), not on the entry line.

Example: Multiply 5 x 4.



2nd and ALPHA keys

Most keys on the TI-84 Plus can perform two or more functions. To use a function printed on a key, press the key. To use a function printed above a key, you must first press the [2nd] key or the [ALPHA] key.

2nd key

Second functions are printed above the keys (the same color as the 2nd key). Some secondary functions enter a function or a symbol on the home screen (\sin^{-1} or $\sqrt{\ }$, for example). Others display menus or editors.

To view the ANGLE menu, for example, look for ANGLE above the APPS key near the top of the TI-84 Plus keyboard. Press the 2nd key (and then release it) and then press APPS. In this guidebook the key combination is indicated by 2nd [ANGLE], not 2nd APPS.

Note: The flashing cursor changes to **1** when you press the **2nd** key.

ALPHA key

The ALPHA key lets you enter the alphabetic characters and some special symbols. To enter T, for example, press ALPHA (and then release it) and then press 4. In the guidebook this key combination is indicated by ALPHA [T].

If you have several alphabetic characters to enter, press [2nd] [A-LOCK] to avoid having to press the [ALPHA] key multiple times. This locks the alpha key in the On position until you press [ALPHA] a second time to unlock it.

Note: The flashing cursor changes to when you press the ALPHA key.

CLEAR and 2nd [QUIT]

CLEAR key

The CLEAR key erases the home screen. This key is located just below the four arrow keys at the upper right corner of the TI-84 Plus keyboard. If you press CLEAR during an entry, it clears the entry line. If you press CLEAR when the cursor is on a blank line, it clears everything on the home screen.

Although it does not affect the calculation, it is frequently helpful to clear the previous work from the home screen before you begin a new problem. As you work through this guide, we recommend that you press [CLEAR] each time you begin a new *Example*. This removes the previous example from the home screen and ensures that the screen you see matches the one shown in the example.

2nd [QUIT]

If you accidentally press a menu key, pressing <code>CLEAR</code> will usually return you to the home screen, but in most cases pressing <code>[QUIT]</code> to leave the menu and return to the home screen.

Entering an expression

An expression consists of numbers, variables, operators, functions, and their arguments that evaluate to a single answer. 2X + 2 is an expression.

Type the expression, and then press **ENTER** to evaluate it. To enter a function or instruction on the entry line, you can:

Press its key, if available. For example, press LOG.

— or —

- Select it from the CATALOG, if the function appears on the CATALOG. For example, press 2nd [CATALOG], press → to move down to log(, and press ENTER to select log(.
 - or -
- Select it from a menu, if available. For example, to find the **round** function, press MATH, press ▶ to select **NUM**, then select **2:round(**.

Example: Enter and evaluate the expression $\pi \times 2$.

Press	Result
<pre>2nd [π] × 2</pre>	π*2
ENTER	π*2 6.283185307

Interchangeable Faceplates

The TI-84 Plus Silver Edition has interchangeable faceplates that let you customize the appearance of your unit. To purchase additional faceplates, refer to the TI Online Store at **education.ti.com**.


Removing a Faceplate

- Lift the tab at the bottom edge of the faceplate away from the TI-84 Plus Silver Edition case.
- Carefully lift the faceplate away from the unit until it releases. Be careful not to damage the faceplate or the keypad.



Installing New Faceplates

- Align the top of the faceplate in the corresponding grooves of the TI-84 Plus Silver Edition case.
- 2. Gently click the faceplate into place. Do not force.



 Make sure you gently press each of the grooves to ensure the faceplate is installed properly. See the diagram for proper groove placement.




Using the Clock

Use the Clock to set the time and date, select the clock display format, and turn the clock on and off. The clock is turned on by default and is accessed from the mode screen.

Displaying the Clock Settings

- 1. Press MODE
- Press the

 to move the cursor to SET CLOCK.
- 3. Press ENTER.



Changing the Clock settings

- Press the or to highlight the date format you want, example: M/D/Y. Press ENTER.
- 2. Press ▼ to highlight YEAR. Press CLEAR and type the year, example: 2004.
- 4. Press ▼ to highlight DAY. Press CLEAR and type the date.
- 5. Press ▼ to highlight TIME. Press ▶ or ◀ to highlight the time format you want. Press ENTER.
- Press

 to highlight HOUR. Press CLEAR
 and type the hour. A number from 1–12 or 0–23.
- Press
 ▼ to highlight MINUTE. Press CLEAR
 and type the minutes. A number from 0–
 59.
- Press
 ▼ to highlight AM/PM. Press
 ▼ or ▼ to highlight the format. Press
 ĒNTĒR.
- To Save changes, press
 ▼ to select SAVE.
 Press ENTERI.

FORMAT: 1004 D/M/Y Y/M/D YEAR: 2004 MODTH: 3 DAY: 18 TIME: 18/1013 24HOUR HOUR: 2 MINUTE: 37 AM/PM: AM 31 SAVE

Error Messages

If you type the wrong date for the month, for example: June 31, June does not have 31 days, you will receive an error message with two choices:

 To Quit the Clock application and return to the Home screen, select 1: Quit. Press ENTER1.

— or —

 To return to the clock application and correct the error, select 2: Goto. Press ENTER1. ERR:DATE IMBQuit 2:Goto Invalid day for month selected.

Turning the Clock On

There are two options to turn the clock on. One option is through the MODE screen, the other is through the Catalog.

Using the Mode Screen to turn the clock on

- 2. Press ENTER].



Using the Catalog to turn the clock on

- 1. If the Clock is turned off, Press [2nd] [CATALOG]
- 3. Press ENTER.



Turning the Clock Off

- 1. Press 2nd [CATALOG].
- 3. Press ENTER.

ClockOff will turn off the Clock display.



TI-84 Plus menus

Many functions and instructions are entered on the home screen by selecting from a menu.

To select an item from the displayed menu:

• Press the number or letter shown at the left of that item.

```
— or —
```

• Use the cursor arrow keys,

or

or


n, to highlight the item, and then press [ENTER].

Some menus close automatically when you make a selection, but if the menu remains open, press [2nd] [QUIT] to exit. Do not press [CLEAR] to exit, since this will sometimes delete your selection.

Example: Enter $\sqrt[3]{27}$ on the home screen entry line.


Press	Result
MATH	Menus containing an arrow next to the final item continue on a second page. Menus containing an arrow next to the final item continue on a second page.
4 — or — • • • ENTER	<u>≱1(∎</u>
2 7 DENTER	\$1(27) 3

Example: Change the FORMAT menu setting to display grid points on the graph.



Press	Result
ENTER	xecuto PolarGC CoordOn CoordOff GridOff GricOn Exesur AxesOff LabelOff LabelOn ExerOn ExerOff
(GRAPH)	

Example: Turn off the display of grid points.



Note: Press 2nd [QUIT] or CLEAR to close the FORMAT menu and return to the home screen.

Summary of menus on the TI-84 Plus

Press	To display	
[APPS]	APPLICATIONS menu — to see a list of TI-84 Plus graphing handheld software applications (APPS).	
2nd [LINK]	LINK menu — to communicate with another graphing handheld.	
2nd [MEM]	MEMORY menu — to check available memory and manage existing memory.	
MATH	MATH menu — to select a math operation.	
[VARS]	VARS menu — to select variable names to paste to the home screen.	
2nd [STAT PLOT]	STAT PLOTS menu — to define statistical plots.	

Press	To display	
[2nd] [CATALOG]	CATALOG menu — to select from a complete, alphabetic list of all TI-84 Plus built-in functions and instructions.	
[2nd] [FORMAT]	FORMAT menu — to define a graph's appearance.	
2nd [MATRIX]	MATRIX menu — to define, view, and edit matrices.	
[2nd] [DRAW]	DRAW menu — to select tools for drawing on graphs.	
[2nd] [DISTR]	DISTRIBUTIONS menu — to select distribution functions to paste to the home screen or editor screens.	
[2nd] [TEST]	TEST menu — to select relational operators (=, \neq , \leq , \geq , etc.) and Boolean operators (and, or, xor, not) to paste to the home screen.	

Editing and deleting

You can change any expression or entry using the backspace \P key, the delete \P key, or the insert \P [INS] key. You can make a change before or after you press \P

Example: Enter the expression $5^2 + 1$, and then change the expression to $5^2 + 5$.

Press	Result
5 x ² + 1	52+1■
₫ 5	52+5

Example: Enter the expression $5^2 + 1$, and then change the expression to $5^2 - 5$.

Press	Result
5 x ² + 1	5 ² +1 ■
◀ ● DEL DEL	CG
□ 5 ENTER	52-5 20

Example: Change the example above to $5^2 + 2 - 5$ using [2nd [ENTRY] to recall the expression and [2nd [INS] to insert + 2 into the expression.

Press	Result
[2nd] [ENTRY]	52-5 ■
1 2nd [NS] + 2 ENTER	52+2-5 22

Using - and -

Many graphing handhelds (including the TI-84 Plus) make a distinction between the symbols for subtraction and negation.

Use _ to enter subtraction operations. Use ① to enter a negative number in an operation, in an expression, or on a setup screen.

Example: Subtract 10 from 25.

Press	Result
2 5 - 1 0	25-10
ENTER	15

Example: Add 10 to -25.

Press	Result
<u>-</u> 2 5 + 1 0	-25+10 -15
ENTER	

Example: Subtract -10 from 25.

Press	Result
2510	2510 35
ENTER	

Note: Notice that the TI-84 Plus displays a slightly different symbol for negation and subtraction to make it easier for you to distinguish between the two. The negative symbol is raised and slightly shorter.

Using parentheses

Since all calculations inside parentheses are completed first, it is sometimes important to place a portion of an expression inside parentheses.

Example: Multiply 4*1+2; then multiply 4*(1+2).

Press	Result
4 × 1 + 2 ENTER	4*1+2 6
4 × (1 + 2) ENTER	4*1+2 4*(1+2) 6 12

Note: The closing parenthesis ① is optional. The operation will be completed if you omit it. The exception to this rule occurs when there is another operation following the parenthetical operation. In this case, you must include the closing parenthesis.

Example: Divide 1/2 by 2/3.

14

Press	Result
(1÷2)÷	(1/2)/(2/3)
(2 ÷ 3)	.75
ENTER	

Example: Calculate 16 1

Press	Result
16 A (1 ÷ 2) ENTER	16^(1/2) 4

Example: Calculate (-3)².

Press	Result
((-) 3) x^2 ENTER	(-3)2

Note: Try each of these examples without the parentheses and see what happens!

Storing a value

Values are stored to and recalled from memory using variable names.

Example: Store 25 to variable A and multiply A by 2.

Press	Result
2 5 STO→ [ALPHA] [A]	25+A

Press	Result
ENTER	25→A 25
2 × ALPHA [A] ENTER	25÷A 25 2*A 50
— or — [ALPHA] [A] × 2 ENTER	25÷A 25 2*A 50 A*2 50

Example: Find the value of $2X^3 - 5X^2 - 7X + 10$ when X = -0.5.


Press	Result
[-] . 5 STO▶ [X,T,⊖,n]	5÷X 5
(stores5 to X)	
(3.07.03 .3 .0 7.0	
2 [X,T,Θ,n] ^ 3	5÷X
$-$ 5 X,T,Θ,Π x^2	2X^3-5X²-7X+10 12
- 7 (X,T,Θ,n) + 1 0	12
ENTER	

You can remove a value stored to a variable using the DELVAR function or by storing 0 to the variable.

Example: Delete the value (-.5) stored to X above by storing 0.

Press	Result
O STO→ (X,T,⊖,n) ENTER	Ø÷X
X,T,O,n ENTER	Ø÷X X Ø

Graphing a function



To graph a function, you must:

- 1. Display the Y= Editor.
- 2. Enter the function.
- 3. Display the graph.

Note: If you previously changed graph type in the mode settings, you must change the type back to Func (the default setting) before you graph.

Example: Graph the function $Y = X^2 + 1$.

Press	Result
Υ <u>=</u>	Plot1 Plot2 Plot3 \Y1=\(\frac{1}{2}\) \Y2= \Y3= \Y4= \Y5= \Y6= \Y7=
X,Τ,Θ,η x ² + 1	Plot1 Plot2 Plot3 \1
(GRAPH)	

Note: If Y1 is not empty, press <u>CLEAR</u>. If there are additional entries in the Y= Editor, press <u>CLEAR</u> until all are clear.

Changing mode settings

The mode settings determine how entries are interpreted and how answers are displayed on the TI-84 Plus.

Example: Change the mode setting for decimals from Float to 3 decimal places.

Press	Result
MODE	Normal Sci Eng Float 0123456789 Radian Degree Func Par Pol Seq Connected Dot Sequential Simul Real a+bi re^0i Full Horiz G-T
ENTER	Normal Sci Eng Float 0128456789 Radian Degree Func Par Pol Seg Connected Dot Seguential Simul Real a+bi re^0i Full Horiz G-T
2nd [QUIT] 1 . 2 3 4 5 6 ENTER	1.23456

Note: You must press ENTER to change a mode setting. If you highlight the setting and then exit the mode menu without pressing ENTER, the setting will not be changed.

The mode menu includes the following settings:

Setting	Choices
Numeric notation	 Normal: for example, 12345.67 Sci (scientific): for example, 1.234567E4 Eng (engineering): for example, 12.34567E3
Decimal	 Float: lets the number of decimal places change based on the result (up to 10 digits) 0-9: sets the number of decimal places to a value (0-9) that you specify
Angle measure	 Radian: interprets angle values as radians Degree: interprets angle values as degrees

Setting	Choices
Type of graph	Func (functional): plots functions, where Y is a function of X
	 Par (parametric): plots relations, where X and Y are functions of T
	• Pol (polar): plots functions, where r is a function of $[n]$ θ
	Seq (sequence): plots sequences
Plot type	Connected: draws a line connecting each point calculated for the selected functions
	Dot: plots only the calculated points of the selected functions
Sequential or	Sequential: draws graphs one at a time
simultaneous graphing	Simul (simultaneous): draws several graphs at the same time
Real or	• <i>Real</i> : displays real numbers, such as 1, 1/2, $\sqrt{3}$
complex mode	• $a+bi$ (rectangular complex): displays as 3+2i
	• re^θi (polar complex): displays as re^θi
Screen display	Full: displays full screen
	Horiz: displays a horizontal split screen
	G-T: displays a vertical split screen (graph & table)

The importance of mode settings

Example: Multiply $2/3 \times 2$.

Press	Result
MODE ▼ ▶ ENTER	Normal Sci Eng Float 123456789 Radiar Degree Func Par Pol Seq Connected Dot Sequential Simul Real a+bi re^0i Full Horiz G-T

Press	Result
2 ÷ 3 × 2 ENTER	2/3*2


Your first reaction to this example is that the graphing handheld has produced a wrong answer. But you have set it to round to 0 decimal places (the nearest whole number), so for this setting the answer is correct. If you set rounding (decimals displayed) to 0 and then forget to reset it for later calculations, you may be surprised by some of your answers! With mode set to the default setting of *Float*, the result will be:

Press	Result
2	2/3*2 1.333333333


Setting the graphing window

To obtain the best view of the graph, you may need to change the boundaries of the window.

To display the WINDOW Editor, press WINDOW.



Window variables (shown in WINDOW Editor)



Corresponding viewing window (shown on Graph window)

The *Xmin, Xmax, Ymin,* and *Ymax* variables represent the boundaries of the viewing window.

Xmin: the minimum value of X to be displayed. Xmax: the maximum value of X to be displayed. Ymin: the minimum value of Y to be displayed. Ymax: the maximum value of Y to be displayed.

Xcsl (X scale): the distance between the tick marks on the X axis. Yscl (Y scale): the distance between the tick marks on the Y axis. Xres: pixel resolution—not usually changed except by advanced users.

To change the values:

- 1. Move the cursor to highlight the value you want to change.
- 2. Do one of the following:
 - Type a value or an expression. The old value is erased when you begin typing.
 - or —
 - Press CLEAR to clear the old value; then type the new one.

Note: Values are stored as you type them; you do not need to press ENTER. Pressing ENTER simply moves the cursor to the next window variable.

4. After you have made all changes, press 2nd [QUIT] to close the WINDOW Editor (or GRAPH to display the graph).

Example: Change the window settings to display a maximum X value of 25, a minimum X value of -25, a maximum Y value of 50, and a minimum Y value of -50.

Press	Result
(WINDOW)	WINDOW Xmin=-10 Xmax=10 Xscl=1 Ymin=-10 Ymax=10 Yscl=1 Xres=1
○ 25 ▼ 25 ▼ ▼○ 50 ▼ 50	WINDOW Xmin=-25 Xmax=25 Xscl=1 Ymin=-50 Ymax=50 Yscl=1 Xres=1

Press	Result
2nd [QUIT]	

Using **ZOOM**

The TI-84 Plus has ten predefined window settings that let you quickly adjust the graph window to a predetermined level of magnification. To display this menu, press ZOOM.

Selection	Result
1: ZBox	Lets you draw a box (using the cursor pad) to define the viewing window.
2: Zoom In	After you position the cursor and press ENTER, magnifies the graph around the cursor.
3: Zoom Out	After you position the cursor and press ENTER, displays more of the graph.
4: ZDecimal	Sets the change in X and Y to increments of .1 when you use TRACE.
5: ZSquare	Adjusts the viewing window so that X and Y dimensions are equal.
6: ZStandard	Sets the standard (default) window variables.
7: ZTrig	Sets the built-in trigonometry window variables.
8: ZInteger	After you position the cursor and press ENTER, sets the change in X and Y to whole number increments.
9: ZoomStat	Sets the values for currently defined statistical lists.
0: ZoomFit	Fits Ymin and Ymax between Xmin and Xmax .

Building a table

Tables are useful tools for comparing values for a function at multiple points.

Example: Build a table to evaluate the function $Y = X^3 - 2X$ at each integer between -10 and 10.

Press	Result
MODE ENTER (sets function graphing mode)	Normal Sci Eng Float 0123456789 Radian Degree Func Par Pol Seq Connected Dot Sequential Simul Real a+bi re^0i Full Horiz G-T
Y=	Plot1 Plot2 Plot3 \\Y1=\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\
X,T,Θ,η MATH 3 - 2 X,T,Θ,η	Plot1 Plot2 Plot3 \Y1■X³-2X■ \Y2= \Y3= \Y4= \Y5= \Y6= \Y7=
2nd [TBLSET]	TABLE SETUP TblStart=0 aTbl=1 Indent: Guto Ask Depend: Guto Ask
(sets TblStart; default settings shown for the other fields are appropriate)	TABLE SETUP TblStart=-10 aTbl=1 Indent: futo Ask Depend: Auto Ask
2nd [TABLE]	X Y1 = 1980 -9 -711 -8 -496 -7 -229 -6 -204 -5 -115 -4 -56 X=-10

Note: Press **→** repeatedly to see the changes in X and Y.

Clearing the Y= Editor

Before proceeding with the remaining examples in this guidebook, clear the Y= Editor.

Press	Result
Y =	Plot1 Plot2 Plot3 \Y1
CLEAR	Plot1 Plot2 Plot3 \Y1= \Y2= \Y3= \Y4= \Y4= \Y5= \Y6= \Y7=

Using the CATALOG

The CATALOG is an alphabetic list of all functions and instructions on the TI-84 Plus. Some of these items are also available on keys and menus.

To select from the CATALOG:

- 1. Position the cursor where you want to insert the item.
- 2. Press 2nd [CATALOG].
- 3. Press
 or
 or
 or to move the
 indicator to the function or instruction.

 (You can move quickly down the list by typing the first letter of the item you need.)
- 4. Press ENTER. Your selection is pasted on the home screen.

Notes:

- Items are listed in alphabetical order. Those that do not start with a letter $(+, \ge, \sqrt{\pi})$, π , and so on) are at the end of the list.
- You can also paste from the CATALOG to an editor, such as the Y= Editor.

Example: Enter the rand function on the home screen.

Press	Result
2nd [CATALOG] [R] ▼	CATALOG
ENTER	rand∎

Performing simple calculations

Changing a decimal to a fraction

Example: Add 1/2 + 1/4 and change your answer to a fraction.

Press	Result
1 ÷ 2 + 1 ÷ 4 ENTER	.75
MATH 1 [ENTER]	1/2+1/4 .75 Ans⊧Frac 3/4

Finding the least common multiple

Example: Find the least common multiple of 15 and 24.

Result
lcm(15,24)
120

Finding the square root

Example: Find the square root of 256.

Press	Result
2nd [√] 2 5 6)	T(256)
ENTER	16

Finding the factorial of numbers

Example: Compute the factorial of 5 and 30.

Press	Result
5 MATH PP 4 ENTER	5! 120
3 0 MATH > P 4 ENTER	5! 120 30! 2.652528598£32 Scientific notation

Solving trigonometric functions

Example: Find the sine of an angle of 72°.

Press	Result
SIN 7 2 2nd [ANGLE] [ENTER [) ENTER	sin(72°) .9510565163

If you are solving multiple problems using angles, be sure that mode is set to Degree. If you are in Radian mode and do not wish to change the mode, you can use [2nd] [ANGLE] [ENTER] (as you did in this example) to add the degree symbol to the calculation and override the Radian mode setting.

Adding Complex Numbers

Example: Add (3+5i) + (2-3i).

Press	Result
(3 + 5 2nd [i]) + (2 - 3 2nd [i]) ENTER	(3+5i)+(2-3i) 5+2i

Note: The i character is the second function of \Box (the decimal key).

Using the equation solver

You can use the TI-84 Plus equation solver to solve for a variable in an equation.

Example: Find the roots for the equation $X^2 - 13X - 48 = 0$.

Press	Result
MATH A	ITME NUM CPX PRB 4†31(5: */ 6:fMin(7:fMax(8:nDeriv(9:fnInt(IMSolver
ENTER	EQUATION SOLVER ean:0=

If you do not see **eqn:0=** as shown above, press ♠ (the up arrow), and then press <u>CLEAR</u> to erase the existing equation.

Press	Result
X,T,Θ,n x² - 1 3 X,T,Θ,n - 4 8	EQUATION SOLVER ean:0=X2-13X-48
ENTER	X2-13X-48=0 X=0 bound={-1e99,1
(ALPHA) [SOLVE]	X2-13X-48=0 • X=-3 bound={-1£99,1 • left-rt=0

Press	Result
100	X2-13X-48=0 X=100 0 bound={-1£99,1 left-rt=0
(ALPHA) [SOLVE]	X2-13X-48=0 •X=16 bound={-1e99,1 •left-rt=0

The two roots are -3 and 16. Since you did not enter a guess, the TI-84 Plus used 0 (the default guess) and first returned the answer nearest 0. To find other roots, you must enter another guess. In this example, you entered 100.

Entering data into lists

You can enter data into lists using either of two methods:

- Using braces and STO→ on the home screen
 - or —
- Using the statistical list editor.

Using ST0▶

Example: Store 1, 2, 3, and 4 to list 1 (L1).

Press	Result	
2nd [{] 1 , 2 , 3 , 4 2nd [}]	(1,2,3,4)	

Press	Result
STO▶	(1,2,3,4)→■
2nd [L1] ENTER	(1,2,3,4)+L1 (1 2 3 4)

Using the statistical list editor

Example: Store 5, 6, 7, and 8 to list 2 (L2).

Press	Result
(STAT) (ENTER)	L1 L2 L3 1
(if L2 already contains data)	L1
5 ENTER 6 ENTER 7 ENTER 8 ENTER	L1 L2 L3 2 1

Press	Result
[2nd] [QUIT] [2nd] [L2] [ENTER] (displays the contents of the list on the home screen)	L2 (5 6 7 8)

Plotting data

When you have statistical data stored in lists, you can display the data you have collected in a scatter plot, xyLine, histogram, box plot, or normal probability plot.

You will need to:

- 1. Determine which lists contain your data.
- Tell the TI-84 Plus which lists of data you want to plot and define the plot.
- 3. Display the plot.

Determine which lists contain your data

Press	Result
STAT	### CALC TESTS ##Edit 2:SortA(3:SortD(4:C1rList 5:SetUpEditor
ENTER	L1 L2 L3 2 1 5 5 5 5 5 5 5 5 5

Note: In some cases, you may have several lists stored and you may have to press > several times to find the correct lists.

Tell the TI-84 Plus which lists you want to plot

Press	Result
2nd [STAT PLOT]	3 (1
4 ENTER (turns plots off if any plots are on)	PlotsOff Done
2nd [STAT PLOT]	##Plot1Off
ENTER	Plots Plots On Unit Type: De
(turns Plot1 on)	Plot2 Plot3 Off Off Type: **** **** **** **** **** **** ****
ENTER (enters L1 as the Xlist)	Plot2 Plot3 Proff Type: Profit White Profit Xlist:L1 Ylist:L2 Mark: • •

Press	Result
▼ 2nd [LIST] ▼ [ENTER] (enters L2 as the Ylist)	Plot2 Plot3 Proff Type: Profit White Control Xlist:L1 Ylist:L2 Mark: • •
(selects + as the plotting mark)	Plot2 Plot3 Off Type: De
Y= CLEAR	Plot1 Plot2 Plot3 \Y1= \Y2= \Y3= \Y4= \Y5= \Y6= \Y6= \Y7=

Note: This step is optional and is not necessary unless there is a previous entry in the Y= Editor. If there are additional entries in the Y= Editor, press © CLEAR until all are clear.

Display the plot

Press	Result
(GRAPH)	
ZOOM • ENTER (selects ZoomStat)	· • • · · · · · · · · · · · · · · · · ·

Note: If you would like to add the regression line to a scatter plot, adding Y1 to the end of the instruction: **LinReg(ax+b) L1, L2, Y1**. (Press VARS) [ENTER] [ENTER] to add Y1.) Press [GRAPH] to see the regression line.

Calculating a linear regression

If you wish to calculate the linear regression for data, you can do so using the **LinReg** instruction from the <u>STAT</u> CALC menu.

Example: Calculate the linear regression for the data entered in L1 and L2.

Press	Result
STAT PVV	EDIT MINE TESTS 1:1-Var Stats 2:2-Var Stats 3:Med-Med SHLinRe9(ax+b) 5:QuadRe9 6:CubicRe9 7-QuartRe9
ENTER	LinRe9(ax+b) ■
2nd [L1] , 2nd [L2]	LinRe9(ax+b) L1, L2∎
ENTER	LinRe9 9=ax+b a=1 b=4

Note: The information on the last screen means that the points in L1 and L2 [(1,5)(2,6)(3,7)(4,8)] all lie on the line Y = X + 4.

Calculating statistical variables

The TI-84 Plus lets you easily calculate one-variable or two-variable statistics for data that you have entered into lists.

Example: Using the data that you entered into L1 from the previous section "Using STOO", calculate one-variable statistics.

Press	Result
STAT ▶	EDIT MINE TESTS #1-Var Stats 2:2-Var Stats 3:Med-Med 4:LinRe9(ax+b) 5:QuadRe9 6:CubicRe9 7-QuartRe9
ENTER	1-Var Stats
2nd [L1]	1-Var Stats L1
ENTER	1-Var Stats x=2.5 Σx=10 Σx≥=30 Sx=1.290994449 σx=1.118033989 ↓n=4

Using the MATRIX Editor

Creating a new matrix

Press	Result
2nd [MATRIX] •	NAMES MATH (±000) 100 (A) 110 (B) 120 (B) 130 (C) 140
ENTER	MATRIX[A] 1 ×1
2 ENTER 2 ENTER	MATRIX[A] 2 ×2
1 ENTER 5 ENTER 2 ENTER 8 ENTER	MATRIX[A] 2 ×2 [1 5] [2 6] [2 7]

Note: When you press ENTER, the cursor automatically highlights the next cell so that you can continue entering or editing values. To enter a new value, you can start typing without pressing ENTER, but you must press ENTER to edit an existing value.

Using matrices to solve systems of equations

You can solve several equations simultaneously by entering their coefficients into a matrix and then using the **rref** (reduced row-echelon form) function. For example, in the equations below, enter 3, 3, and 24 (for 3X, 3Y, and 24) in the first row, and 2, 1, 13 (for 2X, 1Y, and 13) in the second row.

Example: Solve 3X + 3Y = 24 and 2X + Y = 13

Press	Result
2nd [MATRIX] I I	NAMES MATH (1000) 1: [A] 2×2 201 3: [C] 4: [D] 5: [E] 6: [F] 7↓[G]
ENTER	MATRIX[B] 1 ×1
2 ENTER 3 ENTER	MATRIX[B] 2 ×3
3 ENTER 3 ENTER 2 4 ENTER 2 ENTER 1 ENTER 1 3 ENTER	MATRIX[B] 2 ×3 [3 3 24] [2 3 2 3]
2nd [QUIT]	
2nd [MATRIX] >	NAMES MANNE EDIT Manual Edit 2: T 3: dim(4: Fill(5: identity(6: randM(7↓au9ment(

Press	Result
	NAMES INDIE EDIT Ø1cumSum(A:ref(SHrref(C:rowSwap(D:row+(E:*row(F:*row+(
ENTER	rref(
2nd [MATRIX] ▼ ENTER	rref([B]■
ENTER	rref([B] [[1 0 5] [0 1 3]]

You can interpret the resulting matrix as:

$$[1\ 0\ 5]$$
 represents $1X + 0Y = 5$ or $X = 5$

$$[0\ 1\ 3]$$
 represents $0X + 1Y = 3$ or $Y = 3$

The solution to this system of equations is X = 5, Y = 3.

Grouping

Grouping lets you make a copy of two or more variables and store them in the Flash memory of the TI-84 Plus. This function is similar to "zipping" a computer file and storing it. For example, suppose that you want to save data you collected for time, temperature, humidity, and barometric pressure because you may need to use the data for another assignment.

Grouping lets you keep these lists together for future use. Instead of trying to locate the correct lists and remember which ones were collected together, you can simply recall the group. Grouping also saves space on your graphing handheld by copying variables from RAM to Flash memory.

Example: Group lists L1, L2, and L3 and name them GROUPA.

Press	Result	
2nd [MEM]	ilaina 2iMem M9mt/Del 3:Clear Entries 4:ClrAllLists 5:Archive 6:UnArchive 7:Reset 8:Group	
8	HROUE UNGROUP ■Create New	
ENTER	GROUP Name=0 Caution: You are in alpha mode.	
[G] [R] [O] [U] [P] [A]	GROUP Name=GROUPA	
ENTER	#####################################	

Press	Result	
4	DONE L1 LIST L2 LIST L3 LIST L4 LIST L5 LIST L5 LIST L5 LIST	
ENTER • ENTER • ENTER	DONE	
P .	SELECT DONE	
ENTER	Copying Variables to Group: GROUPA Done	

Ungrouping

To use variables that have been grouped, you must ungroup.

Example: Ungroup GROUPA.

Press	Result
2nd [MEM]	ilain: ilain: ilain: M9mt/Del 3:Clear Entries 4:ClrAllLists 5:Archive 6:UnArchive 7:Reset 8:Group

Press	Result	
8	###Create New	
P	GROUP WINGKOUS MH*GROUPA	
ENTER	OuplicateNams 1 Rename 2: Overwrite 3: Overwrite All 4: Omit 5: Quit L1 LIST	
(to overwrite all three lists)	Ungrouping: GROUPA L1 LIST L2 LIST • L3 LIST Done	

Error messages

Occasionally, when you enter a function or instruction or attempt to display a graph, the TI-84 Plus will return an error message.

For more details, see Appendix B

Example: Enter the least common multiple function **Icm(** followed by only one number.

Press	Result
MATH • • ENTER 2 7 .	lcm(27,
ENTER	ERR:SYNTAX ##Quit 2:Goto

If you select **1:Quit**, you return to the home screen with the cursor on a new entry line. If you select **2:Goto**, you return to the original entry line; the cursor is flashing at the location of the error. You can now correct the error and continue.

You can find a complete list of error conditions with explanations in Appendix B: General Information.

Resetting defaults

If you are getting unexpected results, or if another person has used your TI-84 Plus and may have changed the settings, you should consider resetting defaults on the TI-84 Plus.

Press	Result
2nd [MEM]	#####################################

Press	Result	
7	### ARCHIVE ALL ##All RAM 2: Defaults	
2	ASSIMENIS UNIC UNIO 2: Reset	
2	TI-84Plus Silver Edition 2.20 Defaults set	

WARNING: If you reset All RAM in step 3 above, you will delete stored variables, lists, applications, and programs. Be sure you have backed up any essential data before you select this option.

Installing applications

Graphing handheld software applications (Apps) let you update the functionality of your TI-84 Plus by installing Apps. This is similar to the way that you add new features to your computer by installing new software applications.

You can find applications for the TI-84 Plus at the TI Online Store at **education.ti.com**. Once you have downloaded an application to your computer, you must use TI Connect™ or TI-GRAPH LINK™ software and the USB computer cable or TI Connectivity Cable USB to install the application on your TI-84 Plus.

Instructions for Windows®

- 1. Connect the USB computer cable between your computer and TI-84 Plus. Make sure the TI-84 Plus is on the home screen.
- 2. Using Windows (or NT) Explorer, locate the application file you want to transfer to the connected device.

- 3. Reduce the size of the Explorer window so you can see the TI Connect desktop icon.
- 4. Click the application file you want to transfer.
- Drag the application file out of Explorer and drop it on the TI Connect desktop icon.

Instructions for Macintosh®

- Connect the TI Connectivity Cable USB for Macintosh/Windows between your computer and TI-84 Plus, and make sure the TI-84 Plus is on the home screen.
- 2. Launch the TI-GRAPH LINK 2 software and establish a connection to your TI-84 Plus.
- Drag the application to the TI-84 Plus window in TI-GRAPH LINK. Follow any on-screen instructions that are given.

Running applications

Once you have installed an application on your TI-84 Plus, you must start the application to use its features.

Example: Start the Catalog Help (CtlgHelp) app on the TI-84 Plus.

Press	Result
[APPS]	######################################
▼ ENTER	TI-83PIUS Catalog Help 1.0 ©Texas Instruments 2000

Ouick reference

Press	То
2nd 🛋	Darken the screen
2nd ▼	Lighten the screen
2nd •	Move the cursor to the end of an expression
2nd ◀	Move the cursor to the beginning of an expression
(ALPHA) ▼	Page down to the next screen (on menus)
ALPHA 📤	Page up to the next screen (on menus)
[2nd] [ENTRY]	Place your last entry on the current entry line on the home screen
[2nd] [ANS]	Place Ans (a reference to your last answer) on the current entry line on the home screen, allowing you to use the answer in the next calculation
DEL	Delete the character under the cursor
2nd [INS]	Insert additional characters at the cursor
▼▲	Move the cursor from line to line
Pd	Move the cursor from character to character within a line
CLEAR	Clear the current line. (If the cursor is on a blank line, clears everything on the home screen.)

Battery precautions

Take these precautions when replacing batteries.

- Do not leave batteries within the reach of children.
- Do not mix new and used batteries. Do not mix brands (or types within brands) of batteries.
- Do not mix rechargeable and non-rechargeable batteries.
- Install batteries according to polarity (+ and) diagrams.
- Do not place non-rechargeable batteries in a battery recharger.
- Properly dispose of used batteries immediately.
- Do not incinerate or dismantle batteries.

Activities

The Quadratic Formula

Entering a Calculation


Use the quadratic formula to solve the quadratic equations $3x^2 + 5x + 2 = 0$ and $2x^2 - x + 3 = 0$. Begin with the equation $3x^2 + 5x + 2 = 0$.

- Press 3 STO→ [ALPHA] [A] (above MATH) to store the coefficient of the x² term.
- Press ALPHA [:] (above __). The colon allows you to enter more than one instruction on a line.


3+A:5+B:2+C■

- 3. Press 5 STO→ ALPHA [B] (above APPS) to store the coefficient of the X term. Press ALPHA [:] to enter a new instruction on the same line. Press 2 STO→ ALPHA [C] (above PRGM) to store the constant.
- 4. Press ENTER to store the values to the variables A, B, and C.

The last value you stored is shown on the right side of the display. The cursor moves to the next line, ready for your next entry.




$$\frac{-b \pm \sqrt{b^2 - 4ac}}{2a}$$



6. Press ENTER to find one solution for the equation $3x^2 + 5x + 2 = 0$.

The answer is shown on the right side of the display. The cursor moves to the next line, ready for you to enter the next expression.



Converting to a Fraction

You can show the solution as a fraction.

1. Press MATH to display the **MATH** menu.




Press 1 to select 1:>Frac from the MATH menu.

When you press **1**, **Ans>Frac** is displayed on the home screen. **Ans** is a variable that contains the last calculated answer.

(-B+√(B≥-4AC))/(2A) -.6666666667 Ans⊁Frac∎

3. Press ENTER to convert the result to a fraction.




To save keystrokes, you can recall the last expression you entered, and then edit it for a new calculation.

4. Press 2nd [ENTRY] (above ENTER) to recall the fraction conversion entry, and then press 2nd [ENTRY] again to recall the quadratic-formula expression,

$$\frac{-b+\sqrt{b^2-4ac}}{2a}$$

5. Press • to move the cursor onto the + sign in the formula. Press • to edit the quadratic-formula expression to become:

$$\frac{-b - \sqrt{b^2 - 4ac}}{2a}$$



6. Press ENTER to find the other solution for the quadratic equation $3x^2 + 5x + 2 = 0$.

Displaying Complex Results


Now solve the equation $2x^2 - x + 3 = 0$. When you set $\mathbf{a} + \mathbf{b}i$ complex number mode, the TI-84 Plus displays complex results.

 Press MODE ▼▼▼▼ (6 times), and then press ► to position the cursor over a+bi. Press ENTER to select a+bi complexnumber mode.



- Press 2nd [QUIT] (above MODE) to return to the home screen, and then press CLEAR to clear it.
- 3. Press 2 STO ALPHA [A] ALPHA [:] (-) 1 STO ALPHA [B] ALPHA [:] 3 STO ALPHA [C] ENTER.

The coefficient of the x^2 term, the coefficient of the X term, and the constant for the new equation are stored to A, B, and C, respectively.




 Press 2nd [ENTRY] to recall the store instruction, and then press 2nd [ENTRY] again to recall the quadratic-formula expression,

$$\frac{-b-\sqrt{b^2-4ac}}{2a}$$

5. Press ENTER to find one solution for the equation $2x^2 - x + 3 = 0$.

6. Press 2nd [ENTRY] repeatedly until this quadratic-formula expression is displayed:

$$\frac{-b + \sqrt{b^2 - 4ac}}{2a}$$



7. Press ENTER to find the other solution for the quadratic equation: $2x^2 - x + 3 = 0$.

Note: An alternative for solving equations for real numbers is to use the built-in Equation Solver.

Box with Lid

Defining a Function

Take a 20 cm \times 25 cm. sheet of paper and cut X \times X squares from two corners. Cut X \times 12.5 cm rectangles from the other two corners as shown in the diagram below. Fold the paper into a box with a lid. What value of X would give your box the maximum volume V? Use the table and graphs to determine the solution.

Begin by defining a function that describes the volume of the box.

From the diagram:


$$2X + A = 20$$

$$2X + 2B = 25$$

$$V = A*B*X$$

Substituting:

$$V = (20 - 2X) (25/2 - X) X$$



1. Press \(\begin{align*} = \text{to display the } \begin{align*} \begin{align*} \begin{align*} \begin{align*} = \begin{align*} \begin{align

Plot1 Plot2	P1ot3
\Y1= ■	
\Y2=	
\Υ3=	
\Ŷ4=	
\Υs=	
\Ŷ6=	
√Ý7=	

Press (20 - 2 (X,T,Θ,n)) (25 ÷ 2 - (X,T,Θ,n)) (X,T,Θ,n ENTER to define the volume function as Y1 in terms of X.

 $[X,T,\Theta,n]$ lets you enter **X** quickly, without having to press [ALPHA]. The highlighted = sign indicates that **Y1** is selected.


Plot1 Plot2 Plot3
NY18(20-2X)(25/2
I-XX
\Y2= ■
\Ŷ3=
\Y4=
\Ys=
√Ŷ6=

Defining a Table of Values

The table feature of the TI-84 Plus displays numeric information about a function. You can use a table of values from the function you just defined to estimate an answer to the problem.

- Press 2nd [TBLSET] (above WINDOW) to display the TABLE SETUP menu.
- 2. Press ENTER to accept TblStart=0.
- Press 1 ENTER to define the table increment
 ΔTbl=1. Leave Indpnt: Auto and
 Depend: Auto so that the table will be
 generated automatically.
- 4. Press 2nd [TABLE] (above GRAPH) to display the table.

Notice that the maximum value for **Y1** (box's volume) occurs when **X** is about **4**, between **3** and **5**.




Notice that the maximum length of **X** for this problem occurs where the sign of **Y1** (box's volume) changes from positive to negative, between **10** and **11**.

6. Press 2nd [TBLSET].

Notice that **TbIStart** has changed to **6** to reflect the first line of the table as it was last displayed. (In step 5, the first value of **X** displayed in the table is **6**.)



X	Y1	
SHAMFING	0.07699 0.0399 0.03394	
X=0		





Zooming In on the Table

You can adjust the way a table is displayed to get more information about a defined function. With smaller values for $\Delta \mathbf{Tbl}$, you can zoom in on the table.

1. Press 3 ENTER to set **TblStart**. Press . 1 ENTER to set Δ**Tbl**.

This adjusts the table setup to get a more accurate estimate of **X** for maximum volume **Y1**.


- 2. Press [2nd] [TABLE].
- Press

 and

 to scroll the table.

Notice that the maximum value for Y1 is 410.26, which occurs at X=3.7. Therefore, the maximum occurs where 3.6<X<3.8.


4. Press 2nd [TBLSET]. Press 3 . 6 [ENTER] to set TblStart. Press . 01 [ENTER] to set ΔTbl.





5. Press 2nd [TABLE], and then press → and → to scroll the table.

Four equivalent maximum values are shown, **410.26** at **X=3.67**, **3.68**, **3.69**, and **3.70**.



Press
 or
 or
 to move the cursor to 3.67.
 Press
 to move the cursor into the Y1 column.

The value of **Y1** at **X=3.67** is displayed on the bottom line in full precision as **410.261226**.

X	Y1		
3.667 3.669 3.69 3.77 3.72 3.72	410.25 410.26 410.26 410.26 410.25 410.23		
Y1=410.261226			

7. Press

to display the other maximum.

The value of **Y1** at **X=3.68** in full precision is **410.264064**, at **X=3.69** is **410.262318** and at **X=3.7** is **410.256**.


The maximum volume of the box would occur at **3.68** if you could measure and cut the paper at .01-centimeter increments.

X	Υ1 I	
3.66 3.669 3.7 3.7 3.7 3.7 3.7 3.7	410.25 410.26 410.26 410.26 410.25 410.23	
Y1=410.264064		


Setting the Viewing Window

You also can use the graphing features of the TI-84 Plus to find the maximum value of a previously defined function. When the graph is activated, the viewing window defines the displayed portion of the coordinate plane. The values of the window variables determine the size of the viewing window.

 Press <u>WINDOW</u> to display the window editor, where you can view and edit the values of the window variables.



The standard window variables define the viewing window as shown. **Xmin**, **Xmax**, **Ymin**, and **Ymax** define the boundaries of the display. **Xscl** and **Yscl** define the distance between tick marks on the **X** and **Y** axes. **Xres** controls resolution.



- 2. Press **0** ENTER to define **Xmin**.
- WINDOW Xmin=0 Xmax=20/2∎ Xscl=1 Ymin=-10 Ymax=10 Yscl=1 Xres=1
- Press <u>ENTER</u>. The expression is evaluated, and **10** is stored in **Xmax**. Press <u>ENTER</u> to accept **Xscl** as **1**.
- Press 0 ENTER 500 ENTER 100 ENTER 1 ENTER to define the remaining window variables.


```
WINDOW
Xmin=0
Xmax=10
Xscl=1
Ymin=0
Ymax=500
Yscl=100
Xres=1
```

Displaying and Tracing the Graph

Now that you have defined the function to be graphed and the window in which to graph it, you can display and explore the graph. You can trace along a function using the **TRACE** feature.


 Press GRAPH to graph the selected function in the viewing window.

The graph of Y1=(20-2X)(25/2-X)X is displayed.




Press to activate the free-moving graph cursor.

The **X** and **Y** coordinate values for the position of the graph cursor are displayed on the bottom line.




 Press ◀, ▶, ♠, and ▼ to move the freemoving cursor to the apparent maximum of the function.

As you move the cursor, the **X** and **Y** coordinate values are updated continually.



4. Press TRACE. The trace cursor is displayed on the **Y1** function.

The function that you are tracing is displayed in the top-left corner.




Y1=(20-2X)(25/2-X)X

5. Press ◀ and ▶ to trace along Y1, one X dot at a time, evaluating Y1 at each X.


You also can enter your estimate for the maximum value of **X**.

6. Press 3 . 8. When you press a number key while in **TRACE**, the **X**= prompt is displayed in the bottom-left corner.




7. Press ENTER.

The trace cursor jumps to the point on the Y1 function evaluated at X=3.8



8. Press • and • until you are on the maximum • value.

This is the maximum of **Y1(X)** for the **X** pixel values. The actual, precise maximum may lie between pixel values.




Zooming In on the Graph

To help identify maximums, minimums, roots, and intersections of functions, you can magnify the viewing window at a specific location using the **ZOOM** instructions.

1. Press 200M to display the **ZOOM** menu.


This menu is a typical TI-84 Plus menu. To select an item, you can either press the number or letter next to the item, or you can press

until the item number or letter is highlighted, and then press ENTER.




Press 2 to select 2:Zoom In.

The graph is displayed again. The cursor has changed to indicate that you are using a **ZOOM** instruction.




3. With the cursor near the maximum value of the function, press [ENTER].

The new viewing window is displayed. Both **Xmax-Xmin** and **Ymax-Ymin** have been adjusted by factors of 4, the default values for the zoom factors.



4. Press <u>WINDOW</u> to display the new window settings.




Finding the Calculated Maximum

You can use a **CALCULATE** menu operation to calculate a local maximum of a function.

 Press 2nd [CALC] (above TRACE) to display the CALCULATE menu. Press 4 to select 4:maximum.

The graph is displayed again with a **Left Bound?** prompt.



 Press 1 to trace along the curve to a point to the left of the maximum, and then press ENTER.

A > at the top of the screen indicates the selected bound.


A **Right Bound?** prompt is displayed.


3. Press > to trace along the curve to a point to the right of the maximum, and then press ENTER.

A \ at the top of the screen indicates the selected bound.

A Guess? prompt is displayed.

4. Press 1 to trace to a point near the maximum, and then press ENTER.







Or, press **3** • **8**, and then press ENTER to enter a guess for the maximum.

When you press a number key in **TRACE**, the **X**= prompt is displayed in the bottom-left corner.

Notice how the values for the calculated maximum compare with the maximums found with the free-moving cursor, the trace cursor, and the table.

Note: In steps 2 and 3 above, you can enter values directly for Left Bound and Right Bound, in the same way as described in step 4.





Comparing Test Results Using Box Plots

Problem

An experiment found a significant difference between boys and girls pertaining to their ability to identify objects held in their left hands, which are controlled by the right side of their brains, versus their right hands, which are controlled by the left side of their brains. The TI Graphics team conducted a similar test for adult men and women.


The test involved 30 small objects, which participants were not allowed to see. First, they held 15 of the objects one by one in their left hands and guessed what they were. Then they held the other 15 objects one by one in their right hands and guessed what they were. Use box plots to compare visually the correct-guess data from this table.

Correct Guesses				
Women Left	Women Right	Men Left	Men Right	
8	4	7	12	
9	1	8	6	
12	8	7	12	
11	12	5	12	
10	11	7	7	
8	11	8	11	
12	13	11	12	

Correct Guesses				
Women Left	Women Right	Men Left	Men Right	
7	12	4	8	
9	11	10	12	
11	12	14	11	
		13	9	
		5	9	


Procedure

- Press <u>STAT</u> 5 to select 5:SetUpEditor. Enter list names WLEFT, WRGHT, MLEFT, and MRGHT, separated by commas. Press <u>ENTER</u>. The stat list editor now contains only these four lists.
- 2. Press STAT 1 to select 1:Edit.
- 3. Enter into **WLEFT** the number of correct guesses each woman made using her left hand (**Women Left**). Press ▶ to move to **WRGHT** and enter the number of correct guesses each woman made using her right hand (**Women Right**).
- Likewise, enter each man's correct guesses in MLEFT (Men Left) and MRGHT (Men Right).
- 5. Press and STAT PLOT]. Select 1:Plot1. Turn on plot 1; define it as a modified box plot : that uses WLEFT. Move the cursor to the top line and select Plot2. Turn on plot 2; define it as a modified box plot that uses WRGHT.
- 6. Press Y=1. Turn off all functions.
- Press WINDOW. Set Xscl=1 and Yscl=0. Press ZOOM 9 to select
 9:ZoomStat. This adjusts the viewing window and displays the box plots for the women's results.
- 8. Press TRACE.



Use (and) to examine minX, Q1, Med, Q3, and maxX for each plot. Notice the outlier to the women's right-hand data. What is the median for the left hand? For the right hand? With which hand were the women more accurate guessers, according to the box plots?

 Examine the men's results. Redefine plot 1 to use MLEFT, redefine plot 2 to use MRGHT. Press (TRACE).



Press (and) to examine minX, Q1, Med, Q3, and maxX for each plot. What difference do you see between the plots?

- 10. Compare the left-hand results. Redefine plot 1 to use WLEFT, redefine plot 2 to use MLEFT, and then press TRACE to examine minX, Q1, Med, Q3, and maxX for each plot. Who were the better left-hand guessers, men or women?
- 11. Compare the right-hand results. Define plot 1 to use WRGHT, define plot 2 to use MRGHT, and then press TRACE to examine minX, Q1, Med, Q3, and maxX for each plot. Who were the better right-hand guessers?

In the original experiment boys did not guess as well with right hands, while girls guessed equally well with either hand. This is not what our box plots show for adults. Do you think that this is because adults have learned to adapt or because our sample was not large enough?

Graphing Piecewise Functions

Problem

The fine for speeding on a road with a speed limit of 45 kilometers per hour (kph) is 50; plus 5 for each kph from 46 to 55 kph; plus 10 for each kph from 56 to 65 kph; plus 20 for each kph from 66 kph and above. Graph the piecewise function that describes the cost of the ticket.

The fine (Y) as a function of kilometers per hour (X) is:


Y = 0	$0 < X \le 45$
Y = 50 + 5 (X - 45)	45 < X ≤ 55
Y = 50 + 5 * 10 + 10 (X - 55)	55 < X ≤ 65
Y = 50 + 5 * 10 + 10 * 10 + 20 (X - 65)	65 < X

Procedure

- 1. Press MODE. Select **Func** and the default settings.
- 2. Press \(\) Turn off all functions and stat plots. Enter the \(\) = function to describe the fine. Use the \(\) TEST menu operations to define the piecewise function. Set the graph style for \(\) 1 to \(\). (dot).

```
Piots Piots Piots
'\18(50+5(X-45))
(45(X)(X≤55)+(10
0+10(X-55))(55(X
)(X≤65)+(200+20(
X-65))(65(X)
\\2=
\\3=
```

- 3. Press WINDOW and set Xmin=-2, Xscl=10, Ymin=-5, and Yscl=10. Ignore Xmax and Ymax; they are set by ΔX and ΔY in step 4.
- 4. Press [2nd] [QUIT] to return to the home screen. Store 1 to ΔX, and then store 5 to ΔY. ΔX and ΔY are on the VARS Window X/Y secondary menu. ΔX and ΔY specify the horizontal and vertical distance between the centers of adjacent pixels. Integer values for ΔX and ΔY produce nice values for tracing.
- 5. Press TRACE to plot the function. At what speed does the ticket exceed 250?



Graphing Inequalities


Problem

Graph the inequality $0.4x^3 - 3x + 5 < 0.2x + 4$. Use the **TEST** menu operations to explore the values of X where the inequality is true and where it is false.


Procedure

- 1. Press MODE. Select **Dot**, **Simul**, and the default settings. Setting **Dot** mode changes all graph style icons to '. (dot) in the **Y=** editor.
- 2. Press Y=. Turn off all functions and stat plots. Enter the left side of the inequality as **Y4** and the right side as **Y5**.

3. Enter the statement of the inequality as **Y6**. This function evaluates to **1** if true or **0** if false.




- 4. Press 200M 6 to graph the inequality in the standard window.
- 5. Press TRACE ▼ to move to Y6. Then press and to trace the inequality, observing the value of Y.




6. Press Y=. Turn off **Y4**, **Y5**, and **Y6**. Enter equations to graph only the inequality.



7. Press TRACE. Notice that the values of **Y7** and **Y8** are zero where the inequality is false.






Solving a System of Nonlinear Equations

Problem


Using a graph, solve the equation $x^3-2x=2\cos(x)$. Stated another way, solve the system of two equations and two unknowns: $y = x^3-2x$ and $y = 2\cos(x)$. Use **ZOOM** factors to control the decimal places displayed on the graph.

Procedure

1. Press MODE. Select the default mode settings. Press Y=. Turn off all functions and stat plots. Enter the functions.



2. Press 200M 4 to select 4:**ZDecimal**. The display shows that two solutions may exist (points where the two functions appear to intersect).



- Press ZOOM 4 to select 4:SetFactors from the ZOOM MEMORY menu. Set XFact=10 and YFact=10.
- 4. Press <u>Z00M</u> 2 to select 2:Zoom In. Use <u>I</u>, <u>I</u>, <u>A</u>, and <u>I</u> to move the free-moving cursor onto the apparent intersection of the functions on the right side of the display. As you move the cursor, notice that the X and Y values have one decimal place.
- 5. Press ENTER to zoom in. Move the cursor over the intersection. As you move the cursor, notice that now the **X** and **Y** values have two decimal places.
- 6. Press ENTER to zoom in again. Move the free-moving cursor onto a point exactly on the intersection. Notice the number of decimal places.
- 7. Press 2nd [CALC] **5** to select **5:intersect**. Press ENTER to select the first curve and ENTER to select the second curve. To guess, move the trace cursor near the intersection. Press ENTER. What are the coordinates of the intersection point?
- 8. Press 200M 4 to select 4:**ZDecimal** to redisplay the original graph.


9. Press 200M. Select **2:Zoom In** and repeat steps 4 through 8 to explore the apparent function intersection on the left side of the display.

Using a Program to Create the Sierpinski Triangle

Setting up the Program

This program creates a drawing of a famous fractal, the Sierpinski Triangle, and stores the drawing to a picture. To begin, press PRGM >> 1. Name the program **SIERPINS**, and then press ENTER. The program editor is displayed.

Program




:Pt-On(X,Y) :End

:StorePic 6

Draw point.
End of **For** group.
Store picture.

After you execute the program above, you can recall and display the picture with the instruction **RecallPic 6**.



Graphing Cobweb Attractors

Problem

Using **Web** format, you can identify points with attracting and repelling behavior in sequence graphing.

Procedure

- 1. Press MODE. Select **Seq** and the default mode settings. Press 2nd [FORMAT]. Select **Web** format and the default format settings.
- 2. Press Y=. Clear all functions and turn off all stat plots. Enter the sequence that corresponds to the expression Y = K X(1-X).

- 3. Press 2nd [QUIT] to return to the home screen, and then store 2.9 to K.
- 4. Press WINDOW. Set the window variables.


 nMin=0
 Xmin=0
 Ymin=-.26

 nMax=10
 Xmax=1
 Ymax=1.1


 PlotStart=1
 Xscl=1
 Yscl=1

PlotStep=1

5. Press TRACE to display the graph, and then press to trace the cobweb. This is a cobweb with one attractor.



- Change K to 3.44 and trace the graph to show a cobweb with two attractors.
- Change K to 3.54 and trace the graph to show a cobweb with four attractors.



Using a Program to Guess the Coefficients

Setting Up the Program

This program graphs the function A sin(BX) with random integer coefficients between 1 and 10. Try to guess the coefficients and graph your guess as C sin(DX). The program continues until your guess is correct.

Program

```
PROGRAM: GUESS
:PlotsOff :Func
:FnOff :Radian
:ClrHome
:"Asin(BX)">Y1
:"Csin(DX)">Y2

:GraphStyle(1,1)
:GraphStyle(2,5)

:FnOff 2
:randInt(1,10)>A
:randInt(1,10)>B
:0>C:0>Define equations.

Define equations.
```

```
: -2π→Xmin
:2\pi \rightarrow Xmax
:π/2>Xscl
                                Set viewing window.
:-10>Ymin
:10→Ymax
:1>Yscl
:DispGraph
                                Display graph.
:Pause
:FnOn 2
:Lbl 7
                                Prompt for guess.
:Prompt C, D
:DispGraph
                                Display graph.
:Pause
: Tf C=A
:Text(1,1,"C IS OK")
:If C≠A
:Text(1,1,"C IS
WRONG")
:If D=B
:Text(1,50,"D IS OK")
:If D≠B
:Text(1,50,"D IS
WRONG")
:DispGraph
                                Display graph.
:Pause
:If C=A and D=B
                                Quit if guesses are correct.
:Stop
:Goto Z
```

Graphing the Unit Circle and Trigonometric Curves

Problem

Using parametric graphing mode, graph the unit circle and the sine curve to show the relationship between them.

Any function that can be plotted in **Func** mode can be plotted in **Par** mode by defining the **X** component as **T** and the **Y** component as **F(T)**.

Procedure

- 1. Press MODE. Select Par, Simul, and the default settings.
- 2. Press WINDOW. Set the viewing window.

Tmin=0	Xmin=⁻2	Ymin=⁻3
Tmax=2 π	Xmax=7.4	Ymax=3
Tstep=.1	$Xscl=\pi/2$	Yscl=1

3. Press \(\frac{1}{2} \). Turn off all functions and stat plots. Enter the expressions to define the unit circle centered on (0,0).

```
Plot1 Plot2 Plot3

\X1TBCOS(T)

\Y1TBSin(T)

\X2TBT

\Y2TBSin(T)
```

4. Enter the expressions to define the sine curve.

```
Plot1 Plot2 Plot3


\X11 BCOS(T)

\Y11 BSIN(T)

\X21 BT

\Y21 BSIN(T)
```

5. Press TRACE. As the graph is plotting, you may press ENTER to pause and ENTER again to resume graphing as you watch the sine function "unwrap" from the unit circle.



Note: You can generalize the unwrapping. Replace **sin(T)** in **Y2T** with any other trig function to unwrap that function.

Finding the Area between Curves

Problem

Find the area of the region bounded by:

```
f(x) = 300x/(x^2 + 625)

g(x) = 3\cos(.1x)

x = 75
```

Procedure

- 1. Press MODE. Select the default mode settings.
- 2. Press WINDOW. Set the viewing window.

Xmin=0 Ymin=-5 Xres=1


Xmax=100 Ymax=10 Xscl=10 Yscl=1

3. Press 🖫. Turn off all functions and stat plots. Enter the upper and lower functions.

 $Y1=300X/(X^2+625)$ $Y2=3\cos(.1X)$

- 4. Press 2nd [CALC] 5 to select 5:Intersect. The graph is displayed. Select a first curve, second curve, and guess for the intersection toward the left side of the display. The solution is displayed, and the value of X at the intersection, which is the lower limit of the integral, is stored in Ans and X.
- 5. Press [2nd [QUIT] to go to the home screen. Press [2nd [DRAW] 7 and use Shade(to see the area graphically.

Shade(Y2,Y1,Ans,75)



6. Press [2nd] [QUIT] to return to the home screen. Enter the expression to evaluate the integral for the shaded region.

fnInt(Y1-Y2,X,Ans,75)

The area is 325.839962.

Using Parametric Equations: Ferris Wheel Problem

Problem

Using two pairs of parametric equations, determine when two objects in motion are closest to each other in the same plane.

A ferris wheel has a diameter (d) of 20 meters and is rotating counterclockwise at a rate (s) of one revolution every 12 seconds. The parametric equations below describe the location of a ferris wheel passenger at time T, where α is the angle of rotation, (0,0) is the bottom center of the ferris wheel, and (10,10) is the passenger's location at the rightmost point, when T=0.

$$X(T) = r \cos \alpha$$
 where $\alpha = 2\pi Ts$ and $r = d/2$
 $Y(T) = r + r \sin \alpha$

A person standing on the ground throws a ball to the ferris wheel passenger. The thrower's arm is at the same height as the bottom of the ferris wheel, but 25 meters (b) to the right of the ferris wheel's lowest point (25,0). The person throws the ball with velocity (v_0) of 22 meters per second at an angle (θ) of 66° from the horizontal. The parametric equations below describe the location of the ball at time T.

$$X(T) = b - Tv_0 \cos\theta$$

 $Y(T) = Tv_0 \sin\theta - (g/2) T^2$ where $g = 9.8 \text{ m/sec}^2$

Procedure


- 1. Press MODE. Select **Par**, **Simul**, and the default settings. **Simul** (simultaneous) mode simulates the two objects in motion over time.
- 2. Press WINDOW. Set the viewing window.

Tmin=0	Xmin=⁻13	Ymin=0
Tmax=12	Xmax=34	Ymax=31
Tstep=.1	Xscl=10	Yscl=10

3. Press [Y=]. Turn off all functions and stat plots. Enter the expressions to define the path of the ferris wheel and the path of the ball. Set the graph style for X2T to ⊕ (path).

Note: Try setting the graph styles to 4 **X1T** and 4 **X2T**, which simulates a chair on the ferris wheel and the ball flying through the air when you press GRAPH.


4. Press GRAPH to graph the equations. Watch closely as they are plotted. Notice that the ball and the ferris wheel passenger appear to be closest where the paths cross in the top-right quadrant of the ferris wheel.




5. Press <u>WINDOW</u>. Change the viewing window to concentrate on this portion of the graph.

Tmin=1	Xmin=0	Ymin=10
Tmax=3	Xmax=23.5	Ymax=25.5
Tstep=.03	Xscl=10	Yscl=10

6. Press TRACE. After the graph is plotted, press ▶ to move near the point on the ferris wheel where the paths cross. Notice the values of **X**, **Y**, and **T**.



7. Press
 to move to the path of the ball. Notice the values of X and Y (T is unchanged). Notice where the cursor is located. This is the position of the ball when the ferris wheel passenger passes the intersection. Did the ball or the passenger reach the intersection first?



You can use TRACE to, in effect, take snapshots in time and explore the relative behavior of two objects in motion.

Demonstrating the Fundamental Theorem of Calculus

Problem 1

Using the functions **fnInt(** and **nDeriv(** from the **MATH** menu to graph functions defined by integrals and derivatives demonstrates graphically that:

$$F(x) = \int_{1}^{x} dt = \ln(x), x > 0$$
 and that

$$Dx\left[\int_{1}^{x} \frac{1}{t} dt\right] = \frac{1}{x}$$

Procedure 1

- 1. Press MODE. Select the default settings.
- 2. Press WINDOW. Set the viewing window.

 Xmin=.01
 Ymin=-1.5
 Xres=3

 Xmax=10
 Ymax=2.5


 Xscl=1
 Yscl=1


3. Press №. Turn off all functions and stat plots. Enter the numerical integral of 1/T from 1 to X and the function ln(X). Set the graph style for Y1 to \(\cdot\) (line) and Y2 to \(\dilph\) (path).

- Press TRACE. Press ◀, ♠, ▶, and ▼ to compare the values of Y1 and Y2.
- 5. Press \(\frac{\frac{1}{2}}{2} \). Turn off \(\frac{1}{4} \) and \(\frac{1}{2} \), and then enter the numerical derivative of the integral of 1/X and the function 1/X. Set the graph style for \(\frac{1}{3} \) to \(\frac{1}{3} \) (line) and \(\frac{1}{4} \) (thick).

Plots Plots Plots \Y1=fnInt(1/T,T, 1,X) 0Yz=ln(X) \X38nDeriv(Y1,X, X) \Y481/X

6. Press TRACE. Again, use the cursor keys to compare the values of the two graphed functions, **Y3** and **Y4**.





Problem 2

Explore the functions defined by

$$y = \int_{2}^{x} t^{2} dt$$
, $\int_{0}^{x} t^{2} dt$, and $\int_{2}^{x} t^{2} dt$

Procedure 2


1. Press [√=]. Turn off all functions and stat plots. Use a list to define these three functions simultaneously. Store the function in Y5.

```
Plot1 Plot2 Plot3
1,X)
0Y2=ln(X)
\Y3=nDeriv(Y1,X,
X)
Y4=1/X
\Y58fnInt(T2,T,(
-2,0,2),X)
```

- 2. Press ZOOM 6 to select 6:ZStandard.
- 3. Press TRACE. Notice that the functions appear identical, only shifted vertically by a constant.
- 4. Press ¥=. Enter the numerical derivative of ¥5 in ¥6.

```
Plots Plot2 Plot3
\Y3=nDeriv(Y1,X,
X)
\Y4=1/X
\Y5\fnInt(T2,T,(
-2,0,2),X)
\Y6\fnDeriv(Ys,X,
X)
```

5. Press TRACE. Notice that although the three graphs defined by **Y5** are different, they share the same derivative.




Computing Areas of Regular N-Sided Polygons

Problem


Use the equation solver to store a formula for the area of a regular N-sided polygon, and then solve for each variable, given the other variables. Explore the fact that the limiting case is the area of a circle, πr^2 .

Consider the formula $A = NB^2 \sin(\pi/N) \cos(\pi/N)$ for the area of a regular polygon with N sides of equal length and B distance from the center to a vertex.



Procedure

- Press MATH 0 to select 0:Solver from the MATH menu. Either the
 equation editor or the interactive solver editor is displayed. If the
 interactive solver editor is displayed, press to display the equation
 editor.
- 2. Enter the formula as $0=A-NB^2\sin(\pi/N)\cos(\pi/N)$, and then press ENTER. The interactive solver editor is displayed.



Enter N=4 and B=6 to find the area (A) of a square with a distance
 (B) from center to vertex of 6 centimeters.

4. Press to move the cursor onto **A**, and then press ALPHA [SOLVE]. The solution for **A** is displayed on the interactive solver editor.

```
A-NB²sin(π/N)..=0
■ A=72.000000000...
N=4
B=6
bound={-1£99,1...
■ left-rt=0
```

- Now solve for B for a given area with various number of sides. Enter
 A=200 and N=6. To find the distance B, move the cursor onto B, and
 then press [ALPHA] [SOLVE].
- 6. Enter **N=8**. To find the distance **B**, move the cursor onto **B**, and then press [ALPHA] [SOLVE]. Find **B** for **N=9**, and then for **N=10**.

Find the area given **B=6**, and **N=10**, **100**, **150**, **1000**, and **10000**. Compare your results with $\pi 6^2$ (the area of a circle with radius 6), which is approximately 113.097.

Enter B=6. To find the area A, move the cursor onto A, and then press [ALPHA] [SOLVE]. Find A for N=10, then N=100, then N=150, then N=1000, and finally N=10000. Notice that as N gets large, the area A approaches πB².

Now graph the equation to see visually how the area changes as the number of sides gets large.

- 8. Press MODE. Select the default mode settings.
- 9. Press WINDOW. Set the viewing window.


Xmin=0	Ymin=0	Xres=1
Xmax=200	Ymax=150	
Xscl=10	Yscl=10	


10. Press Y=. Turn off all functions and stat plots. Enter the equation for the area. Use **X** in place of **N**. Set the graph styles as shown.

```
Plot1 Plot2 Plot3
\Y18X82sin(π/Χ)c
os(π/Χ)
-0Y28π82
\Y3=
\Y4=
\Y5=
\Y6=
```

11. Press TRACE. After the graph is plotted, press **100** ENTER to trace to **X=100**. Press **150** ENTER. Press **188** ENTER. Notice that as **X** increases, the value of **Y** converges to π 6², which is approximately 113.097.

Y2= π **B**² (the area of the circle) is a horizontal asymptote to **Y1**. The area of an N-sided regular polygon, with r as the distance from the center to a vertex, approaches the area of a circle with radius r (π r²) as N gets large.






Computing and Graphing Mortgage Payments

Problem

You are a loan officer at a mortgage company, and you recently closed on a 30-year home mortgage at 8 percent interest with monthly payments of 800. The new home owners want to know how much will be applied to the interest and how much will be applied to the principal when they make the 240th payment 20 years from now.

Procedure

- 1. Press MODE and set the fixed-decimal mode to **2** decimal places. Set the other mode settings to the defaults.
- 2. Press [APPS] [ENTER] [ENTER] to display the **TVM Solver**. Enter these values.



Note: Enter a positive number (800) to show PMT as a cash inflow. Payment values will be displayed as positive numbers on the graph. Enter 0 for FV, since the future value of a loan is 0 once it is paid in full. Enter PMT: END, since payment is due at the end of a period.

3. Move the cursor onto the **PV**= prompt, and then press <u>ALPHA</u> [SOLVE]. The present value, or mortgage amount, of the house is displayed at the **PV**= prompt.

```
N=360.00
1%=8.00
•PV=-109026.80
•PMT=800.00
FV=0.00
P/Y=12.00
C/Y=12.00
PMT:|■NU BEGIN
```

Now compare the graph of the amount of interest with the graph of the amount of principal for each payment.

- 4. Press MODE. Set Par and Simul.
- 5. Press 🔁 Turn off all functions and stat plots. Enter these equations and set the graph styles as shown.




Note: Σ **Prn(** and Σ **Int(** are located on the **FINANCE** menu (**APPS** 1:**FINANCE**).

6. Press WINDOW. Set these window variables.

Tmin=1	Xmin=0	Ymin=0
Tmax=360	Xmax=360	Ymax=1000
Tstep=12	Xscl=10	Yscl=100

Note: To increase the graph speed, change **Tstep** to **24**.


7. Press TRACE. After the graph is drawn, press **240** ENTER to move the trace cursor to **T=240**, which is equivalent to 20 years of payments.



The graph shows that for the 240th payment (**X=240**), 358.03 of the 800 payment is applied to principal (**Y=358.03**).

Note: The sum of the payments (Y3T=Y1T+Y2T) is always 800.

8. Press to move the cursor onto the function for interest defined by **X2T** and **Y2T**. Enter **240**.



The graph shows that for the 240th payment (**X=240**), 441.97 of the 800 payment is interest (**Y=441.97**).

9. Press [2nd] [QUIT] [APPS] [ENTER] 9 to paste 9:bal(to the home screen. Check the figures from the graph.

At which monthly payment will the principal allocation surpass the interest allocation?

Memory and Variable Management


Checking Available Memory

MEMORY Menu

At any time you can check available memory or manage existing memory by selecting items from the **MEMORY** menu. To access this menu, press [2nd] [MEM].

MEMORY	
1: About	Displays information about the graphing handheld.
2: Mem Mgmt/Del	Reports memory availability and variable usage.
3: Clear Entries	Clears ENTRY (last-entry storage).
4: ClrAllLists	Clears all lists in memory.
5: Archive	Archives a selected variable.
6: UnArchive	UnArchives a selected variable.
7: Reset	Displays the RAM , ARCHIVE , and ALL menus
8: Group	Displays GROUP and UNGROUP menus.

To check memory usage, first press 2nd [MEM] and then select 2:Mem Mgmt/Del.




Available RAM, Archive, and App Slots

The TI-84 Plus / TI-84 Plus Silver Edition has Archive, RAM, and Application (App) slot memory for you to use and manage. The available RAM stores computations, lists, variables, and data. The available Archive lets you store programs, Apps, and groups. The App slots are actually individual sectors of Flash ROM where Apps are stored.

Graphing Handheld	Available RAM	Available Archive	App Slots
TI-84 Plus	24 Kilobytes	491 Kilobytes	30
TI-84 Plus Silver Edition	24 Kilobytes	1.5 Megabytes	94

Displaying the About Screen

About displays information about the TI-84 Plus Operating System (OS) Version, Product Number, Product Identification (ID), and Flash Application (App) Certificate Revision Number. To display the About screen, press 2nd [MEM] and then select **1:About**.



Displays the Product ID. Each Flash-based graphing handheld has a unique product ID, which you may need if you contact technical support. You can also use this 14 digit ID to register your handheld at education.ti.com, or identify your handheld in the event that it is lost or stolen.

Displaying the MEMORY MANAGEMENT/DELETE Menu

Mem Mgmt/Del displays the **MEMORY MANAGEMENT/DELETE** menu. The two lines at the top report the total amount of available RAM (**RAM FREE**) and Archive (**ARC FREE**) memory. By selecting menu items on this screen, you can see the amount of memory each variable type is using. This information can help you determine if you need to delete variables from memory to make room for new data, such as programs or applications.

To check memory usage, follow these steps.

1. Press [2nd [MEM] to display the **MEMORY** menu.



Note: The \uparrow and \downarrow in the top or bottom of the left column indicate that you can scroll up or down to view more variable types.

 Select 2:Mem Mgmt/Del to display the MEMORY MANAGEMENT/ DELETE menu. The TI-84 Plus expresses memory quantities in bytes.



3. Select variable types from the list to display memory usage.

Notes: Real, List, Y-Vars, and **Prgm** variable types never reset to zero, even after memory is cleared.

AppV are independent applications which are stored in Flash ROM. **AppVars** is a variable holder used to store variables created by independent applications. You cannot edit or change variables in **AppVars** unless you do so through the application which created them

To leave the **MEMORY MANAGEMENT/DELETE** menu, press either [2nd] [QUIT] or [CLEAR]. Both options display the home screen.

Deleting Items from Memory


Deleting an Item

To increase available memory by deleting the contents of any variable (real or complex number, list, matrix, **Y**= variable, program, Apps, AppVars, picture, graph database, or string), follow these steps.

1. Press 2nd [MEM] to display the **MEMORY** menu.

- Select 2:Mem Mgmt/Del to display the MEMORY MANAGEMENT/ DELETE menu.
- 3. Select the type of data you want to delete, or select **1:All** for a list of all variables of all types. A screen is displayed listing each variable of the type you selected and the number of bytes each variable is using.

For example, if you select **4:List**, the **LIST** editor screen is displayed.



4. Press A and T to move the selection cursor (▶) next to the item you want to delete, and then press □□□. The variable is deleted from memory. You can delete individual variables one by one from this screen.

Note: If you are deleting programs or Apps, you will receive a message asking you to confirm this delete action. Select **2:Yes** to continue.

To leave any variable screen without deleting anything, press [2nd] [QUIT], which displays the home screen.

You cannot delete some system variables, such as the last-answer variable **Ans** and the statistical variable **RegEQ**.

Clearing Entries and List Elements

Clear Entries

Clear Entries clears the contents of the **ENTRY** (last entry) storage area. To clear the **ENTRY** storage area, follow these steps.

- 1. Press 2nd [MEM] to display the **MEMORY** menu.
- 2. Select **3:Clear Entries** to paste the instruction to the home screen.
- 3. Press ENTER to clear the ENTRY storage area.

To cancel **Clear Entries**, press **CLEAR**.

Note: If you select **3:Clear Entries** from within a program, the **Clear Entries** instruction is pasted to the program editor, and the **Entry** (last entry) is cleared when the program is executed.

CIrAllLists

CIrAllLists sets the dimension of each list in RAM to 0.

To clear all elements from all lists, follow these steps.

- 1. Press [2nd] [MEM] to display the **MEMORY** menu.
- 2. Select **4:CirAllLists** to paste the instruction to the home screen.
- 3. Press ENTER to set the dimension of each list in memory to **0**.

To cancel **CIrAllLists**, press CLEAR.

CITAILLISTS does not delete list names from memory, from the **LIST NAMES** menu, or from the stat list editor.

Note: If you select **4:CIrAllLists** from within a program, the **CIrAllLists** instruction is pasted to the program editor. The lists are cleared when the program is executed.

Archiving and UnArchiving Variables

Archiving and UnArchiving Variables

Archiving lets you store data, programs, or other variables to the user data archive where they cannot be edited or deleted inadvertently. Archiving also allows you to free up RAM for variables that may require additional memory.

Archived variables cannot be edited or executed. They can only be seen and unarchived. For example, if you archive list **L1**, you will see that **L1** exists in memory but if you select it and paste the name **L1** to the home screen, you won't be able to see its contents or edit it.

Note: Not all variables may be archived. Not all archived variables may be unarchived. For example, system variables including r, t, x, y, and θ cannot be archived. Apps and Groups always exist in Flash ROM so there is no need to archive them. Groups cannot be unarchived. However, you can ungroup or delete them.

Variable Type	Names	Archive? (yes/no)	UnArchive? (yes/no)
Real numbers	A, B, , Z	yes	yes
Complex numbers	A, B, , Z	yes	yes
Matrices	[A], [B], [C], , [J]	yes	yes

Variable Type	Names	Archive? (yes/no)	UnArchive? (yes/no)
Lists	L1, L2, L3, L4, L5, L6, and user-defined names	yes	yes
Programs		yes	yes
Functions	Y1, Y2, , Y9, Y0	no	not applicable
Parametric equations	X1T and Y1T, , X6T and Y6T	no	not applicable
Polar functions	r1, r2, r3, r4, r5, r6	no	not applicable
Sequence functions	u, v, w	no	not applicable
Stat plots	Plot1, Plot2, Plot3	no	not applicable
Graph databases	GDB1, GDB2,	yes	yes
Graph pictures	Pic1, Pic2, , Pic9, Pic0	yes	yes
Strings	Str1, Str2, Str9, Str0	yes	yes
Tables	TblStart, Tb1, TblInput	no	not applicable
Apps	Applications	see Note above	no
AppVars	Application variables	yes	yes
Groups		see Note above	no
Variables with reserved names	minX, maxX, RegEQ, and others	no	not applicable
System variables	Xmin, Xmax, and others	no	not applicable

Archiving and unarchiving can be done in two ways:

- Use the 5:Archive or 6:UnArchive commands from the MEMORY menu or CATALOG.
- Use a Memory Management editor screen.

Before archiving or unarchiving variables, particularly those with a large byte size (such as large programs) use the **MEMORY** menu to:

- Find the size of the variable.
- See if there is enough free space.

For:	Sizes must be such that:
Archive	Archive free size > variable size
UnArchive	RAM free size > variable size

Note: If there is not enough space, unarchive or delete variables as necessary. Be aware that when you unarchive a variable, not all the memory associated with that variable in user data archive will be released since the system keeps track of where the variable has been and where it is now in RAM.


Even if there appears to be enough free space, you may see a Garbage Collection message when you attempt to archive a variable. Depending on the usability of empty blocks in the user data archive, you may need to unarchive existing variables to create more free space.

To archive or unarchive a list variable (L1) using the Archive/UnArchive options from the **MEMORY** menu:


1. Press 2nd [MEM] to display the **MEMORY** menu.



- Select 5:Archive or 6:UnArchive to place the command in the edit screen.
- 3. Press [2nd] [L1] to place the **L1** variable in the edit screen.



4. Press ENTER to complete the archive process.



Note: An asterisk will be displayed to the left of the Archived variable name to indicate it is archived.

To archive or unarchive a list variable (L1) using a Memory Management editor:

1. Press [2nd] [MEM] to display the **MEMORY** menu.




Select 2:Mem Mgmt/Del to display the MEMORY MANAGEMENT/ DELETE menu.



3. Select 4:List to display the LIST menu.

RAM FREE ARC FREE L1 L2	23896 868260 12 12
L3	12
Ļ4	12
Ļ5	12
L6	12

4. Press ENTER to archive **L1**. An asterisk will appear to the left of **L1** to indicate it is an archived variable. To unarchive a variable in this screen, put the cursor next to the archived variable and press ENTER. The asterisk will disappear.



5. Press [2nd] [QUIT] to leave the **LIST** menu.

Note: You can access an archived variable for the purpose of linking, deleting, or unarchiving it, but you cannot edit it.

Resetting the TI-84 Plus

RAM ARCHIVE ALL Menu

Reset displays the **RAM ARCHIVE ALL** menu. This menu gives you the option of resetting all memory (including default settings) or resetting selected portions of memory while preserving other data stored in memory, such as programs and **Y**= functions. For instance, you can choose to reset all of RAM or just restore the default settings. Be aware that if you choose to reset RAM, all data and programs in RAM will be erased. For archive memory, you can reset variables (Vars), applications (Apps), or both of these. Be aware that if you choose to reset Vars, all data and programs in archive memory will be erased. If you choose to reset Apps, all applications in archive memory will be erased.

When you reset defaults on the TI-84 Plus, all defaults in RAM are restored to the factory settings. Stored data and programs are not changed.

These are some examples of TI-84 Plus defaults that are restored by resetting the defaults.

- Mode settings such as Normal (notation); Func (graphing); Real (numbers); and Full (screen)
- Y= functions off
- Window variable values such as Xmin=-10, Xmax=10, Xscl=1, Yscl=1, and Xres=1
- Stat plots off
- Format settings such as CoordOn (graphing coordinates on);
 AxesOn; and ExprOn (expression on)
- rand seed value to 0

Displaying the RAM ARCHIVE ALL Menu

To display the **RAM ARCHIVE ALL** menu on the TI-84 Plus, follow these steps.

- 1. Press 2nd [MEM] to display the **MEMORY** menu.
- 2. Select 7:Reset to display the RAM ARCHIVE ALL menu.



Resetting RAM Memory

Resetting all RAM restores RAM system variables to factory settings and deletes all nonsystem variables and all programs. Resetting RAM defaults restores all system variables to default settings without deleting variables and programs in RAM. Resetting all RAM or resetting defaults does not affect variables and applications in user data archive.

Note: Before you reset all RAM memory, consider restoring sufficient available memory by deleting only selected data.

To reset all **RAM** memory or **RAM** defaults on the TI-84 Plus, follow these steps.

 From the RAM ARCHIVE ALL menu, select 1:All RAM to display the RESET RAM menu or 2:Defaults to display the RESET DEFAULTS menu.





- If you are resetting RAM, read the message below the RESET RAM menu.
 - To cancel the reset and return to the home screen, press ENTER.
 - To erase RAM memory or reset defaults, select 2:Reset.
 Depending on your choice, the message RAM cleared or
 Defaults set is displayed on the home screen.

Resetting Archive Memory

When resetting archive memory on the TI-84 Plus, you can choose to delete from user data archive all variables, all applications, or both variables and applications.

To reset all or part of user data archive memory, follow these steps.

 From the RAM ARCHIVE ALL menu, press to display the ARCHIVE menu.



2. Select one of the following:

1:Vars to display the RESET ARC VARS menu.



2:Apps to display the RESET ARC APPS menu.



3:Both to display the **RESET ARC BOTH** menu.



- 3. Read the message below the menu.
 - To cancel the reset and return to the home screen, press ENTER.
 - To continue with the reset, select 2:Reset. A message indicating the type of archive memory cleared will be displayed on the home screen.

Resetting All Memory

When resetting all memory on the TI-84 Plus, RAM and user data archive memory is restored to factory settings. All nonsystem variables, applications, and programs are deleted. All system variables are reset to default settings.

Before you reset all memory, consider restoring sufficient available memory by deleting only selected data.

To reset all memory on the TI-84 Plus, follow these steps.

 From the RAM ARCHIVE ALL menu, press >> to display the ALL menu.



2. Select 1:All Memory to display the RESET MEMORY menu.



- 3. Read the message below the **RESET MEMORY** menu.
 - To cancel the reset and return to the home screen, press ENTER.
 - To continue with the reset, select 2:Reset. The message MEM cleared is displayed on the home screen.

When you clear memory, the contrast sometimes changes. If the screen is faded or blank, adjust the contrast by pressing [2nd] or .

Grouping and Ungrouping Variables


Grouping Variables

Grouping allows you to make a copy of two or more variables residing in RAM and then store them as a group in user data archive. The variables in RAM are not erased. The variables must exist in RAM before they can be grouped. In other words, archived data cannot be included in a group.

To create a group of variables:

1. Press [2nd] [MEM] to display the **MEMORY** menu.

2. Select 8:Group to display GROUP UNGROUP menu.



3. Press ENTER to display the GROUP menu.



4. Enter a name for the new group and press [ENTER].


Note: A group name can be one to eight characters long. The first character must be a letter from A to Z or θ . The second through eighth characters can be letters, numbers, or θ .




5. Select the type of data you want to group. You can select 1:All+ which shows all variables of all types available and selected. You can also select 1:All- which shows all variables of all types available but not selected. A screen is displayed listing each variable of the type you selected.




For example, suppose some variables have been created in RAM, and selecting **1:All-** displays the following screen.




6. Press → and → to move the selection cursor (▶) next to the first item you want to copy into a group, and then press ENTER. A small square will remain to the left of all variables selected for grouping.



Repeat the selection process until all variables for the new group are selected and then press \(\bar{\cup} \) to display the **DONE** menu.



7. Press ENTER to complete the grouping process.



Note: You can only group variables in RAM. You cannot group some system variables, such as the last-answer variable **Ans** and the statistical variable **RegEQ**.

Ungrouping Variables

Ungrouping allows you to make a copy of variables in a group stored in user data archive and place them ungrouped in **RAM**.

DuplicateName Menu

During the ungrouping action, if a duplicate variable name is detected in **RAM**, the **DUPLICATE NAME** menu is displayed.

DuplicateName	
1: Rename	Prompts to rename receiving variable.
2: Overwrite	Overwrites data in receiving duplicate variable.
3: Overwrite All	Overwrites data in all receiving duplicate variables.
4: Omit	Skips transmission of sending variable.
5: Quit	Stops transmission at duplicate variable.

Notes about Menu Items:

 When you select 1:Rename, the Name= prompt is displayed, and alpha-lock is on. Enter a new variable name, and then press ENTER. Ungrouping resumes.

- When you select **2:Overwrite**, the unit overwrites the data of the duplicate variable name found in RAM. Ungrouping resumes.
- When you select **3: Overwrite All**, the unit overwrites the data of all duplicate variable names found in RAM. Ungrouping resumes.
- When you select 4:Omit, the unit does not ungroup the variable in conflict with the duplicated variable name found in RAM.
 Ungrouping resumes with the next item.
- When you select 5:Quit, ungrouping stops, and no further changes are made.

To ungroup a group of variables:


1. Press 2nd [MEM] to display the **MEMORY** menu.



- 2. Select 8:Group to display the GROUP UNGROUP menu.
- 3. Press 1 to display the **UNGROUP** menu.



4. Press A and to move the selection cursor (*) next to the group variable you want to ungroup, and then press ENTER.



The ungroup action is completed.

Note: Ungrouping does not remove the group from user data archive. You must delete the group in user data archive to remove it.

Garbage Collection

Garbage Collection Message

If you use the user data archive extensively, you may see a **Garbage Collect?** message. This occurs if you try to archive a variable when there is not enough free contiguous archive memory.

The **Garbage Collect?** message lets you know an archive will take longer than usual. It also alerts you that the archive will fail if there is not enough memory. The message can also alert you when a program is caught in a loop that repetitively fills the user data archive. Select **No** to cancel the garbage collection process, and then find and correct the errors in your program.

The TI-84 Plus will attempt to rearrange the archived variables to make additional room.

Responding to the Garbage Collection Message

- To cancel, select 1:No.
- If you choose 1:No, the message ERR:ARCHIVE FULL will be displayed.
- To continue archiving, select 2:Yes.



If you select **2:Yes**, the process message **Garbage Collecting...** or **Defragmenting...** will be displayed.


Note: The process message **Defragmenting...** is displayed whenever an application marked for deletion is encountered. Garbage collection may take up to 20 minutes, depending on how much of archive memory has been used to store variables.

After garbage collection, depending on how much additional space is freed, the variable may or may not be archived. If not, you can unarchive some variables and try again.

Why Is Garbage Collection Necessary?

The user data archive is divided into sectors. When you first begin archiving, variables are stored consecutively in sector 1. This continues to the end of the sector.

An archived variable is stored in a continuous block within a single sector. Unlike an application stored in user data archive, an archived variable cannot cross a sector boundary. If there is not enough space left in the sector, the next variable is stored at the beginning of the next sector. Typically, this leaves an empty block at the end of the previous sector.




Each variable that you archive is stored in the first empty block large enough to hold it.

This process continues to the end of the last sector. Depending on the size of individual variables, the empty blocks may account for a significant amount of space. Garbage collection occurs when the variable you are archiving is larger than any empty block.

How Unarchiving a Variable Affects the Process

When you unarchive a variable, it is copied to RAM but it is not actually deleted from user data archive memory. Unarchived variables are "marked for deletion," meaning they will be deleted during the next garbage collection.



If the MEMORY Screen Shows Enough Free Space

Even if the **MEMORY** screen shows enough free space to archive a variable or store an application, you may still get a **Garbage Collect?** message or an **ERR: ARCHIVE FULL** message.


When you unarchive a variable, the **Archive free** amount increases immediately, but the space is not actually available until after the next garbage collection.

If the **Archive free** amount shows enough available space for your variable, there probably will be enough space to archive it after garbage collection (depending on the usability of any empty blocks).

The Garbage Collection Process

The garbage collection process:

- Deletes unarchived variables from the user data archive.
- Rearranges the remaining variables into consecutive blocks.



Note: Power loss during garbage collection may cause all memory (RAM and Archive) to be deleted.

Using the GarbageCollect Command

You can reduce the number of automatic garbage collections by periodically optimizing memory. This is done by using the **GarbageCollect** command.

To use the **GarbageCollect** command, follow these steps.

1. Press 2nd [CATALOG] to display the CATALOG.



- 2. Press
 or
 or
 or to scroll the CATALOG until the selection cursor points to the GarbageCollect command.
- 3. Press ENTER to paste the command to the current screen.
- 4. Press ENTER to display the Garbage Collect? message.
- 5. Select 2:Yes to begin garbage collection.

ERR:ARCHIVE FULL Message

Even if the **MEMORY** screen shows enough free space to archive a variable or store an application, you may still get an **ERR: ARCHIVE FULL** message.



An ERR:ARCHIVE FULL message may be displayed:

- When there is insufficient space to archive a variable within a continuous block and within a single sector.
- When there is insufficient space to store an application within a continuous block of memory.

When the message is displayed, it will indicate the largest single space of memory available for storing a variable and an application.

To resolve the problem, use the **GarbageCollect** command to optimize memory. If memory is still insufficient, you must delete variables or applications to increase space.

Communication Link


Getting Started: Sending Variables

Getting Started is a fast-paced introduction. Read the chapter for details.

Create and store a variable and a matrix, and then transfer them to another TI-84 Plus.

- 1. On the home screen of the sending unit, press 5 . 5 STO→ ALPHA Q. Press ENTER to store 5.5 to Q.
- 2. Press 2nd[[] 2nd[[] 1 , 2 2nd[]] 2nd[[] 3 , 4 2nd [] 2nd [] STO▶ 2nd [MATRIX] 1. Press ENTER to store the matrix to [A].
- 3. On the sending unit, press 2nd [MEM] to display the **MEMORY** menu.

- On the sending unit, press 2 to select
 2:Mem Mgmt/Del. The MEMORY
 MANAGEMENT menu is displayed.
- On the sending unit, press 5 to select
 5:Matrix. The MATRIX editor screen is displayed.
- On the sending unit, press ENTER to archive
 [A]. An asterisk (*) will appear, signifying
 that [A] is now archived.





```
RAM FREE 23896

ARC FREE 868260

LEA11...

2:Real...

3:Complex...

4:List...

5:Matrix...

6-V-Vars...
```



```
RAM FREE 23934
ARC FREE 868210
**[A] 47
```

- Connect the graphing handhelds with the USB unit-to-unit cable. Push both ends in firmly.
- 8. On the receiving unit, press 2nd [LINK] to display the **RECEIVE** menu. Press 1 to select 1:Receive. The message Waiting... is displayed and the busy indicator is on.
- 9. On the sending unit, press 2nd [LINK] to display the **SEND** menu.
- Press 2 to select 2:All -. The All SELECT screen is displayed.
- Press until the selection cursor is next to Q REAL. Press ENTER. A square dot next to [A] and Q indicates that each is selected to send.
- 13. On the sending unit, press to display the **TRANSMIT** menu.
- 14. On the sending unit, press 1 to select 1:Transmit and begin transmission. The receiving unit displays the message Receiving....When the items are transmitted, both units display the name and type of each transmitted variable.

SEND **⊠⊒0⊒4W⊒** ∰Receive









TI-84 Plus LINK

This chapter describes how to communicate with compatible TI units. The TI-84 Plus has a USB port to connect and communicate with another TI-84 Plus or TI-84 Plus Silver Edition. A USB unit-to-unit cable is included with the TI-84 Plus

The TI-84 Plus also has an I/O port using a I/O unit-to-unit cable to communicate with:

- TI-83 Plus Silver Edition
- TI-83 Plus
- TI-83

- TI-82
- TI-73
- CBL 2[™] or a CBR[™]

Connecting Two Graphing Handhelds with a USB Unit-to-Unit Cable or an I/O Unit-to-Unit Cable

USB Unit-to-Unit Cable

The TI-84 Plus USB link port is located at the top right edge of the graphing handheld.

- Firmly insert either end of the USB unit-to-unit cable into the USB port.
- Insert the other end of the cable into the other graphing handheld's USB port.



I/O Unit-to-Unit Cable

The TI-84 Plus I/O link port is located at the top left edge of the graphing handheld.

- Firmly insert either end of the I/O unit-to-unit cable into the port.
- 2. Insert the other end of the cable into the other graphing handheld's I/O port.



TI-84 Plus to a TI-83 Plus using I/O Unit-to-Unit Cable

The TI-84 Plus I/O link port is located at the top left edge of the graphing handheld. The TI-83 Plus I/O link port is located at the bottom edge of the graphing handheld.

- Firmly insert either end of the I/O unit-to-unit cable into the port.
- Insert the other end of the cable into the other graphing handheld's I/O port.



101

Linking to the CBL/CBR System

The CBL 2[™] and the CBR[™] are optional accessories that also connect to a TI-84 Plus with the I/O unit-to-unit cable. With a CBL 2 or CBR and a TI-84 Plus, you can collect and analyze real-world data.

Communication Link

Linking to a Computer

With TI Connect™ software and the USB computer cable that is included with your TI-84 Plus, you can link the graphing handheld to a personal computer.

Selecting Items to Send

LINK SEND Menu

To display the **LINK SEND** menu, press [2nd] [LINK].


SEND RECEIVE	
1:All+	Displays all items as selected, including RAM and Flash applications.
2:All	Displays all items as deselected.
3: Prgm	Displays all program names.
4:List	Displays all list names.
5:Lists to TI84	Displays list names L1 through L6 .
6:GDB	Displays all graph databases.
7:Pic	Displays all picture data types.
8:Matrix	Displays all matrix data types.
9:Real	Displays all real variables.
0:Complex	Displays all complex variables.
A:Y-Vars	Displays all Y= variables.
B:String	Displays all string variables.
C:Apps	Displays all software applications.
D:AppVars	Displays all software application variables.
E:Group	Displays all grouped variables.
F:SendId	Sends the Calculator ID number immediately. (You do not need to select SEND .)
G:SendOS	Sends operating system updates to another TI-84 Plus Silver Edition or TI-84 Plus. You can not send the operating system to the TI-83 Plus product family.
H:Back Up	Selects all RAM and mode settings (no Flash applications or archived items) for backup to another TI-84 Plus, TI-84 Plus Silver Edition, TI-83 Plus Silver Edition, or to a TI-83 Plus.

When you select an item on the **LINK SEND** menu, the corresponding **SELECT** screen is displayed.

Note: Each **SELECT** screen, except **All+...**, is initially displayed with nothing pre-selected. **All+...** is displayed with everything pre-selected.

To select items to send:

- 1. Press 2nd [LINK] on the sending unit to display the **LINK SEND** menu.
- 2. Select the menu item that describes the data type to send. The corresponding **SELECT** screen is displayed.
- Press
 — and
 — to move the selection cursor (▶) to an item you want
 to select or deselect.
- Press ENTER to select or deselect the item. Selected names are marked with a ■.



Note: An asterisk (*) to the left of an item indicates the item is archived.

5. Repeat steps 3 and 4 to select or deselect additional items.

Sending the Selected Items

After you have selected items to send on the sending unit and set the receiving unit to receive, follow these steps to transmit the items. To set the receiving unit, see Receiving Items.

1. Press • on the sending unit to display the **TRANSMIT** menu.



2. Confirm that **Waiting...** is displayed on the receiving unit, which indicates it is set to receive.

3. Press ENTER to select **1:Transmit**. The name and type of each item are displayed line-by-line on the sending unit as the item is queued for transmission, and then on the receiving unit as each item is accepted.



Note: Items sent from the RAM of the sending unit are transmitted to the RAM of the receiving unit. Items sent from user data archive (flash) of the sending unit are transmitted to user data archive (flash) of the receiving unit.

After all selected items have been transmitted, the message **Done** is displayed on both calculators. Press ▲ and ▼ to scroll through the names.

Sending to a TI-84 Plus Silver Edition or TI-84 Plus

You can transfer variables (all types), programs, and Flash applications to another TI-84 Plus Silver Edition or TI-84 Plus. You can also backup the RAM memory of one unit to another.

Note: Keep in mind that the TI-84 Plus has less Flash memory than the TI-84 Plus Silver Edition.

- Variables stored in RAM on the sending TI-84 Plus Silver Edition will be sent to the RAM of the receiving TI-84 Plus Silver Edition or TI-84 Plus.
- Variables and applications stored in the user data archive of the sending TI-84 Plus Silver Edition will be sent to the user data archive of the receiving TI-84 Plus Silver Edition or TI-84 Plus.

After sending or receiving data, you can repeat the same transmission to additional TI-84 Plus Silver Edition or TI-84 Plus units—from either the sending unit or the receiving unit—without having to reselect data to send. The current items remain selected. However, you cannot repeat transmission if you selected **AII+** or **AII-**.

To send data to an additional TI-84 Plus Silver Edition or a TI-84 Plus:

- 1. Use a USB unit-to-unit cable to link two units together.
- 2. On the sending unit press [2nd [LINK] and select a data type and items to **SEND**.
- 3. Press on the sending unit to display the **TRANSMIT** menu.

- 4. On the other unit, press [2nd [LINK]] to display the **RECEIVE** menu.
- 5. Press ENTER on the receiving unit.
- 6. Press ENTER on the sending unit. A copy of the selected item(s) is sent to the receiving unit.
- 7. Disconnect the link cable only from the receiving unit and connect it to another unit.
- 8. Press 2nd [LINK] on the sending unit.
- Select only the data type. For example, if the unit just sent a list, select 4:LIST.

Note: The item(s) you want to send are pre-selected from the last transmission. Do not select or deselect any items. If you select or deselect an item, all selections or deselections from the last transmission are cleared.

- 10. Press on the sending unit to display the **TRANSMIT** menu.
- 11. On the new receiving unit, press [2nd [LINK]] to display the **RECEIVE** menu.
- 12. Press ENTER on the receiving unit.
- 13. Press ENTER on the sending unit. A copy of the selected item(s) is sent to the receiving unit.
- 14. Repeat steps 7 through 13 until the items are sent to all additional units.

Sending to a TI-83 Plus or TI-83 Plus Silver Edition

You can send all variables from a TI-84 Plus to a TI-83 Plus or TI-83 Plus Silver Edition *except* Flash applications with new features, or programs with new features in them.

If archived variables on the TI-84 Plus are variable types recognized and used on the TI-83 Plus or TI-83 Plus Silver Edition, you can send these variables to the TI-83 Plus or TI-83 Plus Silver Edition. They will be automatically sent to the RAM of the TI-83 Plus or TI-83 Plus Silver Edition during the transfer process. It will send to archive if the item is from archive.

To send data to a TI-83 Plus or TI-83 Plus Silver Edition:

- 1. Use an I/O unit-to-unit cable to link the two units together.
- Set the TI-83 Plus or TI-83 Plus Silver Edition to receive.
- Press 2nd [LINK] on the sending TI-84 Plus to display the LINK SEND menu.

- 4. Select the menu of the items you want to transmit.
- Press > on the sending TI-84 Plus to display the LINK TRANSMIT menu.
- 6. Confirm that the receiving unit is set to receive.
- 7. Press ENTER on the sending TI-84 Plus to select **1:Transmit** and begin transmitting.

Receiving Items

LINK RECEIVE Menu

To display the **LINK RECEIVE** menu, press 2nd [LINK] .

SEND RECEIVE

1: Receive Sets unit to receive data transmission.

Receiving Unit

When you select **1:Receive** from the **LINK RECEIVE** menu on the receiving unit, the message **Waiting...** and the busy indicator are displayed. The receiving unit is ready to receive transmitted items. To exit the receive mode without receiving items, press ON, and then select **1:Quit** from the **Error in Xmit** menu.

When transmission is complete, the unit exits the receive mode. You can select **1:Receive** again to receive more items. The receiving unit then displays a list of items received. Press [2nd [QUIT] to exit the receive mode.

DuplicateName Menu

During transmission, if a variable name is duplicated, the **DuplicateName** menu is displayed on the receiving unit.

DuplicateName

Rename Prompts to rename receiving variable.
 Overwrite Overwrites data in receiving variable.
 Omit Skips transmission of sending variable.
 Quit Stops transmission at duplicate variable.

When you select **1:Rename**, the **Name**= prompt is displayed, and alphalock is on. Enter a new variable name, and then press **ENTER**. Transmission resumes.

When you select **2:Overwrite**, the sending unit's data overwrites the existing data stored on the receiving unit. Transmission resumes.

When you select **3:Omit**, the sending unit does not send the data in the duplicated variable name. Transmission resumes with the next item.

When you select **4:Quit**, transmission stops, and the receiving unit exits receive mode

Receiving from a TI-84 Plus Silver Edition or TI-84 Plus

The TI-84 Plus Silver Edition and the TI-84 Plus are totally compatible. Keep in mind, however that the TI-84 Plus has less Flash memory than a TI-84 Plus Silver Edition.

Receiving from a TI-83 Plus Silver Edition or TI-83 Plus

The TI-84 Plus product family and the TI-83 Plus product family are totally compatible.

Receiving from a TI-83

You can transfer all variables and programs from a TI-83 to a TI-84 Plus if they fit in the RAM of the TI-84 Plus. The RAM of the TI-84 Plus is slightly less than the RAM of the TI-83.

Backing Up RAM Memory

Warning: H:Back Up overwrites the RAM memory and mode settings in the receiving unit. All information in the RAM memory of the receiving unit is lost.

Note: Archived items on the receiving unit are not overwritten.

You can backup the contents of RAM memory and mode settings (no Flash applications or archived items) to another TI-84 Plus Silver Edition. You can also backup RAM memory and mode settings to a TI-84 Plus.

To perform a RAM memory backup:

- 1. Use a USB unit-to-unit cable to link two TI-84 Plus units, or a TI-84 Plus and a TI-84 Plus Silver Edition together.
- On the sending unit press 2nd [LINK] and select H:Back Up. The MEMORYBACKUP screen displays.



- 3. On the receiving unit, press and [LINK] to display the **RECEIVE** menu.
- 4. Press ENTER on the receiving unit.
- 5. Press ENTER on the sending unit. A **WARNING Backup** message displays on the receiving unit.

6. Press ENTER on the receiving unit to continue the backup.


— or —

Press **2:Quit** on the receiving unit to cancel the backup and return to the **LINK SEND** menu

Note: If a transmission error is returned during a backup, the receiving unit is reset.

Memory Backup Complete

When the backup is complete, both the sending graphing handheld and receiving graphing handheld display a confirmation screen.



Error Conditions

A transmission error occurs after one or two seconds if:

- A cable is not attached to the sending unit.
- A cable is not attached to the receiving unit.

Note: If the cable is attached, push it in firmly and try again.

- The receiving unit is not set to receive transmission.
- You attempt a backup between a TI-73, TI-82, TI-83, TI-83 Plus, TI-83
 Plus Silver Edition
- You attempt a data transfer from a TI-84 Plus to a TI-83 Plus, TI-83
 Plus Silver Edition, TI-83, TI-82, or TI-73 with variables or features not
 recognized by the TI-83 Plus, TI-83 Plus Silver Edition, TI-83, TI-82, or
 TI-73.

New variable types and features not recognized by the TI-83, TI-83 Plus, TI-82, or TI-73 include applications, application variables, grouped variables, new variable types, or programs with new features in them such as Archive, UnArchive, SendID, SendOS, Asm(, AsmComp(, AsmPrgm, checkTmr(, ClockOff, ClockOn, dayOfWk(, getDate, getDtFmt, getDtStr(, getTime, getTmFmt, getTmStr, isClockOn, setDate(, setDtFmt(, setTime(, setTmFmt(, startTmr, and timeCnv.

- You attempt a data transfer from a TI-84 Plus to a TI-82 with data other than real lists L1 through L6 or without using menu item
 5:Lists to TI82.
- You attempt a data transfer from a TI-84 Plus to a TI-73 with data other than real numbers, pics, real lists **L1** through **L6** or named lists with θ as part of the name.

- Although a transmission error does not occur, these two conditions may prevent successful transmission.
- You try to use Get(with a graphing handheld instead of a CBL 2[™] or CBR[™].
- You try to use GetCalc(with a TI-83 instead of a TI-84 Plus or TI-84 Plus Silver Edition.

Insufficient Memory in Receiving Unit

- During transmission, if the receiving unit does not have sufficient memory to receive an item, the **Memory Full** menu is displayed on the receiving unit.
- To skip this item for the current transmission, select **1:Omit**. Transmission resumes with the next item.
- To cancel the transmission and exit receive mode, select 2:Quit.

Appendix A: Tables and Reference Information

Table of Functions and Instructions

Functions return a value, list, or matrix. You can use functions in an expression. Instructions initiate an action. Some functions and instructions have arguments. Optional arguments and accompanying commas are enclosed in brackets ([]). For details about an item, including argument descriptions and restrictions, turn to the page listed on the right side of the table.

From the **CATALOG**, you can paste any function or instruction to the home screen or to a command line in the program editor. However, some functions and instructions are not valid on the home screen. The items in this table appear in the same order as they appear in the **CATALOG**.

† indicates either keystrokes that are valid in the program editor only or ones that paste certain instructions when you are in the program editor. Some keystrokes display menus that are available only in the program editor. Others paste mode, format, or table-set instructions only when you are in the program editor.

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
abs(value)	Returns the absolute value of a real number, expression, list, or matrix.	MATH NUM 1:abs(
abs(complex value)	Returns the magnitude of a complex number or list.	MATH CPX 5:abs(
valueA and valueB	Returns 1 if both valueA and valueB are \neq 0. valueA and valueB can be real numbers, expressions, or lists.	[2nd [TEST] LOGIC 1:and
angle(value)	Returns the polar angle of a complex number or list of complex numbers.	MATH CPX 4:angle(

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
ANOVA (<i>list1</i> , <i>list2</i> [, <i>list3</i> ,, <i>list2</i> 0])	Performs a one-way analysis of variance for comparing the means of two to 20 populations.	STAT TESTS F:ANOVA(
Ans	Returns the last answer.	2nd [ANS]
Archive	Moves the specified variables from RAM to the user data archive memory.	2nd [MEM] 5:Archive
Asm(assemblyprgmname)	Executes an assembly language program.	[2nd] [CATALOG] Asm(
AsmComp(prgmASM1, prgmASM2)	Compiles an assembly language program written in ASCII and stores the hex version.	2nd [CATALOG] AsmComp(
AsmPrgm	Must be used as the first line of an assembly language program.	2nd [CATALOG] AsmPrgm
augment(matrixA, matrixB)	Returns a matrix, which is matrixB appended to matrixA as new columns.	2nd [MATRIX] MATH 7:augment(
augment(listA,listB)	Returns a list, which is <i>listB</i> concatenated to the end of <i>listA</i> .	2nd [LIST] OPS 9:augment(
AxesOff	Turns off the graph axes.	† [2nd] [FORMAT] AxesOff
AxesOn	Turns on the graph axes.	† [2nd] [FORMAT] AxesOn
a+bi	Sets the mode to rectangular complex number mode (a+bi).	† [MODE] a+b <i>i</i>

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
bal(npmt[,roundvalue])	Computes the balance at npmt for an amortization schedule using stored values for PV, I%, and PMT and rounds the computation to roundvalue.	(APPS) 1:Finance CALC 9:bal(
binomcdf (<i>numtrials</i> , <i>p</i> [,x])	Computes a cumulative probability at x for the discrete binomial distribution with the specified <i>numtrials</i> and probability p of success on each trial.	2nd [DISTR] DISTR A:binomcdf(
binompdf(numtrials,p [,x])	Computes a probability at x for the discrete binomial distribution with the specified $numtrials$ and probability p of success on each trial.	2nd [DISTR] DISTR 0:binompdf(
χ ² cdf(lowerbound, upperbound,df)	Computes the χ^2 distribution probability between <i>lowerbound</i> and <i>upperbound</i> for the specified degrees of freedom df .	2nd [DISTR] DISTR 7:χ²cdf(
χ ² pdf(x,d/)	Computes the probability density function (pdf) for the χ^2 distribution at a specified x value for the specified degrees of freedom df .	2nd [DISTR] DISTR 6:χ ² pdf(
χ ² -Test(observedmatrix, expectedmatrix [,drawflag])	Performs a chi-square test. drawflag=1 draws results; drawflag=0 calculates results.	† STAT TESTS C:χ ² -Test(

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
checkTmr(starttime)	Returns the number of seconds since you used startTmr to start the timer. The starttime is the value displayed by startTmr.	[2nd [CATALOG] checkTmr(
Circle(X,Y,radius)	Draws a circle with center (X,Y) and $radius$.	2nd [DRAW] DRAW 9:Circle(
Clear Entries	Clears the contents of the Last Entry storage area.	2nd [MEM] MEMORY 3:Clear Entries
ClockOff	Turns off the clock display in the mode screen.	2nd [CATALOG] ClockOff
ClockOn	Turns on the clock display in the mode screen.	[2nd] [CATALOG] ClockOn
CIrAllLists	Sets to 0 the dimension of all lists in memory.	2nd [MEM] MEMORY 4:CIrAllLists
CirDraw	Clears all drawn elements from a graph or drawing.	2nd [DRAW] DRAW 1:ClrDraw
CirHome	Clears the home screen.	† PRGM I/O 8:ClrHome
CIrList listname1 [,listname2,, listname n]	Sets to 0 the dimension of one or more <i>listnames</i> .	STAT EDIT 4:CIrList
CirTable	Clears all values from the table.	† PRGM I/O 9:CirTable
conj(value)	Returns the complex conjugate of a complex number or list of complex numbers.	MATH CPX 1:conj(

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
Connected	Sets connected plotting mode; resets all Y = editor graph-style settings to \(\).	† MODE Connected
CoordOff	Turns off cursor coordinate value display.	† [2nd] [FORMAT] CoordOff
CoordOn	Turns on cursor coordinate value display.	† [2nd] [FORMAT] CoordOn
cos(value)	Returns cosine of a real number, expression, or list.	COS
cos ⁻¹ (value)	Returns arccosine of a real number, expression, or list.	2nd [COS-1]
cosh(value)	Returns hyperbolic cosine of a real number, expression, or list.	2nd [CATALOG] cosh(
cosh ⁻¹ (value)	Returns hyperbolic arccosine of a real number, expression, or list.	[2nd [CATALOG] cosh ⁻¹ (
CubicReg [Xlistname, Ylistname, freqlist, regequ]	Fits a cubic regression model to Xlistname and Ylistname with frequency freqlist, and stores the regression equation to regequ.	STAT CALC 6:CubicReg
cumSum(list)	Returns a list of the cumulative sums of the elements in <i>list</i> , starting with the first element.	2nd [LIST] OPS 6:cumSum(
cumSum(<i>matrix</i>)	Returns a matrix of the cumulative sums of <i>matrix</i> elements. Each element in the returned matrix is a cumulative sum of a <i>matrix</i> column from top to bottom.	[2nd [MATRIX] MATH 0:cumSum(

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
dayOfWk(year,month,day)	Returns an integer from 1 to 7, with each integer representing a day of the week. Use dayOfWk(to determine on which day of the week a particular date would occur. The year must be 4 digits; month and day can be 1 or 2 digit.	2nd [CATALOG] dayOfWk(1:Sunday 2:Monday 3:Tuesday
dbd(date1,date2)	Calculates the number of days between <i>date1</i> and <i>date2</i> using the actual-day-count method.	APPS 1:Finance CALC D:dbd(
value ▶Dec	Displays a real or complex number, expression, list, or matrix in decimal format.	MATH MATH 2:>Dec
Degree	Sets degree angle mode.	† MODE Degree
DelVar variable	Deletes from memory the contents of <i>variable</i> .	† PRGM CTL G:DelVar
DependAsk	Sets table to ask for dependent-variable values.	† 2nd [TBLSET] Depend: Ask
DependAuto	Sets table to generate dependent-variable values automatically.	† [2nd] [TBLSET] Depend: Auto
det(matrix)	Returns determinant of <i>matrix</i> .	[2nd] [MATRIX] MATH 1:det(
DiagnosticOff	Sets diagnostics-off mode; r , r ² , and R ² are not displayed as regression model results.	2nd [CATALOG] DiagnosticOff

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
DiagnosticOn	Sets diagnostics-on mode; r , r ² , and R ² are displayed as regression model results.	2nd [CATALOG] DiagnosticOn
dim(listname)	Returns the dimension of <i>listname</i> .	2nd [LIST] OPS 3:dim(
dim(matrixname)	Returns the dimension of matrixname as a list.	2nd [MATRIX] MATH 3:dim(
length >dim(listname)	Assigns a new dimension (length) to a new or existing listname.	2nd [LIST] OPS 3:dim(
{rows,columns}→ dim(matrixname)	Assigns new dimensions to a new or existing <i>matrixname</i> .	2nd [MATRIX] MATH 3:dim(
Disp	Displays the home screen.	† PRGM I/O 3:Disp
Disp [valueA,valueB, valueC,,value n]	Displays each value.	† PRGM I/O 3:Disp
DispGraph	Displays the graph.	† PRGM I/O 4:DispGraph
DispTable	Displays the table.	† PRGM I/O 5:DispTable
value ≯DMS	Displays <i>value</i> in DMS format.	2nd [ANGLE] ANGLE 4:≻DMS
Dot	Sets dot plotting mode; resets all Y= editor graph- style settings to	† MODE Dot

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
DrawF expression	Draws <i>expression</i> (in terms of X) on the graph.	2nd [DRAW] DRAW 6:DrawF
Drawinv expression	Draws the inverse of expression by plotting X values on the y-axis and Y values on the x-axis.	2nd [DRAW] DRAW 8:DrawInv
:DS<(variable,value) :commandA :commands	Decrements <i>variable</i> by 1; skips <i>commandA</i> if <i>variable</i> < <i>value</i> .	† PRGM CTL B:DS<(
e^(power)	Returns e raised to <i>power</i> .	[2nd] [e ^x]
e^(list)	Returns a list of e raised to a <i>list</i> of powers.	[2nd] [e ^x]
Exponent: valueEexponent	Returns <i>value</i> times 10 to the <i>exponent</i> .	[2nd] [EE]
Exponent: listEexponent	Returns <i>list</i> elements times 10 to the <i>exponent</i> .	[2nd] [EE]
Exponent: matrixEexponent	Returns <i>matrix</i> elements times 10 to the <i>exponent</i> .	[2nd] [EE]
Eff(nominal rate , compounding periods)	Computes the effective interest rate.	APPS 1:Finance CALC C:>Eff(
Else See If:Then:Else		
End	Identifies end of For(, If-Then-Else, Repeat, or While loop.	† PRGM CTL 7:End
Eng	Sets engineering display mode.	† MODE Eng
Equ>String(Y= var,Strn)	Converts the contents of a Y = <i>var</i> to a string and stores it in Str <i>n</i> .	2nd [CATALOG] Equ>String(
expr(string)	Converts <i>string</i> to an expression and executes it.	2nd [CATALOG] expr(

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
ExpReg [Xlistname, Ylistname, freqlist, regequ]	Fits an exponential regression model to Xlistname and Ylistname with frequency freqlist, and stores the regression equation to regequ.	STAT CALC 0:ExpReg
ExprOff	Turns off the expression display during TRACE .	† [2nd] [FORMAT] ExprOff
ExprOn	Turns on the expression display during TRACE .	† [2nd] [FORMAT] ExprOn
Fcdf(lowerbound, upperbound, numerator df, denominator df)	Computes the F distribution probability between <i>lowerbound</i> and <i>upperbound</i> for the specified <i>numerator df</i> (degrees of freedom) and <i>denominator df</i> .	2nd [DISTR] DISTR 9:Fcdf(
Fill(value,matrixname)	Stores <i>value</i> to each element in <i>matrixname</i> .	2nd [MATRIX] MATH 4:Fill(
Fill(value,listname)	Stores <i>value</i> to each element in <i>listname</i> .	2nd [LIST] OPS 4:Fill(
Fix #	Sets fixed-decimal mode for # of decimal places.	† MODE 0123456789 (select one)
Float	Sets floating decimal mode.	† MODE Float
fMax(expression,variable, lower,upper[,tolerance])	Returns the value of variable where the local maximum of expression occurs, between lower and upper, with specified tolerance.	MATH 7:fMax(

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
fMin(expression,variable, lower,upper[,tolerance])	Returns the value of variable where the local minimum of expression occurs, between lower and upper, with specified tolerance.	MATH 6:fMin(
fnInt(expression,variable, lower,upper[,tolerance])	Returns the function integral of <i>expression</i> with respect to <i>variable</i> , between <i>lower</i> and <i>upper</i> , with specified <i>tolerance</i> .	MATH 9:fnInt(
FnOff [function#, function#,function n]	Deselects all Y = functions or specified Y = functions.	VARS Y-VARS 4:On/Off 2:FnOff
FnOn [function#, function#,function n]	Selects all Y = functions or specified Y = functions.	VARS Y-VARS 4:On/Off 1:FnOn
:For(variable,begin,end [,increment]) :commands :End :commands	Executes commands through End , incrementing variable from begin by increment until variable>end.	† PRGM CTL 4:For(
fPart(value)	Returns the fractional part or parts of a real or complex number, expression, list, or matrix.	MATH NUM 4:fPart(
Fpdf(x,numerator df, denominator df)	Computes the F distribution probability between <i>lowerbound</i> and <i>upperbound</i> for the specified <i>numerator df</i> (degrees of freedom) and <i>denominator df</i> .	2nd [DISTR] DISTR 8:Fpdf(

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
value >Frac	Displays a real or complex number, expression, list, or matrix as a fraction simplified to its simplest terms.	MATH 1:>Frac
Full	Sets full screen mode.	† MODE Full
Func	Sets function graphing mode.	† [MODE] Func
GarbageCollect	Displays the garbage collection menu to allow cleanup of unused archive memory.	2nd [CATALOG] GarbageCollect
gcd(valueA,valueB)	Returns the greatest common divisor of <i>valueA</i> and <i>valueB</i> , which can be real numbers or lists.	MATH NUM 9:gcd(
geometcdf(p,x)	Computes a cumulative probability at x , the number of the trial on which the first success occurs, for the discrete geometric distribution with the specified probability of success p .	2nd [DISTR] DISTR E:geometcdf(
geometpdf(p,x)	Computes a probability at x , the number of the trial on which the first success occurs, for the discrete geometric distribution with the specified probability of success p .	2nd [DISTR] DISTR D:geometpdf(
Get(variable)	Gets data from the CBL 2 [™] or CBR [™] System and stores it in <i>variable</i> .	† PRGM I/O A:Get(

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
GetCalc(variable [,portflag])	Gets contents of <i>variable</i> on another TI-84 Plus and stores it to <i>variable</i> on the receiving TI-84 Plus. By default, the TI-84 Plus uses the USB port if it is connected. If the USB cable is not connected, it uses the I/O port. <i>portflag</i> =0 use USB port if connected; <i>portflag</i> =1 use USB port; <i>portflag</i> =2 use I/O port.	† PRGM I/O 0:GetCalc(
getDate	Returns a list giving the date according to the current value of the clock. The list is in {year,month,day} format.	[2nd] [CATALOG] getDate
getDtFmt	Returns an integer representing the date format that is currently set on the device. 1 = M/D/Y 2 = D/M/Y 3 = Y/M/D	[2nd [CATALOG] getDtFmt
getDtStr(integer)	Returns a string of the current date in the format specified by integer, where: 1 = M/D/Y 2 = D/M/Y 3 = Y/M/D	[2nd [CATALOG] getDtStr(
getKey	Returns the key code for the current keystroke, or 0 , if no key is pressed.	† [PRGM] I/O 7:getKey

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
getTime	Returns a list giving the time according to the current value of the clock. The list is in {hour;minute,second} format. The time is returned in the 24 hour format.	2nd [CATALOG] getTime
getTmFmt	Returns an integer representing the clock time format that is currently set on the device.	[2nd [CATALOG] getTmFmt
	12 = 12 hour format 24 = 24 hour format	
getTmStr(integer)	Returns a string of the current clock time in the format specified by integer, where:	[2nd] [CATALOG] getTmStr(
	12 = 12 hour format 24 = 24 hour format	
Goto label	Transfers control to label.	† PRGM CTL 0:Goto
GraphStyle(function#, graphstyle#)	Sets a graphstyle for function#.	† PRGM CTL H:GraphStyle(
GridOff	Turns off grid format.	† [2nd] [FORMAT] GridOff
GridOn	Turns on grid format.	† [2nd] [FORMAT] GridOn
G-T	Sets graph-table vertical split-screen mode.	† MODE G-T
Horiz	Sets horizontal split- screen mode.	† MODE Horiz

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
Horizontal y	Draws a horizontal line at y.	2nd [DRAW] DRAW 3:Horizontal
identity(dimension)	Returns the identity matrix of <i>dimension</i> rows x <i>dimension</i> columns.	2nd [MATRIX] MATH 5:identity(
:If condition :commandA :commands	If condition = 0 (false), skips commandA.	† PRGM CTL 1:If
:If condition :Then :commands :End :commands	Executes <i>commands</i> from Then to End if <i>condition</i> = 1 (true).	† PRGM CTL 2:Then
:If condition :Then :commands :Else :commands :End :commands	Executes commands from Then to Else if condition = 1 (true); from Else to End if condition = 0 (false).	† PRGM CTL 3:Else
imag(value)	Returns the imaginary (nonreal) part of a complex number or list of complex numbers.	MATH CPX 3:imag(
IndpntAsk	Sets table to ask for independent-variable values.	† 2nd [TBLSET] Indpnt: Ask
IndpntAuto	Sets table to generate independent-variable values automatically.	† 2nd [TBLSET] Indpnt: Auto
Input	Displays graph.	† PRGM I/O 1:Input
Input [variable] Input ["text",variable]	Prompts for value to store to <i>variable</i> .	† PRGM I/O 1:Input

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
Input [Strn,variable]	Displays Str n and stores entered value to <i>variable</i> .	† PRGM I/O 1:Input
inString(string,substring [,start])	Returns the character position in <i>string</i> of the first character of <i>substring</i> beginning at <i>start</i> .	2nd [CATALOG] inString(
int(value)	Returns the largest integer ≤ a real or complex number, expression, list, or matrix.	MATH NUM 5:int(
\(\sum_{\text{pmt1},pmt2}\) [,roundvalue])	Computes the sum, rounded to roundvalue, of the interest amount between pmt1 and pmt2 for an amortization schedule.	APPS 1:Finance CALC A:ΣInt(
invNorm(area[,μ,σ])	Computes the inverse cumulative normal distribution function for a given $area$ under the normal distribution curve specified by μ and σ .	2nd [DISTR] DISTR 3:invNorm(
iPart(value)	Returns the integer part of a real or complex number, expression, list, or matrix.	MATH NUM 3:iPart(
irr(CF0,CFList[,CFFreq])	Returns the interest rate at which the net present value of the cash flow is equal to zero.	APPS 1:Finance CALC 8:irr(
:IS>(variable,value) :commandA :commands	Increments <i>variable</i> by 1; skips <i>commandA</i> if <i>variable>value</i> .	† PRGM CTL A:IS>(
isClockOn	Identifies if clock is ON or OFF. Returns 1 if the clock is ON. Returns 0 if the clock is OFF.	[2nd] [CATALOG] isClockOn

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
Llistname	Identifies the next one to five characters as a user-created list name.	2nd [LIST] OPS B:L
LabelOff	Turns off axes labels.	† [2nd] [FORMAT] LabelOff
LabelOn	Turns on axes labels.	† [2nd] [FORMAT] LabelOn
Lbl label	Creates a <i>label</i> of one or two characters.	† PRGM CTL 9:Lbl
Icm(valueA,valueB)	Returns the least common multiple of <i>valueA</i> and <i>valueB</i> , which can be real numbers or lists.	MATH NUM 8:Icm(
length(string)	Returns the number of characters in <i>string</i> .	[2nd [CATALOG] length(
Line(X1,Y1,X2,Y2)	Draws a line from (XI,YI) to $(X2,Y2)$.	2nd [DRAW] DRAW 2:Line(
Line(X1,Y1,X2,Y2,0)	Erases a line from (XI,YI) to $(X2,Y2)$.	2nd [DRAW] DRAW 2:Line(
LinReg(a+bx) [Xlistname, Ylistname,freqlist, regequ]	Fits a linear regression model to Xlistname and Ylistname with frequency freqlist, and stores the regression equation to regequ.	STAT CALC 8:LinReg(a+bx)
LinReg(ax+b) [Xlistname, Ylistname, freqlist, regequ]	Fits a linear regression model to Xlistname and Ylistname with frequency freqlist, and stores the regression equation to regequ.	STAT CALC 4:LinReg(ax+b)

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
LinRegTTest [Xlistname, Ylistname,freqlist, alternative,regequ]	Performs a linear regression and a t-test. alternative=1 is <; alternative=0 is ≠; alternative=1 is >.	† STAT TESTS E:LinRegTTest
ΔList(list)	Returns a list containing the differences between consecutive elements in <i>list</i> .	2nd [LIST] OPS 7:ΔList(
List > matr(listname1,, listname n,matrixname)	Fills matrixname column by column with the elements from each specified listname.	2nd [LIST] OPS 0:List > matr(
In(value)	Returns the natural logarithm of a real or complex number, expression, or list.	LN
LnReg [Xlistname, Ylistname, freqlist, regequ]	Fits a logarithmic regression model to Xlistname and Ylistname with frequency freqlist, and stores the regression equation to regequ.	STAT CALC 9:LnReg
log(value)	Returns logarithm of a real or complex number, expression, or list.	LOG
Logistic [Xlistname, Ylistname, freqlist, regequ]	Fits a logistic regression model to Xlistname and Ylistname with frequency freqlist, and stores the regression equation to regequ.	STAT CALC B:Logistic
Matr>list(matrix, listnameA,,listname n)	Fills each <i>listname</i> with elements from each column in <i>matrix</i> .	2nd [LIST] OPS A:Matr>list(
Matr>list(matrix, column#,listname)	Fills a <i>listname</i> with elements from a specified <i>column#</i> in <i>matrix</i> .	2nd [LIST] OPS A:Matr>list(

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
max(valueA,valueB)	Returns the larger of valueA and valueB.	MATH NUM 7:max(
max(list)	Returns largest real or complex element in <i>list</i> .	2nd [LIST] MATH 2:max(
max(listA,listB)	Returns a real or complex list of the larger of each pair of elements in <i>listA</i> and <i>listB</i> .	2nd [LIST] MATH 2:max(
max(value, list)	Returns a real or complex list of the larger of <i>value</i> or each <i>list</i> element.	2nd [LIST] MATH 2:max(
mean(list[sfreqlist])	Returns the mean of <i>list</i> with frequency <i>freqlist</i> .	2nd [LIST] MATH 3:mean(
median(list[,freqlist])	Returns the median of <i>list</i> with frequency <i>freqlist</i> .	2nd [LIST] MATH 4:median(
Med-Med [Xlistname, Ylistname, freqlist, regequ]	Fits a median-median model to Xlistname and Ylistname with frequency freqlist, and stores the regression equation to regequ.	STAT CALC 3:Med-Med
Menu("title","text1", label1[,,"text7",label7])	Generates a menu of up to seven items during program execution.	† PRGM CTL C:Menu(
min(valueA,valueB)	Returns smaller of <i>valueA</i> and <i>valueB</i> .	MATH NUM 6:min(
min(list)	Returns smallest real or complex element in <i>list</i> .	2nd [LIST] MATH 1:min(

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
min(listA,listB)	Returns real or complex list of the smaller of each pair of elements in <i>listA</i> and <i>listB</i> .	2nd [LIST] MATH 1:min(
min(value,list)	Returns a real or complex list of the smaller of <i>value</i> or each <i>list</i> element.	2nd [LIST] MATH 1:min(
valueA nCr valueB	Returns the number of combinations of <i>valueA</i> taken <i>valueB</i> at a time.	MATH PRB 3:nCr
value nCr list	Returns a list of the combinations of <i>value</i> taken each element in <i>list</i> at a time.	MATH PRB 3:nCr
list nCr value	Returns a list of the combinations of each element in <i>list</i> taken <i>value</i> at a time.	MATH PRB 3:nCr
listA nCr listB	Returns a list of the combinations of each element in <i>listA</i> taken each element in <i>listB</i> at a time.	MATH PRB 3:nCr
nDeriv(expression, variable,value[,ε])	Returns approximate numerical derivative of expression with respect to variable at value, with specified ϵ .	MATH MATH 8:nDeriv(
Nom(effective rate, compounding periods)	Computes the nominal interest rate.	APPS 1:Finance CALC B:>Nom(
Normal	Sets normal display mode.	† MODE Normal

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
normalcdf(lowerbound, upperbound[,μ,σ])	Computes the normal distribution probability between <i>lowerbound</i> and <i>upperbound</i> for the specified μ and σ .	2nd [DISTR] DISTR 2:normalcdf(
normalpdf(x [, μ , σ])	Computes the probability density function for the normal distribution at a specified x value for the specified μ and σ .	2nd [DISTR] DISTR 1:normalpdf(
not(value)	Returns 0 if value is $\neq 0$. value can be a real number, expression, or list.	2nd [TEST] LOGIC 4:not(
valueA nPr valueB	Returns the number of permutations of <i>valueA</i> taken <i>valueB</i> at a time.	PRB 2:nPr
value nPr list	Returns a list of the permutations of <i>value</i> taken each element in <i>list</i> at a time.	MATH PRB 2:nPr
list nPr value	Returns a list of the permutations of each element in <i>list</i> taken <i>value</i> at a time.	MATH PRB 2:nPr
listA nPr listB	Returns a list of the permutations of each element in <i>listA</i> taken each element in <i>listB</i> at a time.	MATH PRB 2:nPr
npv(interest rate,CF0, CFList[,CFFreq])	Computes the sum of the present values for cash inflows and outflows.	APPS 1:Finance CALC 7:npv(
valueA or valueB	Returns 1 if valueA or valueB is ≠ 0. valueA and valueB can be real numbers, expressions, or lists.	2nd [TEST] LOGIC 2:or

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
Output(row,column, "text")	Displays <i>text</i> beginning at specified <i>row</i> and <i>column</i> .	† PRGM I/O 6:Output(
Output(row,column, value)	Displays <i>value</i> beginning at specified <i>row</i> and <i>column</i> .	† PRGM I/O 6:Output(
Param	Sets parametric graphing mode.	† MODE Par
Pause	Suspends program execution until you press ENTER.	† PRGM CTL 8:Pause
Pause [value]	Displays <i>value</i> ; suspends program execution until you press [ENTER].	† PRGM CTL 8:Pause
Plot#(type,Xlistname, Ylistname,mark)	Defines Plot # (1, 2, or 3) of type Scatter or xyLine for Xlistname and Ylistname using mark.	† 2nd [STAT PLOT] STAT PLOTS 1:Plot1- 2:Plot2- 3:Plot3-
Plot#(type,Xlistname, freqlist)	Defines Plot # (1, 2, or 3) of <i>type</i> Histogram or Boxplot for <i>Xlistname</i> with frequency <i>freqlist</i> .	† 2nd [STAT PLOT] STAT PLOTS 1:Plot1- 2:Plot2- 3:Plot3-
Plot#(type,Xlistname, freqlist,mark)	Defines Plot # (1, 2, or 3) of type ModBoxplot for Xlistname with frequency freqlist using mark.	† 2nd [STAT PLOT] STAT PLOTS 1:Plot1- 2:Plot2- 3:Plot3-
Plot#(type,datalistname, data axis,mark)	Defines Plot# (1, 2, or 3) of type NormProbPlot for datalistname on data axis using mark. data axis can be X or Y.	† 2nd [STAT PLOT] STAT PLOTS 1:Plot1- 2:Plot2- 3:Plot3-
PlotsOff [1,2,3]	Deselects all stat plots or one or more specified stat plots (1, 2, or 3).	2nd [STAT PLOT] STAT PLOTS 4:PlotsOff

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
PlotsOn [1,2,3]	Selects all stat plots or one or more specified stat plots (1, 2, or 3).	2nd [STAT PLOT] STAT PLOTS 5:PlotsOn
Pmt_Bgn	Specifies an annuity due, where payments occur at the beginning of each payment period.	APPS 1:Finance CALC F:Pmt_Bgn
Pmt_End	Specifies an ordinary annuity, where payments occur at the end of each payment period.	APPS 1:Finance CALC E:Pmt_End
poissoncdf(μ,x)	Computes a cumulative probability at x for the discrete Poisson distribution with specified mean μ .	[2nd [DISTR] DISTR C:poissoncdf(
poissonpdf(µ,x)	Computes a probability at x for the discrete Poisson distribution with the specified mean μ .	2nd [DISTR] DISTR B:poissonpdf(
Polar	Sets polar graphing mode.	† MODE Pol
complex value Polar	Displays <i>complex value</i> in polar format.	MATH CPX 7:>Polar
PolarGC	Sets polar graphing coordinates format.	† [2nd] [FORMAT] PolarGC
prgmname	Executes the program name.	† PRGM CTRL D:prgm
Σ Prn(pmt1,pmt2 [,roundvalue])	Computes the sum, rounded to roundvalue, of the principal amount between pmt1 and pmt2 for an amortization schedule.	APPS 1:Finance CALC 0:ΣPrn(

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
prod(list[,start,end])	Returns product of <i>list</i> elements between <i>start</i> and <i>end</i> .	2nd [LIST] MATH 6:prod(
Prompt variableA [,variableB,,variable n]	Prompts for value for <i>variableA</i> , then <i>variableB</i> , and so on.	† PRGM I/O 2:Prompt
1-PropZint(x,n [,confidence level])	Computes a one- proportion z confidence interval.	† STAT TESTS A:1-PropZInt(
2-PropZint(x1,n1,x2,n2 [,confidence level])	Computes a two-proportion <i>z</i> confidence interval.	† STAT TESTS B:2-PropZInt(
1-PropZTest(p0,x,n [,alternative,drawflag])	Computes a one- proportion z test. alternative=1 is <; alternative=0 is ≠; alternative=1 is >. drawflag=1 draws results; drawflag=0 calculates results.	† STAT TESTS 5:1-PropZTest(
2-PropZTest(x1,n1,x2,n2 [,alternative,drawflag])	Computes a two- proportion z test. alternative=1 is <; alternative=0 is ≠; alternative=1 is >. drawflag=1 draws results; drawflag=0 calculates results.	† STAT TESTS 6:2-PropZTest(
Pt-Change(x,y)	Reverses a point at (x,y) .	2nd [DRAW] POINTS 3:Pt-Change(
Pt-Off(x,y[,mark])	Erases a point at (x,y) using mark.	2nd [DRAW] POINTS 2:Pt-Off(
Pt-On(x,y[,mark])	Draws a point at (x,y) using mark.	2nd [DRAW] POINTS 1:Pt-On(

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
PwrReg [Xlistname, Ylistname, freqlist, regequ]	Fits a power regression model to Xlistname and Ylistname with frequency freqlist, and stores the regression equation to regequ.	STAT CALC A:PwrReg
PxI-Change(row,column)	Reverses pixel at $(row, column)$; $0 \le row \le 62$ and $0 \le column \le 94$.	2nd [DRAW] POINTS 6:PxI-Change(
PxI-Off(row,column)	Erases pixel at $(row,column)$; $0 \le row \le 62$ and $0 \le column \le 94$.	2nd [DRAW] POINTS 5:PxI-Off(
Pxi-On(row,column)	Draws pixel at $(row, column)$; $0 \le row \le 62$ and $0 \le column \le 94$.	2nd [DRAW] POINTS 4:PxI-On(
pxl-Test(row,column)	Returns 1 if pixel (row, column) is on, 0 if it is off; $0 \le row \le 62$ and $0 \le column \le 94$.	2nd [DRAW] POINTS 7:pxl-Test(
P▶Rx(r,θ)	Returns X , given polar coordinates r and θ or a list of polar coordinates.	2nd [ANGLE] ANGLE 7:P>Rx(
P▶Ry(r;θ)	Returns Y , given polar coordinates r and θ or a list of polar coordinates.	2nd [ANGLE] ANGLE 8:P>Ry(
QuadReg [Xlistname, Ylistname, freqlist, regequ]	Fits a quadratic regression model to Xlistname and Ylistname with frequency freqlist, and stores the regression equation to regequ.	STAT CALC 5:QuadReg
QuartReg [Xlistname, Ylistname,freqlist, regequ]	Fits a quartic regression model to Xlistname and Ylistname with frequency freqlist, and stores the regression equation to regequ.	STAT CALC 7:QuartReg

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
Radian	Sets radian angle mode.	† MODE Radian
rand[(numtrials)]	Returns a random number between 0 and 1 for a specified number of trials numtrials.	MATH PRB 1:rand
randBin(numtrials,prob [,numsimulations])	Generates and displays a random real number from a specified Binomial distribution.	MATH PRB 7:randBin(
randint(lower,upper [,numtrials])	Generates and displays a random integer within a range specified by <i>lower</i> and <i>upper</i> integer bounds for a specified number of trials <i>numtrials</i> .	MATH PRB 5:randint(
randM(rows,columns)	Returns a random matrix of rows (1-99) × columns (1-99).	2nd [MATRIX] MATH 6:randM(
randNorm(μ,σ [,numtrials])	Generates and displays a random real number from a specified Normal distribution specified by μ and σ for a specified number of trials <i>numtrials</i> .	MATH PRB 6:randNorm(
re^θi	Sets the mode to polar complex number mode $(\mathbf{r}e^{\mathbf{A}\theta i})$.	† MODE re^θi
Real	Sets mode to display complex results only when you enter complex numbers.	† MODE Real
real(value)	Returns the real part of a complex number or list of complex numbers.	MATH CPX 2:real(

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
RecallGDB <i>n</i>	Restores all settings stored in the graph database variable GDB n.	2nd [DRAW] STO 4:RecalIGDB
RecallPic n	Displays the graph and adds the picture stored in Pic <i>n</i> .	2nd [DRAW] STO 2:RecallPic
complex value ▶Rect	Displays <i>complex value</i> or list in rectangular format.	MATH CPX 6:>Rect
RectGC	Sets rectangular graphing coordinates format.	† [2nd] [FORMAT] RectGC
ref(matrix)	Returns the row-echelon form of a <i>matrix</i> .	2nd [MATRIX] MATH A:ref(
:Repeat condition :commands :End :commands	Executes commands until condition is true.	† PRGM CTL 6:Repeat
Return	Returns to the calling program.	† [PRGM] CTL E:Return
round(value[,#decimals])	Returns a number, expression, list, or matrix rounded to $\#decimals$ (\leq 9).	MATH NUM 2:round(
*row(value,matrix,row)	Returns a matrix with <i>row</i> of <i>matrix</i> multiplied by <i>value</i> and stored in <i>row</i> .	2nd [MATRIX] MATH E:*row(
row+(matrix,rowA,rowB)	Returns a matrix with <i>rowA</i> of <i>matrix</i> added to <i>rowB</i> and stored in <i>rowB</i> .	2nd [MATRIX] MATH D:row+(
*row+(value,matrix, rowA,rowB)	Returns a matrix with rowA of matrix multiplied by value, added to rowB, and stored in rowB.	2nd [MATRIX] MATH F:*row+(

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
rowSwap(matrix,rowA, rowB)	Returns a matrix with rowA of matrix swapped with rowB.	2nd [MATRIX] MATH C:rowSwap(
rref(matrix)	Returns the reduced row- echelon form of a <i>matrix</i> .	2nd [MATRIX] MATH B:rref(
R≯Pr(x,y)	Returns \mathbf{R} , given rectangular coordinates x and y or a list of rectangular coordinates.	2nd [ANGLE] ANGLE 5:R>Pr(
$\mathbb{R} \triangleright \mathbb{P} \theta(x,y)$	Returns θ , given rectangular coordinates x and y or a list of rectangular coordinates.	2nd [ANGLE] ANGLE 6:R▶Pθ(
2-SampFTest [listname1, listname2, freqlist1, freqlist2, alternative, drawflag] (Data list input)	Performs a two-sample F test. alternative=-1 is <; alternative=0 is ≠; alternative=1 is >. drawflag=1 draws results; drawflag=0 calculates results.	† STAT TESTS D:2-SampFTest
2-SampFTest Sx1,n1, Sx2,n2[,alternative, drawflag] (Summary stats input)	Performs a two-sample F test. alternative=-1 is <; alternative=0 is ≠; alternative=1 is >. drawflag=1 draws results; drawflag=0 calculates results.	† [STAT] TESTS D:2-SampFTest
2-SampTint [listname1, listname2, freqlist1,freqlist2, confidence level,pooled] (Data list input)	Computes a two-sample t confidence interval. pooled=1 pools variances; pooled=0 does not pool variances.	† STAT TESTS 0:2-SampTInt
2-SampTint $\bar{x}1$, $Sx1$, $n1$, $\bar{x}2$, $Sx2$, $n2$ [, confidence level, pooled] (Summary stats input)	Computes a two-sample t confidence interval. pooled=1 pools variances; pooled=0 does not pool variances.	† STAT TESTS 0:2-SampTint

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
2-SampTTest [listname1, listname2, freqlist1, freqlist2, alternative, pooled, drawflag] (Data list input)	Computes a two-sample t test. alternative=-1 is <; alternative=0 is ≠; alternative=1 is >. pooled=1 pools variances; pooled=0 does not pool variances. drawflag=1 draws results; drawflag=0 calculates results.	† STAT TESTS 4:2-SampTTest
2-SampTTest $\bar{x}1$, $Sx1$, $n1$, $v2$, $Sx2$, $n2$ [, $alternative$, $pooled$, $drawflag$] (Summary stats input)	test. alternative=1 is <; alternative=0 is ≠; alternative=1 is >. pooled=1 pools variances; pooled=0 does not pool variances. drawflag=1 draws results; drawflag=0 calculates results.	† STAT TESTS 4:2-SampTTest
2-SampZInt(σ_1 , σ_2 [,listname1,listname2, freqlist1,freqlist2, confidence level]) (Data list input)	Computes a two-sample z confidence interval.	† STAT TESTS 9:2-SampZInt(
2-SampZInt(σ_1 , σ_2 , \overline{x} <i>I</i> , n 1, \overline{x} 2, n 2 [, <i>confidence level</i>]) (Summary stats input)	Computes a two-sample z confidence interval.	† STAT TESTS 9:2-SampZInt(
2-SampZTest(σ_1 , σ_2 [,listname1,listname2, freqlist1,freqlist2, alternative,drawflag]) (Data list input)	Computes a two-sample z test. alternative=1 is <; alternative=0 is ≠; alternative=1 is >. drawflag=1 draws results; drawflag=0 calculates results.	† STAT TESTS 3:2-SampZTest(

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
2-SampZTest(σ_1 , σ_2 , $\bar{\chi}_1$, n_1 , $\bar{\chi}_2$, n_2 [, alternative, drawflag]) (Summary stats input)	Computes a two-sample z test. alternative=-1 is <; alternative=0 is ≠; alternative=1 is >. drawflag=1 draws results; drawflag=0 calculates results.	† STAT TESTS 3:2-SampZTest(
Sci	Sets scientific notation display mode.	† MODE Sci
Select(Xlistname, Ylistname)	Selects one or more specific data points from a scatter plot or xyLine plot (only), and then store•s the selected data points to two new lists, Xlistname and Ylistname.	2nd [LIST] OPS 8:Select(
Send(variable)	Sends contents of <i>variable</i> to the CBL 2 [™] or CBR [™] System.	† PRGM I/O B:Send(
seq(expression,variable, begin,end[,increment])	Returns list created by evaluating <i>expression</i> with regard to <i>variable</i> , from <i>begin</i> to <i>end</i> by <i>increment</i> .	[2nd [LIST] OPS 5:seq(
Seq	Sets sequence graphing mode.	† MODE Seq
Sequential	Sets mode to graph functions sequentially.	† MODE Sequential
setDate(year,month,day)	Sets the date using a year, month, day format. The year must be 4 digits; month and day can be 1 or 2 digit.	[2nd [CATALOG] setDate(
setDtFmt(integer)	Sets the date format. 1 = M/D/Y 2 = D/M/Y 3 = Y/M/D	2nd [CATALOG] setDtFmt(

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
setTime(hour,minute, second)	Sets the time using an hour, minute, second format. The <i>hour</i> must be in 24 hour format, in which 13 = 1 p.m.	2nd [CATALOG] setTime(
setTmFmt(integer)	Sets the time format. 12 = 12 hour format 24 = 24 hour format	2nd [CATALOG] setTmFmt(
SetUpEditor	Removes all list names from the stat list editor, and then restores list names L1 through L6 to columns 1 through 6 .	STAT EDIT 5:SetUpEditor
SetUpEditor listname1 [,listname2,, listname20]	Removes all list names from the stat list editor, then sets it up to display one or more <i>listnames</i> in the specified order, starting with column 1.	STAT EDIT 5:SetUpEditor
Shade(lowerfunc, upperfunc[,Xleft,Xright, pattern,patres])	Draws lowerfunc and upperfunc in terms of X on the current graph and uses pattern and patres to shade the area bounded by lowerfunc, upperfunc, Xleft, and Xright.	2nd [DRAW] DRAW 7:Shade(
Shade χ ² (lowerbound, upperbound,df)	Draws the density function for the χ^2 distribution specified by degrees of freedom df and shades the area between <i>lowerbound</i> and <i>upperbound</i> .	2nd [DISTR] DRAW 3:Shadeχ²(

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
ShadeF (lowerbound, upperbound, numerator df, denominator df)	Draws the density function for the F distribution specified by numerator df and denominator df and shades the area between lowerbound and upperbound.	2nd [DISTR] DRAW 4:ShadeF(
ShadeNorm(lowerbound, upperbound[,μ,σ])	Draws the normal density function specified by μ and σ and shades the area between lowerbound and upperbound.	2nd [DISTR] DRAW 1:ShadeNorm(
Shade_t(lowerbound, upperbound,df)	Draws the density function for the Student-t distribution specified by degrees of freedom df, and shades the area between <i>lowerbound</i> and <i>upperbound</i> .	2nd [DISTR] DRAW 2:Shade_t(
Simul	Sets mode to graph functions simultaneously.	† MODE Simul
sin(value)	Returns the sine of a real number, expression, or list.	SIN
sin ⁻¹ (value)	Returns the arcsine of a real number, expression, or list.	2nd [SIN-1]
sinh(value)	Returns the hyperbolic sine of a real number, expression, or list.	2nd [CATALOG] sinh(
sinh ⁻¹ (value)	Returns the hyperbolic arcsine of a real number, expression, or list.	2nd [CATALOG] sinh ⁻¹ (

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
SinReg [iterations, Xlistname, Ylistname, period, regequ]	Attempts iterations times to fit a sinusoidal regression model to Xlistname and Ylistname using a period guess, and stores the regression equation to regequ.	STAT CALC C:SinReg
solve(expression, variable, guess, {lower, upper})	Solves expression for variable, given an initial guess and lower and upper bounds within which the solution is sought.	† MATH MATH 0:solve(
SortA(listname)	Sorts elements of <i>listname</i> in ascending order.	2nd [LIST] OPS 1:SortA(
SortA(keylistname, dependlist1[,dependlist2,,dependlist n])	Sorts elements of keylistname in ascending order, then sorts each dependlist as a dependent list.	2nd [LIST] OPS 1:SortA(
SortD(listname)	Sorts elements of <i>listname</i> in descending order.	2nd [LIST] OPS 2:SortD(
SortD(keylistname,dependlist1[,dependlist2,, dependlist n])	Sorts elements of keylistname in descending order, then sorts each dependlist as a dependent list.	[2nd [LIST] OPS 2:SortD(
startTmr	Starts the clock timer. Store or note the displayed value, and use it as the argument for checkTmr() to check the elapsed time.	[2nd [CATALOG] startTmr
stdDev(list[,freqlist])	Returns the standard deviation of the elements in <i>list</i> with frequency <i>freqlist</i> .	2nd [LIST] MATH 7:stdDev(

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
Stop	Ends program execution; returns to home screen.	† PRGM CTL F:Stop
Store: value→variable	Stores value in variable.	STO▶
StoreGDB n	Stores current graph in database GDB <i>n</i> .	2nd [DRAW] STO 3:StoreGDB
StorePic n	Stores current picture in picture Pic <i>n</i> .	2nd [DRAW] STO 1:StorePic
String>Equ(string,Y= var)	Converts <i>string</i> into an equation and stores it in Y = <i>var</i> .	2nd [CATALOG] String>Equ(
sub(string,begin,length)	Returns a string that is a subset of another <i>string</i> , from <i>begin</i> to <i>length</i> .	[2nd] [CATALOG] sub(
sum(list[,start,end])	Returns the sum of elements of <i>list</i> from <i>start</i> to <i>end</i> .	2nd [LIST] MATH 5:sum(
tan(value)	Returns the tangent of a real number, expression, or list.	TAN
tan ⁻¹ (value)	Returns the arctangent of a real number, expression, or list.	[2nd] [TAN-1]
Tangent(expression,value)	Draws a line tangent to expression at X =value.	2nd [DRAW] DRAW 5:Tangent(
tanh(value)	Returns hyperbolic tangent of a real number, expression, or list.	[2nd] [CATALOG] tanh(
tanh ⁻¹ (value)	Returns the hyperbolic arctangent of a real number, expression, or list.	2nd [CATALOG] tanh ⁻¹ (

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
tcdf(lowerbound, upperbound,df)	Computes the Student-t distribution probability between lowerbound and upperbound for the specified degrees of freedom df.	2nd [DISTR] DISTR 5:tcdf(
Text(row,column,text1, text2,,text n)	Writes $text$ on graph beginning at pixel $(row, column)$, where $0 \le row \le 57$ and $0 \le column \le 94$.	2nd [DRAW] DRAW 0:Text(
Then See If:Then		
Time	Sets sequence graphs to plot with respect to time.	† [2nd] [FORMAT] Time
timeCnv(seconds)	Converts seconds to units of time that can be more easily understood for evaluation. The list is in {days,hours,minutes,seconds} format.	2nd [CATALOG] timeCnv
Tinterval [listname, freqlist,confidence level] (Data list input)	Computes a t confidence interval.	† STAT TESTS 8:Tinterval
Tinterval x̄,Sx,n [,confidence level] (Summary stats input)	Computes a t confidence interval.	† STAT TESTS 8:TInterval
tpdf(x,df)	Computes the probability density function (pdf) for the Student- <i>t</i> distribution at a specified <i>x</i> value with specified degrees of freedom <i>df</i> .	2nd [DISTR] DISTR 4:tpdf(
Trace	Displays the graph and enters TRACE mode.	TRACE

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
T-Test μ0[,listname, freqlist,alternative, drawflag] (Data list input)	Performs a t test with frequency freqlist. alternative=1 is <; alternative=0 is ≠; alternative=1 is >. drawflag=1 draws results; drawflag=0 calculates results.	† STAT TESTS 2:T-Test
T-Test $\mu\theta$, $\bar{\mathbf{x}}_sSx_sn$ [, alternative, drawflag] (Summary stats input)	Performs a t test with frequency freqlist. alternative=1 is <; alternative=0 is \neq ; alternative=1 is >. drawflag=1 draws results; drawflag=0 calculates results.	† STAT TESTS 2:T-Test
tvm_FV[(N,I%, <i>PV,PMT,</i> <i>P/Y,C/Y</i>)]	Computes the future value.	APPS 1:Finance CALC 6:tvm_FV
tvm_ [%[(N , <i>PV</i> , <i>PMT</i> , <i>FV</i> , <i>P/Y</i> , <i>C/Y</i>)]	Computes the annual interest rate.	APPS 1:Finance CALC 3:tvm_I%
tvm_N[(I%,PV,PMT,FV, P/Y,C/Y)]	Computes the number of payment periods.	APPS 1:Finance CALC 5:tvm_N
tvm_Pmt[(N,I%,PV,FV, P/Y,C/Y)]	Computes the amount of each payment.	APPS 1:Finance CALC 2:tvm_Pmt
tvm_PV[(N,I%,PMT,FV, P/Y,C/Y)]	Computes the present value.	APPS 1:Finance CALC 4:tvm_PV
UnArchive	Moves the specified variables from the user data archive memory to RAM.	2nd [MEM] 6:UnArchive
	To archive variables, use Archive .	

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
uvAxes	Sets sequence graphs to plot $\mathbf{u}(n)$ on the x-axis and $\mathbf{v}(n)$ on the y-axis.	† [2nd] [FORMAT] UV
uwAxes	Sets sequence graphs to plot u (<i>n</i>) on the x-axis and w (<i>n</i>) on the y-axis.	† [2nd] [FORMAT] uw
1-Var Stats [Xlistname, freqlist]	Performs one-variable analysis on the data in Xlistname with frequency freqlist.	STAT CALC 1:1-Var Stats
2-Var Stats [Xlistname, Ylistname, freqlist]	Performs two-variable analysis on the data in Xlistname and Ylistname with frequency freqlist.	STAT CALC 2:2-Var Stats
variance(list[ˌfreqlist])	Returns the variance of the elements in <i>list</i> with frequency <i>freqlist</i> .	2nd [LIST] MATH 8:variance(
Vertical <i>x</i>	Draws a vertical line at x .	2nd [DRAW] DRAW 4:Vertical
vwAxes	Sets sequence graphs to plot v (n) on the x-axis and w (n) on the y-axis.	† [2nd] [FORMAT] VW
Web	Sets sequence graphs to trace as webs.	† [2nd] [FORMAT] Web
:While condition :commands :End :command	Executes commands while condition is true.	† PRGM CTL 5:While
valueA xor valueB	Returns 1 if only valueA or valueB = 0. valueA and valueB can be real numbers, expressions, or lists.	2nd [TEST] LOGIC 3:xor

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
ZBox	Displays a graph, lets you draw a box that defines a new viewing window, and updates the window.	† ZOOM ZOOM 1:ZBox
ZDecimal	Adjusts the viewing window so that $\Delta X=0.1$ and $\Delta Y=0.1$, and displays the graph screen with the origin centered on the screen.	† ZOOM ZOOM 4:ZDecimal
Zinteger	Redefines the viewing window using these dimensions: ΔX=1 Xscl=10 ΔY=1 Yscl=10	† ZOOM ZOOM 8:Zinteger
Zinterval σ[,listname, freqlist,confidence level] (Data list input)	Computes a z confidence interval.	† STAT TESTS 7:ZInterval
Zinterval σ,x̄,n [,confidence level] (Summary stats input)	Computes a z confidence interval.	† STAT TESTS 7:ZInterval
Zoom In	Magnifies the part of the graph that surrounds the cursor location.	† <u>ZOOM</u> ZOOM 2:Zoom In
Zoom Out	Displays a greater portion of the graph, centered on the cursor location.	† ZOOM ZOOM 3:Zoom Out
ZoomFit	Recalculates Ymin and Ymax to include the minimum and maximum Y values, between Xmin and Xmax , of the selected functions and replots the functions.	† ZOOM ZOOM 0:ZoomFit
ZoomRcl	Graphs the selected functions in a user-defined viewing window.	† [ZOOM] MEMORY 3:ZoomRcl

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
ZoomStat	Redefines the viewing window so that all statistical data points are displayed.	† [Z00M] ZOOM 9:ZoomStat
ZoomSto	Immediately stores the current viewing window.	† ZOOM MEMORY 2:ZoomSto
ZPrevious	Replots the graph using the window variables of the graph that was displayed before you executed the last ZOOM instruction.	† ZOOM MEMORY 1:ZPrevious
ZSquare	Adjusts the X or Y window settings so that each pixel represents an equal width and height in the coordinate system, and updates the viewing window.	† [Z00M] ZOOM 5:ZSquare
ZStandard	Replots the functions immediately, updating the window variables to the default values.	† ZOOM ZOOM 6:ZStandard
Z-Test (μ <i>0</i> ,σ[, <i>listname</i> , freqlist,alternative, drawflag]) (Data list input)	Performs a z test with frequency freqlist. alternative=1 is <; alternative=0 is ≠; alternative=1 is >. drawflag=1 draws results; drawflag=0 calculates results.	† STAT TESTS 1:Z-Test(
Z-Test ($\mu \theta$, σ , \overline{x} , n [, alternative, drawflag]) (Summary stats input)	Performs a z test. alternative= 1 is <; alternative=0 is ≠; alternative=1 is >. drawflag=1 draws results; drawflag=0 calculates results.	† STAT TESTS 1:Z-Test(

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
ZTrig	Replots the functions immediately, updating the window variables to preset values for plotting trig functions.	† 200M ZOOM 7:ZTrig
Factorial: value!	Returns factorial of <i>value</i> .	MATH PRB 4:!
Factorial: list!	Returns factorial of <i>list</i> elements.	MATH PRB 4:!
Degrees notation: value°	Interprets <i>value</i> as degrees; designates degrees in DMS format.	2nd [ANGLE] ANGLE 1:°
Radian: angle ^r	Interprets angle as radians.	2nd [ANGLE] ANGLE 3:r
Transpose: matrix ^T	Returns a matrix in which each element (row, column) is swapped with the corresponding element (column, row) of matrix.	[2nd [MATRIX] MATH 2: ^T
xthroot [*] √value	Returns xthroot of value.	MATH MATH 5: ^x √
$x^{th}root^{\mathbf{X}}\sqrt{list}$	Returns xthroot of list elements.	MATH MATH 5: ^x √
list ^{X} √value	Returns <i>list</i> roots of <i>value</i> .	MATH MATH 5: ^x √
listA ^x √listB	Returns <i>listA</i> roots of <i>listB</i> .	MATH MATH 5: ^x √

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
Cube: value ³	Returns the cube of a real or complex number, expression, list, or square matrix.	MATH 3:3
Cube root: ³ √(value)	Returns the cube root of a real or complex number, expression, or list.	MATH MATH 4: ³ √
Equal: valueA=valueB	Returns 1 if valueA = valueB. Returns 0 if valueA ≠ valueB. valueA and valueB can be real or complex numbers, expressions, lists, or matrices.	2nd [TEST] TEST 1:=
Not equal: valueA≠valueB	Returns 1 if valueA ≠ valueB. Returns 0 if valueA = valueB. valueA and valueB can be real or complex numbers, expressions, lists, or matrices.	2nd [TEST] TEST 2:≠
Less than: valueA <valueb< td=""><td>Returns 1 if valueA < valueB. Returns 0 if valueA ≥ valueB. valueA and valueB can be real or complex numbers, expressions, or lists.</td><td>2nd [TEST] TEST 5:<</td></valueb<>	Returns 1 if valueA < valueB. Returns 0 if valueA ≥ valueB. valueA and valueB can be real or complex numbers, expressions, or lists.	2nd [TEST] TEST 5:<
Greater than: valueA>valueB	Returns 1 if valueA > valueB. Returns 0 if valueA ≤ valueB. valueA and valueB can be real or complex numbers, expressions, or lists.	2nd [TEST] TEST 3:>
Less than or equal: valueA≤valueB	Returns 1 if valueA ≤ valueB. Returns 0 if valueA > valueB. valueA and valueB can be real or complex numbers, expressions, or lists.	2nd [TEST] TEST 6: ≤

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
Greater than or equal: valueA≥valueB	Returns 1 if valueA ≥ valueB. Returns 0 if valueA < valueB. valueA and valueB can be real or complex numbers, expressions, or lists.	2nd [TEST] TEST 4: ≥
Inverse: value ⁻¹	Returns 1 divided by a real or complex number or expression.	x-1
Inverse: list ⁻¹	Returns 1 divided by <i>list</i> elements.	[x-1]
Inverse: matrix ⁻¹	Returns matrix inverted.	x-1
Square: value ²	Returns <i>value</i> multiplied by itself. <i>value</i> can be a real or complex number or expression.	x^2
Square: list ²	Returns <i>list</i> elements squared.	<u>[x²]</u>
Square: matrix ²	Returns <i>matrix</i> multiplied by itself.	<u>[x²]</u>
Powers: value*power	Returns <i>value</i> raised to <i>power. value</i> can be a real or complex number or expression.	A
Powers: list*power	Returns <i>list</i> elements raised to <i>power</i> .	۸
Powers: value^list	Returns <i>value</i> raised to <i>list</i> elements.	^
Powers: matrix*power	Returns <i>matrix</i> elements raised to <i>power</i> .	۸
Negation: -value	Returns the negative of a real or complex number, expression, list, or matrix.	

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
Power of ten: 10^(value)	Returns 10 raised to the <i>value</i> power. <i>value</i> can be a real or complex number or expression.	[2nd] [10 ^x]
Power of ten: 10^(list)	Returns a list of 10 raised to the <i>list</i> power.	[2nd] [10 ^x]
Square root: √(value)	Returns square root of a real or complex number, expression, or list.	[2nd] [√]
Multiplication: valueA*valueB	Returns valueA times valueB.	×
Multiplication: value*list	Returns <i>value</i> times each <i>list</i> element.	×
Multiplication: list*value	Returns each <i>list</i> element times <i>value</i> .	×
Multiplication: listA*listB	Returns <i>listA</i> elements times <i>listB</i> elements.	×
Multiplication: value*matrix	Returns value times <i>matrix</i> elements.	×
Multiplication: matrixA*matrixB	Returns <i>matrixA</i> times <i>matrixB</i> .	×
Division: valueA/valueB	Returns <i>valueA</i> divided by <i>valueB</i> .	÷
Division: list/value	Returns <i>list</i> elements divided by value.	÷
Division: value/list	Returns value divided by <i>list</i> elements.	÷
Division: listA/listB	Returns <i>listA</i> elements divided by <i>listB</i> elements.	÷
Addition: valueA+valueB	Returns valueA plus valueB.	+
Addition: list+value	Returns list in which <i>value</i> is added to each <i>list</i> element.	+

Function or Instruction/ Arguments	Result	Key or Keys/Menu or Screen/Item
Addition: listA+listB	Returns <i>listA</i> elements plus <i>listB</i> elements.	+
Addition: matrixA+matrixB	Returns <i>matrixA</i> elements plus <i>matrixB</i> elements.	+
Concatenation: string1+string2	Concatenates two or more strings.	+
Subtraction: valueA-valueB	Subtracts valueB from valueA.	-
Subtraction: value-list	Subtracts <i>list</i> elements from <i>value</i> .	-
Subtraction: list-value	Subtracts <i>value</i> from <i>list</i> elements.	-
Subtraction: listA-listB	Subtracts <i>listB</i> elements from <i>listA</i> elements.	-
Subtraction: matrixA-matrixB	Subtracts matrixB elements from matrixA elements.	
Minutes notation:degrees°minutes' seconds"	Interprets <i>minutes</i> angle measurement as minutes.	2nd [ANGLE] ANGLE 2:'
Seconds notation: degrees°minutes'seconds"	Interprets <i>seconds</i> angle measurement as seconds.	[ALPHA] ['']

Variables

User Variables

The TI-84 Plus uses the variables listed below in various ways. Some variables are restricted to specific data types.

The variables **A** through **Z** and θ are defined as real or complex numbers. You may store to them. The TI-84 Plus can update **X**, **Y**, **R**, θ , and **T** during graphing, so you may want to avoid using these variables to store nongraphing data.

The variables (list names) **L1** through **L6** are restricted to lists; you cannot store another type of data to them.

The variables (matrix names) [A] through [J] are restricted to matrices; you cannot store another type of data to them.

The variables **Pic1** through **Pic9** and **Pic0** are restricted to pictures; you cannot store another type of data to them.

The variables **GDB1** through **GDB9** and **GDB0** are restricted to graph databases; you cannot store another type of data to them.

The variables **Str1** through **Str9** and **Str0** are restricted to strings; you cannot store another type of data to them.

Except for system variables, you can store any string of characters, functions, instructions, or variables to the functions $\mathbf{Y}n$, (1 through $\mathbf{9}$, and $\mathbf{0}$), $\mathbf{X}n\mathbf{T}/\mathbf{Y}n\mathbf{T}$ (1 through $\mathbf{6}$), $\mathbf{r}n$ (1 through $\mathbf{6}$), $\mathbf{u}(n)$, $\mathbf{v}(n)$, and $\mathbf{w}(n)$ directly or through the \mathbf{Y} = editor. The validity of the string is determined when the function is evaluated.

Archive Variables

You can store data, programs or any variable from RAM to user data archive memory where they cannot be edited or deleted inadvertantly. Archiving also allows you to free up RAM for variables that may require additional memory. The names of archived variables are preceded by an asterisk "*" indicating they are in user data archive.

System Variables

The variables below must be real numbers. You may store to them. Since the TI-84 Plus can update some of them, as the result of a **ZOOM**, for example, you may want to avoid using these variables to store nongraphing data.

Xmin, Xmax, Xscl, \(\Delta X\), XFact, Tstep, PlotStart, \(n\)Min, and other window variables.

 ZXmin, ZXmax, ZXscl, ZTstep, ZPlotStart, Zu(nMin), and other ZOOM variables.

The variables below are reserved for use by the TI-84 Plus. You cannot store to them.

n, \bar{x} , Sx, σ x, minX, maxX, Gy, Σ y², Σ xy, a, b, c, RegEQ, x1, x2, y1, z, t, F, χ^2 , \hat{p} , \bar{x} 1, Sx1, n1, lower, upper, r², R² and other statistical variables.

Statistics Formulas

This section contains statistics formulas for the **Logistic** and **SinReg** regressions, **ANOVA**, **2-SampFTest**, and **2-SampTTest**.

Logistic

The logistic regression algorithm applies nonlinear recursive least-squares techniques to optimize the following cost function:

$$J = \sum_{i=1}^{N} \left(\frac{c}{1 + ae^{-bx_i}} - y_i \right)^2$$

which is the sum of the squares of the residual errors,

where: x = the independent variable list

y = the dependent variable list

N = the dimension of the lists

This technique attempts to estimate the constants a, b, and c recursively to make J as small as possible.

SinReg

The sine regression algorithm applies nonlinear recursive least-squares techniques to optimize the following cost function:

$$J = \sum_{i=1}^{N} \left[a \sin(bx_i + c) + d - y_i \right]^2$$

which is the sum of the squares of the residual errors,

where: x = the independent variable list

y = the dependent variable list

N = the dimension of the lists

This technique attempts to recursively estimate the constants a, b, c, and d to make J as small as possible.

ANOVA(

The ANOVA F statistic is:

$$\mathbf{F} = \frac{FactorMS}{ErrorMS}$$

The mean squares (MS) that make up \mathbf{F} are:

$$FactorMS = \frac{FactorSS}{Factordf}$$

$$ErrorMS = \frac{ErrorSS}{Errordf}$$

The sum of squares (SS) that make up the mean squares are:

$$FactorSS = \sum_{i=1}^{I} n_i (\bar{x}_i - \bar{x})^2$$

$$ErrorSS = \sum_{i=1}^{I} (n_i - 1)Sx_i^2$$

The degrees of freedom df that make up the mean squares are:

$$Factor df = I - 1 = numerator df$$
 for **F**

$$Errordf = \sum_{i=1}^{I} (n_i - 1) = denominator df$$
 for **F**

where: I = number of populations

 \bar{x}_i = the mean of each list

= the standard deviation of each list

Sxi = the length of each list ni = the mean of all lists

 \bar{x}

2-SampFTest

Below is the definition for the 2-SampFTest.

Sx1, Sx2 = Sample standard deviations having n_1-1 and n_2-1 degrees of freedom df, respectively.

F = F-statistic =
$$\left(\frac{Sx1}{Sx2}\right)^2$$

$$df(x, n_1-1, n_2-1) = Fpdf()$$
 with degrees of freedom df , n_1-1 , and n_2-1

$$p = \text{reported } p \text{ value}$$

2-SampFTest for the alternative hypothesis $\sigma_1 > \sigma_2$.

$$p = \int_{E}^{\alpha} f(x, n_1 - 1, n_2 - 1) dx$$

2-SampFTest for the alternative hypothesis $\sigma_1 < \sigma_2$.

$$p = \int_{0}^{F} f(x, n_1 - 1, n_2 - 1) dx$$

2-SampFTest for the alternative hypothesis $\sigma_1 \neq \sigma_2$. Limits must satisfy the following:

$$\frac{p}{2} = \int_{0}^{L_{bnd}} f(x, n_1 - 1, n_2 - 1) dx = \int_{U_{bnd}}^{\infty} f(x, n_1 - 1, n_2 - 1) dx$$

where: [Lbnd, Ubnd] = lower and upper limits

The **F**-statistic is used as the bound producing the smallest integral. The remaining bound is selected to achieve the preceding integral's equality relationship.

2-SampTTest

The following is the definition for the **2-SampTTest**. The two-sample t statistic with degrees of freedom df is:

$$t = \frac{\bar{x}_1 - \bar{x}_2}{S}$$

where the computation of S and df are dependent on whether the variances are pooled. If the variances are not pooled:

$$S = \sqrt{\frac{Sx_1^2}{n_1} + \frac{Sx_2^2}{n_2}}$$

$$df = \frac{\left(\frac{Sx_1^2}{n_1} + \frac{Sx_2^2}{n_2}\right)^2}{\frac{1}{n_1 - 1} \left(\frac{Sx_1^2}{n_1}\right)^2 + \frac{1}{n_2 - 1} \left(\frac{Sx_2^2}{n_2}\right)^2}$$

otherwise:

$$Sx_p = \frac{(n_1 - 1)Sx_1^2 + (n_2 - 1)Sx_2^2}{df}$$

$$S = \sqrt{\frac{1}{n_1} + \frac{1}{n_2}Sx_p}$$

$$df = n_1 + n_2 - 2$$

and Sxp is the pooled variance.

Financial Formulas

This section contains financial formulas for computing time value of money, amortization, cash flow, interest-rate conversions, and days between dates.

Time Value of Money

$$i = [e^{(y \times \ln(x+1))}] - 1$$

where: $PMT \neq 0$

 $y = C/Y \div P/Y$

 $x = (.01 \times I\%) \div C/Y$

C/Y = compounding periods per year P/Y = payment periods per year

1% = interest rate per year

$$i = (-FV \div PV)^{(1 \div N)} - 1$$

where: PMT = 0

The iteration used to compute i:

$$0 = PV + PMT \times G_i \left[\frac{1 - (1 + i)^{-N}}{i} \right] + FV \times (1 + i)^{-N}$$

$$I\% = 100 \times C/Y \times [e^{(y \times \ln(x+1))} - 1]$$

where: x = i

 $y = P/Y \div C/Y$

$$G_i = 1 + i \times k$$

where: k = 0 for end-of-period payments

k = 1 for beginning-of-period payments

$$N = \frac{\ln \left(\frac{PMT \times G_i - FV \times i}{PMT \times G_i + PV \times i}\right)}{\ln(1+i)}$$

where: $i \neq 0$

$$N = -(PV + FV) \div PMT$$

where: i = 0

$$PMT = \frac{-i}{G_i} \times \left[PV + \frac{PV + FV}{(1+i)^N - 1} \right]$$

where: $i \neq 0$

$$PMT = -(PV + FV) \div N$$

where: i = 0

$$PV = \left[\frac{PMT \times G_i}{i} - FV\right] \times \frac{1}{(1+i)^N} - \frac{PMT \times G_i}{i}$$

where: $i \neq 0$

$$PV = (FV + PMT \times N)$$

where: i = 0

$$FV = \frac{PMT \times G_i}{i} - (1+i)^N \times \left(PV + \frac{PMT \times G_i}{i}\right)$$

where: $i \neq 0$

$$FV = -(PV + PMT \times N)$$

where: i = 0

Amortization

If computing bal(), pmt2 = npmt

Let bal(0) = RND(PV)

Iterate from m = 1 to pmt2

$$\begin{cases} I_m = RND[RND12(-i \times bal(m-1))] \\ bal(m) = bal(m-1) - I_m + RND(PMT) \end{cases}$$

then:

$$bal() = bal(pmt2)$$

 $EPrn() = bal(pmt2) - bal(pmt1)$
 $\Sigma Int() = (pmt2 - pmt1 + 1) \times RND(PMT) - \Sigma Prn()$

where: RND = round the display to the number of decimal places selected

RND12 = round to 12 decimal places

Balance, principal, and interest are dependent on the values of **PMT**, **PV**, I%, and pmt1 and pmt2.

Cash Flow

$$npv() = CF_0 + \sum_{j=1}^{N} CF_j (1+i)^{-S_j-1} \frac{(1-(1+i)^{-n_j})}{i}$$

where:
$$S_j = \begin{cases} \sum_{i=1}^j n_i & j \ge 1 \\ 0 & j = 0 \end{cases}$$

Net present value is dependent on the values of the initial cash flow (CF_0) , subsequent cash flows (CF_j) , frequency of each cash flow (nj), and the specified interest rate (i).

$$irr() = 100 \times i$$
, where i satisfies $npv() = 0$

Internal rate of return is dependent on the values of the initial cash flow (CF_0) and subsequent cash flows (CF_j) .

$$i = I\% \div 100$$

Interest Rate Conversions

where:
$$x = 100 \times (e^{CP \times \ln(x+1)} - 1)$$

 $= .01 \times Nom \div CP$
 $Nom = 100 \times CP \times [e^{1 \div CP \times \ln(x+1)} - 1]$

where: $x = .01 \times Eff$

Eff = effective rate

CP = compounding periods

Nom = nominal rate

Days between Dates

With the **dbd(** function, you can enter or compute a date within the range Jan. 1, 1950, through Dec. 31, 2049.

Actual/actual day-count method (assumes actual number of days per month and actual number of days per year):

dbd((days between dates) = Number of Days II - Number of Days I

Number of Days I =
$$(Y1-YB) \times 365$$

+ (number of days MB to M1)

+
$$(Y1 - YB)$$

Number of Days II =
$$(Y2-YB) \times 365$$

+ (number of days MB to M2)

$$+$$
 $(Y2 - YB)$

where: M1 = month of first date

DT1 = day of first date Y1 = vear of first date

M2 = month of second date DT2 = day of second date Y2 = year of second date

MB = base month (January)

DB = base day (1)

YB = base year (first year after leap year)

Appendix B: General Information

Battery Information

When to Replace the Batteries

The TI-84 Plus uses five batteries: four AAA alkaline batteries and one SR44SW or 303 silver oxide backup battery. The silver oxide battery provides auxiliary power to retain memory while you replace the AAA hatteries

When the battery voltage level drops below a usable level, the TI-84 Plus:

Displays this message when vou turn on the unit.

Displays this message when you attempt to download an application.

Your batteries are low. Recommend change of batteries.

Batteries are low. Change is required.

Message A

Message B

After Message A is first displayed, you can expect the batteries to function for about one or two weeks, depending on usage. (This oneweek to two-week period is based on tests with alkaline batteries; the performance of other types of batteries may vary.)

If **Message B** is displayed, you must replace the batteries immediately to successfully download an application.

Replace the silver oxide battery every three or four years.

Effects of Replacing the Batteries

Do not remove both types of batteries (AAA and silver oxide) at the same time. **Do not** allow the batteries to lose power completely. If you follow these guidelines and the steps for replacing batteries, you can replace either type of battery without losing any information in memory.

Battery Precautions

Take these precautions when replacing batteries.

- Do not leave batteries within reach of children
- Do not mix new and used batteries. Do not mix brands (or types within brands) of batteries.
- Do not mix rechargeable and nonrechargeable batteries.
- Install batteries according to polarity (+ and -) diagrams.
- Do not place nonrechargeable batteries in a battery recharger.
- Properly dispose of used batteries immediately. Do not leave them within the reach of children.
- Do not incinerate or dismantle batteries.

Replacing the Batteries

To replace the batteries, follow these steps.

- 1. Turn off the graphing handheld. Replace the slide cover over the keyboard to avoid inadvertently turning on the graphing handheld. Turn the back of the unit toward you.
- 2. Hold the graphing handheld upright, push downward on the latch on the top of the battery cover, and then pull the cover toward you.

Note: To avoid loss of information stored in memory, you must turn off the graphing handheld. Do not remove the AAA batteries and the silver oxide battery simultaneously.

- 3. Replace all four AAA alkaline batteries simultaneously. Or, replace the silver oxide battery.
 - To replace the AAA alkaline batteries, remove all four discharged AAA batteries and install new ones according to the polarity (+ and -) diagram in the battery compartment.



 To replace the silver oxide battery, remove the screw from the silver oxide battery cover, and then remove the cover. Install the new battery, + side up. Replace the cover and secure it with the screw. Use a SR44SW or 303 (or equivalent) silver oxide battery.

4. Replace the battery compartment cover. Turn the graphing handheld on and adjust the display contrast, if necessary, by pressing 2nd • or •.

Important Things You Need to Know About Your TI-84 Plus

TI-84 Plus Results

There may be a number of reasons that your TI-84 Plus is not displaying the expected results; however, the most common solutions involve order of operations or mode settings. Your handheld uses an Equation Operating System (EOS) which evaluates the functions in an expression in the following order:

- Functions that precede the argument, such as square root, sin(, or log(
- Functions that are entered after the argument, such as exponents, factorial, r, °, and conversions
- 3. Powers and roots, such as 2⁵, or 5*square root(32)
- 4. Permutations (nPr) and combinations (nCr)
- 5. Multiplication, implied multiplication, and division
- 6. Addition and subtraction
- 7. Relational functions, such as > or <
- 8. Logic operator and
- Logic operators or and xor

Remember that EOS evaluates from left to right and calculations within parentheses are evaluated first. You should use parentheses where the rules of algebra may not be clear.

If you are using trigonometric functions or performing polar and rectangular conversions, the unexpected results may be caused by an angle mode setting. The Radian and Degree angle mode settings control how the TI-84 Plus interprets angle values.

To change the angle mode settings, follow these steps:

- 1. Press MODE to display the Mode settings.
- 2. Select Degree or Radian.
- 3. Press ENTER to save the angle mode setting.

ERR:DIM MISMATCH Error

Your TI-84 Plus displays the **ERR:DIM MISMATCH** error if you are trying to perform an operation that references one or more lists or matrices whose dimensions do not match. For example, multiplying L1*L2, where L1={1,2,3,4,5} and L2={1,2} produces an **ERR:DIM MISMATCH** error because the number of elements in L1 and L2 do not match.

ERR:INVALID DIM Error

The **ERR:INVALID DIM** error message may occur if you are trying to graph a function that does not involve the stat plot features. The error can be corrected by turning off the stat plots. To turn the stat plots off, press [2nd] [STAT PLOT] and then select **4:PlotsOff**.

Contrast Feature

If the contrast setting is too dark (set to 9) or too dim (set to 0) the unit may appear as if it is malfunctioning or turned off. To adjust the contrast, press *and* release 2nd, and then press and hold \blacktriangle or \blacktriangledown .

TI-84 Plus Identification Code

Your graphing handheld has a unique identification (ID) code that you should record and keep. You can use this 14 digit ID to register your handheld at education.ti.com or identify your handheld in the event that it is lost or stolen. A valid ID includes numbers 0 through 9 and the letters A through F.

You can view the handheld's Operating System, Product Number, ID, and Certificate Revision Number from the **About** screen. To display the **About** screen, press [2nd] [MEM] and then select **1:About**.

TI-84 Plus Silver Edition 2.20 PROD #: 0A-2-02-14 ID: 0A3C3-79DF1-E362
Help: education.ti.com

Your unique product I	D code:	

Backups

Your TI-84 Plus is similar to a computer, in that it stores files and Apps that are important to you. It is always a good idea to back up your graphing handheld device files and Apps using the TI Connect™ software and a USB computer cable. You can find the specific procedures for backing up your handheld's device files and Apps in the TI Connect™ Help file.

Apps

TI-84 Plus Software Applications (Apps) is software that you can add to your handheld in the same way you would add software to your computer. Apps let you customize your handheld for peak performance in specific areas of study. You can find apps for the TI-84 Plus at the TI Online Store at education.ti.com.

TI-Cares KnowledgeBase

The TI-Cares KnowledgeBase provides 24-hour access through the Web to find answers to frequently asked questions. The TI-Cares KnowledgeBase searches its repository of known solutions and presents you with the solutions that are most likely to solve your problem. You can search the TI-Cares KnowledgeBase at education.ti.com/support.

In Case of Difficulty

Handling a Difficulty

To handle a difficulty, follow these steps.

- If you cannot see anything on the screen, you may need to adjust the graphing handheld contrast.
 - To darken the screen, press *and* release 2nd, and then press and hold 1 until the display is sufficiently dark.
 - To lighten the screen, press *and* release 2nd, and then press and hold vintil the display is sufficiently light.
- 2. If an error menu is displayed, follow these steps:
 - Note the error type (ERR:error type).
 - Select **2:GOTO**, if it is available. The previous screen is displayed with the cursor at or near the error location.
 - Deteremine the error.
 - Correct the expression.

Refer to the Error Conditions table for details about specific errors, if necessary.

- 3. If the busy indicator (dotted line) is displayed, a graph or program has been paused; the TI-84 Plus is waiting for input. Press ENTER to continue or press ON to break.
- 4. If a checkerboard cursor (■) is displayed, then either you have entered the maximum number of characters in a prompt, or memory is full. If memory is full:
 - Press 2nd [MEM] 2 to display the MEMORY MANAGEMENT / DELETE menu
 - Select the type of data you want to delete, or select 1:All for a list of all variables of all types. A screen is displayed listing each variable of the type you selected and the number of bytes each variable is using.
 - Press A and T to move the selection cursor (*) next to the item
 you want to delete, and then press DEL.
- 5. If the graphing handheld does not seem to work at all, be sure the alkaline batteries are fresh and that they are installed properly.
- 6. If the TI-84 Plus does not function even though you are sure that the batteries are fresh, you can try manually resetting it.
 - Remove all of the AAA batteries from the graphing handheld.
 - Press and hold the ON key for ten seconds.
 - Replace the batteries.
 - Turn on the unit.

When you reset your graphing handheld, the contrast sometimes changes. If the screen is faded or blank, adjust the contrast by pressing 2nd and releasing \bullet or \checkmark .

- If the above solutions do not work you can reset all of the memory.
 The RAM, user data archive memory, and system variables are restored to factory settings when you reset all memory. All nonsystem variables, applications (Apps), and programs are deleted.
 - Press 2nd [MEM] to display the **MEMORY** menu.
 - Select 7:Reset to display the RAM ARCHIVE ALL menu.
 - Press ▶ to display the ALL menu.
 - Select **1:All Memory** to display the **RESET MEMORY** menu.
 - To continue with the reset, select 2:Reset. The message
 Mem cleared is displayed on the home screen.

Error Conditions

When the TI-84 Plus detects an error, it returns an error message as a menu title, such as **ERR:SYNTAX** or **ERR:DOMAIN**. This table contains each error type, possible causes, and suggestions for correction. The error types listed in this table are each preceded by **ERR:** on your graphing handheld display. For example, you will see **ERR:ARCHIVED** as a menu title when your graphing handheld detects an **ARCHIVED** error type.

Error Type	Possible Causes and Suggested Remedies
ARCHIVED	You have attempted to use, edit, or delete an archived variable. For example, the expression dim(L1) produces an error if L1 is archived.
ARCHIVE FULL	You have attempted to archive a variable and there is not enough space in archive to receive it.
ARGUMENT	A function or instruction does not have the correct number of arguments. See Appendix A for function and instruction syntax. Appendix A displays the arguments and punctuation needed to execute the function or instruction. For
TI-84 Plus. The argu arguments in brack not type them. You multiple arguments stdDev (list[.freqlist] or stdDev(L1,L2) sin	example, stdDev (<i>list</i> [, <i>freqlist</i>]) is a function of the TI-84 Plus. The arguments are shown in italics. The arguments in brackets are optional and you need not type them. You must also be sure to separate multiple arguments with a comma (,). For example, stdDev (<i>list</i> [, <i>freqlist</i>]) might be entered as stdDev(L1) or stdDev(L1,L2) since the frequency list or <i>freqlist</i> is optional.
BAD ADDRESS	You have attempted to send or receive an application and an error (e.g. electrical interference) has occurred in the transmission.
BAD GUESS	 In a CALC operation, you specified a Guess that is not between Left Bound and Right Bound.
	 For the solve(function or the equation solver, you specified a guess that is not between lower and upper.
	 Your guess and several points around it are undefined.
	Examine a graph of the function. If the equation has a solution, change the bounds and/or the initial guess.

Error Type	Possible Causes and Suggested Remedies
BOUND	 In a CALC operation or with Select(, you defined Left Bound > Right Bound. In fMin(, fMax(, solve(, or the equation solver, you entered lower ≥ upper.
BREAK	You pressed the ON key to break execution of a program, to halt a DRAW instruction, or to stop evaluation of an expression.
DATA TYPE	You entered a value or variable that is the wrong data type.
	 For a function (including implied multiplication) or an instruction, you entered an argument that is an invalid data type, such as a complex number where a real number is required. See Appendix A and the appropriate chapter.
	 In an editor, you entered a type that is not allowed, such as a matrix entered as an element in the stat list editor. See the appropriate chapter.
	 You attempted to store an incorrect data type, such as a matrix, to a list.
DIM MISMATCH	Your handheld displays the ERR:DIM MISMATCH error if you are trying to perform an operation that references one or more lists or matrices whose dimensions do not match. For example, multiplying L1*L2, where L1={1,2,3,4,5} and L2={1,2} produces an ERR:DIM MISMATCH error because the number of elements in L1 and L2 do not match.
DIVIDE BY 0	 You attempted to divide by zero. This error is not returned during graphing. The TI-84 Plus allows for undefined values on a graph.
	 You attempted a linear regression with a vertical line.

Error Type	Possible Causes and Suggested Remedies	
DOMAIN	 You specified an argument to a function or instruction outside the valid range. This error is not returned during graphing. The TI-84 Plus allows for undefined values on a graph. See Appendix A. 	
	• You attempted a logarithmic or power regression with a -X or an exponential or power regression with a -Y.	
	• You attempted to compute Σ Prn(or Σ Int(with $pmt2 < pmt1$.	
DUPLICATE	You attempted to create a duplicate group name.	
Duplicate Name	A variable you attempted to transmit cannot be transmitted because a variable with that name already exists in the receiving unit.	
EXPIRED	You have attempted to run an application with a limited trial period which has expired.	
Error in Xmit	 The TI-84 Plus was unable to transmit an item. Check to see that the cable is firmly connected to both units and that the receiving unit is in receive mode. 	
	 You pressed ON to break during transmission. 	
	 You attempted to perform a backup from a TI-82 to a TI-84 Plus. 	
	 You attempted to transfer data (other than L1 through L6) from a TI-84 Plus to a TI-82. 	
	 You attempted to transfer L1 through L6 from a TI-84 Plus to a TI-82 without using 5:Lists to TI82 on the LINK SEND menu. 	
ID NOT FOUND	This error occurs when the SendID command is executed but the proper graphing handheld ID cannot be found.	
ILLEGAL NEST	 You attempted to use an invalid function in an argument to a function, such as seq(within expression for seq(. 	

Error Type	Possible Causes and Suggested Remedies		
INCREMENT	 The increment in seq(is 0 or has the wrong sign. This error is not returned during graphing. The TI-84 Plus allows for undefined values on a graph. 		
	• The increment in a For(loop is 0.		
INVALID	 You attempted to reference a variable or use a function where it is not valid. For example, Yn cannot reference Y, Xmin, ΔX, or TblStart. 		
	 You attempted to reference a variable or function that was transferred from the TI-82 and is not valid for the TI-84 Plus For example, you may have transferred Un-1 to the TI-84 Plus from the TI-82 and then tried to reference it. 		
	 In Seq mode, you attempted to graph a phase plot without defining both equations of the phase plot. 		
	 In Seq mode, you attempted to graph a recursive sequence without having input the correct number of initial conditions. 		
	 In Seq mode, you attempted to reference terms other than (n−1) or (n−2). 		
	 You attempted to designate a graph style that is invalid within the current graph mode. 		
	 You attempted to use Select(without having selected (turned on) at least one xyLine or scatter plot. 		
INVALID DIM	 The ERR:INVALID DIM error message may occur if you are trying to graph a function that does not involve the stat plot features. The error can be corrected by turning off the stat plots. To turn the stat plots off, press [2nd] [STAT PLOT] and then select 4:PlotsOff. 		
	 You specified a list dimension as something other than an integer between 1 and 999. 		
	 You specified a matrix dimension as something other than an integer between 1 and 99. 		
	 You attempted to invert a matrix that is not square. 		

Error Type	Possible Causes and Suggested Remedies
ITERATIONS	 The solve(function or the equation solver has exceeded the maximum number of permitted iterations. Examine a graph of the function. If the equation has a solution, change the bounds, or the initial guess, or both.
	 irr(has exceeded the maximum number of permitted iterations.
	 When computing I%, the maximum number of iterations was exceeded.
LABEL	The label in the Goto instruction is not defined with a Lbl instruction in the program.
MEMORY	Memory is insufficient to perform the instruction or function. You must delete items from memory before executing the instruction or function. Recursive problems return this error; for example,
	graphing the equation Y1=Y1. Branching out of an If/Then, For(, While, or Repeat loop with a Goto also can return this error because the End statement that terminates the loop is never reached.
MemoryFull	 You are unable to transmit an item because the receiving unit's available memory is insufficient. You may skip the item or exit receive mode.
	 During a memory backup, the receiving unit's available memory is insufficient to receive all items in the sending unit's memory. A message indicates the number of bytes the sending unit must delete to do the memory backup. Delete items and try again.
MODE	You attempted to store to a window variable in another graphing mode or to perform an instruction while in the wrong mode; for example, Drawinv in a graphing mode other than Func .

Error Type	Possible Causes and Suggested Remedies
NO SIGN CHNG	The solve(function or the equation solver did not detect a sign change.
	 You attempted to compute I% when FV, (N*PMT), and PV are all ≥ 0, or when FV, (N*PMT), and PV are all ≤ 0.
	 You attempted to compute irr(when neither CFList nor CFO is ò 0, or when neither CFList nor CFO is ò 0.
NONREAL ANS	In Real mode, the result of a calculation yielded a complex result. This error is not returned during graphing. The TI-84 Plus allows for undefined values on a graph.
OVERFLOW	You attempted to enter, or you have calculated, a number that is beyond the range of the graphing handheld. This error is not returned during graphing. The TI-84 Plus allows for undefined values on a graph.
RESERVED	You attempted to use a system variable inappropriately. See Appendix A.
SINGULAR MAT	 A singular matrix (determinant = 0) is not valid as the argument for -1.
	 The SinReg instruction or a polynomial regression generated a singular matrix (determinant = 0) because it could not find a solution, or a solution does not exist.
	This error is not returned during graphing. The TI-84 Plus allows for undefined values on a graph.
SINGULARITY	expression in the solve(function or the equation solver contains a singularity (a point at which the function is not defined). Examine a graph of the function. If the equation has a solution, change the bounds or the initial guess or both.

Error Type	Possible Causes and Suggested Remedies
STAT	You attempted a stat calculation with lists that are not appropriate.
	 Statistical analyses must have at least two data points.
	 Med-Med must have at least three points in each partition.
	• When you use a frequency list, its elements must be ≥ 0 .
	 (Xmax – Xmin) / Xscl must be ≤ 47 for a histogram.
STAT PLOT	You attempted to display a graph when a stat plot that uses an undefined list is turned on.
SYNTAX	The command contains a syntax error. Look for misplaced functions, arguments, parentheses, or commas. Appendix A displays the arguments and punctuation needed to execute the function or instruction.
	For example, stdDev (<i>list</i> [, <i>freqlist</i>]) is a function of the TI-84 Plus. The arguments are shown in italics. The arguments in brackets are optional and you need not type them. You must also be sure to separate multiple arguments with a comma (,). For example stdDev (<i>list</i> [, <i>freqlist</i>]) might be entered as stdDev(L1) or stdDev(L1,L2) since the frequency list or <i>freqlist</i> is optional.
TOL NOT MET	You requested a tolerance to which the algorithm cannot return an accurate result.
UNDEFINED	You referenced a variable that is not currently defined. For example, you referenced a stat variable when there is no current calculation because a list has been edited, or you referenced a variable when the variable is not valid for the current calculation, such as a after Med-Med .
VALIDATION	Electrical interference caused a link to fail or this graphing handheld is not authorized to run the application.

Error Type	Possible Causes and Suggested Remedies	
VARIABLE	You have tried to archive a variable that cannot be archived or you have tried to unarchive an application or group.	
	Examples of variables that cannot be archived include:	
	 Real numbers LRESID, R, T, X, Y, Theta, Statistic variables under Vars, STATISTICS menu, Yvars, and the AppldList. 	
VERSION	You have attempted to receive an incompatible variable version from another graphing handheld.	
WINDOW RANGE	A problem exists with the window variables.	
	• You defined Xmax ≤ Xmin or Ymax ≤ Ymin .	
	• You defined θ max $\leq \theta$ min and θ step > 0 (or vice versa).	
	• You attempted to define Tstep=0 .	
	• You defined Tmax ≤ Tmin and Tstep > 0 (or vice versa).	
	 Window variables are too small or too large to graph correctly. You may have attempted to zoom in or zoom out to a point that exceeds the TI-84 Plus's numerical range. 	
ZOOM	A point or a line, instead of a box, is defined in ZBox .	
	• A ZOOM operation returned a math error.	

Accuracy Information

Computational Accuracy

To maximize accuracy, the TI-84 Plus carries more digits internally than it displays. Values are stored in memory using up to 14 digits with a two-digit exponent.

- You can store a value in the window variables using up to 10 digits (12 for Xscl, Yscl, Tstep, and θstep).
- Displayed values are rounded as specified by the mode setting with a maximum of 10 digits and a two-digit exponent.

 RegEQ displays up to 14 digits in Float mode. Using a fixed-decimal setting other than Float causes RegEQ results to be rounded and stored with the specified number of decimal places.

Xmin is the center of the leftmost pixel, **Xmax** is the center of the next-to-the-rightmost pixel. (The rightmost pixel is reserved for the busy indicator.) $\Delta \mathbf{X}$ is the distance between the centers of two adjacent pixels.

- In Full screen mode, ΔX is calculated as (Xmax Xmin) / 94. In G-T split-screen mode, ΔX is calculated as (Xmax Xmin) / 46.
- If you enter a value for ΔX from the home screen or a program in
 Full screen mode, Xmax is calculated as Xmin + ΔX * 94. In G-T split screen mode, Xmax is calculated as Xmin + ΔX * 46.

Ymin is the center of the next-to-the-bottom pixel; **Ymax** is the center of the top pixel. Δ **Y** is the distance between the centers of two adjacent pixels.

- In Full screen mode, ΔY is calculated as (Ymax Ymin) / 62. In Horiz split-screen mode, ΔY is calculated as (Ymax Ymin) / 30. In G-T split-screen mode, ΔY is calculated as (Ymax Ymin) / 50.
- If you enter a value for ΔY from the home screen or a program in Full screen mode, Ymax is calculated as Ymin + ΔY * 62. In Horiz split-screen mode, Ymax is calculated as Ymin + ΔY * 30. In G-T split-screen mode. Ymax is calculated as Ymin + ΔY * 50.

Cursor coordinates are displayed as eight-character numbers (which may include a negative sign, decimal point, and exponent) when **Float** mode is selected. **X** and **Y** are updated with a maximum accuracy of eight digits.

minimum and maximum on the CALCULATE menu are calculated with a tolerance of 1E-5; |f(x)dx is calculated at 1E-3. Therefore, the result displayed may not be accurate to all eight displayed digits. For most functions, at least five accurate digits exist. For fMin(, fMax(, and fnInt(on the MATH menu and solve(in the CATALOG, the tolerance can be specified.

Function Limits

Function	Range of Input Values	
$\sin x$, $\cos x$, $\tan x$	$0 \le x < 10^{12}$ (radian or degree)	
$\sin^{-1} x$, $\cos^{-1} x$	-1 ≤ <i>x</i> ≤ 1	
$\ln x$, $\log x$	$10^{-100} < x < 10^{100}$	
e x	$-10^{100} < x \le 230.25850929940$	
10 <i>x</i>	$-10^{100} < x < 100$	
sinh x, cosh x	x \le 230.25850929940	
tanh x	$ x < 10^{100}$	
$sinh^{-1} x$	$ x < 5 \times 10^{99}$	
$\cosh^{-1} x$	$1 \le x < 5 \times 10^{99}$	
tanh ⁻¹ x	-1 < <i>x</i> < 1	
\sqrt{x} (real mode)	$0 \le x < 10^{100}$	
\sqrt{x} (complex mode)	$ x < 10^{100}$	
x!	$5 \le x \le 69$, where x is a multiple of .5	

Function Results

Function	Range of Result	
sin ⁻¹ x, tan ⁻¹ x	-90° to 90°	or $-\pi/2$ to $\pi/2$ (radians)
$\cos^{-1} x$	0° to 180°	or 0 to π (radians)

Texas Instruments Support and Service

For general information

Home Page: <u>education.ti.com</u>

KnowledgeBase and

e-mail inquires: education.ti.com/support

Phone: (800) TI-CARES / (800) 842-2737

For U.S., Canada, Mexico, Puerto Rico, and

Virgin Islands only

International

information: <u>education.ti.com/international</u>

For technical support

KnowledgeBase and

support by e-mail: education.ti.com/support

Phone

(not toll-free): (972) 917-8324

For product (hardware) service

Customers in the U.S., Canada, Mexico, Puerto Rico and Virgin Islands: Always contact Texas Instruments Customer Support before returning a product for service.

All other customers: Refer to the leaflet enclosed with this product (hardware) or contact your local Texas Instruments retailer/ distributor.

Texas Instruments (TI) Warranty Information

Customers in the U.S. and Canada Only

One-Year Limited Warranty for Commercial Electronic Product

This Texas Instruments ("TI") electronic product warranty extends only to the original purchaser and user of the product.

Warranty Duration. This TI electronic product is warranted to the original purchaser for a period of one (1) year from the original purchase date.

Warranty Coverage. This TI electronic product is warranted against defective materials and construction. THIS WARRANTY IS VOID IF THE PRODUCT HAS BEEN DAMAGED BY ACCIDENT OR UNREASONABLE USE, NEGLECT, IMPROPER SERVICE, OR OTHER CAUSES NOT ARISING OUT OF DEFECTS IN MATERIALS OR CONSTRUCTION.

Warranty Disclaimers. ANY IMPLIED WARRANTIES ARISING OUT OF THIS SALE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE ABOVE ONE-YEAR PERIOD. TEXAS INSTRUMENTS SHALL NOT BE LIABLE FOR LOSS OF USE OF THE PRODUCT OR OTHER INCIDENTAL OR CONSEQUENTIAL COSTS, EXPENSES, OR DAMAGES INCURRED BY THE CONSUMER OR ANY OTHER USER.

Some states/provinces do not allow the exclusion or limitation of implied warranties or consequential damages, so the above limitations or exclusions may not apply to you.

Legal Remedies. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or province to province.

Warranty Performance. During the above one (1) year warranty period, your defective product will be either repaired or replaced with a reconditioned model of an equivalent quality (at Tl's option) when the product is returned, postage prepaid, to Texas Instruments Service Facility. The warranty of the repaired or replacement unit will continue for the warranty of the original unit or six (6) months, whichever is longer. Other than the postage requirement, no charge will be made for such repair and/or replacement. TI strongly recommends that you insure the product for value prior to mailing.

Software. Software is licensed, not sold. TI and its licensors do not warrant that the software will be free from errors or meet your specific requirements. **All software is provided "AS IS."**

Copyright. The software and any documentation supplied with this product are protected by copyright.

Australia & New Zealand Customers only

One-Year Limited Warranty for Commercial Electronic Product

This Texas Instruments electronic product warranty extends only to the original purchaser and user of the product.

Warranty Duration. This Texas Instruments electronic product is warranted to the original purchaser for a period of one (1) year from the original purchase date.

Warranty Coverage. This Texas Instruments electronic product is warranted against defective materials and construction. This warranty is void if the product has been damaged by accident or unreasonable use, neglect, improper service, or other causes not arising out of defects in materials or construction.

Warranty Disclaimers. Any implied warranties arising out of this sale, including but not limited to the implied warranties of merchantability and fitness for a particular purpose, are limited in duration to the above one-year period. Texas Instruments shall not be liable for loss of use of the product or other incidental or consequential costs, expenses, or damages incurred by the consumer or any other user.

Except as expressly provided in the One-Year Limited Warranty for this product, Texas Instruments does not promise that facilities for the repair of this product or parts for the repair of this product will be available.

Some jurisdictions do not allow the exclusion or limitation of implied warranties or consequential damages, so the above limitations or exclusions may not apply to you.

Legal Remedies. This warranty gives you specific legal rights, and you may also have other rights that vary from jurisdiction to jurisdiction.

Warranty Performance. During the above one (1) year warranty period, your defective product will be either repaired or replaced with a new or reconditioned model of an equivalent quality (at Tl's option) when the product is returned to the original point of purchase. The repaired or replacement unit will continue for the warranty of the original unit or six (6) months, whichever is longer. Other than your cost to return the product, no charge will be made for such repair and/or replacement. TI strongly recommends that you insure the product for value if you mail it.

Software. Software is licensed, not sold. TI and its licensors do not warrant that the software will be free from errors or meet your specific requirements. **All software is provided "AS IS."**

Copyright. The software and any documentation supplied with this product are protected by copyright.

All Other Customers

For information about the length and terms of the warranty, refer to your package and/or to the warranty statement enclosed with this product, or contact your local Texas Instruments retailer/distributor.

Symbols

- ° (degrees notation) 149
- (negation) 151
- (subtraction) 153
- ! (factorial) 149
- → Store 143
- →dim((assign dimension) 117
- ≠ (not equal to) 150
- $\sqrt{\text{(square root)}}$ 152
- ' (minutes notation) 153
- Σ Int((sum of interest) 125
- ΣPrn((sum of principal) 132
- * (multiplication) 152
- *row(136
- *row+(136
- + (addition) 152
- + (concatenation) 153
- / (division) 152
- ⁻¹ (inverse) 151
- < (less than) 150
- = (equal-to relational test) 150
- > (greater than) 150
- ^ (power) 151
- ≤ (less than or equal to) 150
- ≥ (greater than or equal to) 151
- ² (square) 151
- ³ (cube) 150
- $\sqrt[3]{}$ (cube root) 150
- ▶Dec (to decimal conversion) 116
- ▶DMS (to degrees/minutes/seconds) 117
- ▶Frac (to fraction) 121
- ▶Nom((to nominal interest rate) 129
- ▶Polar (to polar) 132
- ▶Rect (to rectangular) 136
- (subtraction key) 13
- (negation key) 13
- **[Z00M]** (Zoom key) 23
- [ALPHA] (alphabetic key) 3, 4
- CLEAR (Clear key) 4
- STO▶ (Store key) 30
- 2nd (second modifier key) 3
- [2nd] [QUIT] key command 4

Numerics

10⁽ (power of ten) 152

1-PropZInt (one-proportion \emph{z}

confidence interval) 133

1-PropZTest (one-proportion z test) 133

1-Var Stats (one-variable statistics) 146

2-PropZInt (two-proportion z confidence interval) 133

2-PropZTest (two-proportion z test) 133

2-SampFTest (two-sample F-Test) 137

2-SampTInt (two-sample t confidence interval) 137

2-SampTTest (two-sample t test) 138

2-SampZInt (two-sample z confidence interval) 138

2-SampZTest (two-sample z test) 138

2-Var Stats (two-variable statistics)
146

Α

a+bi (rectangular complex mode)
112

about 79

about 19

abs((absolute value) 111

accuracy information

computational and graphing 176 function limits and results 178

adding complex numbers 28

addition (+) 152

alphabetic characters, entering 4 amortization

 Σ Int((sum of interest) 125 Σ Prn((sum of principal) 132

bal (amortization balance) 113

formula 160

and (Boolean operator) 111

angle measure modes 19

angle(111

ANOVA((one-way variance analysis)

112, 156

Ans (last answer) 81, 112	check memory 79
applications	checkTmr((check timer) 114
installing 44	chi-square cdf (χ²cdf() 113
running 45	chi-square pdf (χ²pdf() 113
Apps 81	chi-square test (χ²(Test) 113
AppVars 81	Circle((draw circle) 114
Archive 83, 112	Clear Entries 79, 114
archive full error 97, 169	clearing
garbage collection 94	all lists (ClrAllLists) 79, 114
memory error 94	drawing (ClrDraw) 114
archived variables 154	entries (Clear Entries) 79, 114
Asm(112	Home screen 4
AsmComp(112	home screen (ClrHome) 114
AsmPrgm(112	list (ClrList) 114
augment(112	table (ClrTable) 114
Automatic Power Down™ 2	Y= Editor 25
axes, displaying (AxesOn, AxesOff)	Clock 6
112	Clock Off 8
AxesOff 112	Clock On 8
AxesOn 112	ClockOff, turn clock off 114
	ClockOn, turn clock on 114
В	ClrAllLists (clear all lists) 79, 114
	ClrDraw (clear drawing) 114
backing up calculator memory 104,	ClrHome (clear home screen) 114
107	ClrList (clear list) 114
bal((amortization balance) 113	ClrTable (clear table) 114
batteries 163	combinations (nCr) 129
battery precautions 46	compiling an assembly program 112
binomcdf(113	complex
binompdf(113 block 94	modes (a+bi, re 0 i) 20, 112, 135
	numbers 135
building tables 23	numbers, adding 28
	concatenation (+) 153
C	conj((conjugate) 114
χ²cdf((chi-square cdf) 113	Connected (plotting mode) 115
χ²pdf((chi-square pdf) 113	connecting two calculators 101, 105
χ²-Test (chi-square test) 113	contact information 179
calculating	conversions
linear regressions 35	▶Dec (to decimal) 116
statistical variables 36	▶DMS (to degrees/minutes/
cash flow	seconds) 117
formula 161	▶Frac (to fraction conversion) 121
irr((internal rate of return) 125	Nom (to nominal interest rate
npv((net present value) 130	conversion) 129
CATALOG, clearing 25	▶Polar (to polar conversion) 132
CBL 2 [™] 101, 121	▶Rect (to rectangular conversion)
CBR™ 101, 121	136
changing mode settings 18	decimals to fractions 26

Equ▶String((equation-to-string	determining data in lists 32
conversion) 118	DiagnosticOff 116
List▶matr((list-to-matrix	DiagnosticOn 117
conversion) 127	dim((dimension) 117
Matr list ((matrix-to-list	dimensioning a list or matrix 117
conversion) 127	Disp (display) 117
P▶Rx(, P▶Ry((polar-to-	DispGraph (display graph) 117
rectangular conversion) 134	displaying graphing plots 34
R▶Pr(, R▶Pθ((rectangular-to-polar	Displaying the Clock Settings 6
conversion) 137	DispTable (display table) 117
String Equ((string-to-equation	distribution functions
conversion) 143	binomcdf(113
convert time, timeCnv() 144	binompdf(113
CoordOff 115	χ²cdf(113
CoordOn 115	χ²pdf(113
cos((cosine) 115	Fcdf(144
cos ⁻¹ ((arccosine) 115	Fpdf(144
cosh((hyperbolic cosine) 115	geometcdf(121
cosh ⁻¹ ((hyperbolic arccosine) 115	geometpdf(121
cosine (cos() 115	invNorm(125
creating new matrices 37	normalcdf(130
cube (3) 150	normalpdf(130
cube root (³ √() 150	poissoncdf(132
cubic regression (CubicReg) 115	poissonpdf(132
CubicReg (cubic regression) 115	distribution shading instructions
cumSum((cumulative sum) 115	Shade_t(141
cumulative sum (cumSum() 115	Shadeχ²(140
customer support and service 179	ShadeF(141
_	ShadeNorm(141
D	division (/) 152
dayOfWk((day of week) 116	division, example 14
days between dates (dbd() 116, 162	ΔList(127
dbd((days between dates) 116, 162	DMS (degrees/minutes/seconds entry
decimal modes 19	notation) 153
decimals to fractions, changing 26	Dot (plotting mode) 117
decrement and skip (DS<() 118	DrawF (draw a function) 118
defragmenting 94	Drawlnv (draw inverse) 118
Degree angle mode 19, 116	DS<((decrement and skip) 118
degrees notation (°) 149	DuplicateName menu 106
delete variable contents (DelVar)	
116	E
deleting expressions 11	E (exponent) 118
deleting expressions 11 deleting items from memory 81	e^((exponential) 118
DependAsk 116	editing expressions 11
DependAuto 116	End 118
det((determinant) 116	Eng (engineering notation mode)
	118
determinant (det() 116	110

entening	changing mode settings 19
alphabetic characters 4	decimals to fractions 26
data into lists 30	editing and deleting 11, 12
expressions 4	entering data into lists 30
lists to plot 33	equation solving 29
Equ•String((equation-to-string	error messages 43
conversion) 118	finding factorials (!) 27
equal-to relational test (=) 150	finding square roots 27
equation solver 28	graphing functions 18
error messages 42	grouping lists 40
_	least common multiples 27
errors	
messages 169	matrix equation solving 38
examples—applications	mode settings 20
area between curves 67	rand function 26
areas of regular n-sided	running applications 45
polygons 73	sending variables 99
box plots 57	setting graphing window 22
box with lid 50	solving trigonometric functions
defining a 50	28
defining a table of values 51	statistical list editor 31
setting the viewing window	storing values 15, 16, 17
53	subtraction and negation 13
tracing the graph 54	turning off grid points 10
zooming in on the graph 55	ungrouping variables 41
zooming in on the table 52	using parentheses 14
cobweb attractors 64	exponential regression (ExpReg) 119
fundamental theorem of	expr((string-to-expression
calculus 71	conversion) 118
guess the coefficients 65	ExpReg (exponential regression) 119
inequalities 60	expression
	•
mortgage payments 75	converting from string (expr()
parametric equations, ferris	118
wheel problem 68	turning on and off (ExprOn 119
piecewise functions 59	expressions
quadratic formula	deleting 11
converting to a fraction 48	editing 11
displaying complex results 49	entering 4
entering a calculation 47	ExprOff (expression off) 119
Sierpinski triangle 63	ExprOn (expression on) 119
solving a system of nonlinear	
equations 62	F
unit circle and trig curves 66	Faceulates F
examples—Getting Started	Faceplates 5
adding complex numbers 28	factorial (!) 27, 149
building tables 24	Fill(119
calculating linear regressions 35	finding
calculating statistical variables 36	factorials (!) 27
changing FORMAT menu 9	least common multiples 27
changing rount mena 2	

Fix (fixed-decimal mode) 119	getTime, get current time 123
fixed-decimal mode (Fix) 119	getTmFmt, get time format 123
Float (floating-decimal mode) 119	getTmStr((get time string) 123
floating-decimal mode (Float) 119	Goto 123
fMax((function maximum) 119	graphing
fMin((function minimum) 120	modes 20
fnInt((function integral) 120	graphing functions 17, 18
FnOff (function off) 120	graphing window, setting 21
FnOn (function on) 120	GraphStyle(123
For(120	graph-table split-screen mode (G-T)
formulas	123
amortization 160	greater than (>) 150
ANOVA 156	greater than or equal to (≥) 151
cash flow 161	greatest common divisor (gcd() 121
days between dates 162	greatest integer (int() 125 GridOff 123
interest rate conversions 161	
logistic regression 155	GridOn 123
sine regression 155	grouping 39, 90
time value of money 159	G-T (graph-table split-screen mode)
two-sample F-Test 156	123
two-sample t test 157	
fPart((fractional part) 120	Н
Full (full-screen mode) 121	Home screen 2
full-screen mode (Full) 121	Horiz (horizontal split-screen mode
Func (function graphing mode) 121	123
function graphing	Horizontal (draw line) 124
maximum of (fMax() 119	,
minimum of (fMin() 120	ı
modes 121	•
selecting 120	identity(124
function integral (fnInt() 120	If instructions
functions and instructions table 111	If 124
	If-Then 124
G	If-Then-Else 124
garbage collecting 93	imag((imaginary part) 124
	imaginary part (imag() 124
GarbageCollect 95, 121	increment and skip (IS>() 125
gcd((greatest common divisor) 121	independent variable 124
geometcdf(121	IndpntAsk 124
geometpdf(121	IndpntAuto 124
Get((get data from CBL 2/CBL or	Input 124
CBR) 121	installation instructions
GetCalc((get data from a TI-84 Plus)	Macintosh® 45
122	Windows® 44
getDate, get current date 122	installing applications 44
getDtFmt, get date format 122	Installing New Faceplates 6
getDtStr((get date string) 122	Installing new faceplates 6
getKey 122	inString((in string) 125
	J

int((greatest integer) 125 integer part (iPart() 125 interest rate conversions formula 161 internal rate of return (irr() 125 inverse (-1) 151 inverse cumulative normal distribution (invNorm() 125 invNorm((inverse cumulative normal distribution) 125 iPart((integer part) 125 irr((internal rate of return) 125 IS>((increment and skip) 125	Listhmatr((lists-to-matrix conversion) 127 lists deleting from memory 81 ln(127 LnReg (logarithmic regression) 127 log(127 Logistic (regression) 127 logistic regression formula 155 M marked for deletion 94 Matrhlist((matrix-to-list conversion)
isClockOn, is clock on 125	127
K key commands, quick reference 46	MATRIX Editor 37 max((maximum) 128 maximum of a function (fMax() 119 mean(128
L	median(128 Med-Med (median-median) 128
LabelOff 126 LabelOn 126	Mem Mgmt/Del menu 80
labels	memory
graph 126 program 126 Lbl (label) 126 lcm((least common multiple) 126 least common multiple (lcm() 126 least common multiples, finding 27 length(of string 126 less than (<) 150 less than or equal to (≤) 150 Line((draw line) 126 linear regressions, calculating 35 LINK RECEIVE menu 106 LINK SEND menu 102 linking receiving items 106 to a CBL 2™ or CBR™ 101 to a PC or Macintosh 102 to a TI-84 Plus Silver Edition or TI-84 Plus 107 transmitting items 99 two TI-84 Plus units 104 LinReg(a+bx) (linear regression) 126 LinReg(ax+b) (linear regression) 126	backing up 107 checking available 79 clearing all list elements from 83 clearing entries from 82 deleting items from 81 error 95 insufficient during transmission 109 resetting defaults 88 resetting memory 88 MEMORY menu 79 Menu((define menu) 128 menus defining (Menu() 128 TI-84 Plus 10 min((minimum) 128 minimum of a function (fMin() 120 minutes notation (') 153 mode menu 19 changing settings 18 mode settings a+bi (complex rectangular) 112 Connected (plotting) 115
LinRegTTest (linear regression t test) 127	Degree (angle) 116 Dot (plotting) 117

Eng (notation) 118	or (Boolean) operator 130
Fix (decimal) 119	Output(131
Float (decimal) 119	Overwrite 92, 106
Full (screen) 121	Overwrite All 92
Func (graphing) 121	
G-T (screen) 123	P
Horiz (screen) 123	•
importance 20	P•Rx(, P•Ry((polar-to-rectangular
Normal (notation) 129	conversions) 134
Par/Param (graphing) 131	Par/Param (parametric graphing
Pol/Polar (graphing) 132	mode) 131
Radian (angle) 135	Pause 131
re^θi (complex polar) 135	performing simple calculations 26
Real 135	permutations (nPr) 130
Sci (notation) 139	plot types modes 20
Seq (graphing) 139	Plot1(131
Sequential (graphing order) 139	Plot2(131
Simul (graphing order) 141	Plot3(131
multiplication (*) 152	PlotsOff 131
multiplication, example 14	PlotsOn 132
maniplication, example 14	plotting
NI.	data 32
N	lists 33
nCr (number of combinations) 129	Pmt_Bgn (payment beginning
nDeriv((numerical derivative) 129	variable) 132
negation (-) 151	Pmt_End (payment end variable) 132
negation key (🕒) 13	poissoncdf(132
normal distribution probability	poissonpdf(132
(normalcdf() 130	Pol/Polar (polar graphing mode) 132
Normal notation mode 129	polar graphing
normalpdf((probability density	mode (Pol/Polar) 132
function) 130	PolarGC (polar graphing
not equal to (≠) 150	coordinates) 132
not((Boolean operator) 130	power (^) 151
nPr (permutations) 130	power of ten (10 ⁽) 152
npv((net present value) 130	precautions, battery 46
numeric notation modes 19	prgm (program name) 132
	probability density function
0	(normalpdf() 130
	prod((product) 133
Omit 92, 107	programming
one-proportion z confidence interval	name (prgm) 132
(1-PropZInt) 133	Prompt 133
one-proportion z test (1-PropZTest)	Pt-Change(133
133	Pt-Off(133
one-sample t confidence interval	Pt-On(133
(Tinterval) 144	PwrReg (power regression) 134
one-variable statistics (1-Var Stats) 146	Pxl-Change(134

Pxl-Off(134 Pxl-On(134	rref((reduced-row-echelon form) 137
pxl-Test(134	running applications 45
Q	S
QuadReg (quadratic regression) 134 QuartReg (quartic regression) 134 quick reference key commands 46 Quit 92, 107	Sci (scientific notation mode) 139 screen display modes 20 second functions 3 second modifier key (2nd) 3 sector 94
R	Select(139
r (radian notation) 149 R▶Pr(, R▶P(((rectangular-to-polar	Send((send to CBL 2/CBL or CBR) 139 SendID 102 SendSW 102
conversions) 137 Radian angle mode 19, 135 radian notation (「) 149	Seq (sequence graphing mode) 139 seq((sequence) 139
RAM ARCHIVE ALL menu 87	Sequential (graphing order mode) 139
rand (random number) 135 randBin((random binomial) 135 randInt((random integer) 135 randM((random matrix) 135 randNorm((random Normal) 135 re^0i (polar complex mode) 135 Real mode 20, 135 real((real part) 135 RecallGDB 136 RecallPic 136 RectGC (rectangular graphing coordinates) 136	sequential graphing mode 20 setDate((set date) 139 setDtFmt((set date format) 139 setTime((set time) 140 setting graphing windows 21 setTmFmt((set time format) 140 SetUpEditor 140 Shade(140 Shade_t(141 Shadex²(140 ShadeF(141 ShadeNorm(141
ref((row-echelon form) 136 RegEQ (regression equation variable) 81	Simul (simultaneous graphing order mode) 141
Removing a Faceplate 5 Repeat 136 RESET MEMORY menu 89 resetting all memory 89	simultaneous graphing mode 20 sin((sine) 141 sin-1 (arcsine) 141 sine (sin() 141 sinh((hyperbolic sine) 141 sinh-1 (hyperbolic arcsine) 141
archive memory 88 defaults 43, 88 memory 88 RAM memory 88 Return 136 root (^x √) 149 round(136 row+(136	Sinn ((hyperbolic arcsine) 141 SinReg (sinusoidal regression) 142 solve(142 solving
rowSwap(137	square (2) 151 square root ($\sqrt{()}$ 152

startTmr, start timer 142	tvm_FV (future value) 145
statistical list editor 31	tvm_I% (interest rate) 145
statistical variables, calculating 36	tvm_N (# payment periods) 145
stdDev((standard deviation) 142	tvm_Pmt (payment amount) 145
Stop 143	tvm_PV (present value) 145
Store (→) 143	timeCnv(), convert time 144
Store key (STO→) 30	Tinterval (one-sample t confidence
StoreGDB 143	interval) 144
StorePic 143	tpdf((student-t distribution
storing values 15, 16, 17	probability density function) 144
String Equ((string-to-equation	TRACE
conversions) 143	Trace instruction in a program
strings	144
concatenation (+) 153	transmitting
length (length() 126	error conditions 108
student-t distribution	from a TI-83 107
probability (tcdf() 144	from a TI-83 Plus Silver Edition or
student-t distribution	TI-83 Plus 107
probability density function	from a TI-84 Plus Silver Edition or
(tpdf() 144	TI-84 Plus 107
sub((substring) 143	stopping 104
subtraction (–) 153	to a TI-84 Plus Silver Edition or TI-
subtraction and negation, examples	84 Plus 104
13	transpose matrix (T) 149
subtraction key (-) 13	trigonometric functions, solving 28
sum((summation) 143	T-Test (one-sample t test) 145
support and service 179	turn clock off, ClockOff 114
system variables 154	turn clock on, ClockOn 114
	turning TI-84 Plus on and off 2
Т	tvm_FV (future value) 145
I (transpose matrix) 140	tvm_I% (interest rate) 145
^T (transpose matrix) 149 tables, building 23	tvm_ N (# payment periods) 145
tan((tangent) 143	tvm_Pmt (payment amount) 145
tan (tangent) 143	tvm_PV (present value) 145
tangent (tan() 143	two-proportion z confidence
Tangent (draw line) 143	interval (2-PropZInt) 133
tanh((hyperbolic tangent) 143	two-proportion z test (2-PropZTest)
tanh-1 (hyperbolic arctangent) 143	133
tcdf((student-t distribution	two-sample F-Test formula 156
probability) 144	two-sample t test formula 157
Text(two-variable statistics (2-Var Stats)
instruction 144	146
Then 124	
TI Connect™ 102	U
Time axes format 144	UnArchive 83, 145
time value of money (TVM)	ungrouping 90
formulas 159	ungrouping variables 41

user variables 154 uv/uvAxes (axes format) 146 uw/uwAxes (axes format) 146

V

variables
user and system 154
variance of a list (variance() 146
variance((variance of a list) 146
Vertical (draw line) 146
vw/uvAxes (axes format) 146

W

Web (axes format) 146 While 146

X

x√ (root) 149 xor (Boolean) exclusive or operator 146

Υ

Y= Editor, clearing 25

Z

ZBox 23, 147 ZDecimal 23, 147 ZInteger 23, 147 ZInterval (one-sample z confidence interval) 147 Zoom In (zoom in) 23, 147 Zoom Out (zoom out) 23, 147 ZoomFit (zoom to fit function) 23, 147 ZoomRcl (recall stored window) 147 ZoomStat (statistics zoom) 23, 148 ZoomSto (store zoom window) 148 ZPrevious (use previous window) 148 ZSquare (set square pixels) 23, 148 ZStandard (use standard window) 23, 148 Z-Test (one-sample z test) 148 ZTrig (trigonometric window) 23, 149