

LA CROSSE TECHNOLOGY QUICK SET-UP INSTRUCTIONS

Make sure you start with new brand-name alkaline batteries if you are not using the A/C adapter.

The MODE/MIN button will get you to the menu options. The AL/HR or MODE/MIN buttons will change them when they are flashing.

1. Check the polarity and install batteries into the back of clock.
2. Press and hold the MODE/MIN button to select your TIME ZONE. Adjust to your correct Time Zone with the MODE/MIN button. Press and release SNOOZE button to advance.
3. The HOUR will be flashing. Press and release the AL/HR button to adjust the hour and the MODE/MIN button to adjust the minutes. Press and release the SNOOZE button to advance.
4. Press and release the MODE/MIN button to adjust the YEAR. Press and release the SNOOZE button to advance.
5. Press and release the MODE/MIN button to adjust the MONTH. Press and release the SNOOZE button to advance.
6. Press and release the MODE/MIN button to adjust the Day of the Month. Press and release the SNOOZE button to advance.
7. Press and release the MODE/MIN button to adjust the Weekday. Press and release the SNOOZE button to advance.
8. A 12h or 24h will be flashing. (12h for AM/PM, 24h for military time) To change between 12h and 24h, press and release the MODE/MIN button. Press and release the SNOOZE button to advance.
9. Degrees Fahrenheit or Celsius will now be flashing; to change between Fahrenheit and Celsius press and release the MODE/MIN button. When your choice is shown on the display, press and release the SNOOZE button to advance.
10. Daylight Savings Time (DST) will be flashing. Most states use DST, so this should be ON. However if your location does not use DST, use the MODE/MIN button to turn it off. Press and release the SNOOZE button to exit the setup mode.