



- ▲ WARNING: Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all components are properly assembled and installed using the instructions provided.
- ▲ WARNING: Failure to provide adequate structural strength for this component can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the structure to which this component is attached can support five times the combined weight of all equipment. Reinforce the structure as required before installing the component. The wall to which the screen/whiteboard is being attached may have a maximum drywall thickness of 5/8" (1.6cm) for wood stud installation, and 1/2" (1.3cm) minimum for steel stud installation.
- WARNING: Use this screen/whiteboard system only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- **WARNING:** Do not use this product outdoors.



Tools Required for Installation





Cleaning Cloth (1)

Installation

- 1. Determine desired height of image (measured from floor) (Figure 1).
- 2. Determine desired center of image area (Figure 1).
- 3. Measure 4-1/16" up from desired height (top) of image and 4" to the right of center of screen and mark location (Figure 1).
- 4. Determine location of studs behind drywall.
- 5. Drill one pilot hole into a wall stud at location marked in Step 3 (Figure 1).



Figure 1

Installation (continued)

NOTE: The (3) 1/4" x 1-1/2" bolts and (3) washers required in Steps 6-8 are NOT INCLUDED with the screen/whiteboard packaging.

- Install (1) 1/4" x 1-1/2" bolt and (1) washer through middle of bracket into previously drilled hole, leaving 1/2" of the bolt extending from wall. Use carpenter's level to make sure bracket is properly level (Figure 2).
- 7. Position level on top of wall bracket. Move bracket until level. Drill (2) holes for the other bolts in wall studs.
- 8. Install the other (2) 1/4" x 1-1/2" bolts and (2) 1/4" washers in the previously drilled holes. Tighten all bolts against wall bracket.
- 9. Measure down 52-1/4" on center and mark spot. Move right and left of screen until wall studs are found and mark (Figure 3).







10. Install the (3) screen brackets using:

Wood or steel studs: (3) supplied #8 x 1" screws.

Concrete wall or no studs: (3) supplied #8-10 wall anchors and (3) supplied #8 x 1" screws.

- Install projector mount. Refer to the S520 Dual Stud Wall Mount (MSP-DCCUST2) manual. Do not install the (2) plastic covers for mount (Figure 4).
- 12. Run cables for projector up through hole in wall bracket and cover to projector location (Figure 5).







Figure 5

Installation (continued)

13. Mount screen onto wall bracket by hooking into the back groove of the screen frame (Figure 6).

NOTE: The bumpers on the back side of the screen/whiteboard are used to maintain planarity when pressure is applied to the projection surface during usage. If the bumpers are obstructing installation on your wall during Steps 13 and 14, they can be removed.

- 14. Secure bottom of screen to wall using (3) of the supplied #8 x 1/2" screws through bottom brackets into the lower channel of the screen frame (Figure 7).
- 15. Install the (2) top brackets (Figure 8) using:

Wood or steel studs: (2) supplied #8 x 1" screws.

Concrete wall or no studs: (2) supplied #8-10 wall anchors and (2) supplied #8 x 1" screws.

 Secure top of screen to wall using (2) of the supplied #8 x 1/2" screws through top brackets into the top channel of the screen (Figure 8).







Figure 7

Figure 8

- Secure marker tray to right side of screen frame at desired height by using (2) of the supplied #8 x 1/2" screws into the side channel of the screen frame (Figure 9).
- 18. Secure marker tray (Figure 10) to wall using:

Wood or steel studs: (1) supplied #8 x 1" screw.

Concrete wall or no studs: (1) supplied #8-10 wall anchor and (1) #8 x 1" screw.

 Secure IR sensor bar (packaged with the S520 Projector) to screen by sliding it onto the metal bracket. Insert safety screw through IR sensor bar into bracket (Figure 11).



Figure 9







Installation (continued)

- 20. Attach sensor cover by snapping clips over screen frame. Secure to frame by screwing down into the upper channel of the screen frame with supplied #8 x 3/4" screw (Figure 12).
- 21. In between the projector mount and the IR sensor cover, cable clips will be mounted to the wall for cable management. Attach clips to the wall using:

Wood studs: (4) supplied #8 x 1" screws.

Concrete wall or no studs: (4) supplied #8-10 wall anchors and (4) supplied #8 x 1" screws.

When secure, route cables and cords behind the two cable clips. Attach cable cover to the cable clips (Figure 13).

NOTE: Two cable clips are shipped with the screen/ whiteboard. For some installations, only one cable clip may be needed.

22. Install projector mount covers and projector (Figure 14). Refer to the S520 Dual Stud Wall Mount (MSP-DCCUST1) manual.



Figure 12



Figure 13



Figure 14

Recommended Screen/Whiteboard Markers

This Dell S520 Screen/Whiteboard is a dual-purpose projection screen and whiteboard. The surface of the screen/whiteboard can be used with dry erase markers from a wide variety of manufacturers and brands. Do not use permanent markers with this product.

Recommended Screen/Whiteboard Cleaning

The supplied cleaning cloth can be used to clean marks on the Dell S520 Screen/Whiteboard surface made by everyday dry erase marker usage. To clean persistent marks from dry erase markers, only use a standard dry erase marker cleaning solution and the cleaning cloth. To clean permanent marks and other unintentional marks on the surface, use a non-abrasive or nonscouring spray cleaning solution with the cleaning cloth or a melamine foam cleaning pad. For further guidance and helpful information about installing an S520 Dual Stud Wall Mount and S520 Screen/Whiteboard, please reference the installation video:

http://downloads.chiefmfg.com/MANUALS-I/Dell Interactive Solution.mp4

- Go to http://downloads.chiefmfg.com/MANUALS-I/PTDRV-I.pdf for translated instructions.
- Entre en http://downloads.chiefmfg.com/ MANUALS-I/PTDRV-I.pdf para obtener las instrucciones traducidas en su idioma.
- Bedienungsanleitungen in Ihrer Sprache finden Sie auf http://downloads.chiefmfg.com/ MANUALS-I/PTDRV-I.pdf.
- Pour la traduction des instructions, allez à http:// downloads.chiefmfg.com/MANUALS-I/PTDRV-I.pdf.
- Visitare il sito http://downloads.chiefmfg.com/ MANUALS-I/PTDRV-I.pdf per le istruzioni tradotte.
- Visite http://downloads.chiefmfg.com/ MANUALS-I/PTDRV-I.pdf para obter instruções traduzidas.

- 日本語の説明書は、http:// downloads.chiefmfg.com/MANUALS-I/PTDRV-I.pdf をご覧ください。
- 访问 http://downloads.chiefmfg.com/MANUALS-I/PTDRV-I.pdf 参考说明书译本。
- 如需翻譯版指示說明,請前往 http:// downloads.chiefmfg.com/MANUALS-I/PTDRVl.pdf。
- 번역된 안내서를 보려면 http:// downloads.chiefmfg.com/MANUALS-I/PTDRV-I.pdf 을 (를) 방문하십시오.
- โปรดเข้าไปที่ http://downloads.chiefmfg.com/ MANUALS-I/PTDRV-I.pdf สำหรับคำแนะนำฉบับแปล

CW88R Rev. A00 24695 Rev00

