
Skid Steer Quick Hitch

SH35 Category 1 & 2



22130



320-019P Parts Manual

Read the Operator's manual entirely. When you see this symbol, the subsequent instructions and warnings are serious - follow without exception. Your life and the lives of

© Copyright 2008 Printed 09/23/08

Cover photo may show optional equipment not supplied with standard unit.

Table of Contents

| Section 1: Introduction | 4 |
|--|----|
| Using This Manual | |
| Manual Replacement Information | |
| Manual Revisions | |
| Touch-up Paint | |
| Hardware Legend | |
| Replacement Hardware | |
| Serial Numbers | |
| Part Number Service Coding | |
| SKID STEER QUICK-HITCH Section 2: Complete Assembly - SH35 | 6 |
| Complete Assembly | |
| Section 3: Labels - SH35 | |
| Label Placement | |
| | |
| Part Number Index | 10 |

© Copyright 2008. All rights reserved.

Land Pride provides this publication "as is" without warranty of any kind, either expressed or implied. While every precaution has been taken in the preparation of this manual, Land Pride assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein. Land Pride reserves the right to revise and improve its products as it sees fit. This publication describes the state of this product at the time of its publication, and may not reflect the product in the future. The illustrations in this manual are not intended for safe and proper assembly or disassembly of equipment. The illustrations are intended for ordering parts only.

Land Pride is registered trademark.

All other brands and product names are trademarks or registered trademarks of their respective holders.

Printed in the United States of America.



Alphabetized Table of Contents

SKID STEER QUICK-HITCH

| С | Complete Assembly | .6 |
|---|-------------------|----|
| L | Label Placement | .8 |

General Information

Using This Manual

This manual is divided into sections. The first section contains General Information. The remaining sections divide the machine into segments (i.e. Frames, Drives, Hydraulics, etc.) which illustrate and list all parts. A Parts Number Index is located at the back of the book.

The Land Pride parts in this manual are specially designed for this machine and should be replaced with Land Pride parts only.

The information in this manual is current at time of printing. Some parts may change to assure top performance.

Right-hand and left-hand as used in this manual are determined by facing the direction the machine will travel while in use.

Below is an example of two facing pages from a parts manual. Familiarize yourself with the type of information contained on these pages.

Manual Replacement Information

Replacement manuals are available. Refer to our website at www.landpride.com or e-mail us at lit@landpride.com for additional information. Our website continues to provide the most up-to-date manuals available.


Touch-up Paint

Repaint parts where paint is worn or scratched to prevent rust. Aerosol cans and touch-up bottles with brush applicator are available through your local dealer. Land Pride color descriptions and part numbers are listed below. Also available are quart and gallon size paints. Add QT or GL to end of the Aerosol P/N.

| Color | Product ¹ | Aerosol | Touch-Up |
|---------------------------|----------------------|----------|------------|
| Gloss Black | LP | 821-032C | 821-032CTU |
| Medium Gloss Black | UV | 821-053C | 821-053CTU |
| Beige | LP | 821-011C | 821-011CTU |
| Green | SLP | 821-058C | 821-058CTU |
| Orange | SLP | 821-066C | 821-066CTU |
| Red | SLP/UV | 821-054C | 821-054CTU |
| Blue | SLP/UV | 821-067C | 821-067CTU |
| Dark Green Sparkle | UV | 821-055C | 821-055CTU |
| Gondo Forest Green | UV | 821-057C | 821-057CTU |
| Brite Yellow ² | UV | 821-056C | 821-056CTU |
| Gondo Yellow ³ | UV | 821-059C | 821-059CTU |

Notes:

- LP = All Land Pride Products except Utility Vehicles
 SLP = Select Land Pride Products that are available in optional Green, Orange, Red, & Blue colors.
 UV = Utility Vehicles
- 2 Used on Trekers and (Runabouts with S/N 407628-)
- 3 Used on Gondos and (Runabouts with S/N 407629+)



Land Pride Section 1 Introduction

General Information

Hardware Legend

| AR | As Required |
|----------|--|
| BLADE | Blade Bolt |
| | |
| С | Cap Screw |
| СР | Cotter Pin |
| CPHSSS | Cup Point Hex Socket Set Screw |
| CPSHSS | Cup Point Square Head Set Screw |
| CPSQHSS | Cup Point Square Head Set Screw |
| CRFCHMS3 | Cross Recess Flat Countersunk Head Machine Screw |
| CRPHMS | Cross Recess Pan Head Machine Screw |
| CRPHTFS | Cross Recess Pan Head Thread Forming |
| CRRHMS | Cross Recess Round Head Machine Screw |
| CRTHMS | Cross Recess Truss Head Machine Screw |
| CSNB | Countersunk Square Neck Bolt |
| FHMS | Flat Head Machine Screw |
| FTC | Full Thread Cap Screw |
| Н | Hex Nut |
| HCLN | Hex Center Lock Nut |
| HFLCS | Hex Flange Lock Cap Screw |
| HFS | Hex Flange Screw |
| HFSLN | Hex Flange Serrated Lock Nut |
| HFSS | Hex Flange Serrated Screw |
| HHCS | Hex Head Cap Screw or Metric Bolt |
| HSBHCS | Hex Socket Button Head Cap Screw |
| HSFCHCS | Hex Socket Flat Countersunk Head Cap Screw |
| HSHCS | Hex Socket Head Cap Screw |
| HSSS | Hex Socket Head Screw |
| HTLN | Hex Top Lock Nut |
| HWHCS | Hex Washer Head Cap Screw |

Replacement Hardware

The **Hardware Legend** above lists hardware abbreviations used in the parts list. All bolts and nuts are Grade 5 unless otherwise noted. The use of improper grades of hardware can result in personal injury, damage to equipment, or loss of property.

Colored Replacement Parts

Land Pride offers replacement parts in factory standard colors and also on select models in Green, Orange, Red and Blue. Because of the variety of colors available, special attention must be given to the part number to prevent ordering the wrong replacement part.

A suffix number corresponding to one of the colors below must be added at the end of Land Pride's part number when ordering a replacement part with that color.

| 81 | Green | 83 | Red |
|----|--------|----|------|
| 82 | Orange | 84 | Blue |

For example, if you are ordering a replacement part with part number 555-555C and the part you need is red, then add the suffix 83 to the end of the number to make the part number read 555-555C83. Parts ordered without a suffix number will be supplied in factory standard colors.

| HWHMS | Hex Washer Head Machine Screw | | |
|----------------|---|--|--|
| HXBHCS | Hex Socket Button Head Cap Screw | | |
| J | Hex Jam Nut | | |
| JIC | 37 Degree Tapered Thread | | |
| L | Helical Spring Lock Washer | | |
| LUG | Lug Bolt | | |
| NFC | National Fine Cap Screw | | |
| NPSM | National Pipe Straight Mechanical | | |
| NPTF | National Pipe Taper Fuel | | |
| P | Wide Plain Washer | | |
| PHMS | Pan Head Machine Screw | | |
| PLOW | Plow Bolt | | |
| RHMS | Round Head Machine Screw | | |
| RHSNB | Round Head Square Neck Bolt | | |
| SCREW LEVELING | Leveling Screw | | |
| SCREW THUMB | Thumb Screw | | |
| SCREW WELD | Weld Screw | | |
| SFCHMS | Slotted Flat Countersunk Head Machine Screw | | |
| SFHMS | Slotted Fillister Head Machine Screw | | |
| SP | Special | | |
| SP SCREW | Special Screw | | |
| SQHSS | Square Head Set Screw | | |
| SRHMS | Slotted Round Head Machine Screw | | |
| SSS | Socket Set Screw | | |
| STCS | Self Tapping Cap Screw | | |
| STHMS | Slotted Truss Head Machine Screw | | |
| WHEEL | Wheel Studs and Hub Long Bolts | | |
| WING | Wing Bolt | | |

Black Replacement Parts

Some parts are factory standard black and some must be special ordered black. If your part is special ordered black, a second part number with the additional suffix number 85 on the end will be available. In this situation you must order that part with the suffix number for it to be black. Parts that are factory standard black will not have the suffix number.

Part Number Service Coding

Within the parts list some part numbers are coded for revisions and interchangeability. See notations in revision column.

Serial Numbers

Always use the serial and model number when ordering parts. Refer to the Operator's Manual for serial number plate location.

| (S/N 20001+) Includes serial numbers 200 |
|--|
|--|

and above (to the latest

number)

(S/N 10001 to 20000) Includes serial numbers

between and including 10001

and 20000


(S/N 10000-) Includes serial numbers 10000

and below (to the earliest

number)

Complete Assembly

Applies to SH35




18446

Complete Assembly

| Applies to SH35 | | | | |
|-----------------|----------|--------------------------------|-------------------------------------|-----------------------------|
| Ref | Part No. | Part Description | Comments | Revision |
| | dwg18446 | Drawing Image Number | | |
| 1. | 802-091C | HHCS 1/2-13X1 1/2 GR5 | | |
| 2. | 804-015C | WASHER LOCK SPRING 1/2 PLT | | |
| 3. | 804-016C | WASHER FLAT 1/2 SAE PLT | | |
| 4. | 320-032D | ADJUSTABLE ARM CAP | | |
| 5. | 805-002C | PIN HITCH 1/2 X 3 USABLE LG | | |
| 6. | 805-066C | PIN CLEVIS 5/16 X 1 BEE IND. | | |
| 7. | 320-014D | LOCK UP HANDLE | | |
| 8. | 805-067C | PIN COTTER 1/8 X 3/4 | | |
| 9. | 320-049D | LOWER 3 POINT LOCK ARM | (S/N 388293+) | Rev. 2 not compat. w/Rev. 1 |
| 9. | 320-011D | LOWER 3 POINT LOCK ARM | (S/N 388292-) | Rev. 1 |
| 10. | 805-123C | PIN ROLL 1/2 X 1 1/4 PLT | | |
| 11. | 805-032C | PIN HAIR COTTER .148 WIRE | | |
| 12. | 807-007C | SPRING LEVER | | |
| 13. | 320-022H | QH35 SPRING LEVER ARM WLDMNT | | Rev. 2 not compat. w/Rev. 1 |
| 13. | 320-031D | SPRING LEVER ARM | Replaced by 320-022H | Rev. 1 |
| 14. | 320-046D | SPRING WIRE CLIP | No Longer Used Replaced by 320-022H | |
| 15. | 320-008H | LOWER 3PNT ADJUSTABLE ARM LH | | |
| 16. | 805-303C | PIN CLEVIS 1/2X1 49/64 USABLE | | |
| 17. | 320-030D | UPPER 3PNT LUG CAT.1 & 2 | | |
| 18. | 805-010C | PIN HAIR COTTER .094 | | |
| 19. | 320-005H | CAT.1 & 2 SKID STEER Q.H. WLD | | |
| 20. | 320-009H | LOWER 3PNT ADJUSTABLE ARM RH | | |
| 21. | 320-048D | CAT1 QUICK HITCH LWR SPCR TUBE | (S/N 388293+) Standard | |
| 21. | 320-044D | SPCR TUBE 1.44ODX.93IDX1.50LG | Optional Order as Required | |
| 21. | 320-045D | SPCR TUBE 1.44ODX.93IDX1.93LG | Optional Order as Required | |
| 21. | 320-050D | SPCR TUBE 1.44ODX.93IDX2.18LG | Optional Order as Required | |
| 21. | 320-051D | SPCR TUBE 1.44ODX.93IDX2.43LG | Optional Order as Required | |
| 21. | 325-017D | SPCR TUBE 1.44ODX.93IDX2.88LG | Optional Order as Required | |
| 22. | 817-246C | GRIP HANDLE .84 ID X 4LG | (S/N 431490+) | |

Label Placement

Applies to SH35



18447

Land Pride SKID STEER QUICK-HITCH

Label Placement

| Appl | Applies to SH35 | | | |
|------|-----------------|--------------------------------|----------|----------|
| Ref. | Part No. | Part Description | Comments | Revision |
| | dwg18447 | Drawing Image Number | | |
| 1. | 838-117C | DECAL SH35 BEIGE | | |
| 2. | 838-851C | DECAL LAND PRIDE 6.00 X .76 | | |
| 3. | 838-167C | DECAL DANGER CRUSHING HAZARD | | |
| 4. | 818-866C | DECAL CAUTION PINCH POINT HAZ. | | |
| 5. | 990-232R | 3M CONFORM, ANTI-SLIP 1" WIDE | | |



Part Number Index

The Part Number Index is a numeric index of all part numbers included in this manual. The index shows what page(s) the part is used on.

| Part Number | Page |
|-------------|------|
| | _ |
| 320-005H | 7 |
| 320-008H | 7 |
| 320-009H | 7 |
| 320-011D | 7 |
| 320-014D | 7 |
| 320-022H | 7 |
| 320-030D | 7 |
| 320-031D | 7 |
| 320-032D | 7 |
| 320-044D | 7 |
| 320-045D | 7 |
| 320-046D | 7 |
| 320-048D | 7 |
| 320-049D | 7 |
| 320-050D | 7 |
| 320-051D | 7 |
| 325-017D | 7 |
| 802-091C | 7 |
| 804-015C | 7 |
| 804-016C | |
| 805-002C | |
| 805-010C | |
| 805-032C | *** |
| 805-066C | |
| 805-067C | |
| 805-123C | |
| 805-303C | |
| 807-007C | |
| 817-246C | |
| 818-866C | |
| 838-117C | |
| 838-167C | |
| 838-851C | |
| 990-232R | |
| dwg18446 | |
| dwg18447 | 9 |

This Page Intentionally Left Blank



Great Plains Manufacturing, Inc.

Corporate Office: P.O. Box 5060 Salina, Kansas 67402-5060 USA

www.landpride.com