

ITA3D 710

RGB DMX laser with 3D effect



User manual

Safety precautions

WARNING: This unit may cause serious injury to eyesight when used incorrect. It therefore is strongly advised to read this user manual carefully, to get familiar with the functions of this laser device.

WARNING: This unit must be operated by, or under the supervision of an adult. This device is not suitable for children.

WARNING: Do not look directly into the beam coming out of the lens, from short distance or when a solid beam is projected. This may cause serious injury to eyesight. Ayra is not responsible for any injuries caused by incorrect use of this device.

WARNING: Do not project the beam of this unit on to reflective surfaces, as the shattering beam may cause injury to eyesight.

Installation requirements:

- Always check the voltage settings on the unit and the power supply you want to connect the device to. If the voltage requirements do not meet, do not connect the device as this may cause serious damage.
- This device must be installed by a professional technician, in a standing or hanging position. Always pay attention to the positioning of the unit, as the beams may project directly into your audience.
- It is strongly advised to **NOT** project the beams directly into your audience. Ayra strongly recommends a minimum distance of 1.5 meters in height between the lowest projected laser beam and your audience, for optimal safety. If there is no other option, keep a minimum distance of 5 meters from the beam exit to the first beam that hits your audience.
- When installed in a standing position, a safety cable is recommended to secure the unit.
- When installed in a hanging position, this unit **MUST** be secured by using a safety cable, capable of holding 10x the weight of this device.
- When installed in a hanging position, this unit must be mounted to a proper surface, e.g. a truss system. When using a truss system, Ayra recommends the use of a proper hook or halfcoupler.
- Make sure there are no flammable objects in the direct environment of the device (such as decorative objects). Keep a minimum distance of 1.5 meter.
- Do not block the beam-exit and fan
- Keep a minimum distance of 0.5 meter from any walls to provide sufficient cooling
- Make sure the beam-exit and fan are not blocked by any objects in the near environment
- This unit must be connected to a grounded power supply that meets the voltage requirements of the device.

Maintenance and protection

- Keep the unit away from dusty environments, as this may have negative effect on the fan-cooling system and laser optics. Ayra recommends using a flightcase for storage of this device. Clean the optics and fan of the laser with a small, soft brush and vacuum cleaner when needed. Clean the housing of the unit with a damp cloth. **WARNING:** Always disconnect the unit from the power supply when cleaning the unit. Reconnect the unit only if any moist on the fixture disappeared completely.
- This laser device is a lighting effect, designed to support visual entertainment while playing music. Continuous use is not recommended. Do not use the device longer than 3 hours subsequently, so the unit can cool down. This will provide a longer lifespan for the diodes. Apply a cooling-down time of 25 minutes before re-activating the laser.
- Do not switch the power on and off too often, as this may cause serious damage to the unit.

- Avoid heavy shocks and collision during transport and use, as this might cause damage to the laser diodes, electronic circuit, optics and housing.
- Keep the device away from moisture, rain, water or any liquids as this may cause a short circuit and/or electric shocks. If any liquid enters the unit, power supply or housing of the unit, disconnect the unit immediately and do not reconnect the power supply. Contact your local dealer or technician to inspect the unit for any damage.



Box contents

Box contents


1x ITA3D 710 laser device 1x user manual 1x IEC to Schuko power cable 1x XLR – XLR DMX signal cable


Unit and accessory inspection

- Always use the supplied power cable to connect the unit to a power supply. If the cable appears broken or has visible damage, do not use it. The supplied cable can be replaced with a regular IEC to Schuko cable, with a minimum cable diameter of 0.75m².
- If the unit will not be used for a longer period of time, disconnect it from the power supply and store it in a dust-free environment.
- Always check the unit for possible damage before use. If you suspect that something is wrong with the unit, do not connect it to a power source! When you suspect that your unit is broken or damaged, contact your local dealer or a certified technician to inspect the unit.
- When your device does not generate any laser beams, do not look directly into the lens. When the laser suddenly produces a beam, it may cause severe eye damage, possibly resulting in permanent visual loss.



Device overview





- 1. Beam output
- 2. Power status LED-indicator (red)
- 3. Microphone sensitivity LED indicator (blue)
- 4. Built-in microphone (used for sound-active mode)
- 5. DMX input
- 6. DMX output
- 7. DMX dipswitch setting (also used for activation of auto/sound active mode
- 8. Microphone sensitivity knob (low-high)
- 9. Pattern size adjustment (small-large)
- 10. Cooling fan
- 11. IEC power inlet
- 12. ON/OFF switch

Setting up the device

Setting up the device

- When the power supply is connected, the unit will first calibrate the stepping motors of the unit. It is normal that this may cause any noise. When the calibration is done, the unit is ready to be used (in the selected DMX, automatic or music controlled mode)
- It is possible that the unit may shut off the beam projection when no music or sound is detected. This will avoid the projection of a solid, static beam, which may cause injury to eyesight.
- This unit uses stepping motors to create variable movements to the laser beam. This way, figures and patterns can be made. The unit uses high-speed stepping motors to create the moving beams of the laser. It is normal that the laser beam and projection may appear 'flickering' when projecting large or complex patterns.
- The projected beams of the unit may appear shivering when projecting complex or large patterns on surfaces as a wall, ceiling or decorative cloth.

Selecting a working mode

This laser device has three working modes, which are **automatic**, **music-controlled** and **DMX**. To select the right operating mode for your situation, use the dipswitch panel on the rear of the unit.

A DMX-dipswitch panel works with a binary character. It sends a 0 or 1 message to the electrical circuit. To select a working mode, pay close attention to the information scheduled below. Every DMX dipswitch stands for a certain value, which is on or off. The values are stated as below:

1 – 1

2 – 2

3 - 4

4 – 8

5 - 16

6 - 32

7 - 648 - 128

9 – 256

10 – mode switch (DMX ON/OFF)

To select the different working modes, pay close attention to the setting of DMX dipswitches below: **NOTE:** value "X" = not used or not active for this mode

			DIPS	WIT	ELINCTION					
#1	#2	#3	#4	#5	#6	#7	#8	#9	#10	FUNCTION
0	0	0	X	X	X	X	X	X	0	SOUND ACTIVE
1	0	0	X	X	X	X	X	X	0	AUTO-BEAM
1	1	0	X	X	X	X	X	X	0	AUTO-ANIMATION
0	0	1	X	X	X	X	X	X	0	SLAVE MODE
	SET DMX ADDRESS 1									DMX MODE

Working mode explanation:

Sound active:

The unit uses its internal microphone to sense music (the beat of the music) and will change patterns according to the beat of the music. The microphone is situated at the front of the laser device. On the rear of the laser, there is an adjustable microphone sensitivity knob.

Please note that the sound-activated mode will not function properly when the music source is not loud enough or when only high-pitched sounds are played.

Auto-beam:

The laser device will activate a pre-defined lasershow on a solid speed setting. The patterns are mainly beam-effects.

Auto-animation:

The laser device will activate a pre-defined lasershow on a solid speed setting. The patterns are mainly animations and graphics.

Slave mode:

It is possible to link several ITA3D 710 fixtures for a synchronized lasershow, without the use of a DMX controller.

Connect your devices with standard XLR-XLR cables. The first device in the chain needs to be set to a basic function, such as sound-active or one of the auto shows.

Select the slave mode on all other connected device in the chain. You will notice that these devices will mimic the actions of the first device.

DMX mode:

With an external DMX-controller (or DMX-software) it is possible to control every feature of the laser device. It is possible to adjust the built-in patterns and to add several effects, such as zoom-effects or pattern rotation.

NOTE: When the DMX-signal or master/slave signal is lost (due to a failure in the DMX-connection or any other reason), the laser will shut off the output due to safety issues. This prevents the projection of static images and/or patterns.

DMX operating mode

While in the DMX mode, it is possible to select the working mode of the laser. That way, you can either choose to use your own programmed presets of your DMX controller, or to activate the music activated/automatic working mode of the laser to have a fully-automatic lasershow. Depending on the starting address you selected earlier, the laser responds to the following commands. In this example, we use DMX starting address 1. When you use a different DMX-starting value, for example 29, the unit will respond from channel 29, 30, 31.. and so on.

For more information about DMX, consult the manual of your DMX controller or software.

Channel	Function	Value	Description					
1	Mode	0-49	Sound active mode					
		50-99	Auto beam mode					
		100-149	Auto animation mode					
		150-199	Manual mode auto run					
		200-255	Manual mode sound-active run					
2	Color/shutter	0-255	Closed, single color, flashing color, multi-color and moving multicolor effects					
3	Pattern selection	0-255	256 patterns to be selected					
4	Movement Y	0-127	Manual up/down movement					
		128-191	Auto down-movement					
		192-255	Auto up-movement					
5	Movement X	0-127	Manual left/right movement					
		128-191	Auto right-movement					
		192-255	Auto left-movement					
6	Rolling X	0-127	Manual rolling (position)					
		128-255	Auto rolling (movement)					
7	Rolling Y	0-127	Manual rolling (position)					
		128-255	Auto rolling (movement)					
8	Rotation	0-127	Manual rotation (position)					
		128-191	Auto clockwise rotation (movement)					
		192-255	Auto counter-clockwise rotation (movement)					
9	Zoom	0-85	Auto zoom (+)					
		86-170	Auto zoom (-)					
		171-255	Manual zoom (+/-)					
10	10 Pattern size		0 is standard, 1-255 is small to large					
11	Display dot	0-255	Variable adjustment, 0 is dot-display, 255 is best brightness					
12	Drawing	0-127	Auto drawing mode 1					
		128-255	Auto drawing mode 2					

Technical specifications

TYPE: ITA3D 710

Laser diodes

Type ITA3D 710:

- 60mW green laser (wavelength: 532nm)- 150mW red laser (wavelength: 650nm)- 500mW blue laser (wavelength: 450nm)

Tech specs:

- scanset: 15 kpps high-speed optical scanner with big angle capacities
- working modes: auto, sound-active, master/slave, DMX-512
- graphics and effects: 128 beam show and animated graphic show patterns with 3D animation
- high-efficiency 3D optical grating system for unique 3D lighting effects
- hanging bracket, for use with a lighting stand or truss system
- built-in microphone with adjustable microphone sensitivity
- adjustable pattern size (small-large)
- DMX-control with 3-pin XLR connectors
- DMX-control: 12 channels
- Power supply: 100-250V AC, 50/60 Hz
- Power consumption: 20 Watt
- dimensions: 300 x 185 x 100 mm
- weight: 2.5 kg

