Stream Geomorphic Assessment Tools

Appendix H

Development of Stream Corridor Buffers

Introduction

Stream corridors are created in **Step 09** by creating *buffers* around certain *features* and then combining those buffers in a specific manner. The concepts of *buffers* and *features* are used from the perspective of *Geographic Information Systems*.

Features can be points, lines (or polylines, which are a connected string of line segments) or polygons (enclosed or bounded areas). A *feature* is a digital "model" or representation of an object in the real-world. As examples: Points can represent such objects as fire hydrants, signs, reach points; polylines can represent such things as road centerlines, electric transmission lines, stream centerlines; and polygons can represent such things as town boundaries, rivers, lakes, valleys.

Within the *Stream Geomorphic Assessment Tools* (the *Tools*), the predominant *feature* type is a polyline. *Stream centerlines*, *meander centerlines* and the *valley walls* are represented as polylines.

Note: While *valley walls* are digitized and provided as polygons, the toes of the valley walls are "extracted" from those polygons and used as polylines.

With the release of Version 3 of the *Tools*, significant flexibility has been incorporated into the development of *stream corridors* via processing **Step 09**. This flexibility is based upon the implementation of the following concepts:

- **Application** Through an *application*, one establishes a linkage to a *buffer reference table*. In effect, an *application* can be associated with one and only one *buffer reference table*. A *buffer reference table*, however, can be associated with any number of *applications*.
- **Buffer Reference Table** A buffer reference table contains records that define the parameters to be used in creating buffers around specific features. (Features refer to the stream centerline, meander centerline and valley walls.) There are two versions of the buffer reference table that identify the source of data to be used in defining the buffer for a reach. The sources are:
 - Stream Geomorphic Assessment **Phase I**; or
 - Stream Geomorphic Assessment **Phase II**.
- **Buffer Parameters** Each record in a *buffer reference table* defines *parameters* to be used in buffering *features*. These *parameters* establish the requirements for buffering as follows:
 - (1) Whether a specific feature will be buffered,
 - (2) The width of the buffer to be used for a specific feature,
 - (3) Whether a *default* buffer of a specified with around the *stream centerline* is to be used,
 - (4) Whether an *alternate buffer* (using the *stream centerline*) is to be developed when a *meander centerline* is not present, and
 - (5) Whether to ignore buffering the *meander centerline* if *valley walls* are not present.
- Accessing a specific record in a Buffer Reference Table A buffer reference table can be composed of any number of records. Each record is identified by a key; and the key is a reflection of certain conditions that categorize a reach. For example, a key <u>may</u> reflect a specific stream type, stream group designation (e.g. sensitivity class), valley confinement group and valley slope group.

SGAT – Version 3

Each record contains the *parameters* to be used in creating a *stream corridor* for reaches whose conditions are reflected in the *key*.

A specific hierarchy is implemented to combine the conditions of a reach in an attempt to find a record with a matching *key* in the *buffer reference table*. This hierarchy is in the order of the most specific (or highest sensitivity) conditions to the most general. The most general conditions are reflected in a record containing a *key* value of "*Default*", which reflects the general parameters for creating a *stream corridor* for the *application* associated with the *buffer reference table*.

Note: All *buffer reference tables* must have a record containing a *key* with a value of "*Default*". The buffering *parameters* in this record will be used in the absence of finding any other record that meets the conditions of the reach.

Import of Phase I/Phase II Data – The data necessary to define the conditions of a reach are not inherent in the calculations or derivation of data within the *Tools*. This data is, however, entered by the user in a Microsoft Access data base as part of the assessment process. As a result, the necessary data must be transferred from the data base into the attribute table for the reach point theme.

Each *feature*, if present, is *buffered* in accordance with the applicable *parameters* in the record selected from the *buffer reference table*. These "*component*" buffers are then merged using specific rules to form the *stream corridor*. This permits creating a stream corridor specific to the conditions of a given reach.

The implementation of the above has been accomplished in such a manner that it is, for the most part, transparent to the user. Further, the average user will not need to understand the details presented in this Appendix. However, for users who have specific needs or applications, the information presented herein can be used to tailor the buffering procedure in arriving at specific *stream corridor* configurations.

This Appendix will provide detailed descriptions of the concepts introduced above. However, some background on relevant aspects of the *Geomorphic Assessment* is necessary. These are presented in the next section.

Related Background on the Geomorphic Assessment Process

During the *Phase I* assessment process, the following data is captured for each reach:

- Stream type,
- Sensitivity Class (grouping of stream types),
- Valley slope and
- Valley confinement.

During the *Phase II* assessment process, the following data <u>may be</u> captured for each reach:

- Stream type (revision from or more detailed stream typing than conducted in Phase I),
- Sensitivity Class (revision from Phase I grouping of stream types),
- Whether the existing stream type represents a departure from the reference stream type,
- Whether a *major channel adjustment* is in progress,

The above data is entered into and maintained in the Phase I/II Access Data Base on a reach basis for the watershed being assessed. A brief description of the data elements follows.

Stream Type

The *stream type* is a concatenation of up to three characters that generally defines the reach, as described below:

Example: C2b, where

- "C" (first character) defines the *class* associated with the reach. The *class* indicates certain characteristics of the reach such as entrenchment, width, slope, etc.
- "2" (second character) defines the *dominant sediment material*. This character may not always be present as part of the *stream type* identifier (especially during *Phase I* assessment).
- "b" (third character) is a *slope modifier* and categorizes the slope of the channel, when the slope is different than that associated with the *class*. This modifier may not always be present as part of the *stream type* identifier.

Stream Group (Sensitivity Class)

As illustrated in the following table, the *sensitivity class* is used to "group" *stream types* based upon similar characteristics.

Stream Group	Sensitivity Class
VL	Very Low to Low
LW	Low to Moderate
MD	Moderate to High
HI	High to Very High
VH	Very High to Extreme
EX	Extreme

The column under *Stream Group* represents the values for the field *StrmGroup* as used in defining a *stream corridor* via a *buffer reference table*. These values may be used in matching data entered by a user during a *geomorphic assessment* to a *key* in a *buffer reference table*. As a result, the values <u>must</u> be consistent between those used during the assessment and the development of the *buffer reference tables*.

Departure from Reference Stream Type

"Whether the existing stream type is a *departure from reference stream type*" is, at present, a Yes/No data element.

Major Channel Adjustment

"Whether a major channel adjustment is in progress" is, at present, a Yes/No data element.

Valley Slope

The following table for Valley Slope categorizes streams using a range of valley slopes.

Valley Slope								
Group	Designation	Slope Range						
а	Very Steep	> 4%						
b	Moderate to Steep	>= 2% but <= 4%						
С	Moderate to Low	> 0.5% but <= 2%						
С	Gentle	<= 0.5%						

The column under *Group* represents the values used for the field *VSGroup* as used in defining a *stream corridor* via the buffer reference table.

Valley Confinement

The following table for *Valley Confinement* categorizes streams using a range of *confinement* ratios (valley width divided by channel width).

	Valley Confinement									
Group	Code	Designation	Valley Width / Channel Width Ratio							
1	NC	Narrowly Confined	>= 1 and < 2							
1	SC	Semi Confined	>= 2 and < 4							
2	NW	Narrow	>= 4 and < 6							
3	BD	Broad	>= 6 and < 10							
3	VB	Very Broad	>= 10 with abandoned terraces on one or both sides							

The column under *Group* represents the values used for the field *VCGroup* as used in defining a *stream corridor* via the buffer reference table.

When using the Stream Geomorphic Assessment Tools (Tools) for floodway determination and for Phase I of stream geomorphic assessment, the data elements described above serve as the foundation for determining the stream corridor for each reach (**Step 09** in Tools).

The tables and information provided in this section were current as of the date of writing this manual. For <u>current</u> and additional information on the data elements, refer to the *Stream Geomorphic Assessment Handbooks* available from:

River Corridor Management Section, Water Quality Division, Department of Environmental Conservation, Agency of Natural Resources 103 South Main Street, Building 10 North Waterbury, VT 05671-0408

Concept of Application in the Tools Extension

The concept of *applications* has been implemented in the *Tools* to permit certain functionality to be used for different purposes. The following table lists the *applications* that have currently been defined:

Application	Application (<i>Applicatn</i>)	Buffer Reference Table (<i>BuffrTable</i>)	Access Level (AccessLvl)
Floodway Determination Option 1	FD Option 1	SysBufOpt1.dbf	2
Floodway Determination Option 2	FD Option 2	SysBufOpt2.dbf	2
Stream Geomorphic Assessment	SGA	SysBufSGA.dbf	1

Note: Floodway Determination (Options 1 and 2) are defined in the "Floodway Determination Technical Guidance" document and Stream Geomorphic Assessment is defined in the "Stream Geomorphic Assessment Handbooks". These documents are available from the River Corridor Management Section (refer to address on previous page).

The <u>only</u> difference between the *applications*, as far as use of the *Tools* is concerned, is in the development of *stream corridors* (*Step 09*). This difference is implemented through the use of *buffer reference tables*.

The above table actually represents the contents of the system table "SysApps.dbf". The field names in the system table are shown within parentheses in the column heading. As illustrated in the table, each application (row) is associated with a *buffer reference table*. Once an application is selected, the *buffer reference table* to be used in **Step 09** has been identified.

To establish the *application* to be used, one first identifies the *user type* and then the *application* on the *Setup Dialog*. The upper area of that dialog is shown below:

Stream Geomorphic Assessment Tools (Ver: 3.00.0) Setup Dialog	
Primary Functions	
User Access Type and Application Designation	
User Type: Watershed Group 💌 Application: SGA 💌	
Select Application for which SGAT is to be used.	

The user type must be established first because certain applications are restricted to certain user types. Whenever the user type or application are changed on the Setup Dialog, the selected values are entered into the system table named "SysSystem.dbf". That table maintains the currently selected values. Thus, when you exit the Tools extension and, subsequently, re-enter the extension, the user type and application last selected will remain known.

In certain circumstances, the *user type* and *application* may be pre-defined and "locked". In these cases, one will not be allowed to alter either setting. This, in turn, pre-determines the *buffer reference table* that will be used for determining *stream corridors* (via *Step 09*). This is done so that those who will only be using one specific *application*, such as *stream geomorphic assessment*, will not have to be confronted with "decisions" that are not relevant to their work.

The records of the "SysApps.dbf" table must be manually edited to effect any changes. It is imperative that the *buffer reference table* referred to in a record actually exist in the SysData

SGAT – Version 3

directory. If the *buffer reference table* does not exist, an error message will be issued during the initialization procedure of the *Tools* extension and access to the functions will be prevented.

Note: Additional verification of each *buffer reference table* is performed during this procedure. If any errors are detected, appropriate error messages will be issued. Access to any functions will be prevented until such error conditions are cleared up. Refer to the Section of the User Manual for the *Tools* entitled "*Initialization Procedure*" for a description of the error conditions.

As implied, one can edit the "SysApps.dbf" table to include additional "applications". If this is to be done, adhere to the following rules:

- (1) Any editing <u>should not</u> be performed while the *Tools* extension is active. Always exit the extension (click on *Exit* on the *Setup Dialog*) before editing.
- (2) <u>Do not modify</u> any data for the existing records in the SysApps.dbf table. These "applications" are to be used for their intended purposes and have statutory or scientific basis.
- (3) Enter the name to be associated with the application into the Applicatn field.
- (4) Enter the name of a valid *buffer reference table* (which will exist in the *SysData* directory) into the *BuffrTable* field. The format, contents and use of *buffer reference tables* are described subsequently in this Appendix.
- (5) If the new application pertains to stream geomorphic assessment and is to be available to watershed groups, enter a value of one ("1") in the AccessLvl field. Otherwise, enter a value of two ("2").

Once the editing has been completed <u>and</u> the referenced *buffer reference table* is copied or moved to the *SysData* directory, the *Tools* extension will list the application on the *Setup Dialog*. While in that dialog, select the *application*. After that, the associated *buffer reference table* will be used during processing of **Step 09**.

Buffer Reference Tables

As described in the preceding section, a *buffer reference table* is associated with each *application*. A *buffer reference table* contains records that define the *parameters* to be used in creating *buffers* around specific features. (*Features* refer to the stream centerline, meander centerline and valley walls.) During the development of stream corridors in **Step 09**, specific records in these tables will be retrieved based upon assessment data for a given reach.

There are two formats that may be used in defining a *buffer reference table*. The format should be selected based upon the <u>source</u> of data to be used in defining the stream corridor for a reach. The sources are:

- o Stream Geomorphic Assessment Phase I; or
- o Stream Geomorphic Assessment Phase II.

The differences in the two formats are the presence of the fields:

- VCGroup and VSGroup (for use with Phase I data) OR
- Adjustment and Departure (for use with Phase II data).

Only one of the above sets of fields may exist in a *buffer reference table*. All other fields are identical in format and content. The two formats for *buffer reference tables* are provided on the following pages.

St	ream Geo	Format of Buffer Reference Tables for morphic Assessment (Phase I) and Floodway Determination Option 1
Field Name	Format	Description
Кеу	C (24)	Format of <u>Key</u> field used for Stream Geomorphic Assessment and Floodway Determination Option 1: Various concatenations which may include values from StrmGroup, StrmType, VCGroup, and VSGroup. Refer to descriptions of these fields below and the discussion in the text regarding how a specific value is to be created and how a record will be retrieved. A value of "Default" designates a default record, which will be used if no other key is matched.
StrmGroup	C (16)	Group designation for stream type, e.g. <i>sensitivity class</i> . For permissible values, refer to the column Stream Group and its definition in the table presented earlier.
StrmType12	C (2)	Stream Type designation: First and second characters identifying Stream Class (must always be present) and Dominant Sediment Material (if not present, a dash, "-", must be used).
StrmType3	C (1)	Stream Type designation: Third, and optional, character identifying Slope Modifier (if not present, a dash, "-", must be used)
VCGroup	C (3)	Valley Confinement Group designation. For permissible values, refer to the column <i>Group</i> and its definition in the table for Valley Confinement presented earlier.
VSGroup	C (3)	Valley Slope Group designation. For permissible values, refer to the column <i>Group</i> and its definition in the table for Valley Slope presented earlier.
DefaultBuf	N (6, 0)	Fixed distance for creating a default buffer around the stream centerline. Value of this field represents a fixed distance on <u>either</u> side of the stream with a total width of twice the value. A value of zero will indicate this buffer is <u>not</u> to be used.
StreamCL	N (6,3)	<i>Channel width</i> multiplier for defining a buffer around the stream centerline. Buffer distance will be the value of this field multiplied by the <i>channel width</i> and will represent distance on <u>either</u> side of the stream with a total width of twice the product. A value of zero will indicate this buffer is not to be used.
SCLnoMCL	N (6,3)	Channel width multiplier for defining a secondary buffer based upon the stream centerline when a meander centerline is not present. A value of zero will indicate this buffer is <u>not</u> to be used.
MeanderCL	N (6,3)	<i>Channel width</i> multiplier for defining a buffer around the meander centerline. Buffer distance will be the value of this field multiplied by the <i>channel width</i> and will represent distance on <u>either</u> side of the meander centerline with a total width of twice the product. A value of zero will indicate this buffer is <u>not</u> to be used. If no meander centerline feature is present for a given reach, no meander centerline buffer will be created. (See also RequireVW below).
ValleyToe	N (6,3)	<i>Channel width</i> multiplier for defining a buffer from the valley toe in the direction toward the stream centerline. Buffer distance will be the value of this field multiplied by the <i>channel width</i> and will represent distance on the side of the valley toe towards the stream centerline. Buffers will be created using the left <u>and</u> right valley walls. A value of zero will indicate this buffer is <u>not</u> to be used. If no valley toe feature is present for a given reach, no valley toe buffer will be created.
RequireVW	C (1)	Permissible values are "Y" (Yes) or "N" (No) defining whether the valley toe feature must be present for a given reach to perform buffering of the <u>meander centerline</u> (see MeanderCL above). If the value is "Y" (Yes), buffering of the meander centerline will only be performed if the valley toe feature is present. If the value is "N" (No) then buffering of the meander centerline will be performed <u>independent</u> of whether a valley toe feature is present.

Note: The values in fields *StrmType12*, *StrmType3*, *VCGroup* and *VSGroup* are not used within the *Tools*. These fields, however, <u>must be present in the buffer reference table</u>. The *Tools* uses the <u>existence</u> of fields *VCGroup* and *VSGroup* to specify the use of the buffering decision tree for *Phase I* data (i.e. for *Assessment* and *Floodway Determination Option 1*). Using <u>Phase I</u> data for a given reach, the decision tree identifies which record to use for obtaining the buffering parameters. In addition, these fields provide documentation for the value of the *Key* field. If any of these fields are <u>not</u> used in forming the value of the *Key* field, the value of the field should be left blank; otherwise, adhere to the format described in the table above.

	Format	of Buffer Reference Table for Floodway Determination Option 2
Field Name	Format	Description
Кеу	C (24)	<i>Format of <u>Key</u> field used for Floodway Determination Option 2:</i> Various concatenations which may include values from <i>StrmGroup</i> , <i>StrmType</i> , <i>Departure</i> and <i>Adjustment</i> . Refer to descriptions of these fields below and the discussion in the text regarding how a specific value is to be created and how a record will be retrieved. A value of " <i>Default</i> " designates a default record, which will be used if no other key is matched.
StrmGroup	C (16)	Group designation for stream type, e.g. <i>sensitivity class</i> . For permissible values, refer to the column Stream Group and its definition in the table presented earlier.
StrmType12	C (2)	Stream Type designation: First and second characters identifying Stream Class (must always be present) and Dominant Sediment Material (if not present, a dash, "-", must be used).
StrmType3	C (1)	Stream Type designation: Third, and optional, character identifying Slope Modifier (if not present, a dash, "-", must be used).
Departure	C (1)	Designation of existing stream <i>departure from reference stream</i> , which at present is either "Y" (for "Yes") or "N" (for "No"). If value does not exist, use a dash ("-").
Adjustment	C (1)	Designation of whether existing stream is in major adjustment, which at present is either "Y" (for "Yes") or "N" (for "No"). If value does not exist, use a dash ("-").
DefaultBuf	N (6, 0)	Fixed distance for creating a default buffer around the stream centerline. Value of this field represents a fixed distance on <u>either</u> side of the stream with a total width of twice the value. A value of zero will indicate this buffer is <u>not</u> to be used.
StreamCL	N (6,3)	<i>Channel width</i> multiplier for defining a buffer around the stream centerline. Buffer distance will be the value of this field multiplied by the <i>channel width</i> and will represent distance on <u>either</u> side of the stream with a total width of twice the product. A value of zero will indicate this buffer is not to be used.
SCLnoMCL	N (6,3)	<i>Channel width</i> multiplier for defining a secondary buffer based upon the stream centerline <u>when a meander centerline is not present</u> . A value of zero will indicate this buffer is <u>not</u> to be used.
MeanderCL	N (6,3)	<i>Channel width</i> multiplier for defining a buffer around the meander centerline. Buffer distance will be the value of this field multiplied by the <i>channel width</i> and will represent distance on <u>either</u> side of the meander centerline with a total width of twice the product. A value of zero will indicate this buffer is <u>not</u> to be used. If no meander centerline feature is present for a given reach, no meander centerline buffer will be created. (See also RequireVW below).
ValleyToe	N (6,3)	<i>Channel width</i> multiplier for defining a buffer from the valley toe in the direction toward the stream centerline. Buffer distance will be the value of this field multiplied by the <i>channel width</i> and will represent distance on the side of the valley toe towards the stream centerline. Buffers will be created using the left <u>and</u> right valley walls. A value of zero will indicate this buffer is <u>not</u> to be used. If no valley toe feature is present for a given reach, no valley toe buffer will be created.
RequireVW	C (1)	Permissible values are "Y" (Yes) or "N" (No) defining whether the valley toe feature must be present for a given reach to perform buffering of the <u>meander centerline</u> . If the value is "Y" (Yes), buffering of the meander centerline will only be performed if the valley toe feature is present (see MeanderCL above). If the value is "N" (No) then buffering of the meander centerline will be performed <u>independent</u> of whether a valley toe feature is present.

Note: The values in fields *StrmType12*, *StrmType3*, *Departure* and *Adjustment* are not used within the *Tools*. These fields, however, <u>must be present in the buffer reference table</u>. The *Tools* uses the <u>existence</u> of the fields *Departure* and *Adjustment* to specify use of the buffering decision tree for *Phase II* data (i.e. for *Floodway Determination Option 2*). Using <u>*Phase II*</u> data associated with a given reach, the decision tree identifies which record to use for obtaining the buffering parameters. In addition, these fields provide documentation for the value of the *Key* field. If any of these fields are <u>not</u> used in forming the value of the *Key* field, the value of the field should be left blank; otherwise, adhere to the format described in the table above.

Development of Stream Corridor Buffers in Step 09

In the *buffer reference tables*, the field *StrmGroup* can be used in a much broader sense than *sensitivity class*. It can be used to relate stream types in any manner. It is important, however, that whatever values are assigned to *StrmGroup* be consistent between field data collection and development of the *buffer reference tables* described herein.

Each *buffer reference table* <u>must</u> have a record with a *Key* value of *Default*. This record will contain the general buffering parameters to be used if no other record can be found to match the "conditions" of a reach.

There are three *buffer reference tables* distributed with the *Tools*:

- SysBufSGA.dbf for use with the stream geomorphic assessment Phase I (based upon <u>Phase I</u> data);
- SysBufOpt1.dbf for use with the Floodway Determination Option 1 (based upon Phase I data); and
- SysBugOpt2.dbf for use with Floodway Determination Option 2 (based upon <u>Phase II</u> data).

At the time of writing this Appendix, the content of the *buffer reference tables* is shown in the following:

			Buffer Re	eference Tabl	e for the Phas	se 1 Stream G	eomorphic A	ssessment			
Key	StrmGroup	StrmType12	StrmType3	VCGroup	VSGroup	DefaultBuf	StreamCL	SCLnoMCL	MeanderCL	ValleyToe	RequireVW
Default						100	2.5		4	8	Y
			Buffer Refe	ence Table f	or Option 1 of	the Floodway	y Determinati	ion Procedure			
Key	StrmGroup	StrmType12	StrmType3	VCGroup	VSGroup	DefaultBuf	StreamCL	SCLnoMCL	MeanderCL	ValleyToe	RequireVW
Default			Buffer Refe	ence Table f	or Option 2 of	the Floodway	0.5 y Determinat i	3 ion Procedure	3	6	Ν
Key	StrmGroup	StrmType12	StrmType3	Departure	Adjustment	DefaultBuf	StreamCL	SCLnoMCL	MeanderCL	ValleyToe	RequireVW
Low Mod ModYY ModNY High	Low Mod Mod High			Y N	Y Y		0.5 0.5 0.5 0.5 0.5	2 3 3 3	2 3 3 3	4 6 6	N N N N

To summarize:

- Selecting an *application* on the Setup Dialog establishes the buffer reference table that will be used in **Step 09**. (Refer to the table on page H-5.)
- In the *buffer reference table*, the presence of the fields
 - VCGroup and VSGroup indicate that Phase I data and decision tree will be used.
 - Adjustment and Departure indicate that Phase II data and decision tree will be used.

Let's take a close look at a single record in a *buffer reference table*. Each record contains the *buffering parameters* to be used in creating a *stream corridor*. The method for determining which record to be used (or the *decision tree*) will be presented subsequently.

Buffering Parameters

Each record in a *buffer reference table* contains the following fields:

DefaultBuf (default buffering specifications used with the stream centerline),
 StreamCL (stream centerline buffering specifications),
 MeanderCL (meander centerline buffering specifications),
 SCLnoMCL (buffering specifications used with the stream centerline when no meander centerline is present),
 ValleyToe (buffering specifications for toe of valley wall) and
 RequireVW (specification that valley walls be present in order for any buffering to be performed on the meander centerline).

The above define the *buffering parameters* that are to be applied for a given reach.

The field *RequireVW* is used to differentiate between policies used in calculating the *stream corridor* for *stream geomorphic assessment* from those for *floodway determination*. For *stream geomorphic assessment*, at present, a buffer for the meander centerline is <u>not</u> created if valley walls are <u>not</u> present for the reach. As a result, all records in the *buffer reference table* for the *stream geomorphic assessment* will contain the value of "Y" for this field. Values for this field will be "N" for all other *applications*.

The *Tools* has been developed such that *stream corridor* definition is composed of merging "component" buffers created using the following *features*:

Default Buffer (fixed distance from stream centerline) Stream Centerline (multiple of channel widths) Meander Centerline (multiple of channel widths) Valley Wall (toe) (multiple of channel widths)

The *Tools* will develop each of the component buffers in accordance with the criteria in the *buffer reference table* for the designated *application*. In addition, the following rules will apply:

- 1. Per the value for the field *DefaultBuf*, a default buffer will (or will not) be created. If the value is zero, no default buffer will be created. Otherwise, a buffer equal to the value, which represents a fixed distance, on either side of the stream centerline will be created. The value of the *DefaultBuf* field is to be in feet.
- 2. If a given feature (*stream centerline, meander centerline* or *valley wall*) is not present for a given reach, that (or those) component buffer(s) will not be created.
- 3. If the value in the *buffer reference table* for a component buffer is zero (0), that component buffer will not be created.
- 4. Where a meander centerline is not present, a second buffer will be created on the stream centerline where the channel width multiplier has been supplied in the *field* "*SCLnoMCL*". If, however, the value for the field *SCLnoMCL* is zero, no buffer will be created.
- 5. If a given feature is present and a non-zero value is found in the *buffer reference table* for a component buffer, a buffer will be created. The value in the *buffer reference table* will be multiplied by the *channel width* for the reach to define the buffer distance. (The buffer distance represents the distance from the feature to the edge of the buffer, i.e. on either side.) **Note:** The *default* buffer is a fixed distance as specified in (1) above.

- 6. Per the field *RequireVW* in the *reference table*, a buffer for the meander centerline will (or will not) be created if valley walls are not present.
- 7. If a component buffer is created using the *meander centerline* and the *valley walls* are present for that reach, component buffer will be constrained to fall within the toes of the valley walls. (I.e. the meander centerline buffer will be clipped off by the valley wall polygon, if present).
- 8. The final buffer will be the composite (sum) of the component buffers created as per the corridor delineations described in the assessment protocols (Appendix E) or the VTDEC Floodway Determination Technical Guidance.
- 9. Any "holes" formed within the composite buffer will be removed to provide complete coverage.

A graphic example of the procedure used in developing the component buffers and the merging of those to form the *stream corridor* is provided at the end of this Appendix.

Accessing a specific record in a Buffer Reference Table

The *buffer reference tables* and the logic (or *decision tree*) to access a specific record have been designed to permit the use of buffering *parameters* for very specific conditions and or configurations of a reach. These conditions and configurations are identified during the *Phase I* and *Phase II* assessment efforts.

If *Phase I* data is being used, certain <u>combinations</u> of the following data elements can be used to define buffering parameters:

- Stream Type,
- Stream Type slope modifier,
- Valley Confinement Group,
- Valley Slope Group and
- Stream Group (e.g. sensitivity class).

If *Phase II* data is being used, certain <u>combinations</u> of the following data elements can be used to define buffering parameters:

- Stream Type,
- Stream Type slope modifier,
- Whether a major channel <u>adjustment</u> is in progress,
- Whether the existing stream type is a <u>departure</u> from the reference stream type and
- Stream Group (e.g. sensitivity class).

Note: Remember the *application* selected on the *Setup Dialog* identifies the *buffer reference table* to be used. The presence of the fields *VCGroup* and *VSGroup* in the *buffer reference table* establish the use of <u>Phase I</u> data. Or, the presence of the fields *Adjustment* and <u>Departure</u> in the *buffer reference table* establish the use of <u>Phase II</u> data.

To create a *buffer reference table* that contained all possible combinations of the data elements would involve creating literally hundreds (if not more) records. This would be cumbersome, potentially error-prone and difficult to manage. Instead a hierarchical method has been implemented for designing the *buffer reference tables* and for accessing specific records in those tables. The method implemented recognizes that

- Only a few reach conditions (represented by specific combinations of the data elements listed above) require special consideration for buffering; and
- Flexibility is required to add or alter specific buffering requirements for any combination of the data elements as the needs dictate.

An example is used to illustrate the concepts implemented for *Floodway Determination Option 2* (and therefore *Phase II* data). Assume that there are six unique *stream types* "Y1", "Y2", "Y3a", "Y3b" and "Z1". (Keep in mind that experience may lead to the definition of new *stream types*.) These *stream types* are associated with *stream sensitivity classes* as follows: "Y1" and "Z1" are Low, "Y2" and "Y3a" are moderate and "Y3b" is high. Each *stream type* may be associated with a *departure from reference stream type* and may be experiencing *major adjustment*. To provide the capability where each unique combination of the data elements could be assigned unique buffering criteria would require the definition of 72 records (6 stream types * 3 sensitivity classes * 2 departure conditions * 2 major adjustment conditions). Experience, however, indicates that only a few records are required. The following table exemplifies a set of records.

Кеу	Strm Group	Strm Type12	Strm Type3	Depar ture	Adjust ment	Default Buf	Stream CL	SCL noMCL	Meander CL	Valley Toe	Require VW
Y3bYY		Y3	b	Y	Y	0	2.5	3	4	8	Ν
Y3		Y3				0	2.5	3	3	8	Ν
Mod	Mod					0	2.5	3	3	6	Ν
Default						0	2.5	3	2	5	Ν

In the above example note that different *buffering requirements* (not intended to be realistic) are identified in each record. The following describes each record:

Record 1 pertains to *stream type* "Y3b" (Y3 with slope modifier appended) when it is undergoing *Major Adjustment* and is a *departure from the reference stream*. Note: *Sensitivity class* (stream group) is disregarded.

Record 2 pertains to <u>all</u> other conditions of *stream type* "Y3" regardless of *slope modifiers*, *sensitivity class*, *departure condition* or *major adjustment condition*.
 Record 3 pertains to <u>all</u> other *stream* types in the *sensitivity class* "Mod" regardless of *stream type*, *departure condition* or *major adjustment condition*.

Record 4 pertains to all remaining stream types regardless of sensitivity class, departure condition or major adjustment condition.

In summary, creating a *buffer reference table* requires that one define records from the most specific conditions (using meaningful combinations of the data elements) that require "special attention". After those, have been defined, records are defined on a more and more aggregate level. Finally, a *default* record <u>is required</u> to cover all remaining conditions.

A *Default* record can be included for each combination of *departure condition* or *major adjustment condition*. However, a *Default* record <u>must</u> <u>also</u> be included without reference to those conditions. The following table illustrates this concept:

Key	Strm Group	Strm Type12	Strm Type3	Depar ture	Adjust ment	Default Buf	Stream CL	SCL noMCL	Meander CL	Valley Toe	Require VW
DefaultYY				Y	Υ	а	b	с	d	е	Ν
DefaultYN				Y	Ν	f	g	h	i	J	Ν
DefaultNY				Ν	Y	k	I	m	n	0	Ν
DefaultNN				Ν	Ν	р	q	r	S	t	Ν
Default						u	v	w	х	У	Ν

Note: Specific records for *key* values of "*Default* <u>with</u> conditions appended" can be omitted if the buffering requirements are the same as the overall *Default* record (last record in the above table).

Note: At a minimum each *buffer reference table* must have one record with a *key* value of "*Default*" and only values for the following fields: DefaultBuf, StreamCL, MeanderCL, ValleyToe and RequireVW. All other fields would be blank.

The first column in the previous tables refers to a "*key*". The values for this field are simply formed by various combinations (concatenation) of the values in *StrmGroup*, *StrmType*, *Departure* and/or *Adjustment*. Access to a specific record will be by the value in the *key* field.

For each reach, the *Tools* will construct *keys* in a pre-determined order using data collected in either the *Phase I* or *Phase II* assessments. After a key is constructed, an attempt is made to find a matching key in the *buffer reference table*. If the *key* is found, the associated buffering *parameters* are used to define the *stream corridor* for the reach. If, however, the *key* is not found, the next *key* in the pre-determined order is constructed. This process is repeated until the generic *key* of "*Default*" is constructed; at which time the record from the *buffer reference table* having the same value will be used to obtain the buffering *parameters*.

Note: It is mandatory that each *buffer reference table* contain a record with a *key* value of "*Default*". The presence of such a record in each table is verified during the initialization procedure for the *Tools* extension. If no such record is found in <u>any</u> *buffer reference table*, an error message is issued and access to the *Tools* extension is prevented.

The preceding has the following implications:

- 1. The data collected from the *Phase I* and *Phase II* assessments is entered and maintained in a Microsoft Access data base; and must be transferred into the attribute table for the Reach Point theme. The approach for performing this task is described in a subsequent section of this Appendix.
- 2. The pre-determined order in which *keys* are constructed must be carefully defined and followed in both the development of *buffer reference tables* and the search for a matching *key* in the *Tools*.

The pre-determined order in which *keys* are to be constructed is defined through the *decision trees* shown on the following two pages. When designing or implementing changes to records within a *buffer reference table*, review the *decision tree* with respect to the <u>order</u> in which combinations of the data elements are used to form a *Key*. The order, from left to right, represents the most "sensitive" and specific cases to the most general. Identify where a new record should fit in the hierarchy. Then, take time to see if inserting that record will affect others; and, if so, what changes or new records are required to make the hierarchy work.

SGAT – Version 3

Decision tree for finding record in Buffer Reference Table for Stream Geomorphic Assessment and Floodway Determination Option 1







Import of Phase I/Phase II Data

Thus far, the discussion has been oriented around the development and use of the *buffer reference tables*. The data elements required to access these tables, however, will not be available until a set of export/import procedures has been executed.

Until the export/import procedures have been run, the only stream corridor development that can occur will be for the stream geomorphic assessment application and Floodway Determination Option 1. And, in those cases, all stream corridors will be created using the Default record in the buffer reference table associated with the given application. Any attempts to create stream corridors for the other applications will result in an error being generated in **Step 09** and access to the buffer function will be prevented.

The data elements required for using the *buffer reference table* are collected during the *Phase I* and *Phase II* assessment efforts. These data elements, however, are entered into and maintained in a separate Microsoft Access data base. An automated method for extracting the required data elements is provided as part of the interface to that data base.

Note: Refer to the documentation for the *Phase I/II* Access data base for instructions on performing the extraction.

When the extraction is performed (from within the Access data base), a dBase table named "*StrmCorDat.dbf*" will be created. This table must be moved or copied to the *BaseData* directory. Then, the *Import* function available on the dialog for **Step 10** can be used to transfer that data to the attribute table for the reach point theme.

The *Import* function is described in the section of the User Manual for the *Tools* extension pertaining to **Step 10**. A portion of that section has been incorporated below for completeness of this Appendix.

During *Phase I* and *Phase II* of geomorphic assessment for a watershed, a significant amount of data will be entered into a Microsoft Access data base. A limited set of that data will be required for developing and/or refining the stream corridor calculations of *Step 09*. The data elements which are required are included in the lower right corner of the dialog for *Step 10*.

If the fields shown on the dialog have values of "N/A", then the import function has not been executed. The operation for importing the data will be initiated by clicking on the *Import Stream Type* button.

The dialog for *Step 10* with the relevant areas highlighted are shown in the figure on the following page.

Development of Stream Corridor Buffers in Step 09

Peach Point Identifiers Vermont Id: 0201000805-0001 Reach ID: Image: Channel and Valley Distance Id: M-000.000 Peach Point Data Image: Channel and Valley Channel and Valley Vermont Id: 0201000805-0001 Distance Id: Image: Channel and Valley Channel and Valley Vermont Id: 000 Distance to Start: 0.00 Feet Channel and Valley Vermont Id: Vermont Id: Vermont Id: Vermont Id: Map Documentation and Notes/Comments for Reach Map Documentation and Notes/Comments for Reach Reach Attributes Imported (for defining Stream Conditions) Stream Type: C-/ Vermont Id: Vermont Id: 000 Vermont Id: 000 Niles Map Documentation and Notes/Comments for Reach Reach Attributes Imported (for defining Stream Conditions) Stream Type: C-/ Velley Slope Group: Stream Type: Vermont Id: Stream Group: Confirment: Stream Group: Stream Identified Addustment: Stream Group: Stream Identified Addustment: Maior Charmel Addustment:	each Point Theme Multip Theme: S06RPts01.shp I to be r	e Themes for this input created. Select Theme used (last one created shown first).
each Point Data Reach Point Type: Dutflow Location Distance to Start Elevation: Onoo Feet State Plane Coordinates Geographic Coordinates Long: -73.279040 Let: 44.247495 Channel and Valley Channel Valley Width: 98 Valley Valley Vidth: 98 Vidth: 98 Vidth: 98 Vidth: 98 Vidth: 98 Vidth: 98	each Point Identifiers Reach ID: MOT	Vermont Id: 0201000805-0001 Distance Id: M-000.000
Location Distance to Stat: 0.00 Feet Distance to Stat: 0.00 Feet Length: 5684 Conditionates State Plane Coordinates 437778.67 Y 194434.96 Sinuosity: 0.00 <- Percent> Slope: Geographic Coordinates 437778.67 Y 194434.96 Areas Reach Sub-Watershed: 0.60 Sq. Miles Long: -73.279040 Let: 44.247495 Reach Drainage Area: 23.10 Sq. Miles Map Documentation and Notes/Comments for Reach Reach Attributes Imported (for defining Stream Corridors) Stream Type: Confinement Group: Stream Group: Confinement Group: 3 Towns: Towns: Confinement Group: 3 Major Charmel Adjustment: Stream Group: 3	aach Point Data Reach Point Type: Outflow	Channel and Valley Channel < Units> Valley
Elevation: 0.00 Feet State Plane Coordinates Slope: Slop: <	Distance to Start: 0.00 Feet	ength: 5004 (- Feet -> Width: 0
Sinuosity: 0.0 < Ratio> Confinement: Sinuosity: 0.0 < Ratio> Confinement: Areas Reach Sub-Watershed: 0.60 Sq. Miles Long: -73.279040 Let: 44.247495 Reach Dreinage Area: 23.10 Sq. Miles Map Documentation and Notes/Comments for Reach Reach Attributes Imported (for defining Stream Corridors) Stream Type: C-/ Valley Slope Group: Stream Group: Stream Corrigo: 3 Outhos: Downs: Maior Charmel Addustment:	Elevation: 0,00 Feet	Slope: 0.00 <- Percent ->' Slope: 0.00
Geographic Coordinates 0.60 Sq. Miles Long: -73.279040 Lat: 44.247495 Map Documentation and Notes/Comments for Reach Reach Attributes Imported (for defining Stream Corridors) Stream Type: C-/ Values: Orthos: Stream Group: / Confinement Group: 3 Major Chennel Adjustment: / Stream Group: / Stream Group: 3	× 437778.67 Y 194434.9	6 Sinuosity: 0.0 < Ratio> Confinement: 0
Map Documentation and Notes/Comments for Reach Quads: Quads: Controls: Control: Cont	Geographic Coordinates	Reach Sub-Watershed: 0.60 Sq. Miles Reach Drainage Area: 23.10 Sq. Miles Overall's fearmatics: 23.10 Sq. Miles
Orthos: Stream Group:	Map Documentation and Notes/Comments for Reach Quads:	Reach Attributes Imported (for defining Stream Corridors) Stream Type: C/ Valley Slope Group: c
Towns: Major Channel Adjustment	Orthos:	Stream Group:
Notes: Reference Stream Departure: No	Towns:	Major Lhannel Adjustment: Reference Stream Departure: No

When one clicks on the button labeled Import Stream Type, the following message is issued.

Continue	with Import?
0	This will transfer data from the table 'StrmCorDat.dbf' to the attribute table for the Reach Point theme.
	Continue?
	Yes No

The above simply provides a chance for the user to "bail out" if the button was inadvertently clicked. Select *No* to quit the import function. Otherwise, click on Yes to continue.

For the *Tools* to import the data, the table must be named "*StrmCorDat.dbf*" and must be located in the *BaseData* directory. If the table is not found, the following error message is issued.



If the table is found, a check is made to ensure that the required fields are included and that the table can be edited. The following error messages will be issued if problems are encountered.

🍭 (Revu) Incorrect dBase File Format
STOP	Table, StrmCorDat.dbf, does not have one/more of the required fields. File selection ignored.
	OK

🝳 (Revu) dBase File Cannot be Edited	×
Table, StrmCorDat.dbf, cannot be edited. Table in use by another application or marked as Read-Only. File selection ignored.	

If no error conditions are detected, the following fields will be created in the reach point theme:

- **StrmType11** (Stream Type): The first character of the stream types assigned during the *Phase I*.
- **StrmType12** (Stream Type): The second character of the stream types assigned during the *Phase I*.
- **StrmType13** (Stream Type): The third character of the stream types assigned during the *Phase I*.
- **StrmGroup1** (Stream Group): The group designation (e.g. Sensitivity Class) assigned during the *Phase I*.
- **VSGroup:** The valley slope group assigned during the *Phase I* based upon the slope of the valley line for the reach.
- **VCGroup:** The valley confinement group assigned during the *Phase I* based upon the confinement of the valley for the reach.
- **StrmType21** (Stream Type): The first character of the stream types assigned during the *Phase II*.
- **StrmType22** (Stream Type): The second character of the stream types assigned during the *Phase II*.
- **StrmType23** (Stream Type): The third character of the stream types assigned during the *Phase II*.
- **StrmGroup2** (Stream Group): The group designation (e.g. Sensitivity Class) assigned during the *Phase II*.
- **Adjustment** (Whether a major channel adjustment is in progress): Values will be "Yes" or "*No*".
- **Departure** (Whether the existing stream type is a departure from the Reference Stream Type): Values will be "*Yes*" or "*No*".

The data from the import table named "*StrmCorDat.dbf*" is then transferred into the attribute table for the reach point theme.

Following import, the values transferred from the import table will be displayed for each reach. These values will include *dashes* to identify data not entered into the Microsoft Access data base.

Upon successful completion of the *Import* operation, the *Export* function will include the above data fields. In addition, one can then create stream corridors for all applications with use of the data imported.

Warning: It is possible that running **Step 09** for the **SGA** (Stream Geomorphic Assessment, Phase I) and **FD Option-1** (Floodway Determination Option 1) applications <u>following</u> the *import* operation will create different stream corridors. This will be dependent upon the structure of the *buffer reference table* associated with these *applications*. At present, the stream corridors will be the same; however, if modifications to related *buffer reference table* are made the stream corridors may be different.

Warning: The *Phase II* assessment effort will, most likely, <u>not</u> be performed for all reaches. For those reaches in which the assessment was not conducted, the *stream type* imported will have a value composed of dashes ("-"). In **Step 09**, any reach having a *stream type* value of dashes <u>will</u> <u>not</u> have a *stream corridor* created. This will result in *stream corridors* being created <u>only</u> for those reaches in which a *Phase II* effort was conducted. This will only affect the **FD Option-2** (*Floodway Determination Option 2*) application.

Steps used to Create the Stream Corridor from Component Buffers

The figures in this Appendix are provided for the purposes of documenting the process, data and themes used in creating the stream corridor buffer in **Step 09**. The essential themes are as follows:

- Sub-watershed delineation (polygons);
- Valley wall delineation (polygons)
- Meander centerline (polyline) and
- Stream Centerline (polyline).

Note: Refer to Appendix E of the "Vermont Phase 1 Stream Geomorphic Assessment Handbook" and "*Floodway Determination Technical Guidance*" for scientific concepts and reasoning behind the development of the stream corridor.

The following figure illustrates the basic themes used in creating Stream Corridor Buffers:



Note: The valley line developed in Step 07 is shown for illustrative purposes only. It is <u>not</u> used in the process for creating stream corridors.

Creating a stream corridor involves a ten step process of creating individual buffers around a specific feature (stream centerline, meander centerline or valley wall); clipping a previously developed buffer to a specific feature and/or combining previously developed buffers to form a composite buffer. The steps are briefly described and illustrated in the following.

Please note: In this document, references are made to the use of specific numbers for creating the individual (component) buffers. These numbers identify a specific distance or channel width multiplier and are used for illustrative purposes only. The actual numbers used in the implementation of the Stream Geomorphic Assessment Tools (Tools) may be different.

The channel width is calculated in Step 08 of the Tools. A "channel width multiplier" is a number that is multiplied by the channel width to determine a buffering distance. Since the channel width is based upon the drainage (or watershed) area above a reach point, the channel width will increase as one proceeds from upstream reaches downstream. Those buffers dependant upon the channel width (and the resultant stream corridor) will also increase laterally as one proceeds downstream.



Step 1

The figure to the right illustrates the default buffer. This buffer is created using a specific distance of 100 feet to each side of the stream centerline. and is not dependant upon the channel width. This buffer is allowed to extend laterally outside of the valley walls.

Step 2

The buffer shown to the right is the basic stream corridor. This buffer is created using the stream centerline with the buffer distance calculated as 2.5 times the channel width. For this reach, the channel width is 91.67 feet and the valley width has been calculated (via Step 07) as 1426.43 feet. As with the default buffer, this buffer is allowed to extend laterally outside of the valley walls.

<u>Step 3</u>

To the right is the Union (i.e. combination of Step 1 and Step 2) of the default and stream corridor buffers. In reaches such as the one shown, the basic stream corridor will always be larger. In upland reaches, however, the default buffer may be the more dominant buffer. As indicated earlier, the resultant buffer is allowed to extend laterally outside of the valley walls. This provides a more accurate reflection of conditions where the resolution of the source maps (digital versions of the USGS topographic maps) prevented a more detailed delineation of the valley walls.



Step 4

The buffer shown to the right illustrates the meander centerline buffered at 4.0 times the channel width. For the *stream geomorphic assessment application*, this buffer will be created <u>only if both</u> the valley walls <u>and</u> the meander centerline are present for a given reach. Specifically, if a valley wall polygon is not present that encompasses the entire reach (the reach point and its neighboring upstream reach point), then this buffer will not be created.

For *Floodway Determination Options 1* and 2, a buffer will be created using the meander centerline regardless of the presence of valley walls.

For <u>all</u> applications: Following creation

of the meander centerline buffer, it will be clipped by the valley walls. (Note: This portion of <u>Step</u> <u>4</u> is not shown.) In other words, this buffer is not allowed to extend laterally beyond the valley walls.



Optional Intervening Step

If <u>no</u> meander centerline is present for a reach, a secondary buffer <u>may</u> be created using the stream centerline as the selected feature. The development of this buffer will be dependent upon the value of the *SCLnoMCL* field in the *buffer reference table* being used. If that value is zero, no secondary buffer will be created. If, however, the value is non-zero, then it will be used as a *channel width multiplier* and multiplied by the *channel width* to form the buffer distance (on each side of the stream centerline). This buffer will <u>not</u> be constrained to fall within the valley walls; and therefore may extend laterally beyond the valley walls. This step is not illustrated.

The following represents the *decision tree* implemented for determining whether the "*secondary buffer*" on the stream centerline is to be created.



Decision Tree for Buffering of Meander Centerline

Decisions shown on horizontal lines with positive (true) conditions taking the upper (blue) branch and negative (false) conditions taking the bottom (magenta) branch.

RequireWV value is obtained from the buffer reference table for each reach. A value of "Yes" requires that valley walls be present. If valley walls are not present for a given reach, buffering of the meander centerline is not be be performed.

VW Present identifies the fact that a given reach point and its upstream neighboring reach point are contained within a polygon representing valley walls, i.e. valley walls are present for the reach.

MCL Present identifies the fact that a meander centerline is present for the reach. This centerline need not pass completely through the reach, i.e. it may extend only partly into a reach.

MCL CW Multiplier > 0 -- The channel width (CW) multiplier for the meander centerline (MCL) is obtained from the buffer reference table for a given reach. If the value is zero, no buffer will be created using the meander centerline.

SCLnoMCL CW Multiplier > 0 -- The channel width (CW) multiplier for the SCLnoMCL is obtained from the buffer reference table for a given reach. This value is intended to be used to create a buffer around the stream centerline <u>if no meander centerline is present</u>. If the value for SCLnoMCL is zero, no buffer will be created.

<u>Step 5</u>

The following is the Union (i.e. combination of <u>Step 3</u> and <u>Step 4</u>). As stated earlier, the buffer resulting from <u>Step 3</u> is allowed to extend laterally beyond the valley walls, while the buffer resulting from <u>Step 4</u> is constrained (clipped off) by the valley walls. This can be seen in the figure below by the "stair-step" appearance at the valley wall of the easterly portion of the buffer resulting from this step.



<u>Step 6</u>

The figure below to the left is the buffer for the southerly valley wall and to the right is the northerly valley wall resulting from <u>Step 6</u>. These buffers are to be constrained by the valley wall delineation. As a result, the buffers shown below have been clipped off by the valley walls.

It is important to note that in more confined valleys the buffer created for one valley wall may extend laterally beyond the opposite valley wall. Since these buffers are to be constrained by the valley walls, the area extending beyond the opposite valley wall is also clipped off.



The following illustrates the valley wall buffers resulting from <u>Step 6</u> in the same figure. The overlap of the buffers is not illustrated.



<u>Step 7</u>

The following on the left illustrates contribution of the lower (southerly) valley wall buffer to the stream corridor resulting from <u>Step 7</u>. The area is shown is that part of the buffer from <u>Step 6</u> that falls on the <u>opposite</u> side of the stream centerline. The contribution of upper (northerly) valley wall buffer to the stream corridor is shown on the right below.



<u>Step 8</u>

The following figure illustrates the combination of all of the contributing buffers (from <u>Step 5</u> and the two contributing valley wall buffers from <u>Step 7</u>) defining the composite buffer resulting from <u>Step 8</u>.



<u>Step 9</u>

As show below, the composite buffer resulting from <u>Step 8</u> is clipped to the sub-watershed boundary. This is performed to prevent overlapping stream corridors forming at sub-watershed boundaries and to ensure that subsequent data (LcLu and soils) is properly calculated for a given sub-watershed (reach).



<u>Step 10</u>

It is possible that certain configurations of the features buffered will result in gaps or holes left in the composite buffer. This could occur, for example, in very broad valleys or if the meander centerline or stream centerline makes a significant loop outside of the valley walls. This step reviews the composite buffer and removes any holes (island polygons). The result is the *stream corridor*.



And "That's all folks"