

# Craignell User Manual

## Issue – 1.01

©2008 Enterpoint Ltd. - Craignell Manual - Issue 1.01 25/01/2008

#### **Kit Contents**

You should receive the following items with you Craignell development kit:

1 – Craignell CR28/CR32/CR36/CR40 Board.

#### **Purchase Optional Extras**

The following, or equivalent, are necessary to program a Craignell module.

- 1 Prog2 Programming Cable.
- 2 Craignell Programming Adaptor

We also have ZIF based module to power a Craignell outside of a target board to allow programming. Contact <u>boardsales@enterpoint.co.uk</u> for more details on this item.

#### **Foreword**

## PLEASE READ THIS ENTIRE MANUAL BEFORE PLUGGING IN OR POWERING UP YOUR CRAIGNELL BOARD. PLEASE TAKE SPECIAL NOTE OF THE WARNINGS WITHIN THIS MANUAL.

#### **Trademarks**

Coolrunner-II, Spartan, ISE, EDK, Webpack, Xilinx are the registered trademarks of Xilinx Inc, San Jose, California, US.

Craignell is a trademark of Enterpoint Ltd.

#### **Introduction**

Welcome to your Craignell board. Craignell is a low cost high performance Spartan<sup>TM</sup>-3E FPGA based module.

This manual covers Issue2 and later of the Craignell modules. If you need information on Issue1 the schematics are available at http://www.enterpoint.co.uk/component\_replacements/craignell.html.

The aim of this manual is to assist in using the main features of Craignell. Should this manual fail to explain a feature sufficiently then our support team can be reached by email on support@enterpoint.co.uk.

#### **Finding Your Way Around**



#### **Getting Started**

Craignell is currently available in 4 pinout sizes – 28 pins, 32 pins, 36 pins and 40 pins.

Your Craignell normally comes with our LED Flash Test build loaded. This application will cause the LED to flash on and off and indicates power is applied, the on-board oscillator is running and the FPGA has configured from the on-board SPI Flash Memory.

Pin1 of the module is on the back side of the module at the top left of the picture above (CR40). Pins count counter-clockwise from Pin1.

Some useful links and other information can be obtained from our website here:

http://www.enterpoint.co.uk/techitips/techitips.html

#### **Craignell Features**

#### **Power Inputs and Power Supplies**

Craignell uses a notional 5V input but can operate from 3.5V to 5.5V (specification guaranteed) but in practise can operate as low as 2.8V and as high as 6V if care in interfacing signal levels is taken. An optimised version for 3.3V power supply operation will be available shortly. Please contact sales if you are interested in this version or require more information.

The power is supplied to the module on the top right pin - 5V (facing from the front of the module and most components visible) and the bottom left pin - 0V/GND. We can supply other variants of power pinning as special builds for component replacements with differing requirements. Input current requirements will depend on the design loaded into the FPGA on the board, the size of the FPGA, and I/O loading. We would normally expect this would be in the range 100-500mA.

An onboard a Texas Instruments TPS70402 linear regulator produces 1.22V and 2.5V from the input supply voltage. The 1.22V is used for the Spartan<sup>TM</sup>-3E core voltage and the 2.5V is used for all other devices and for the Vccaux/Bank Voltages of Spartan<sup>TM</sup>-3E.

## WARNING – THE REGULATORS CAN POTENTIALLY GET VERY HOT IN SOME UNUSUAL CIRCUMSTANCES ALONG WITH THE BOARDS THERMAL RELIEF. PLEASE DO NOT TOUCH OR PLACE HIGHLY FLAMABLE MATERIALS NEAR THIS DEVICE WHILST THE CRAIGNELL BOARD IS IN OPERATION.

#### Selecting the FPGA Bank (VCCIOX) voltages.

Craignell fixes the I/O voltages all of FPGA banks to 2.5V. However there are pull-ups to all the I/O pins on the Gull-Wing Connectors to the input supply voltage allow the I/O to achieve CMOS type levels were these are needed.

#### **Programming Craignell**

For programming and building your design you will need to download a copy of ISE Webpack<sup>TM</sup> form Xilinx<sup>TM</sup>. You can obtain it here:

http://www.xilinx.com/ise/logic\_design\_prod/webpack.htm

The programming of the FPGA and Serial Flash parts on Craignell are achieved using 2 separate interfaces. Both of these interfaces are accessed through a single 2x6 1.27mm header. Our Craignell Programming Adaptor which breaks out these interfaces into two standard 2x7 2mm headers for use with out Prog2 cable or Xilinx programming cables. The picture below shows their interface locations. Please take special note of the orientation and alignment of the Programming adaptor shown in the photograph below.



The first interface is a standard JTAG port which follows the standard layout for our Prog2 cable and for Xilinx Programming Cables IV and later. The Xilinx ISE Impact tool can be used to control programming (boundary scan mode). ISE Webpack can be downloaded free from Xilinx on their website. Direct JTAG programming is volatile and the FPGA will lose its configuration every time the board power is turned off/on. From sustained use of FPGA design programming the design into the Serial Flash memory is recommended. Generation of suitable Serial Flash content files and control of the JTAG chain can be achieved using the ISE Impact.

The second interface contains the signals that connect to Serial Flash and additionally Prog\_B. When a Prog2 or suitable Xilinx cable is plugged in Prog\_B is connected to DGND/0V and the Spartan<sup>TM</sup>-3E FPGA is placed into the pre-configured state. This avoids conflicts on the Serial Flash control and data lines with drive from the programming cable. The pinout of the header also

allows ISE Impact tool (serial flash mode) to program the Serial Flash. Please note to allow the FPGA to configure you must remove the programming cable from the Serial Flash Programming Header.

#### **FPGA**

Craignell supports Spartan<sup>TM</sup>-3E devices in the CP/CPG132 package. Standard builds of Craignell use commercial grade devices but industrial grade parts can be fitted at extra cost subject to minimum order quantities and charges. Currently we are supplying only the XC3S100E-4CPG132C and XC3S500E-4CPG132C FPGAs as standard options. The XC3S250E-4CPG132C is also possible.

#### **LEDS**

Supplied on Craignell there is 1 LED driven by the FPGA. LED1 has a positive polarity i.e. '1' = on. LED2 and LED3 are negative polarity i.e. '0' = on.

The LEDS are situated on FPGA IO pins as indicated below:

LED	LED1
FPGA	C14
PIN	

#### **CLOCK**

Craignell comes fitted with a 40 MHz oscillator. This is input on FPGA pin M6.

### FLASH MEMORY

Supplied as standard on Craignell is a 4Mbit ST Microelectronics M25P40. This device is used to configure the Spartan<sup>TM</sup>-3E. The remainder of flash memory is available for storing code for PicoBlaze<sup>TM</sup>, MicroBlaze<sup>TM</sup> or other microprocessors.

A XC3S100E will use 581,344 bits of this memory for configuration. The XC3S500E will use 2,270,208 bits for configuration.

#### **General I/O**

Craignell supports between twenty six and thirty eight 5V tolerant, I/O depending on which Craignell you purchase.

#### **CR40 Pinout Constraints**

```
NET "CLK"
             LOC = "M6" | IOSTANDARD = LVTTL;
NET "LED DRIVE" LOC = "C14" | IOSTANDARD = LVTTL;
#
#
NET "PIN1"
             LOC="B9"
                        | IOSTANDARD = LVTTL ;# IO9
NET "PIN2"
             LOC="A7"
                        | IOSTANDARD = LVTTL :# IO8
NET "PIN3"
             LOC="B5"
                        | IOSTANDARD = LVTTL ;# IO7
NET "PIN4"
             LOC="C6"
                        | IOSTANDARD = LVTTL :# IO6
NET "PIN5"
             LOC="C3"
                        | IOSTANDARD = LVTTL ;# IO5
NET "PIN6"
             LOC="C5"
                        | IOSTANDARD = LVTTL ;# IO4
NET "PIN7"
             LOC="B1"
                        | IOSTANDARD = LVTTL ;# IO0
NET "PIN8"
             LOC="G1"
                       | IOSTANDARD = LVTTL ;# IO1
NET "PIN9"
             LOC="F3"
                       | IOSTANDARD = LVTTL ;# IO2
NET "PIN10"
              LOC="A3"
                        | IOSTANDARD = LVTTL ;# IO3
NET "PIN11"
                        | IOSTANDARD = LVTTL ;# IO35
              LOC="H3"
NET "PIN12"
              LOC="J3"
                       | IOSTANDARD = LVTTL ;# IO36
NET "PIN13"
              LOC="H1"
                        | IOSTANDARD = LVTTL ;# IO37
NET "PIN14"
              LOC="F1"
                        | IOSTANDARD = LVTTL ;# IO34
NET "PIN15"
              LOC="M4"
                        | IOSTANDARD = LVTTL :# IO38
NET "PIN16"
              LOC="L3"
                        | IOSTANDARD = LVTTL ;# IO26
NET "PIN17"
              LOC="P4" | IOSTANDARD = LVTTL ;# IO33
              LOC="M5" | IOSTANDARD = LVTTL ;# IO32
NET "PIN18"
NET "PIN19"
              LOC="P6" | IOSTANDARD = LVTTL ;# IO31
NET "PIN21"
              LOC="P7" | IOSTANDARD = LVTTL :# IO30
NET "PIN22"
              LOC="M12" | IOSTANDARD = LVTTL ;# IO28
NET "PIN23"
              LOC="L14" | IOSTANDARD = LVTTL ;# IO27
NET "PIN24"
              LOC="N14" | IOSTANDARD = LVTTL ;# IO25
NET "PIN25"
              LOC="H12" | IOSTANDARD = LVTTL ;# IO24
NET "PIN26"
              LOC="J12" | IOSTANDARD = LVTTL ;# IO23
NET "PIN27"
              LOC="G13" | IOSTANDARD = LVTTL ;# IO20
NET "PIN28"
              LOC="J14" | IOSTANDARD = LVTTL :# IO21
NET "PIN29"
              LOC="K14" | IOSTANDARD = LVTTL ;# IO22
NET "PIN30"
              LOC="C12" | IOSTANDARD = LVTTL ;# IO16
              LOC="F12" | IOSTANDARD = LVTTL ;# IO17
NET "PIN31"
              LOC="F14" | IOSTANDARD = LVTTL ;# IO18
NET "PIN32"
NET "PIN33"
              LOC="F2" | IOSTANDARD = LVTTL ;# IO19
NET "PIN34"
              LOC="G14" | IOSTANDARD = LVTTL ;# IO15
NET "PIN35"
              LOC="A13" | IOSTANDARD = LVTTL :# IO14
NET "PIN36"
              LOC="A10" | IOSTANDARD = LVTTL ;# IO13
NET "PIN37"
              LOC="C9"
                        | IOSTANDARD = LVTTL ;# IO12
NET "PIN38"
              LOC="G3"
                        | IOSTANDARD = LVTTL :# IO11
NET "PIN39"
              LOC="A9" | IOSTANDARD = LVTTL ;# IO10
```

#### **CR36 Pinout Constraints**

```
NET "CLK" TNM_NET = "CLK";
TIMESPEC "TS CLK" = PERIOD "CLK" 25 ns HIGH 50 %;
OFFSET = IN 3 ns BEFORE "CLK";
OFFSET = OUT 8.5 ns AFTER "CLK" ;
#
NET "CLK"
              LOC = "M6" | IOSTANDARD = LVTTL;
NET "LED_DRIVE" LOC = "C14" | IOSTANDARD = LVTTL;
#
#
NET "PIN1"
             LOC="B9"
                        | IOSTANDARD = LVTTL ; #IO9
NET "PIN2"
             LOC="A7"
                         | IOSTANDARD = LVTTL; #IO8
NET "PIN3"
                        | IOSTANDARD = LVTTL; #IO7
             LOC="B5"
NET "PIN4"
             LOC="C6"
                        | IOSTANDARD = LVTTL ; #IO6
NET "PIN5"
             LOC="C3"
                        | IOSTANDARD = LVTTL; #IO5
NET "PIN6"
                        | IOSTANDARD = LVTTL ; #IO4
             LOC="C5"
NET "PIN7"
             LOC="B1"
                        | IOSTANDARD = LVTTL ; #IO0
NET "PIN8"
             LOC="G1"
                        | IOSTANDARD = LVTTL ; #IO1
NET "PIN9"
             LOC="F3"
                        | IOSTANDARD = LVTTL ; #IO2
NET "PIN10"
              LOC="A3"
                         | IOSTANDARD = LVTTL ; #IO3
NET "PIN11"
              LOC="H3"
                         | IOSTANDARD = LVTTL ; #IO35
NET "PIN12"
              LOC="J3"
                         | IOSTANDARD = LVTTL ; #IO36
                         | IOSTANDARD = LVTTL ; #IO37
NET "PIN13"
              LOC="H1"
NET "PIN14"
              LOC="F1"
                         | IOSTANDARD = LVTTL ; #IO34
NET "PIN15"
              LOC="M4"
                         | IOSTANDARD = LVTTL : #IO38
NET "PIN16"
              LOC="L3"
                         | IOSTANDARD = LVTTL ; #IO26
              LOC="P4"
NET "PIN17"
                         | IOSTANDARD = LVTTL ; #IO33
#
NET "PIN19"
              LOC="L14"
                         | IOSTANDARD = LVTTL ; #IO27
NET "PIN20"
              LOC="N14"
                         | IOSTANDARD = LVTTL ; #IO25
                         | IOSTANDARD = LVTTL ; #IO24
NET "PIN21"
              LOC="H12"
NET "PIN22"
              LOC="J12"
                         | IOSTANDARD = LVTTL : #IO23
NET "PIN23"
              LOC="G13"
                         | IOSTANDARD = LVTTL ; #IO20
NET "PIN24"
              LOC="J14"
                         | IOSTANDARD = LVTTL ; #IO21
                         | IOSTANDARD = LVTTL ; #IO22
NET "PIN25"
              LOC="K14"
NET "PIN26"
              LOC="C12"
                         | IOSTANDARD = LVTTL ; #IO16
NET "PIN27"
              LOC="F12"
                         | IOSTANDARD = LVTTL ; #IO17
NET "PIN28"
              LOC="F14"
                         | IOSTANDARD = LVTTL ; #IO18
NET "PIN29"
              LOC="F2"
                         | IOSTANDARD = LVTTL ; #IO19
NET "PIN30"
              LOC="G14"
                         | IOSTANDARD = LVTTL ; #IO15
NET "PIN31"
              LOC="A13"
                         | IOSTANDARD = LVTTL ; #IO14
NET "PIN32"
              LOC="A10"
                         | IOSTANDARD = LVTTL : #IO13
NET "PIN33"
              LOC="C9"
                         | IOSTANDARD = LVTTL ; #IO12
NET "PIN34"
              LOC="G3"
                         | IOSTANDARD = LVTTL ; #IO11
NET "PIN35"
              LOC="A9"
                         | IOSTANDARD = LVTTL ; #IO10 .
```

#### **CR32 Pinout Constraints**

```
NET "CLK" TNM_NET = "CLK";
TIMESPEC "TS CLK" = PERIOD "CLK" 25 ns HIGH 50 %;
OFFSET = IN 3 ns BEFORE "CLK";
OFFSET = OUT 8.5 ns AFTER "CLK" ;
#
NET "CLK"
             LOC = "M6" | IOSTANDARD = LVTTL;
NET "LED_DRIVE" LOC = "C14" | IOSTANDARD = LVTTL;
#
#
NET "PIN1"
             LOC="B9"
                       | IOSTANDARD = LVTTL ; #IO9
NET "PIN2"
             LOC="A7"
                       | IOSTANDARD = LVTTL : #IO8
NET "PIN3"
                       | IOSTANDARD = LVTTL; #IO7
             LOC="B5"
NET "PIN4"
             LOC="C6" | IOSTANDARD = LVTTL ; #IO6
NET "PIN5"
             LOC="C3"
                       | IOSTANDARD = LVTTL; #IO5
NET "PIN6"
             LOC="C5" | IOSTANDARD = LVTTL; #IO4
NET "PIN7"
             LOC="B1" | IOSTANDARD = LVTTL ; #IO0
NET "PIN8"
             LOC="G1" | IOSTANDARD = LVTTL; #IO1
NET "PIN9"
             LOC="F3" | IOSTANDARD = LVTTL ; #IO2
NET "PIN10"
             LOC="A3"
                        | IOSTANDARD = LVTTL : #IO3
NET "PIN11"
             LOC="H3" | IOSTANDARD = LVTTL; #IO35
NET "PIN12"
             LOC="J3" | IOSTANDARD = LVTTL ; #IO36
             LOC="H1" | IOSTANDARD = LVTTL; #IO37
NET "PIN13"
NET "PIN14"
             LOC="F1" | IOSTANDARD = LVTTL ; #IO34
NET "PIN15"
             LOC="M4" | IOSTANDARD = LVTTL : #IO38
#
NET "PIN17"
             LOC="H12" | IOSTANDARD = LVTTL; #IO24
NET "PIN18"
             LOC="J12" | IOSTANDARD = LVTTL ; #IO23
NET "PIN19"
             LOC="G13" | IOSTANDARD = LVTTL; #IO20
NET "PIN20"
             LOC="J14" | IOSTANDARD = LVTTL ; #IO21
             LOC="K14" | IOSTANDARD = LVTTL ; #IO22
NET "PIN21"
NET "PIN22"
             LOC="C12" | IOSTANDARD = LVTTL : #IO16
NET "PIN23"
             LOC="F12" | IOSTANDARD = LVTTL; #IO17
NET "PIN24"
             LOC="F14" | IOSTANDARD = LVTTL ; #IO18
NET "PIN25"
             LOC="F2" | IOSTANDARD = LVTTL; #IO19
             LOC="G14" | IOSTANDARD = LVTTL; #IO15
NET "PIN26"
NET "PIN27"
             LOC="A13" | IOSTANDARD = LVTTL ; #IO14
NET "PIN28"
             LOC="A10" | IOSTANDARD = LVTTL; #IO13
NET "PIN29"
             LOC="C9" | IOSTANDARD = LVTTL : #IO12
NET "PIN30"
             LOC="G3"
                        | IOSTANDARD = LVTTL ; #IO11
NET "PIN31"
             LOC="A9" | IOSTANDARD = LVTTL ; #IO10
```

#### **CR28 Pinout Constraints**

```
NET "CLK" TNM NET = "CLK";
TIMESPEC "TS_CLK" = PERIOD "CLK" 25 ns HIGH 50 %;
OFFSET = IN 5 ns BEFORE "CLK" ;
OFFSET = OUT 15 ns AFTER "CLK" ;
#
NET "CLK"
             LOC = "M6" | IOSTANDARD = LVTTL;
NET "LED DRIVE" LOC = "C14" | IOSTANDARD = LVTTL;
#
#
NET "PIN2"
             LOC="A7" | IOSTANDARD = LVTTL : #IO8
NET "PIN3"
             LOC="B5"
                       | IOSTANDARD = LVTTL; #IO7
NET "PIN4"
             LOC="C6" | IOSTANDARD = LVTTL ; #IO6
             LOC="C3" | IOSTANDARD = LVTTL; #IO5
NET "PIN5"
             LOC="C5" | IOSTANDARD = LVTTL : #IO4
NET "PIN6"
NET "PIN7"
             LOC="B1" | IOSTANDARD = LVTTL; #IO0
NET "PIN8"
             LOC="G1" | IOSTANDARD = LVTTL; #IO1
NET "PIN9"
             LOC="F3" | IOSTANDARD = LVTTL : #IO2
NET "PIN10"
             LOC="A3" | IOSTANDARD = LVTTL ; #IO3
NET "PIN11"
              LOC="H3" | IOSTANDARD = LVTTL ; #IO35
NET "PIN12"
              LOC="J3" | IOSTANDARD = LVTTL : #IO36
NET "PIN13"
              LOC="H1" | IOSTANDARD = LVTTL; #IO37
#
NET "PIN15"
              LOC="H12" | IOSTANDARD = LVTTL; #IO23
              LOC="J12" | IOSTANDARD = LVTTL ; #IO20
NET "PIN16"
NET "PIN17"
              LOC="G13" | IOSTANDARD = LVTTL ; #IO21
NET "PIN18"
              LOC="J14" | IOSTANDARD = LVTTL ; #IO22
NET "PIN19"
              LOC="K14" | IOSTANDARD = LVTTL; #IO16
NET "PIN20"
              LOC="C12" | IOSTANDARD = LVTTL; #IO17
              LOC="F12" | IOSTANDARD = LVTTL ; #IO18
NET "PIN21"
NET "PIN22"
              LOC="F14" | IOSTANDARD = LVTTL ; #IO19
NET "PIN23"
              LOC="F2" | IOSTANDARD = LVTTL; #IO15
NET "PIN24"
              LOC="G14" | IOSTANDARD = LVTTL ; #IO14
NET "PIN25"
              LOC="A13" | IOSTANDARD = LVTTL; #IO13
NET "PIN26"
              LOC="A10" | IOSTANDARD = LVTTL : #IO12
NET "PIN27"
              LOC="C9" | IOSTANDARD = LVTTL; #IO11
```

#### **Medical and Safety Critical Use**

Craignell boards are not authorised for the use in, or use in the design of, medical or other safety critical systems without the express written person of the Board of Enterpoint. If such use is allowed the said use will be entirely the responsibility of the user. Enterpoint Ltd will accept no liability for any failure or defect of the Craignell board, or its design, when it is used in any medical or safety critical application.

#### <u>Warranty</u>

Craignell comes with a 90 return to base warranty.

Other specialised warranty programs can be offered to users of multiple Enterpoint products. Please contact sales on <u>boardsales@enterpoint.co.uk</u> if you are interested in these types of warranty,

#### **Support**

Enterpoint offers support during normal United Kingdom working hours 9.00am to 5.00pm. Please examine our Craignell FAQ web page and the contents of this manual before raising a support query. We can be contacted as follows:

Telephone- +44 (0) 1684 585262Email- support@enterpoint.co.uk