

User Manual
Gigabit Ethernet Vision
Quick Start Guide



All information provided in this manual is believed to be accurate and reliable. No responsibility is assumed by Photonfocus AG for its use. Photonfocus AG reserves the right to make changes to this information without notice.

Reproduction of this manual in whole or in part, by any means, is prohibited without prior permission having been obtained from Photonfocus AG.



Contents

1	How to get started	5
1.1	Introduction	5
1.2	Hardware Installation	5
1.3	Network Adapter Configuration	7
1.4	Software for Photonfocus GigE Cameras	11
1.5	Additional Software Installation for DR1 Cameras	11
2	Pleora eBUS SDK	13
2.1	Introduction	13
2.2	Software Installation	13
2.3	Network Adapter Configuration for Pleora eBUS SDK	14
2.4	Getting started	15
2.5	Width setting in DR1-D1312(IE) cameras	19
3	Cognex VisionPro	21
3.1	Introduction	21
3.2	Software Installation Tips	21
3.3	Network Adapter Configuration	25
3.4	Getting started	26
3.5	Modifying Basic Parameters in VisionPro QuickBuild	29
3.6	Modifying All Camera Parameters in VisionPro QuickBuild	30
3.7	Modifying Camera Parameters in Custom Properties Dialog	31
4	Mathworks Matlab	33
4.1	Introduction	33
4.2	Software Installation Tips	33
4.3	Network Adapter Configuration	34
4.4	Getting started	35
5	Matrox MIL	37
5.1	Introduction	37
5.2	Software Installation Tips	37
5.3	Network Adapter Configuration	38
5.4	Getting started	39
6	MVTec HALCON	45
6.1	Introduction	45
6.2	Software Installation Tips	45
6.3	Network Adapter Configuration	46
6.4	Getting started	47
6.5	FPN Correction Calibration in HALCON	50
6.6	HDevelop Scripts	50
6.7	DR1 Demodulation Package	50

7	National Instruments Measurement & Automation	51
7.1	Introduction	51
7.2	Software Installation Tips	51
7.3	Network Adapter Configuration	52
7.4	Getting started	53
8	Stemmer Common Vision Blox	55
8.1	Introduction	55
8.2	Software Installation Tips	55
8.3	Network Adapter Configuration	56
8.4	Getting started	57
A	Revision History	59

How to get started

1.1 Introduction

Photonfocus GigE cameras are fully GigE Vision and GenICam compliant. The cameras can be run with the Pleora eBUS SDK that can be downloaded from the Photonfocus webpage or with any other tool that supports GigE Vision and GenICam. This document will help you to get started with your Photonfocus GigE camera and to grab the first images with different image acquisition tools.

1.2 Hardware Installation

The hardware installation that is required for this guide is described in this section. The following hardware is required:

- PC with Microsoft Windows OS (XP, Vista, Windows 7)
- A Gigabit Ethernet networking card must be installed in the PC. To ensure maximum performance of the GigE camera it is mandatory to have an interface card with the Intel PRO/1000 PT installed in your PC. The descriptions in the following chapters assume that such a network interface card (NIC) is installed. The latest drivers for this NIC should be installed.
- Photonfocus GigE camera.
- Suitable power supply for the camera (see in the camera manual for specification) which can be ordered from your Photonfocus dealership.
- GigE cable of Cat 5E or 6

The following list describes the connection of the camera to the PC (see in the camera manual for more information):

1. Remove the Photonfocus GigE camera from its packaging. Please make sure the following items are included with your camera:
 - Power supply connector
 - Camera body cap

If any items are missing or damaged, please contact your dealership.

2. Connect the camera to the GigE interface of your PC with a GigE cable of Cat 5E or 6.
3. Connect a suitable power supply to the power plug. The pin out of the connector is shown in the camera manual.



Check the correct supply voltage and polarity! Do not exceed the operating voltage range of the camera.



A suitable power supply can be ordered from your Photonfocus dealership.

4. Connect the power supply to the camera (see Fig. 1.1).




Figure 1.1: Rear view of the GigE camera MV1-D1312(IE)-40-G2 with power supply and I/O connector, Ethernet jack (RJ45) and status LED

1.3 Network Adapter Configuration

This section describes recommended network adapter card (NIC) settings that enhance the performance for GigEVision. Additional tool-specific settings are described in the tool chapter.

1. Open the Network Connections window (Control Panel -> Network and Internet Connections -> Network Connections), right click on the name of the network adapter where the Photonfocus camera is connected and select Properties from the drop down menu that appears.




Figure 1.2: Local Area Connection Properties

2. By default, Photonfocus GigE Vision cameras are configured to obtain an IP address automatically. For this quick start guide it is recommended to configure the network adapter to obtain an IP address automatically. To do this, select Internet Protocol (TCP/IP) (see Fig. 1.2), click the Properties button and select Obtain an IP address automatically (see Fig. 1.3).




Figure 1.3: TCP/IP Properties

- Open again the Local Area Connection Properties window (see Fig. 1.2) and click on the Configure button. In the window that appears click on the Advanced tab and click on Jumbo Frames in the Settings list (see Fig. 1.4). The highest number gives the best performance. Some tools however don't support the value 16128. For this guide it is recommended to select 9014 Bytes in the Value list.




Figure 1.4: Advanced Network Adapter Properties

4. No firewall should be active on the network adapter where the Photonfocus GigE camera is connected. If the Windows Firewall is used then it can be switched off like this: Open the Windows Firewall configuration (Start -> Control Panel -> Network and Internet Connections -> Windows Firewall) and click on the Advanced tab. Uncheck the network where your camera is connected in the Network Connection Settings (see Fig. 1.5).




Figure 1.5: Windows Firewall Configuration

1.4 Software for Photonfocus GigE Cameras

Various software packages for Photonfocus GigE (G2) cameras are available on the Photonfocus website:

eBUS SDK Contains the GEVPlayer GUI program, the Pleora SDK and the Pleora GigE filter drivers. Many examples of the SDK are included.

GigE software package Contains a property list for every GigE camera and documents that are missing in the Pleora eBUS SDK installer.

DR1 software package (DR1 cameras only) Contains the DR1_GEVPlayer (using Pleora eBUS SDK) for DR1 cameras and the DR1 Evaluator tool. The purpose of the DR1 Evaluator tool is to evaluate the image quality of the DR1 modulation without a camera.

PFInstaller (required for DR1 cameras only) Contains the DR1 demodulation DLL for application development and for the DR1 GEVPlayer.

DR1 HALCON extension package pf_demod (DR1 cameras only) Extension package that adds DR1 demodulation to the HALCON image processing library. It is included in the DR1 software package.

1.5 Additional Software Installation for DR1 Cameras

Additional software is required for Photonfocus DR1 cameras to demodulate the images.

1. Download the PFInstaller software from the support page at www.photonfocus.com to your computer.
2. Run the PFInstaller installer by double-clicking on the file. Please follow the instructions of the PFRremote setup wizard. This step is required to install the DLL for demodulation of the camera image. The pfDoubleRate.dll is located in the PFRremote directory (e.g. C:\Program Files\Photonfocus\PFRremote). The lib and h files are located in the SDK directory (e.g. C:\Program Files\Photonfocus\PFRremote\SDK).



Figure 1.6: Screen shot PFRremote setup wizard

3. Download the DR1 software package from the support page at www.photonfocus.com to your computer. It contains the DR1_GEVPlayer that is a replacement of the GEVPlayer for DR1 cameras. Note, that the Pleora eBUS SDK must be installed (see Chapter 2) before the DR1_GEVPlayer can be used.


Pleora eBUS SDK

2.1 Introduction

This chapter will help you getting started using a Photonfocus GigE camera with the Pleora GEVPlayer which can be downloaded from the Photonfocus webpage at www.photonfocus.com.

2.2 Software Installation

This section describes the installation of the required software to accomplish the tasks described in this chapter.

1. Install the latest drivers for your GigE network interface card.
2. Download the latest eBUS SDK installation file from the Photonfocus server.
 -  You can find the latest version of the eBUS SDK on the support (Software Download) page at www.photonfocus.com.
3. Install the eBUS SDK software by double-clicking on the installation file. Please follow the instructions of the installation wizard. A window might be displayed warning that the software has not passed Windows Logo testing. You can safely ignore this warning and click on Continue Anyway. If at the end of the installation you are asked to restart the computer, please click on Yes to restart the computer before proceeding.
4. After the computer has been restarted, open the eBUS Driver Installation tool (Start -> All Programs -> eBUS SDK -> Tools -> Driver Installation Tool) (see Fig. 2.1). If there is more than one Ethernet network card installed then select the network card where your Photonfocus GigE camera is connected. In the Action drop-down list select Install eBUS Universal Pro Driver and start the installation by clicking on the Install button. Close the eBUS Driver Installation Tool after the installation has been completed. Please restart the computer if the program asks you to do so.




Figure 2.1: eBUS Driver Installation Tool

2.3 Network Adapter Configuration for Pleora eBUS SDK

Open the Network Connections window (Control Panel -> Network and Internet Connections -> Network Connections), right click on the name of the network adapter where the Photonfocus camera is connected and select Properties from the drop down menu that appears. A Properties window will open. Check the eBUS Universal Pro Driver (see Fig. 2.2) for maximal performance. Recommended settings for the Network Adapter Card are described in Section 1.3.




Figure 2.2: Local Area Connection Properties

2.4 Getting started

This section describes how to acquire images from the camera and how to modify camera settings.

1. For all Photonfocus cameras, except the DR1 cameras: open the GEVPlayer software (Start -> All Programs -> Pleora Technologies Inc -> eBUS SDK -> GEVPlayer) which is a GUI to set camera parameters and to see the grabbed images (see Fig. 2.3). For DR1-D1312(IE)-G2 cameras: open the DR1_GEVPlayer software contained in the DR1 software package. DR1_GEVPlayer adds the demodulation of images grabbed in DoubleRate_Enable=True mode while all the functionality of the GEVPlayer is retained.




Figure 2.3: GEVPlayer start screen

- Click on the Select / Connect button in the GEVPlayer. A window with all detected devices appears (see Fig. 2.4). If your camera is not listed then select the box Show unreachable GigE Vision Devices.




Figure 2.4: GEV Device Selection Procedure displaying the selected camera

- Select camera model to configure and click on Set IP Address... (see Fig. 2.5).




Figure 2.5: GEV Device Selection Procedure displaying GigE Vision Device Information

- Select a valid IP address for selected camera (see Fig. 2.6). There should be no exclamation mark on the right side of the IP address. Click on Ok in the Set IP Address dialog. Select the camera in the GEV Device Selection dialog and click on Ok.



The IP address for your camera and the IP address for the network adapter to which the camera is connected must be in the same subnet. The camera and the network adapter to which the camera is connected must also both have the same subnet mask.




Figure 2.6: Setting IP address

- Finish the configuration process and connect the camera to eBUS PURE GEV Player.






Figure 2.7: GEV Player is readily configured

- The camera is now connected to the GEVPlayer. Click on the Play button to grab images.

-  An additional check box DR1 appears for DR1-D1312(IE) cameras. The camera is in double rate mode if this check box is checked. The demodulation is done in the GEV Player software. If the check box is not checked, then the camera outputs an unmodulated image and the frame rate will be lower than in double rate mode.
-  If no images can be grabbed, close the GEVPlayer and adjust the Jumbo Frame parameter (see Section 1.3) to a lower value and try again.





Figure 2.8: GEV Player displaying live image stream

7. Check the status LED on the rear of the camera.

-  The status LED light is green when an image is being acquired, and it is red when serial communication is active. For more information see the camera manual.

8. Camera parameters can be modified by clicking on GEV Device control (see Fig. 2.9). The visibility option Beginner shows the basic parameters and hides the more advanced parameters. If you don't have previous experience with Photonfocus GigE cameras, it is recommended to use Beginner level.




Figure 2.9: Control settings on the camera

9. To modify the exposure time scroll down to the AcquisitionControl control category (bold title) and modify the value of the ExposureTime property. The handling of the GEVPlayer is described in more detail in the camera manual.

2.5 Width setting in DR1-D1312(IE) cameras

To set the width in DR1-D1312(IE) camera, please follow this procedure:

1. Set property Window_W to target width.
2. Read value of property WidthInterface.
3. Set property Width to the value of property WidthInterface.

When double rate is enabled (property DoubleRate_Enable=True), WidthInterface shows the width of the modulated image. When double rate is disabled (property DoubleRate_Enable=False), WidthInterface has the same value as Window_W.

Cognex VisionPro

3.1 Introduction

This chapter will help you getting started using a Photonfocus GigE camera with the VisionPro image processing framework from Cognex. The procedures in this manual have been run with VisionPro Version 7.1, but it is recommended to install the latest version of the software.

3.2 Software Installation Tips

To ensure installation of the Cognex Drivers, the Launch Cognex Driver Installer box must be checked during the installation of the Cognex VisionPro software package (see Fig. 3.1).




Figure 3.1: Cognex VisionPro Installation Wizard

If you select Custom in the Cognex Drivers Wizard (see Fig. 3.2), then make sure that Cognex GigE Interface for Cameras is checked (see Fig. 3.3). In the complete installation this is automatically checked.




Figure 3.2: Cognex Drivers Installation Wizard: installation type




Figure 3.3: Cognex Drivers Installation Wizard: Custom installation type

Later in the installation there might be messages that the software or hardware has not passed the Windows Logo Test (see Fig. 3.4). In this case the warning can safely be ignored and Continue Anyway should be clicked, otherwise the drivers are not installed properly.




Figure 3.4: Warning about Windows Logo Test not passed

3.3 Network Adapter Configuration

Open the Network Connections window (Control Panel -> Network and Internet Connections -> Network Connections), right click on the name of the network adapter where the Photonfocus camera is connected and select Properties from the drop down menu that appears. A Properties window will open. Check the eBUS Universal Pro Driver (see Fig. 3.5) for maximal performance. Recommended settings for the Network Adapter Card are described in Section 1.3.




Figure 3.5: Local Area Connection Properties

3.4 Getting started

This section describes how to connect to the Photonfocus GigE camera and how to modify parameters and to grab images using the Cognex VisionPro QuickBuild tool. More information is available in the GigEGuide (possible location: C:\Program Files\Cognex\VisionPro\Doc\en\Hardware Manuals) that is installed with VisionPro.

1. The first step is to assign a valid IP address to the camera. Open the GigE Vision Configuration Tool (Start -> All Programs -> Cognex -> VisionPro -> Utilities -> GigE Vision Configuration Tool) and select the camera on the left panel (see Fig. 3.6). This tool can be used to modify the IP address and the subnet mask of the camera. Click on Update Camera Address if you modified the settings.



The IP address for your camera and the IP address for the network adapter to which the camera is connected must be in the same subnet. The camera and the network adapter to which the camera is connected must also both have the same subnet mask.




Figure 3.6: GigE Vision Configuration

2. Open the QuickBuild tool (Start -> All Programs -> Cognex -> VisionPro -> VisionPro (R) Quick Build) and double-click on ImageSource (see Fig. 3.7).




Figure 3.7: VisionPro QuickBuild start screen

3. In the Image Source window select the Camera radio button, select the camera in the in the Image Acquisition Device/Frame Grabber drop-down list and select the Video Format (e.g. Mono) (see Fig. 3.8). Click on Initialize Acquisition.




Figure 3.8: VisionPro Image Source selection

4. Camera parameter can be modified in the Camera Settings window (see Fig. 3.9). Basic properties can be modified in the tabs Settings, Strobe & Trigger and Image Properties.




Figure 3.9: VisionPro Camera Settings dialog

5. To grab images click on the camera icon at upper left corner in the Camera Settings Dialog (see Fig. 3.9).



Photonfocus DR1 cameras only: The demodulation of images grabbed with double rate enabled (`DoubleRate_Enable=True`) is not supported in the QuickBuild GUI. To view unmodulated images in QuickBuild, the property `DoubleRate_Enable` (category `DoubleRate`) must be set to `False` in the GigE tab (see Section 3.6) or in the Custom Properties dialog (see Section 3.6). In this mode however, the frame rate is about half compared to the double rate mode. To use the double rate mode, the VisionPro SDK and the `pfDoubleRate` DLL must be used.

3.5 Modifying Basic Parameters in VisionPro QuickBuild

Camera parameter can be modified in the Camera Settings window (see Fig. 3.9). Basic properties can be modified in the tabs Settings, Strobe & Trigger and Image Properties.

3.6 Modifying All Camera Parameters in VisionPro QuickBuild

All available camera parameters can be read or written in the GigE tab of Image Source window (see Fig. 3.10). The name of the property can be retrieved from the properties list of your camera that is included in the Photonfocus GigE software package.



The basic settings shown in Settings, Strobe & Trigger and Image Properties tabs should not be modified in the GigE tab as these are overwritten whenever a basic setting is modified.




Figure 3.10: VisionPro QuickBuild GigE tab

3.7 Modifying Camera Parameters in Custom Properties Dialog

A custom camera properties GUI can be built in the Custom Properties tab by adding items (see Fig. 3.11).



A command must not be included in the Custom Properties tab: a command is first executed when it is included in the Custom Properties tab. After that it is executed every time a parameter is modified. This behaviour will lead to unexpected and undesired results.



The basic settings shown in Settings, Strobe & Trigger and Image Properties tabs should not be modified in the GigE tab as these are overwritten whenever a basic setting is modified. These parameters are displayed in red in the parameters list.




Figure 3.11: VisionPro QuickBuild Custom Properties

Mathworks Matlab

4.1 Introduction

This chapter will help you getting started using a Photonfocus GigE camera with the Matlab framework from Mathworks. The procedures in this manual have been run with version R2011A, but it is recommended to install the latest version of the software.

4.2 Software Installation Tips

1. To grab images from the Photonfocus GigE camera and to modify its parameters it is required that you have a license for the Image Acquisition Toolbox. If you select the Custom setup type then make sure that at least Image Acquisition Toolbox is installed (see Fig. 4.1). In Typical setup type the mentioned components are installed anyway.




Figure 4.1: Matlab required toolbox

2. The following step describes the installation of additional software for GigE Vision support. This is described in more detail in the MATLAB help of the Image Acquisition Box (path in MATLAB help: Image Acquisition Box -> User's Guide -> Configuring GigE Vision Devices).

3. This step describes the installation of GenICam support. Run MATLAB. From within MATLAB, issue the following commands:

```
cd([matlabroot '\toolbox\imaq\imaqextern']);  
installgenicam;
```

When the installation is finished the following text should appear: The GenICam software has been successfully installed. Please restart MATLAB for the changes to take effect. Exit MATLAB and start it again.

4.3 Network Adapter Configuration

Open the Network Connections window (Control Panel -> Network and Internet Connections -> Network Connections), right click on the name of the network adapter where the Photonfocus camera is connected and select Properties from the drop down menu that appears. A Properties window will open. Make sure that any vendor drivers are unchecked (see Fig. 4.2). Recommended settings for the Network Adapter Card are described in Section 1.3.




Figure 4.2: Local Area Connection Properties

4.4 Getting started

1. Start the Image Acquisition tool by clicking inside MATLAB on Start -> Toolboxes -> Image Acquisition -> Image Acquisition Tool (imaqtool). Your Photonfocus camera should now appear in the left pane (see Fig. 4.3). Click on Mono8 in the left pane.



If your camera doesn't appear then a correct IP must be configured. MATLAB provides only limited access to GigE Vision configuration and unreachable cameras can not be configured by MATLAB. To do this, the Pleora eBUS SDK must be installed (see Chapter 2) and the IP must be set in the GEVPlayer.




Figure 4.3: Matlab Image Acquisition Toolbox

2. To modify camera properties, click on the Device Properties tab in the Acquisition Parameters pane (see Fig. 4.3). The properties are listed in alphabetical order. E.g. to modify the exposure time, scroll down to ExposureTime, modify the numerical value and press Enter. Time values are normally specified in μs .
3. To preview images click on the Start Preview button (see Fig. 4.3). A live camera preview should appear in the Preview window.



Prior to modifying device properties stop all grabbing, e.g. by clicking on the Stop Preview or Stop Acquisition button. Parameters must not be modified during a grabbing process.



Photonfocus DR1 cameras only: The demodulation of images grabbed with double rate enabled (`DoubleRate_Enable=True`) is not supported in the Image Acquisition Tool GUI. To view unmodulated images in the Image Acquisition Tool GUI, the property `DoubleRate_Enable` (category `DoubleRate`) must be set to `False` in the Acquisition Parameters pane. In this mode however, the frame rate is about half compared to the double rate mode. To use the double rate mode in MATLAB scripts, use the `pfDoubleRate` DLL with the `loadlibrary` function.

Matrox MIL

5.1 Introduction

This chapter will help you getting started using a Photonfocus GigE camera with the MIL image processing framework from Matrox. The procedures in this manual have been run with MIL Version 9 R2 with the patches M900U09B11 and M900U34B50, but it is recommended to install the latest version of the software.

5.2 Software Installation Tips

In the installation of the MIL software it is important to include support for GigEVision. Check GigE Vision (Concord G-series) in the Matrox Imaging Setup (see Fig. 5.1).




Figure 5.1: MIL Matrox Imaging Setup

After the installation of MIL at least the following patches should be applied (MIL 9): M900U09B11 and M900U34B50.

5.3 Network Adapter Configuration

Open the Network Connections window (Control Panel -> Network and Internet Connections -> Network Connections), right click on the name of the network adapter where the Photonfocus camera is connected and select Properties from the drop down menu that appears. A Properties window will open. Check the siFilterIP GigE Vision Filter Driver (see Fig. 5.2) for maximal performance. Recommended settings for the Network Adapter Card are described in Section 1.3.




Figure 5.2: Local Area Connection Properties

5.4 Getting started

1. Open MilConfig (Start -> All Programs -> Matrox Imaging -> Tools -> MilConfig) and click on Boards -> GigE (see Fig. 5.3). For maximum performance it is recommended to uncheck Use Camera Discovery Service. Click on Launch Matrox GigE Vision Discovery and Configuration Assistant.




Figure 5.3: MilConfig

- The Photonfocus camera should appear in the camera list (see Fig. 5.4). If it doesn't appear then click on the Perform Discovery button. Changes in the IP configuration can be made in this tool.




Figure 5.4: Matrox GigE Vision Discovery and Configuration Assistant

3. Close the previously opened windows and run Intellicam (Start -> All Programs -> Matrox Imaging -> Tools -> Intellicam). Click on File .> New.... In the new window select GigEvision (see Fig. 5.5). Click on Ok button.




Figure 5.5: Intellicam New Document

4. To modify camera parameters click on the Feature Browser tab (see Fig. 5.6). To modify the exposure time for example, expand the Acquisition Control category and modify the value ExposureTime value by entering a numerical value or by moving the slider. Time values are normally specified in μs . Categories can be expanded or collapsed by double-clicking on the (+) or (-) sign. To grab a live image click on one of the camera icons in the tool bar. Size of the image window is determined by the Width and Height (category Image Format Control) settings. After modifying the window size it is recommended to close the image window and open it again to adjust it to the Width and Height settings.



Photonfocus DR1 cameras only: The demodulation of images grabbed with double rate enabled (DoubleRate_Enable=True) is not supported in the Intellicam GUI. To view unmodulated images in Intellicam, the property DoubleRate_Enable (category DoubleRate) must be set to False in the Feature Browser. In this mode however, the frame rate is about half compared to the double rate mode. To use the double rate mode, the MIL SDK and the pfDoubleRate DLL must be used.




Figure 5.6: Intellicam Feature Browser

MVtec HALCON

6.1 Introduction

This chapter will help you getting started using a Photonfocus GigE camera with the HALCON image processing framework from MVtec. The procedures in this manual have been run with HALCON Version 10.0.1, but it is recommended to install the latest version of the software.

6.2 Software Installation Tips

For maximum performance it is important that the HALCON GigE filter driver is installed in the installation of the HALCON software. In the Additional Drivers dialog during the installation check Install HALCON GigE Vision Streaming Filter (see Fig. 6.1).




Figure 6.1: Dialog to install HALCON GigE Vision Streaming filter

6.3 Network Adapter Configuration

Open the Network Connections window (Control Panel -> Network and Internet Connections -> Network Connections), right click on the name of the network adapter where the Photonfocus camera is connected and select Properties from the drop down menu that appears. A Properties window will open. Check the HALCON GigE Vision Streaming Filter (see Fig. 6.2) for maximal performance. Recommended settings for the Network Adapter Card are described in Section 1.3.




Figure 6.2: Local Area Connection Properties

6.4 Getting started

This section describes how to connect to the Photonfocus GigE camera and how to modify parameters and to grab images using the HDevelop tool.

1. Open HDevelop.
2. In HDevelop open the Image Acquisition Assistant by selecting the menu item Assistants -> Open New Image Acquisition.
3. Select Image Acquisition Interface and click on Detect (see Fig. 6.3). A window might be displayed that asks you to assign a fixed IP, click on Yes (see Fig. 6.4).




Figure 6.3: Detection of Image Acquisition Interface




Figure 6.4: Force IP window

4. In the drop-down box in Image Acquisition Interface, select GigEVision (see Fig. 6.3).
5. Select Connection tab and click on Connect (see Fig. 6.5).




Figure 6.5: Connect to GigE Vision device

- To modify parameters select the Parameters tab. Often it is more convenient to filter the parameters by category. E.g. to modify the Exposure Time, the display can be filtered by selecting AcquisitionControl in the Category drop-down list (see Fig. 6.6). The exposure time can be set by changing the ExposureTime value. The value is sent to the camera after pressing Enter on the parameter value.




Figure 6.6: Storage Layout (bits)

- To grab a live image click on the video camera symbol (see Fig. 6.6).



If no images can be grabbed, then the Jumbo Frames parameter might be too high (see also Section 6.3). Select a lower value and try again.



Photonfocus DR1 cameras only: The demodulation of images grabbed with double rate enabled (`DoubleRate_Enable=True`) is not supported when the images are displayed directly by the Image Acquisition Assistant. To view unmodulated images directly from the Image Acquisition Assistant, the property `DoubleRate_Enable` (category `DoubleRate`) must be set to `False` in the Feature Browser. In this mode however, the frame rate is about half compared to the double rate mode. To use the double rate mode, the HALCON extension package `pf_demod` can be used in a HDevelop script (see also Section 6.7).

6.5 FPN Correction Calibration in HALCON

The calibration of the FPN correction parameters is described in Photonfocus camera manual. This section gives hints how to do this procedure in HALCON HDevelop. The ordering of the parameters in HALCON is not convenient to calibrate the FPN Correction. The best is to always filter the display to the category of the parameter.

6.6 HDevelop Scripts

The best way to get started in writing a script for a Photonfocus GigE Vision camera is to study the examples provided by HALCON. There are various example in the Example Browser (File -> Browse Examples) in the category Operator -> Image -> Acquisition -> `open_framegrabber`; scroll down to `gigevision*.hdev`.

There is GigE Vision specific information in the GigE Vision manual (Reference Manuals -> Image Acquisition Interfaces -> Windows x64 -> GigE Vision).

6.7 DR1 Demodulation Package

`pf_demod` is a HALCON extension package to demodulate images from DR1 camera from within HALCON. An installer for Microsoft Windows (`PFDemodHalconInstaller_V_Winxx.exe`) is included in the DR1 software package that can be downloaded from the Photonfocus web page (Support -> Software Download). Note that there are separate versions for 32-bit Windows and for 64-bit Windows.

To install the DR1 Demodulation package (`PFDemodHalconInstaller_V_Winxx.exe`), double-click on the installer file and follow the instructions. An example is included in the installation (Start -> All Programs -> Photonfocus -> PFDemod Extension for Halcon -> Examples).



To use the `pf_demod` package it is required that `PFRemote` is installed with the `PFInstaller` (see Section 1.5).

National Instruments Measurement & Automation

7.1 Introduction

This chapter will help you getting started using a Photonfocus GigE camera with the Measurement & Automation (M&A) tool from National Instrument . The procedures in this manual have been run with M&A Version 2011.09, but it is recommended to install the latest version of the software..

7.2 Software Installation Tips

For maximum performance it is important that the High-Performance GigE Vision Driver from NI is installed in the installation of the NI software. Installation options dialog during the installation check that High-Performance GigE Vision Driver is selected (see Fig. 7.1).




Figure 7.1: Dialog to install NI High-Performance GigE Vision Driver

7.3 Network Adapter Configuration

Open the Network Connections window (Control Panel -> Network and Internet Connections -> Network Connections), right click on the name of the network adapter where the Photonfocus camera is connected and select Properties from the drop down menu that appears. A Properties window will open. Check the eBUS Universal Pro Driver (see Fig. 7.2) for maximal performance. Recommended settings for the Network Adapter Card are described in Section 1.3. Note that Jumbo Frames size setting is not available in the National Instruments Network Adapter Driver. The driver takes care of an optimal setting of this setting.




Figure 7.2: Local Area Connection Properties

7.4 Getting started

This section describes how to connect to the Photonfocus GigE camera and how to modify parameters and to grab images using the Measurement & Automation tool.

1. Open the Measurement & Automation tool (Start -> National Instruments -> Measurement & Automation).
2. If the camera has a valid IP it should be listed in the list of NI-IMAQdx Devices (see Fig. 7.3). The GUI tools from NI provide only limited access to the camera's IP properties. The M&A tool will not find the camera if the camera's IP does not match the IP range of the network card. If the camera doesn't appear in the list, then it is recommended to install the Pleora eBUS package that can be downloaded from Photonfocus (see also the Photonfocus GigE Manual MAN049). In the GEVPlayer included in the eBUS package, a valid IP address can be given for unreachable cameras.



The IP address for your camera and the IP address for the network adapter to which the camera is connected must be in the same subnet. The camera and the network adapter to which the camera is connected must also both have the same subnet mask.




Figure 7.3: M&A GigEVision device list

3. Clicking on the camera icon (cam0 in Fig. 7.3) opens the dialog to modify parameters and grab images (see Fig. 7.4). All camera parameters can be modified in the Camera Attributes tab. The parameter display can be configured in View Options. To modify the exposure time for example, expand the AcquisitionControl category and modify the ExposureTime value. Click on Save button to apply setting to camera.



Parameters are applied to the camera only after clicking on the Save button.




Figure 7.4: M&A camera dialog

4. Click on the Grab button to grab images.



Photonfocus DR1 cameras only: The demodulation of images grabbed with double rate enabled (`DoubleRate_Enable=True`) is not supported in the M&A GUI. To view unmodulated images in M&A, the property `DoubleRate_Enable` (category `DoubleRate`) must be set to `False` in the Feature Browser. In this mode however, the frame rate is about half compared to the double rate mode. To use the double rate mode, the National Instrument SDK and the `pfDoubleRate` DLL must be used.

Stemmer Common Vision Blox

8.1 Introduction

This chapter will help you getting started using a Photonfocus GigE camera with the Common Vision Blox (CVB) image processing framework from Stemmer. The procedures in this manual have been run with version 11.000.001-Win32, but it is recommended to install the latest version of the software.

8.2 Software Installation Tips

If you select the Custom setup type then make sure that GenICam and GEVServer (in Developer Resources -> Image Manager) are installed (see Fig. 8.1). In Full setup type the mentioned components are installed anyway.




Figure 8.1: CVB required features

8.3 Network Adapter Configuration

Open the Network Connections window (Control Panel -> Network and Internet Connections -> Network Connections), right click on the name of the network adapter where the Photonfocus camera is connected and select Properties from the drop down menu that appears. A Properties window will open. Check the siFilterIP GigE Vision Filter Driver (see Fig. 8.2) for maximal performance. Recommended settings for the Network Adapter Card are described in Section 1.3.




Figure 8.2: Local Area Connection Properties

8.4 Getting started

1. Open the Common Vision Blox Management Console (Start -> All Programs -> STEMMER IMAGING -> Common Vision Blox -> Common Vision Blox Management Console) and select the Device Configurator task in the GenICam group (see Fig. 8.3).




Figure 8.3: Common Vision Blox Management Console

2. Click on the Discover button in the Configured Devices tool bar (see Fig. 8.3) if your camera doesn't appear in the list. Click on the camera name in the Configured Devices list. Camera properties can be modified in the Properties tool section. E.g. To modify the exposure time, expand the Acquisition Control category by clicking on the (+) sign and modify the ExposureTime property by either entering a numerical value or by using the slider when clicking on the (...) button (see Fig. 8.3).
3. Images can be grabbed by checking the Grab check box in the Preview tool section.



Photonfocus DR1 cameras only: The demodulation of images grabbed with double rate enabled (`DoubleRate_Enable=True`) is not supported in the CVB GUI. To view unmodulated images in the CVB GUI, the property `DoubleRate_Enable` (category `DoubleRate`) must be set to `False` in the Feature Browser. In this mode however, the frame rate is about half compared to the double rate mode. To use the double rate mode, the CVB SDK and the `pfDoubleRate` DLL must be used.

Revision History

Revision	Date	Changes
1.0	November 2011	First version