

ARISTA

Safety and Compliance Guide

Arista Networks

www.aristanetworks.com

17 October 2013

Headquarters	Support	Sales
5453 Great America Parkway Santa Clara, CA 95054 USA		
408 547-5500	408 547-5502 866 476-0000	408 547-5501 866 497-0000
www.aristanetworks.com	support@aristanetworks.com	sales@aristanetworks.com

© Copyright 2013 Arista Networks, Inc. The information contained herein is subject to change without notice. Arista Networks and the Arista logo are trademarks of Arista Networks, Inc in the United States and other countries. Other product or service names may be trademarks or service marks of others.

Table of Contents

General Statement4
Electrical Warnings5
Facilities Warnings.....6
Installation, Service, and Disposal Warnings7
Standards and Conformity Compliance8
Battery and Laser Notices.9
EMC Class A Notices and Warnings.10

General Statement

Read Installation Instructions

Read the installation instructions before connecting the system to the power source.

Danger Symbol

This warning symbol means **Danger**

You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents.



Heat Warning Symbol

This warning symbol means **Caution – Hot Surface**

Avoid contact. Surfaces are hot and may cause personal injury if touched.



Hazardous Voltage Shock Warning Symbol

This warning symbol means **Caution – Hazardous Voltages are Present**

To reduce the risk of electric shock and danger to personal health, follow the instructions.



Electrical Warnings

Comply with Local and National Electrical Codes

Installation of the equipment must comply with local and national electrical codes.

This equipment must be grounded. Never defeat the Ground Conductor

This equipment must be grounded. Never defeat the ground conductor or operate the equipment in the absence of a suitably installed ground conductor. Contact the appropriate electrical inspection authority or an electrician if you are uncertain that suitable grounding is available.

Mains Disconnecting Device

For AC-powered systems the plug-socket combination must be accessible at all times, because it serves as the mains disconnecting device.

For DC-powered systems the circuit breakers or fuses on the DC power lines that service the DC circuits serve as the mains disconnecting device. Turn OFF the DC power line circuit breakers and remove the DC power line fuses to ensure that power is removed.

Multiple Power Supply Connections and Hazardous Voltage Warning

This unit might have more than one power supply connection. All power connections must be removed to de-energize the unit. Hazardous voltage or energy may be present on power terminals. Always replace covers over terminals prior to energizing the power circuits. Be sure uninsulated conductors are not accessible when cover is in place.

Short-Circuit Protection

This product requires branch-circuit overcurrent protection, to be provided as part of the building installation.

Activity During Lightning Events

Do not work on the system or connect or disconnect cables during periods of lightning activity.

Jewelry Removal Warning

Before working on equipment that is connected to power lines, remove jewelry (including rings, necklaces, and watches). Metal objects will heat up when connected to power and ground and can cause serious burns or weld the metal object to the terminals.

Power Cord Exclusivity

Any power cords provided by Arista are intended for use with Arista products only.

Facilities Warnings

Restricted Area Warning

This unit is intended for installation in restricted access areas. A restricted access area is where access can only be gained by service personnel through the use of a special tool, lock and key, or other means of security, and is controlled by the authority responsible for the location.

Stacking the Chassis Warning

Do not stack the chassis on any other equipment. The chassis can cause severe bodily injury and equipment damage if it falls.

High Temperature Warning

To prevent the switch from overheating, do not operate it in an area that exceeds the maximum recommended ambient temperature of 104°F (40°C). To prevent airflow restriction, allow at least 3 inches (7.6 cm) of clearance around the ventilation openings.

Installation, Service, and Disposal Warnings

Installation by Qualified Personnel Warning

Only trained and qualified service personnel (as defined in IEC 60950-1 and AS/NZS 60950) should install, replace, or service the equipment.

Chassis Warning for Rack-Mounting and Servicing

To prevent bodily injury when mounting or servicing this unit in a rack, you must take special precautions to ensure that the system remains stable. The following guidelines are provided to ensure your safety:

- This unit should be mounted at the bottom of the rack if it is the only unit in the rack.
- When mounting this unit in a partially filled rack, load the rack from the bottom to the top with the heaviest component at the bottom of the rack.
- If the rack is provided with stabilizing devices, install the stabilizers before mounting or servicing the unit in the rack.

Modular Systems Heavy Equipment Warning

Use mechanical assist to install heavy equipment. To prevent personal injury or damage to the chassis, never attempt to lift or tilt the chassis using the handles on modules (such as power supplies, fans, or cards); these types of handles are not designed to support the weight of the unit.

Product Disposal

Ultimate disposal of this product should be handled according to all local and national laws and regulations.

Establishing the Ground Connection When Installing or Replacing the Unit

When installing or replacing the unit, the ground connection must always be made first and disconnected last.

No User-Serviceable Parts Inside. Do Not Open Unit.

No user serviceable parts inside. Do not open unit. Refer all servicing to qualified service personnel.

Standards and Conformity Compliance

Declaration of Conformity

This equipment is in compliance with the requirements and provisions of Directives 2006/95/EC and 2004/108/EC.

To receive a copy of the latest Declarations of Conformity (DoC) for Arista products, refer to

<http://www.aristanetworks.com/en/support/docs>

California Perchlorate Contamination Prevention Act

(Title 22, California Code of Regulations, Chapter 33)

The battery inside this product might contain perchlorate, a known hazardous substance, so special handling and disposal of this product might be necessary. For more information about perchlorate and best management practices for perchlorate-containing substances, see

<http://www.dtsc.ca.gov/HazardousWaste/Perchlorate/index.cfm>

Battery and Laser Notices

Class 1 Laser Product

This product has provisions to install Class 1 laser transceivers that provide optical coupling to the communication network. Once a Class 1 laser product is installed, the equipment is a Class 1 Laser Product (Appareil à Laser de Classe 1). The customer is responsible for selecting and installing the Class 1 laser transceiver and for insuring that the Class 1 AEL (Allowable Emission Limit) per EN/IEC 60825-1, CSA E60825-1, and Code of Federal Regulations 21 CFR 1040 is not exceeded after the laser transceivers have been installed. Do not install laser products whose class rating is greater than 1. Refer to all safety instructions that accompanied the transceiver prior to installation. Only Class 1 laser devices certified for use in the country of installation by the cognizant agency are to be utilized in this product.

Laser Radiation

Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments.

Laser Beam Exposure

Avoid direct exposure to the laser beam.

Nordic Lithium Battery statement

Danger of explosion if battery is incorrectly replaced. Use the same type of battery or an equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

Norge

Litiumbatteri — Eksplosjonsfare. Ved utskifting benyttes kun batteri som anbefalt av apparatfabrikanten. Brukt batteri returneres apparatleverandøren.

Sverige

Varning! - Explosionsfara vid felaktigt batteribyte. Använd samma batterityp eller en ekvivalent typ som rekommenderas av apparattillverkaren. Kassera använt batteri enligt fabrikantens instruktion.

Danmark

Litiumbatteri — Eksplosionsfare ved fejlagtig håndtering. Udskiftning må kun ske med batteri af samme fabrikat og type. Levér det brugte batteri tilbage til leverandøren.

Suomi

Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan laitevalmistajan suosittelemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.

Nordic Grounded Socket Warning statement

Caution - This product must be connected to a grounded socket.

Norge

Litiumbatteri — Apparatet må tilkoples jordet stikkontakt.

Sverige

Varning! - Apparaten skall anslutas till jordat uttag.

Suomi

Laite on liitettävä suojamaadoituskoskettimilla varustettuun pistorasiaan.

EMC Class A Notices and Warnings

Class A Notice for FCC

Modifying the equipment without Arista's authorization may result in the equipment no longer complying with FCC requirements for Class A digital devices. In that event, your right to use the equipment may be limited by FCC regulations, and you may be required to correct any interference to radio or television communications at your own expense.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case users will be required to correct the interference at their own expense.

Class A Notice for Canada

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

VCCI Class A Warning for Japan

この装置は、クラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。 VCCI-A

Class A (Korean)

이 기기는 업무용 (A 급) 전자파 적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

사용자안내문

A 급 기기 (업무용 방송통신기자재)

이 기기는 업무용 (A 급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

Class A (Hebrew)

אזהרה

מוצר זה הוא מוצר Class A.

להידרש בסביבה ביתית, מוצר זה עלול לגרום הפרעות בתדר רדיו, ובמקרה זה, המשתמש עשוי לנקוט אמצעים מתאימים.