

LOOXCIE 2

User Manual for Android

Model: LX2



Thank You for Purchasing Looxcie

Please read this user manual carefully before using your Looxcie

Customer Support

Visit www.looxcie.com/support or call 1-855-LOOXCIE (566-9243) if you need technical support.

Register Your Looxcie

To receive important product updates, register your Looxcie at www.looxcie.com/support.

Join the Looxcie Community

- Become a Looxcie Facebook fan at facebook.com/looxcie.
- Follow @LooxcieCam on Twitter at twitter.com/looxciecam.
- Subscribe to the Looxcie YouTube channel at youtube.com/looxcie.

Contents

Looxcie Controls Overview	5	Creating Clips	21
Basic Looxcie Controls	6	Instantly Sharing Clips While Recording	23
Getting Started	7	Previewing Clips	24
Charging Your Looxcie	7	Sharing Clips	25
Downloading the Looxcie Companion Apps	8	Saving Clips to Your Mobile Device	26
Pairing Looxcie to Your Mobile Device	9	Editing Clip Titles	26
Adjusting Your Looxcie Fit	11	Deleting Clips	26
Why Fit Matters	11	Transferring Clips to Your Computer	27
Personalizing Your Looxcie Fit	11	Deleting All Clips	27
Recording with the LooxcieCam App	12	Previewing Captured Video	28
Recording Video with LooxcieCam	13	Deleting Captured Video	28
Previewing Your Clips	15	Sharing Settings	29
Saving Clips to Your Mobile Device	16	Using Looxcie as a Standalone Video Cam	31
Editing Clip Titles	16	Using the LooxcieDesktop Utility	32
Deleting Clips	16	Upgrading Your Looxcie Firmware	32
Recording with the LooxcieMoments App	17	Saving Clips to Your Computer	33
Recording Video with LooxcieMoments	18	Changing Device Mode and Recording Quality	34
Recording Quality	20	Using Looxcie as a Bluetooth Headset	35
		Looxcie Specifications	36

What's Inside the Box

Package Contents

Looxcie 2

Record and share life's special moments.

Earbuds

Select the best size earbud for your ear. Try various fit combinations with the earloops.

Earloops

Select the best size earloop for your ear. Insert the end of the earloop into the earloop base to wear on your ear.



USB Cable

Plug into a computer or power adapter (not included in box) to charge Looxcie. Power off Looxcie prior to charging.

Looxcie Controls Overview



Basic Looxcie Controls



Power switch

Slide to power on/off.
(Shows green when switched on.)



Record button

Press to start/stop recording.



Instant Clip button

- Press and release to create an Instant Clip.
- Press and **hold for approximately 2 seconds** to create and send an Instant Clip to your instant share favorite.

Go to Settings in the LooxcieMoments app to set up instant sharing.



Call button

- Press to answer/end a phone call.
- Double press to voice dial (if supported by your mobile phone).
- Press and **hold for approximately 3 seconds** (listen for tone) to adjust volume.

Getting Started

Using your new Looxcie 2

Charging Your Looxcie

Charge your Looxcie for 2 hours before using it the first time.

Using a Computer or Power Adapter

- Power off Looxcie prior to charging.
- Plug one end of the USB Cable into the USB Port on Looxcie, and the other end into a computer USB Port or a power adapter.

Note: Average charging time is around 3 -4 hours.

Power adapter sold separately on www.looxcie.com.



USB Port



Status light (green)

- Flashes green while charging.
- Stays green once the battery is fully charged.
- Blinks green when Looxcie is powered on.



Record light (red)

Glows red while recording.

Downloading the Looxcie Companion Apps

Use the Looxcie companion apps to preview, edit, and share your video clips.

Download the LooxcieCam and LooxcieMoments apps from the Android Market onto your mobile device.



Download apps from Android Market



LooxcieCam



LooxcieMoments

Pairing Looxcie to Your Mobile Device

Before pairing, make sure Looxcie is fully charged. Pairing Looxcie to your mobile device connects the companion apps with your Looxcie.

1 Turn on Bluetooth (on your mobile device)

- Turn on your mobile device's Bluetooth (under your mobile device's Settings).

2 Activate pairing mode (on your Looxcie)

- Power on Looxcie by sliding the Power switch on. (The green Status light turns on.)
- If the green Status light and red Record light are both flashing, pairing mode is active. (Go to step 3 on next page.)
- If the green Status light and red Record light are not both flashing, activate pairing mode manually: Slide the Power switch off. Then press and hold the Call button as you slide the Power switch on. (Both lights will flash.)



Status light (green)



Record light (red)



Power switch



Call button



Turn on Bluetooth

3 Select Looxcie from the Bluetooth device list

- Select **Looxcie** from the Bluetooth device list.


When paired successfully, Looxcie appears in your mobile device's Bluetooth device list as Connected. (The red Record light will turn off and the green Status light will blink.)

Tip: Check your mobile device's user manual for more information on pairing Bluetooth devices.

Help Me Pair

When the LooxcieMoments and LooxcieCam apps are launched, the Help Me Pair screen will appear if Looxcie is not paired to your mobile device. If you want help pairing:

- Tap **Help Me Pair**.
- Follow the three steps on the next two screens to pair Looxcie to your mobile device.
- Tap **Done** to exit the screen.



Bluetooth device list



Help Me Pair screen

Adjusting Your Looxcie Fit

Personalize the fit of your Looxcie so that it is stable and level on your ear

Personalizing Your Looxcie Fit



1 Find the correct fit for your ear

- Select the best earbud and earloop size for your ear (try various combinations).
- Insert the end of the earloop into the earloop base to fit on left/right ear.



2 Place Looxcie on your ear

- Rotate the earloop away from the earbud and toward your face to slip over your ear.
- Make sure the loop of the earbud is angled upward slightly.
- Fit the earbud in your ear with the loop of the earbud resting on your outer ear.

Note: Looxcie will auto rotate the video image to the correct position for recording on either ear.



3 Secure the fit and level the video image

Hold and slide the Boom along the earloop to secure the fit on your ear and level the video image.

Tip: Use the LooxcieCam or LooxcieMoments viewfinder screen to help level and rotate the boom to level the video image.


Why Fit Matters

Every ear is different in shape and size - when Looxcie fits correctly, it should point in the direction of where you're looking.

For more help adjusting your Looxcie fit, see the Fit Video online at: www.looxcie.com.


Recording with the LooxcieCam App

LooxcieCam turns your Looxcie into a basic camcorder that records full motion 480p video



LooxcieCam Camcorder screen

LooxcieCam app menu



Use LooxcieCam with your Looxcie to:

- Record 1 hour of 30 fps video in full 480p
- Use your mobile device as a viewfinder
- Transfer and save recorded video to your mobile device or computer by connecting Looxcie via USB

Note: Looxcie must be connected to your mobile device to use the LooxcieCam app functions.

Recording Video with LooxcieCam

To start recording:

- Launch the LooxcieCam app on your mobile device.
- Press and release either the physical Record button on Looxcie or tap the  button on the Camcorder screen.

Note: When Looxcie starts recording, you will see the solid red  button and a flashing red “Rec” symbol appear on the Camcorder screen.

To stop recording:

- Press and release either the physical Record button on Looxcie or tap the  button on the Camcorder screen.

Note: When Looxcie stops recording, it automatically saves your video as a clip.

Tip: The timer on the Camcorder screen shows the number of recordable minutes left.


Level the video image

Go to page 11 to learn how to level the video image.

Tip: Rotate the Camcorder screen to view the video image in either landscape or portrait format.



Record button



Camcorder screen

Changing the light mode

Looxcie automatically adjusts for different light levels.

To adjust the light mode manually:

- Tap the  button on the Camcorder screen.
- Tap on the light mode you want to record with.


Note: When you power off Looxcie, the light mode will default back to Auto.



Tones you might hear while recording

Power On	4 rising tones
Power Off	4 falling tones
Low Battery	2 low tones
Out of Range	3 falling tones
Bluetooth Connected	3 rising tones
Bluetooth Disconnected	3 falling tones
Answer Call	2 rising tones
End Call	2 falling tones
Instant Clip	Multiple tones
Instant Clip and Share	Multiple tones in long sequence
Start Recording	2 slow rising tones
Stop Recording	2 slow falling tones

Battery Indicator



Previewing Your Clips

Clips created in LooxcieMoments will also appear on the Clips screen. Clips are listed in chronological order with the most recent clip listed first.


Note: The **480p** symbol appears on clips created in LooxcieCam or LooxcieMoments (Highest Quality).

To preview clips:


- Tap **Clips** on the LooxcieCam app menu.
- Tap the clip you want to preview.
- Tap the ▶ button on the Clip Details screen to play the clip.

Note: When you preview clips on your mobile device, the playback will be choppy due to limited Bluetooth speed between Looxcie and your mobile device.

Tip: Save the clips to your mobile device, or connect and save to your computer for high-quality playback.



Clips screen



Clips Details screen

Saving Clips to Your Mobile Device

- Tap **Clips** on the LooxcieCam app menu.
- Tap the clip you want to save.
- Tap **Save** on the Clip Details screen.


Note: Depending on the clip size, saving may take several minutes to hours, due to the limited Bluetooth speed between Looxcie and your mobile device. If your clip is too large to save, transfer the clip to your computer by connecting Looxcie via USB to your computer.

Editing Clip Titles


- Tap **Clips** on the LooxcieCam app menu.
- Tap the clip you want to edit.
- Tap **Edit** on the Clip Details screen.
- Tap **Save**.

Deleting Clips

- Tap **Clips** on the LooxcieCam app menu.
- Tap the clip you want to delete.
- Tap **Delete** on the Clip Details screen.
- Tap **Delete** to confirm you want to delete the clip.




Clips screen



Clip Details screen


Recording with the LooxcieMoments App

LooxcieMoments turns your Looxcie into an “always on” video cam ready to instantly share



LooxcieMoments
Viewfinder screen

LooxcieMoments app menu



See what you're
recording

Preview clips
you've created

View captured
video and create
New Clips

Settings for
Recording Quality
and Sharing



Use LooxcieMoments with your Looxcie to:

- Capture up to 5 or up to 10 hours* of continuous looping video
- Create 30-second Instant Clips or custom length New Clips from captured video
- Save hundreds of clips
- Instantly share clips to social networks

Note: Looxcie must be connected to your mobile device to use the LooxcieMoments app functions.

*Varies based on Looxcie model

Recording Video with LooxcieMoments

To start recording:

- Launch the LooxcieMoments app on your mobile device.
- Press and release either the physical Record button on Looxcie or tap the  button on the Viewfinder screen.

Note: When Looxcie starts recording, you will see the solid red  button on the Viewfinder screen.

To stop recording:

- Press and release either the physical Record button on Looxcie or tap the  button on the Viewfinder screen.

Note: When Looxcie stops recording, it automatically saves the captured video on your Looxcie.


Leveling the video image

Go to page 11 to learn how to level the video image.

Tip: Rotate the Viewfinder screen to view the video image in either landscape or portrait format.



Record button



Viewfinder screen

Changing the light mode

Looxcie automatically adjusts for different light levels.

To adjust the light mode manually:

- Tap the  button on the Viewfinder screen.
- Tap on the light mode you want to record with.


Note: When you power off Looxcie, the light mode will default back to Auto.



Tones you might hear while recording

Power On	4 rising tones
Power Off	4 falling tones
Low Battery	2 low tones
Out of Range	3 falling tones
Bluetooth Connected	3 rising tones
Bluetooth Disconnected	3 falling tones
Answer Call	2 rising tones
End Call	2 falling tones
Instant Clip	Multiple tones
Instant Clip and Share	Multiple tones in long sequence
Start Recording	2 slow rising tones
Stop Recording	2 slow falling tones

Battery Indicator



Recording Quality

Record with LooxcieMoments in either Mobile Sharing (320p) or Highest Quality (480p).

- Use Mobile Sharing (320p) for faster uploading to social networks.
- Use Highest Quality (480p) for higher resolution recording.

Mobile Sharing (320p)

- Record up to 5 or up to 10 hours* of continuous looping capture in 320p
- Save 500+ clips from captured video
- Instantly share clips via mobile device with social networks

Highest Quality (480p)


- Record up to 1.5 or up to 3 hours* of continuous looping capture in 480p
- Save 100+ clips from captured video
- Share clips via computer with social networks

*Varies based on Looxcie model

Changing recording quality

- Tap **Settings** on the LooxcieMoments app menu.
- Tap **Recording Quality**.
- Tap the recording quality you want to record with.

Tip: When you're ready to record, quit the app and place your mobile device in screen saver mode to conserve its battery. Looxcie will continue to record looping video without the app connected to it.



Recording Quality screen

Creating Clips

Create clips in two ways:

- Press and release the Instant Clip button on Looxcie to create 30 second Instant Clips.
- Tap **Video** on the app menu to create custom length New Clips.

Creating Instant Clips from your Looxcie

To create an Instant Clip of the last 30 seconds of captured video:

- Press and release the Instant Clip button. (You will hear multiple tones.)

Note: The “Clip created” message will appear on the app screen.

Tip: Press and hold the Instant Clip button for approximately 2 seconds to create and send an Instant Clip to your instant share favorite. Go to page 23 to learn more.

Creating New Clips from your mobile device


To create a custom length New Clip of up to 30 minutes from the captured video:

- Tap **Video** on the LooxcieMoments app menu.
- Tap **New Clip**.




Instant Clip button

Press and release to create a clip of the last 30 seconds of video




Video screen

New Clip




Set the start of your clip

- Drag the pointer along the video scrollbar or use the video controls to set the start of the clip.
- Tap **Set Start**. The Start Clip icon  marks the start of your new video clip.



Set the end of your clip

- Drag the pointer along the video scrollbar or use the video controls to set the end of the clip.
- Tap **Set End**. The End Clip icon  marks the end of your new video clip.



Save and title your clip

- Tap **Save**. The Edit Title screen will appear.
- Type a new title and tap **Save** or just tap **Save** to create a default title (time and date video created).
- Tap **View Clip** to preview your new clip or tap **Back to Video** to return to the video screen.

Note: Edit the title of a clip by tapping **Edit** on the Clip Details screen.

Instantly Sharing Clips While Recording

To instantly share clips, first set up your instant share favorite under Settings. Go to page 29 to learn how.


To share an Instant Clip to your instant share favorite:

- Press and hold the Instant Clip button for approximately 2 seconds. (You will hear multiple tones in a long sequence.)

Note: The “Sharing clip” message will appear on the app screen while the clip downloads from Looxcie and sends to your instant share favorite.



Instant Clip button



Sharing Settings screen

Previewing Clips

Clips created in LooxcieCam will also appear on the Clips screen. Clips are listed in chronological order with the most recent clip listed first.


Note: The **480p** symbol appears on clips created in LooxcieCam or LooxcieMoments (Highest Quality).

To preview clips:


- Tap **Clips** on the LooxcieMoments app menu.
- Tap the clip you want to preview.
- Tap the ▶ button on the Clip Details screen to play the clip.

Note: When you preview clips on your mobile device, the playback will be choppy due to limited Bluetooth speed between Looxcie and your mobile device.

Tip: Save the clips to your mobile device or connect and save to your computer for high quality playback.



Clips screen



Clips Details screen

Sharing Clips

To share clips, first set up your sharing favorites under Settings. Go to page 29 to learn how.

- Tap **Clips** on the LooxcieMoments app menu.
- Tap the clip you want to share.
- Tap **Share** on the Clip Details screen.
- Tap on the sharing favorite to which you want to send the clip.

Note: The “Sharing clip” message will appear on the app screen while the clip downloads from Looxcie and sends to the sharing favorite you selected. Depending on the clip size, sharing may take awhile and limit your use of the app. Recording will not be interrupted.


Clips waiting to be shared

If your mobile device loses its network connection, the app will queue clips marked for sharing and send them later, when your network connection is restored.


Clip too large

If your clip is too large to share, transfer the clips to your computer by connecting Looxcie via USB to your computer.

Go to page 27 to learn how to transfer clips to your computer.



Sharing Settings screen



Clip Details screen

Saving Clips to Your Mobile Device

- Tap **Clips** on the LooxcieMoments app menu.
- Tap the clip you want to save.
- Tap **Save** on the Clip Details screen.


Note: Depending on the clip size, saving may take several minutes to hours, due to the limited Bluetooth speed between Looxcie and your mobile device. If your clip is too large to save, transfer the clip to your computer by connecting Looxcie via USB to your computer.

Editing Clip Titles


- Tap **Clips** on the LooxcieMoments app menu.
- Tap the clip you want to edit.
- Tap **Edit** on the Clip Details screen.
- Tap **Save**.

Deleting Clips

- Tap **Clips** on the LooxcieMoments app menu.
- Tap the clip you want to delete.
- Tap **Delete** on the Clip Details screen.
- Tap **Delete** to confirm you want to delete the clip.



Clips screen



Clip Details screen

Transferring Clips to Your Computer


Plug one end of the USB Cable into the USB Port on Looxcie and the other into the USB Port on your computer.

Save clips to your computer in two ways:


- Use the LooxcieDesktop utility to save clips to your computer. Go to page 32 to learn how.
- Use Looxcie as a storage drive to drag-and-drop your saved clips onto your computer.

Deleting All Clips

- Tap **Clips** on the LooxcieMoments app menu.
- Press the Menu button on your mobile device.
- Tap **Delete All Clips**.
- Tap **Delete** to confirm you want to delete all clips.



Clips screen



Delete All Clips

Previewing Captured Video

- Tap **Video** on the LooxcieMoments app menu.
- Drag the pointer along the video scrollbar or use the video controls to rewind, fast forward, pause, or play the video.
- To show or hide the video controls, simply tap the screen.

The date and time stamp shows when the video was taken.


Note: When you preview captured video on your mobile device, the playback will be choppy due to limited Bluetooth speed between Looxcie and your mobile device.

Tip: Connect Looxcie to your computer via USB to transfer and save your captured video into 30-minute sized clips for high quality playback.


Deleting Captured Video

- Tap **Video** on the LooxcieMoments app menu.
- Press the Menu button on your mobile device.
- Tap **Delete All Video**.
- Tap **Delete** to confirm you want to delete all video.

Note: When you delete all video, the clips you have created will not be deleted.



Video screen



Delete All Video

Sharing Settings

Set up your email account

Enter the email address and password for the account you want to send Looxcie clips from. Emailed clips will indicate this email account as the clip sender.

- Tap **Settings** on the LooxcieMoments app menu.
- Tap “Your email account”.
- Enter your email address and password.
- Tap **Save**.

Set up your sharing favorites

Add social sites, like Facebook, Twitter, or YouTube, to your sharing favorites.


- Tap **Settings** on the LooxcieMoments app menu. Tap **Sharing**.
- Tap **Add a favorite**.
- Enter your personal upload email address. Tap **Save**.

Note: Go to page 30 to learn how to find your personal upload email address for each social site.

Set up your instant share favorite

Tap the  button next to the sharing favorite you want to set up as your instant share favorite.

Note: Instant Clips will be sent to this sharing favorite when you press and hold the Instant Clip button.



Adding social sites to your sharing favorites

To add Facebook, Twitter, or YouTube to your sharing favorites, visit each site to find your personal video upload email address.

Facebook

- Go to www.facebook.com/video/?upload and sign in.
- Choose **Mobile Video** from the menu.
- Find your personal upload email address in the blue box.

Twitvid (for Twitter or Facebook)

- Go to www.twitvid.com/index.php?area=upload and sign in.
- Find your personal upload email address in the "Email or MMS your video to" box.

YouTube

- Go to www.youtube.com/account#mobile and sign in.
- Choose **Mobile Setup** from the menu.
- Find your personal upload email address in the blue box.

Using Looxcie as a Standalone Video Cam

Recording with Looxcie as a “standalone” video cam

- Fit Looxcie on your ear, and adjust the boom along the earloop to level the video image. (Use a mirror for help.)
- Power on Looxcie by sliding the Power switch on. (The green Status light turns on.)
- Press and release the Record button on Looxcie to start/stop recording.
- Connect Looxcie to your computer via USB to transfer and archive clips and video.

Note: Use the LooxcieDesktop* utility to change the device mode & recording quality on your Looxcie.

Tip: In LooxcieMoments mode, you can create Instant Clips by pressing and releasing the Instant Clip button.

*LooxcieDesktop does not perform the same functions as, nor is it a desktop version of the LooxcieCam or LooxcieMoments mobile apps.



Adjust boom along earloop



Power switch



Record button

Using the LooxcieDesktop Utility

Get the most out of your Looxcie experience

LooxcieDesktop is a utility that installs on your Windows or Mac computer and extends your Looxcie experience.

Use the LooxcieDesktop Utility with your Looxcie to:

- Update your Looxcie firmware with new features when available.
- Transfer and archive clips for easy editing and backup.
- Switch between LooxcieCam and LooxcieMoments mode on your Looxcie.

Note: LooxcieDesktop does not perform the same functions as, nor is it a desktop version of the LooxcieCam or LooxcieMoments mobile apps.

Updating Your Looxcie Firmware

- Visit www.looxcie.com to install LooxcieDesktop on your computer.
- Connect your Looxcie to your computer using the USB cable.
- Launch the LooxcieDesktop utility on your computer.
- Check for updates and follow the easy instructions on the LooxcieDesktop screen.



LooxcieDesktop screen

Saving Clips to Your Computer


- Launch the LooxcieDesktop utility on your computer.
- Click **Save** on the LooxcieDesktop screen.
- Select from the following two options:

Copy existing clips from your Looxcie: Choose this option to save all clips created from the Looxcie companion apps to your computer.

Copy captured video from your Looxcie into 30-minute sized clips: Choose this option to archive 30-minute sized clips of all the captured video recorded in LooxcieMoments.

Note: Use the Looxcie companion apps to delete clips and video on your Looxcie.

Tip: You can view/edit saved clips with any MP4 media player/video editor.



Save screen

Changing Device Mode & Recording Quality on Your Looxcie

- Launch the LooxcieDesktop utility on your computer.
- Click **Settings** on the LooxcieDesktop screen.
- Select from the following three options:

LooxcieCam Highest Quality (480p):


Choose this option to turn your Looxcie into a basic camcorder that records full motion 480p video.

LooxcieMoments Sharing (320p):

Choose this option to turn your Looxcie into an “always on” video cam that records looping video optimized for faster uploading to social networks.

LooxcieMoments Highest Quality (480p):

Choose this option to turn your Looxcie into an “always on” video cam that records looping video optimized for higher resolution recording.



Settings screen

Using Looxcie as a Bluetooth Headset

Pair Looxcie to your mobile device to use Looxcie as a Bluetooth headset

Go to page 9 to learn how to pair Looxcie to your mobile device.

Call Button

Answer/End Calls

Press the Call button on Looxcie or use your mobile device to answer/end a call (listen for 2 tones).

Make Calls

Dial the number on your mobile device and press **Send** (call transfers to Looxcie).

Voice Dial

Double press the Call button and begin speaking (if supported by your mobile device).

Adjust Volume

Press and hold the Call button for approximately 3 seconds (listen for tone). Repeat until you reach desired volume level or adjust the volume on your mobile device.



Call button

Looxcie Specifications

Wearable	Weighs 22g (less than 1 oz.)
Video	<p>With the LooxcieCam app or as a standalone device</p> <ul style="list-style-type: none">VGA, 30fps, 4000kbps bitrate1 hour of record time2 hours of battery life <p>With the LooxcieMoments app in 320p</p> <ul style="list-style-type: none">HVGA, 15fps, 800kbps bitrate5 or 10 hours* continuous, looping video capture (clip storage)4 hours of battery life (record time) <p>With the LooxcieMoments app in 480p</p> <ul style="list-style-type: none">VGA, 30fps, 4000kbps bitrate1.5 or 3 hours* continuous, looping video capture (clip storage)2 hours of battery life (record time) <p>f 2.8 lens</p> <p>62 degree field of view (FOV)</p> <p>Auto high color and light correction</p> <p>Codec: MPEG-4 video, AAC audio</p> <p>*Varies based on Looxcie model</p>
Battery	<p>Fast-charging 365mAh lithium polymer battery</p> <p>UL/CSA-approved power supply</p> <p>Up to 4 hours of record time*</p> <p>Up to 10 hours talk time*</p> <p>*Varies based on how you use your Looxcie</p>
Headset	<p>Bluetooth® Class 2</p> <p>Bluetooth® V2.1 + EDR</p> <p>Range to 33 feet</p>
Audio	DSP-based noise reduction
USB	<p>Micro USB Connector</p> <p>USB 2.0 mass storage compatibility</p>



Copyright © 2011 Looxcie, Inc.

All rights reserved. Looxcie and the Looxcie logo are trademarks or registered trademarks of Looxcie, Inc. US and international patents pending.

For more information, visit www.looxcie.com.

Looxcie Model: LX2