


TMR901 Series



Touch Memory Reader User's Manual

GIGA-TMS

REGISTERED TO ISO 9001:2000

8F, No.31, Lane 169, Kang-Ning St., Hsi-Chih Taipei Hsien, 221 Taiwan

TEL:(886) 2-2695-4214

FAX:(886) 2-2695-4213

www.gigatms.com.tw

Content

Information	3
Introduction	4
Specification	5
Accessory	6
Technical & Operational Description	7
Cable Pin Assignment & Connection	8
Connect to PC	9
Software Operation	10
Default Settings & Data Format	14
USB HID & USB CDC(Virtual Serial RS232)Interface	15
Installation	17

Information

1. TMR901 series models:

- TMR901U Touch Memory Button With USB HID Keyboard Interface Reader
- TMR901R Touch Memory Button With RS232 Interface Reader

2. Standard package includes:

- One TMR901 Touch Memory Button Reader
- One demo software & user manual disk.
- One accessories package.

3. Optional accessories (ordered separately)

- iButton tag

4. FCC Compliance:

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interfaces, and (2) this device must accept any interference received, including interference that may cause undesired operation.

5. Trademarks:

The following are the trademarks of Dallas Semiconductor Corporation:

Dallas

Dallas Semiconductor

Touch Memory Button

Touch Memory

Introduction

TMR901 is a device, that lets you read the Identification Code (sometimes referred to as an ID-code or Registration number) of Dallas Semiconductor's Touch Memory Buttons. The device is extremely simple to use: all you need to do is press the Touch Memory Button against the touch probe, located on top of the TMR901's housing. ID-code will then be read out, verified against possible read errors and output into your PC via USB interface.

TMR901 reads out and outputs touch-button's ID-code. After the read, you can compare the data send to your PC with the data engraved on the touch button's housing. Fig.1 shows the Touch Memory Button with the ID-code engraved on it. After the read, computer will receive a full 16-digit string, shown below the button.



Fig1. Touch Memory Button from Dallas Semiconductor and it'sunique 16-character registration number.

Each of the 16 characters can be a digit from 0 to 9 or a capital letter from A to F. The ID-code of any Touch Memory Buttons is absolutely unique. Dallas Semiconductor guarantees that no two Touch Memory Buttons will ever be manufactured with the same ID-code. Thus, the Buttons can be used for various automated password entry and in other areas requiring a unique code.

In fact, the 16-character ID-code consists of 3 fields:

Family code	Dallas Semiconductor manufactures more than dozen different Touch Memory models. Each model has a unique family code.
Serial number	This serial number is unique for each and any member of the device family.
CRC	2 control characters, used to verify the correctness of the data.

All together Unique 16-characters serial number

All Dallas Semiconductor's Touch Memories, regardless of their type and function have this unique registration number and utilize one single standard protocol for registration number readout. Therefore, you can use the TMR901 to read the registration number of any existing Touch Button.


The TMR901 also allows the user to customize the ID-code output format by programming a Prefix and Postfix strings as well as several other options. For more details refer to the "Programming" section of this Manual.

Specification


Reading capabilities	Read the ID code of all Touch Buttons conforming to Dallas Semiconductor 1-wire protocol. (*)
PC interface	USB HID Keyboard interface for TMR901U RS232 Interface for TMR901R
Power supply	5V through USB port for TMR901U 5V through RS232 cable DC Jack
Power consumption	90mA max
Certificate	CE、FCC
Dimension	45(L) x 40(W) x 28(H) mm
Weight	75g
Operating Temp	-10 to 60 Deg C
Storage Temp	-20 to 65 Deg C
Humidity	10 ~ 90%

- as described in Dallas semiconductor's "Book of Touch Memory Standards".


Accessory




**Main Unit
(TMR901)**



**Software and manual
(DISK5413)**




Accessories package



**iButton Tag
(Option)**

Technical & Operational Description



TMR901 Touch Memory Reader

Located on the upper cover is the touch port. To read the Touch Memory Button, just press it firmly against the touch port.

There is also a 3-color (red, green and orange) status LED. When TMR901 is powered up but no Touch Memory Button is being read, the green light is on. When normal Touch Memory Button read is in progress, the orange light is on.

Status

Status	Green LED	Red LED	Buzzer	Read iButton Tag
Power ON	ON	ON	ON*	X
Ready	OFF	ON	OFF	O
Touch the Tag to the touch port	ON	ON	ON*	O*
Remove the Tag from the touch port	ON	ON	ON*	O*
Firmware Management Mode	OFF	ON	OFF	X

- means this function can control for iButton configure software.

Cable Pin Assignment & Connection


USB :

USB PIN Assignment	Discription
PIN1	VDD
PIN2	D -
PIN3	D+
PIN4	GND


RS232 :

RS232 PIN Assignment	Discription
PIN2	TX
PIN3	RX
DC JACK+	VDD
PIN5 & DC JACK-	GND

Connect to PC




Plug the USB cable of TMR901 to any USB port of your PC. Then go to [Control Panel]\ [System]\ [Hardware]\ [Device Manager]\ [Human Interface Devices], and see if “HID-compliant device” appears. If “HID-compliant device” appears, it indicates TMR901U has been detected by your computer.



Software Operation


Connect TMR901 with PC through USB port , then run the demo software “iButton configure”.(You can find the software in Disk5413)

Step 1: Main page




Step 2: Scan for HID Interface

Select “ HID Port “ and click ”SCAN” to communicate TMR901 with PC. The software will detect TMR901 and related setting. If the communication is successful, it will show”Found TMR901” and product information as below :




Scan for RS232 Interface

Select “ COMx Port “ and click ”SCAN” to communicate TMR901 with PC. The software will detect TMR901 and related setting. If the communication is successful, it will show”Found TMR901” and product information as below :




Step 3: General Settings for HID Interface

Click “General” to set “Buzzer (On or Off)”, “Language (Keyboard type)”. If necessary. Then click “Write” to save the settings to TMR901U.




General Settings for RS232(UART) Interface

Click “General” to set “Buzzer (On or Off)”, “Language (Keyboard type)”. If necessary. Then click “Write” to save the settings to TMR901R.



Click “RS232(UART)” to set “Baudrate”




Step 4: iButton Settings

Select “iButton” to set different iButton formats for data output after reading.

- Set the ID start / length of data information.
- Choose the Prefix / Postfix output data.
- Choose the Delimiter output parameter.
- Choose the iButton tag on remove output parameter..

The click “Write” to save the settings to TMR901.



Save : Click “Save” to save all settings as *.cfg file.

Open : If you want to download the settings form the file, click “Open” to open the file and click “Write” to download the settings.

Read : If you want to know the setting of TMR901, click ”Read” and download the file to show it on display area.

Write : If you want to set new settings , click “Writer” to download the settings for TMR901.

Default : Click “Default” to reset TMR901 and get default setting if necessary. Default values are as below (red –lined area).

Test Mode : Click “Test Mode” to into the test function window.

Cache Mode : Cache TMR901 settings for iButton configure software.

Exit : Click “Exit” to close iButton configure software.

Default Settings

Buzzer	On
Language	USA
ID format	Family + ID + CRC
iButton	Enable
iButton Sound	Enable
ID Start	1
ID Length	16
Prefix	Empty
Postfix	Empty
OnRemove	Empty
Package Delimiter	Data+CR+LF
Check Mode	Check without FS&FE
Baudrate	9600 , N , 8 , 1 for RS232(UART) Interface

Data Format


Pack FS
iButton Present / Release Sentinel
iButton Prefix
iButton Data
iButton Suffix
Delimiter
Pack FE

Switching the interface type (USB model only!) between USB HID (Keyboard Emulation) Interface & USB CDC (Virtual Serial RS232) Interface


The default interface of TMR901U is USB HID (Human Interface Device). It also allows you to use iButton Configure software to set the interface of TMR901U to USB CDC (Communications Device Class also known as “ Serial RS232”). Please refer to the following steps.

Note : Please install USB-CDC (USB to RS232) driver in your PC in advance. For installation details, please refer it to the file "USB-CDC Driver Installation_TM970131" inside the disk.

STEP 1. Select “ Interface “.




STEP 2. Choose “USB CDC(Serial Port)” and then click “ write “ to save the settings to TMR901U.




STEP 3. Reboot TMR901U and restart iButton Configure software.

STEP 4. Set “ Baudrate “(default is 9600).



STEP 5. Set Output format and then click “ Write “ to save the settings to TMR901U .



STEP 6. Click “ Exit “ to close the software.

Installation

