

**Lumintrek TrailBlazer** 

**LED Bicycle Light User Manual** 

Model: TB-1000

#### 1. READ BEFORE USE!

Please read this user manual to completely familiarize yourself with this product. Make sure you understand all functions before hitting the trails.

Cycling in the dark is dangerous inherently. Always make sure the light is firmly secured and the battery is fully charged before you go for a ride. Like all other electronic devices, the light can fail at any unexpected time. It is advised to always keep a backup light and battery pack with you whenever you go on an extended ride. Please note that your Lumintrek light is very bright! Never aim it directly at any oncoming motorists/cyclists.

Your Lumintrek bicycle light is equipped with a high capacity Lithium-ion battery pack. Please fully charge the battery before first use of the light. While the battery pack is double protected, you should always observe the following:


- While charging the batteries, never leave it unattended for a long time.
- Only use the Lumintrek charger to charge the batteries. Using other chargers to charge Lumintrek batteries may cause battery failure and/or other serious damage.

Your Lumintrek bicycle light uses high power LEDs which, especially in turbo/high mode, generate a significant amount of heat. The aluminum light-head is designed to draw most of the excess heat away. The light head may get extremely hot during this process if sufficient air flow is not provided. Please use with caution.


### 2. Charging the battery pack

The battery pack is shipped half charged. You need to fully charge it before first use.

Connect the battery to the charger- the charger LED will turn Green.




• Plug the charger into the power outlet – the charger LED will turn Red indicating that the battery is charging. A full charge from empty will take approximately 4 hours.



 Once fully charged the LED will turn Green. Unplug the charger and disconnect the battery.

# 3. Handle Bar Mounting

• Insert the O-ring into the hook on the front of the light head. You must stretch the O-ring slightly which makes it thinner and then it slips into place easily.



 Place the light head on the handlebars and stretch the O-ring around the bottom of the handle bar. Clip it onto the hook at the rear of the light head. Various O-ring sizes are provided; Use the one which provides the best fit depending on the size of your handle bars.



• Find the most suitable place for mounting the battery. If you have a long enough stem, this is the best place to put it; otherwise you can mount it to your bike frame or handlebars (Opposite side to where the light is).



- Estimate how much cable length you will require and then fold up the excess cable.
- Wrap the Velcro strap around the stem/frame/handle bars, at the same time stuffing the excess cable into the pouch.



• Plug the light cable into the battery cable.



# 4. Helmet mounting

- Attach the helmet bracket to your helmet by feeding the Velcro straps through your helmets air vents. You can cut the straps shorter if needed.
- Insert the O –ring into the hook on the front of the light head.
- Place the light head on the helmet mount bracket and stretch the O-ring around the underneath. Clip it onto the clip at the rear of the light head.

 Guide the cable through one of your helmet straps or Velcro it to the back of your helmet in order to ensure that the cable doesn't snag on a low hanging branch or dangle down in front of your face while you are riding.



- Place the battery in a convenient location. Here are some suggestions:
  - --in your shirt pocket
  - --Inside your hydration pack
  - --Attached to the shoulder strap of your hydration pack
- Plug the light cable into the battery cable.

## 5. Operating Lumintrek TB-1000 Trailblazer light

• The switch is illuminated while plugged in which makes it easy to locate in the dark.



- The light starts in the OFF mode.
- Push the switch button for High, Medium, Low



- Push and hold the switch button for two seconds (from any setting) to turn the light OFF.
- Push and hold the switch button for four seconds to enter into the STROBE mode.

### 6. Battery Level Indicator

The Lumintrek TB-1000 Trailblazer comes with a 4 stage power meter. As the battery depletes, the backlit switch button will change color from Green-Blue -Red-Flashing Red.

• Green 100%-75%

• Blue 75%-30%

• Red 30%-5%

• Flashing Red < 5%

### 7. Battery Storage

Disconnect the battery pack from the light head when not using. Store the battery pack fully charged and re-charge it before using the lighting system again. If not used for an extended period of time, please store the battery pack in a cool dry place to avoid excessive discharge.

## 8. Troubleshooting

Failure	Caused	Solution
No light	Battery is over discharged	Charge the battery
	Battery is not plugged in	Make sure all parts are firmly
	correctly	connected
Running time too short	Battery is not fully charged	Charge the battery
	New battery	Charge the battery
	Very old battery	Replace the battery
	Cold temperature	Keep the battery warm
	Defective charger	Replace the charger
Flicker	Cables not secured	Make sure all parts are firmly
		connected

### 9. Warranty

Lumintrek warrants its products to be free from defects that compromise their functionality. We will repair or replace, at our option, without charge, any product or part which is found to be defective under normal use and service within 5 years from the date of purchase with proof of purchase. Battery pack is warranted for 6 months from the date of purchase. Such repair or replacement shall be the purchaser's sole and exclusive remedy under this warranty.

This warranty does not cover normal maintenance and service and does not apply to any products or parts which have been subject to modification, misuse, abuse, negligence, accident, or improper maintenance or repair by anyone other than Lumintrek.

For repair or replacement contact Customer Service at 1-888-787-8168 (toll free), or email at customerservice@lumintrek.com, or visit http://www.lumintrek.com/warranty.

#### 10. Technical Data

LED: XML- T6

LED lifespan: above 50,000 hours

Max output: 1000 lumens Beam angle: 15 degree

Lens: Anti-reflection toughened optical glass lens, scratch resistant

Reflector: High efficiency orange peel reflector, excellent throw and side spill Modes: 3-level adjustable brightness, flashing and over-heat protection functions

Output levels: Max: 1000 lumens Medium: 580 lumens Low: 260 lumens

Runtime: Max: Nearly 4 hours Medium: 8 hours Low: 14 hours Flash: 10.5 hours.

Power indicator: 3-color/4-modes LED indicator to display battery capacity Battery capacity/Voltage: 5.2 Ah, 8.4V (4X18650 waterproof designed)

Charge time: 4 hours

Charger: 110 Volt to 240 Volt

Shell material: 6061-T6 Aluminum alloy

Surface treatment: Premium Type III hard-anodized anti-abrasive finish

Waterproof grade: IPVI

Weight: 130G without battery pack, 370G with battery pack

Package Includes: light head, battery pack, charger, helmet mount, extension cable, O-rings