

# Storage: Storage device with Ethernet interface Rev 4

Author: Alvin Cox, Seagate Technology LLC
Author: Asghar Riahi, Seagate Technology LLC
Author: Bryan Wyatt, Seagate Technology LLC

# 1 Scope

This specification defines the technical requirements for the storage device with Ethernet interface.

# 2 Contents

1	Scope.		2
2	Conten	ts	2
3	Figures		3
4	Tables		3
5	Overvie	2W	4
	5.1	Description	4
	5.2	License	4
6	Norma	tive references	5
7	Definiti	ons, symbols, abbreviations, key words	5
	7.1	Definitions	5
	7.2	Symbols and abbreviations	5
	7.3	Key words	5
	7.4	Editorial conventions	6
8	Mecha	nical characteristics	6
	8.1	Device and system connectors	6
9	Electric	al characteristics	10
	9.1	TX and RX signals	10
	9.2	I <sup>2</sup> C signals	10
	9.3	+5V and +12V	10
	9.4	PRESENCE DETECT (P1)	10
	9.5	VENDOR SPECIFIC (P11)	10
10	Etherne	et storage device I <sup>2</sup> C communication	10
	10.1	Overview	10
	10.2	Command formats	11
	10.3	Open Commands	13
	10.4	I2C implementation requirements	21
11	FAQ		23

12 Revision History	24
3 Figures	
Figure 1 Device Free (Plug) connector	7
Figure 2 2.5" hard disk drive with Ethernet interface plug connector	7
Figure 3 3.5" hard disk drive with Ethernet interface plug connector	8
Figure 4 System Backplane Fixed (Receptacle) connector	8
4 Tables	
Table 1 Connector signal assignments	9
Table 2 Open I2C commands for the storage device with Ethernet interface	13
Table 3 Get Device IP Address Parameter Byte Format	15
Table 4 Get IP Address Status Byte Format	15
Table 5 Get IP Address Returned Bytes Format	16
Table 6 Network Speed Integer Definition	16
Table 7 Network Speeds Available Bit Field	17
Table 8 Get Device Operating State Bit Description	17
Table 9 Get Write Status Info Byte Definition	18
Table 10 Set Device IP Address Config Byte Format	19
Table 11 Set Device IP Address Parameter Bytes Format	20
Table 12 Get Interface Link State Returned Bytes Format	21
Table 13 Get Data Protocol Version Protocol Enumeration	21



# 5 Overview

## 5.1 Description

The storage device with Ethernet interface provides a common configuration for the implementation of the Ethernet interface on a storage device. It is intended to support large configurations of storage devices in data center applications. Other applications may find the features of this device advantageous where communication to the device through the Ethernet interface is desired.

Some example implementations are documented in <Reference to the white paper>.

#### 5.2 License

As of December 20, 2013, the following persons or entities have made this Specification available under the Open Web Foundation Final Specification Agreement (OWFa 1.0), which is available at <a href="http://www.openwebfoundation.org/legal/the-owf-1-0-agreements/owfa-1-0">http://www.openwebfoundation.org/legal/the-owf-1-0-agreements/owfa-1-0</a>:

Seagate Technology LLC

You can review the signed copies of the Open Web Foundation Agreement Version 1.0 for this Specification at <a href="http://opencompute.org/licensing/">http://opencompute.org/licensing/</a>, which may also include additional parties to those listed above.

Your use of this Specification may be subject to other third party rights. THIS SPECIFICATION IS PROVIDED "AS IS." The contributors expressly disclaim any warranties (express, implied, or otherwise), including implied warranties of merchantability, non-infringement, fitness for a particular purpose, or title, related to the Specification. The entire risk as to implementing or otherwise using the Specification is assumed by the Specification implementer and user. IN NO EVENT WILL ANY PARTY BE LIABLE TO ANY OTHER PARTY FOR LOST PROFITS OR ANY FORM OF INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY CHARACTER FROM ANY CAUSES OF ACTION OF ANY KIND WITH RESPECT TO THIS SPECIFICATION OR ITS GOVERNING AGREEMENT, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), OR OTHERWISE, AND WHETHER OR NOT THE OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

# 6 Normative references

Referenced standards and specifications contain provisions that, by reference in the text, constitute provisions of this specification.

PC-bus specification and user manual, Rev. 5 — 9 October 2012
Serial-GMII Specification
RFC 2119, RFC Key Words
SFF-8201, 2.5" Drive Form Factor Drive Dimensions
SFF-8301, 3.5" Drive Form Factor Drive Dimendions
SFF-8223, 2.5" Drive Form Factor with Serial Connector
SFF-8323, 3.5" Drive Form Factor with Serial Connector
SFF-8482, Serial Attachment 2X Unshielded Connector
SFF-8680, Sorial Attachment 12 Gb/s 2X Unshielded Connector

SFF-8680, Serial Attachment 12 Gb/s 2X Unshielded Connector

# SFF-9639, Multifunction 12 Gb/s 6X Unshielded Connector Pinouts

# 7 Definitions, symbols, abbreviations, key words

#### 7.1 Definitions

## 7.2 Symbols and abbreviations

Abbreviation	Meaning
GPIO	general purpose input/output
I <sup>2</sup> C	Inter-Integrated Circuit
mA	milliampere (i.e., 10-3 amperes)
RX	Receiver
TX	Transmitter
V	Volt

# 7.3 Key words

The key words "MUST", "MUST NOT", "REQUIRED", "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED", "MAY", and "OPTIONAL" in this document are to be interpreted as described in RFC 2119.

MAY This word, or the adjective "OPTIONAL", mean that an item is truly optional. One vendor may choose to include the item because a particular marketplace requires it or because the vendor feels that it enhances the product while another vendor may omit the same item. An implementation which does not include a particular option MUST be prepared to interoperate with another implementation which does include the option, though perhaps with reduced functionality. In the same vein an implementation which does include a particular option MUST be prepared to interoperate with another implementation which does not include the option (except, of course, for the feature the option provides.)

MUST This word, or the terms "REQUIRED" or "SHALL", mean that the definition is an absolute requirement of the specification.

MUST NOT This phrase, or the phrase "SHALL NOT", mean that the definition is an absolute prohibition of the specification.



SHOULD This word, or the adjective "RECOMMENDED", mean that there may exist valid reasons in particular circumstances to ignore a particular item, but the full implications must be understood and carefully weighed before choosing a different course.

SHOULD NOT This phrase, or the phrase "NOT RECOMMENDED" mean that there may exist valid reasons in particular circumstances when the particular behavior is acceptable or even useful, but the full implications should be understood and the case carefully weighed before implementing any behavior described with this label.

VENDOR SPECIFIC Something (e.g., a bit, field, code value) that is not defined by this specification and MAY be used differently in various implementations.

#### 7.4 Editorial conventions

Certain words and terms used in this specification have a specific meaning beyond the normal English meaning. These words and terms are defined either in the glossary or in the text where they first appear.

Lists sequenced by lowercase or uppercase letters show no ordering relationship between the listed items.

Lists sequenced by numbers show an ordering relationship between the listed items.

If a conflict arises between text, tables, or figures, the order of precedence to resolve the conflicts is text; then tables; and finally figures. Not all tables or figures are fully described in the text. Tables show data format and values. Notes and examples do not constitute any requirements for implementers and notes are numbered consecutively throughout this specification.

# 8 Mechanical characteristics

#### 8.1 Device and system connectors

#### 8.1.1 Storage device connector

The storage device with Ethernet interface plug connector is the Device Free (Plug) connector defined in SFF-8482 and SFF-8680. See the SFF specifications for detailed dimensional requirements.

Figure 1 illustrates the interface plug connector.

6 November, 2014




Figure 1 Device Free (Plug) connector

#### 8.1.2 Device form factor and connector location

The storage device with Ethernet interface form factor SHALL comply with SFF-8201 or SFF-8301 (2.5" and 3.5" drive form factors, respectively).

See SFF-8223 and SFF-8323 for the storage device with Ethernet interface plug connector locations on 2.5" and 3.5" drive form factors, respectively. These SFF specifications define the location of the connector relative to the device side mounting holes and the device bottom mounting holes, as applicable. Figure 2 illustrates the connector on a 2.5" hard disk drive. The connector location on the storage device with Ethernet interface SHALL comply with the applicable SFF specification.




Figure 2 2.5" hard disk drive with Ethernet interface plug connector

Figure 3 illustrates the connector on a 3.5" hard disk drive.





Figure 3 3.5" hard disk drive with Ethernet interface plug connector

#### 8.1.3 **System connector**

The system backplane receptacle connector is the Backplane Fixed (Receptacle) connector defined in SFF-8482 and SFF-8680. The backplane receptacle connector defined by SFF-8639 MAY also be used.

Figure 4 illustrates the SFF-8482/SFF-8680 system Fixed (Receptacle) connector.




Figure 4 System Backplane Fixed (Receptacle) connector

#### 8.1.4 Connector pin assignment

Table 1 defines the system and device connector pin signal assignments. The storage device with Ethernet interface SHALL comply with this pin assignment. Other interfaces use common form factors and connectors that MAY physically mate with the device or system connector used

in the storage device with Ethernet interface. See SFF-9639 for a list of these interfaces and pin signal assignments.

**Table 1 Connector signal assignments** 

Segment	Pin	Backplane receptacle	Device plug
	S1	GROUND	GROUND
	S2	TX0+	RX0+
	S3	TX0-	RX0-
	S4	GROUND	GROUND
	S5	RX0-	TX0-
	S6	RX0+	TX0+
Signal	S7	GROUND	GROUND
Sig	S8	GROUND	GROUND
	S9	TX1+	RX1+
	S10	TX1-	RX1-
	S11	GROUND	GROUND
	S12	RX1-	TX1-
	S13	RX1+	TX1+
	S14	GROUND	GROUND
	P1	PRESENCE DETECT	PRESENCE DETECT
	P2	I <sup>2</sup> C CLOCK	I <sup>2</sup> C CLOCK
	P3	I <sup>2</sup> C DATA	I <sup>2</sup> C DATA
	P4	GROUND	GROUND
	P5	GROUND	GROUND
	P6	GROUND	GROUND
<u>_</u>	P7	+5V PRECHARGE	+5V PRECHARGE
Power	P8	+5V	+5V
	P9	+5V	+5V
	P10	GROUND	GROUND
	P11	VENDOR SPECIFIC	VENDOR SPECIFIC
	P12	GROUND	GROUND
	P13	+12V PRECHARGE	+12V PRECHARGE
	P14	+12V	+12V
	P15	+12V	+12V

- 1. See 9.1 for TX and RX electrical characteristics..
- 2. See 9.2 for I<sup>2</sup>C electrical characteristics.
- 3. See 9.3 for +5V and +12V requirements.4. See 9.4 for P1 and P11 electrical characteristics.



# 9 Electrical characteristics

# 9.1 TX and RX signals

The TX and RX signals SHALL meet the requirements defined by the *Serial-GMII Specification*. This specification may be obtained at

ftp://ftp-eng.cisco.com/smii/sgmii.pdf

# 9.2 I<sup>2</sup>C signals

The I²C signals are OPTIONAL, however, a storage device with Ethernet interface that supports multiple speeds provides maximum performance if the Device Network Speed (see 10.3.11) is set through the I²C interface. (A storage device with Ethernet interface that supports multiple speeds defaults to 1 Gbps Ethernet speed, providing backwards compatibility with single speed devices.) If implemented, the I²C signals SHALL comply with the  $I^2$ C-bus specification and user manual at  $V_{DD}$  of 3.3V and operation at the standard mode speed of 100 kHz. The storage device with Ethernet interface is a slave device and lacks internal pull-up resistors. These resistors are omitted to allow the greatest flexibility when implementing shared bus. The host device SHOULD include pull-up resistors that meet the guidelines of the I²C specification. The I²C specification and user manual may be obtained at

www.nxp.com/documents/user\_manual/UM10204.pdf.

#### 9.3 +5V and +12V

The storage device with Ethernet interface MAY require +5V, +12V, or both +5V and +12V. See the device product data sheet for specific voltage and power requirements.

## 9.4 PRESENCE DETECT (P1)

The P1 signal is a bidirectional signal that MAY be used to assign unique device addresses and/or to detect the removal of a storage device from the chassis. The use of this signal requires the host to pull-up the signal to 3.3V. The pull-up resistor SHOULD result in a sink current of less than or equal to 8 mA.

# 9.5 VENDOR SPECIFIC (P11)

Application of P11 is VENDOR SPECIFIC. This pin MAY be not connected or the device MAY connect a GPIO with the following electrical characteristic limits:

Maximum voltage applied to device by chassis: 3.6 V

Minimum device sink current capability: 8 mA

# 10 Ethernet storage device I<sup>2</sup>C communication

#### 10.1 Overview

The I<sup>2</sup>C interface provides a means of communication between the chassis and the storage device with Ethernet interface independent of the Ethernet interface. The I<sup>2</sup>C interface is used to configure operating elements of the storage device with Ethernet

interface and to communicate information about the device to the chassis.

The storage device with Ethernet interface is designed to behave as an I<sup>2</sup>C Slave device at a device address of 0x2F. There are two types of commands that the storage device with Ethernet interface responds to:

- a) Set Commands that send data to the storage device with Ethernet interface;
- b) Get Commands that return data from the storage device with Ethernet interface.

#### 10.2 Command formats

#### 10.2.1 Set Command format (byte)

#### Write

- 1. Length byte
- 2. Opcode byte
- 3. Payload byte(s) (if required)
- 4. Checksum byte

#### 10.2.2 Get Command format (byte)

#### **Dummy Write**

- 1. Length byte
- 2. Opcode byte
- 3. Payload byte(s) (if required)
- 4. Checksum byte

**Delay** (Minimum of 100 microsecond)

#### Read

- 1. Length byte
- 2. Opcode byte
- 3. Payload byte(s)
- 4. Checksum byte

#### 10.2.3 Length

An unsigned integer that indicates the number of bytes being sent in a specific transmission. This number includes the length byte itself, opcode, payload, and the checksum byte.

#### 10.2.4 Opcode

In the case of write transactions, this byte indicates the operation requested. For read transactions, this is a validation byte that SHOULD match the operation that requested data be returned. See section 10.3 for details on the assigned opcodes.



#### 10.2.5 Payload

For set commands the payload is typically the parameters being set, although not every set operation requires parameters. Get commands can make use of the payload field on the dummy write as a parameter to indicate what data to return, or on the read portion of the transaction, which consists of the data requested by the get operation. All integers greater than 8 bits follow big endian format.

#### 10.2.6 Checksum format

Appended to the end of every transaction is a single byte checksum. This checksum takes the form of a modular sum where each character is summed as if it were an unsigned integer. Overflow bits are discarded and the two's complement of the final sum is appended as the checksum byte. Validation of the data MAY be accomplished by summing the characters in the same fashion, including the checksum. Valid data SHOULD result in a sum of zero. A nonzero result indicates an invalid message.

#### 10.2.7 Delay requirements

Discrete Stop and Start conditions SHOULD be issued between any two transactions rather than a repeated start, which is not supported. In addition a 100 µs delay SHOULD be placed between any two transactions to ensure no reads or writes are lost.

# 10.3 Open Commands

#### 10.3.1 Commands overview

I<sup>2</sup>C commands for the storage device with Ethernet interface are listed in Table 2. See referenced paragraphs for detailed descriptions.

The commands are split into two ranges. 0x00 - 0x7f are reserved for Open Commands. 0x80 - 0xff are reserved for Vendor Specific Commands. This section defines Open Commands.

Table 2 Open I2C commands for the storage device with Ethernet interface

Opcode	Name
0x00	Extended command set
0x01	Get Extended Status
0x02	Get Manufacturer
0x03	Get Product ID
0x04	Set Device Present
0x05	Identify Device
0x06	Get Device Temperature
0x07	Set Device I <sup>2</sup> C Address
0x08	Get Device IP Address
0x09	Set Device Network Speed
0x0a	Get Device Network Speed
0x0b	Get Device Operating State
0x0c	Enable External Loopback
0x0d	Get Write Status
0x0e	Get Command Set Version
0x0f	Disable External Loopback
0x10	Reset Device
0x11	Reset Interface
0x12	Set Device IP Address
0x13	Get Device Network MAC
0x14	Get Interface Link State
0x15	Get Firmware Version
0x16	Get Data Protocol Version



## 10.3.2 Extended command set (Opcode 0x00)

**Description:** This opcode is reserved for the future implementation of an extended command set.

#### 10.3.3 Get Extended Status (Opcode 0x01)

Type: Get

Bytes Returned: 0-31 (Extended Status)

**Description:** Returns a value 32 bytes in length. The format of the returned value is vendor specific. This command SHOULD be used when the value returned by Device

Operating State command indicates that Extended Status is available.

#### 10.3.4 Get Manufacturer (Opcode: 0x02)

Type: Get

Bytes Returned: 0 - 15 (Manufacturer)

**Description:** Returns a 16 byte ASCII string indicating the manufacturer of the storage

device with Ethernet interface.

#### 10.3.5 Get Product ID (Opcode: 0x03)

Type: Get

Bytes Returned: 0 - 15 (Model Number)

**Description:** Returns a 16 byte ASCII string indicating the model number of the storage

device with Ethernet interface.

#### 10.3.6 Set Device Present (Opcode: 0x04)

Type: Set

Description: This command facilitates the detection of a device being removed from the system. In its default state the PRESENCE DETECT signal on pin P1 of the connector is high. If the command is sent to an attached storage device with Ethernet interface, then the storage device with Ethernet interface drives the PRESENCE DETECT signal low on pin P1 of the connector signal low until it is physically removed, powered down, or the device is reset.

#### 10.3.7 Identify Device (Opcode 0x05)

Type: Get

Bytes Returned: 0 - 7 (WWN)

Description: Returns the 64-bit Worldwide Name of the storage device with Ethernet

interface.

#### 10.3.8 Get Device Temperature (Opcode 0x06)

Type: Get

Byte Returned: 0 (Degrees Celsius)

14 6 November, 2014 **Description:** Returns a single byte signed integer (2's complement), indicating the storage device with Ethernet interface temperature in degrees Celsius.

#### 10.3.9 Set Device I<sup>2</sup>C Address (Opcode 0x07)

Type: Set

Parameter Byte: 0 (Address)

**Description:** In the case where multiple storage devices with Ethernet interface are attached to the same I<sup>2</sup>C bus, this mechanism allows the default 7-bit address of 0x2f to be changed to a unique value. In addition, the storage device with Ethernet interface is set to the Present state. This command is only acted upon if the PRESENCE DETECT signal is driven low by the host. Since 7-bit addressing is used, the MSB of the address parameter is ignored.

#### 10.3.10 Get Device IP Address (Opcode 0x08)

Type: Get

Parameter Bytes: 0 (Interface Select), 1 (Address Select)
Bytes Returned: 0 (Interface), 1 (Status), 2-18 (Address)

**Description:** Returns the IP address and netmask, or gateway address, as specified in the parameter bytes, of the attached storage device with Ethernet interface. The Interface Select and Interface bytes are both unsigned integers, indicating a specific network interface. The octets and hextets are numbered from left to right, in increasing order. Hextet is used in this context to indicate a 16-bit word.

**Table 3 Get Device IP Address Parameter Byte Format** 

Byte	Bit	Setting
0	0 - 7	Interface Select (Unsigned Integer)
1	2-7	Reserved
1	1	IP Version (0 = IPv4, 1 = IPv6)
1	0	Get Gateway (0 = No, 1 = Yes)

**Table 4 Get IP Address Status Byte Format** 

Bit	Setting
5 – 7	Reserved
4	Interface Configured (0 = No, 1 = Yes)
3	Static Configuration Set (0 = No, 1 = Yes)
2	DHCP Configuration Set (0 = No, 1 = Yes)
1	IP Version (0 = IPv4, 1 = IPv6)
0	Get Gateway (0 = No, 1 = Yes)



**Table 5 Get IP Address Returned Bytes Format** 

Byte	Description (eth0)	Byte	Description (eth1)
0	Interface (Unsigned Integer)	1	Status Byte (see Table 4)
2	IPv4 Octet 1	3	IPv4 Octet 2
	IPv6 Hextet 1 (H)		IPv6 Hextet 1 (L)
4	IPv4 Octet 3	5	IPv4 Octet 4
	IPv6 Hextet 2 (H)		IPv6 Hextet 2 (L)
6	IPv4 Netmask Octet 1   IPv6 Hextet 3 (H)	7	IPv4 Netmask Octet 2   IPv6 Hextet 3 (L)
8	IPv4 Netmask Octet 3   IPv6 Hextet 4 (H)	9	IPv4 Netmask Octet 4   IPv6 Hextet 4 (L)
10	IPv6 Hextet 5 (H)	11	IPv6 Hextet 5 (L)
12	IPv6 Hextet 6 (H)	13	IPv6 Hextet 6 (L)
14	IPv6 Hextet 7 (H)	15	IPv6 Hextet 7 (L)
16	IPv6 Hextet 8 (H)	17	IPv6 Hextet 8 (L)
18	IPv6 Netmask		

#### 10.3.11 Set Device Network Speed (Opcode 0x09)

Type: Set

Parameter Bytes: 0 (Interface Select), 1 (Speed)

**Description:** This command sets the network interface speed of the specified network interface on the storage device with Ethernet interface. Both the Interface Select and Speed bytes are unsigned integers, representing the network interface and network speed respectively. The Speed integer is defined in Table 6.

**Table 6 Network Speed Integer Definition** 

Value	Speed
3 – 256	Reserved
2	10 Gbps
1	2.5 Gbps
0	1 Gbps

#### 10.3.12 Get Device Network Speed (Opcode 0x0a)

Type: Get

Parameter Byte: 0 (Interface Select)

Bytes Returned: 0 (Interface), 1, 2 (Speeds Available), 3 (Current Speed)

**Description:** Returns the network speed capabilities and current setting of the specified network interface on the attached storage device with Ethernet interface. The Interface Select and Interface bytes are both unsigned integers, which should match if the data is valid. The Current Speed byte uses the same form detailed in Table 6 to indicate the currently selected speed. Two bytes take the form of a bit field, defined in Table 7, to represent the network Speeds Available.

**Table 7 Network Speeds Available Bit Field** 

Bit	Speed
3 – 15	Reserved
2	10 Gbps
1	2.5 Gbps
0	1 Gbps

#### 10.3.13 Get Device Operating State (Opcode 0x0b)

Type: Get

Bytes Returned: 0, 1 (Error type)

**Description:** Returns the operating state of the storage device. If the Extended Status available bit is set, then the Extended Status MAY be read with the Extended Status command set. When the Extended Status is read the Extended Status Available bit is cleared.

Bit Description: See Error! Reference source not found.

**Table 8 Get Device Operating State Bit Description** 

Bit	Status
2 – 15	Reserved
1	Loopback Enabled
0	Extended Status Available

#### 10.3.14 Enable External Loopback (Opcode 0x0c)

Type: Set

**Description:** This command explicitly enables the external loopback mode of the storage device with Ethernet interface. While in this mode the storage device with Ethernet interface SGMII interfaces retransmit any packet received on that interface. This command is ignored if the loopback is enabled.



#### 10.3.15 Get Write Status (Opcode 0x0d)

Type: Get

Bytes Returned: 0, 1 (Status Info), 2 (Opcode)

**Description:** Returns an unsigned 16-bit integer and a 1 byte Opcode. This value MAY be used to determine whether or not the command was successful. The opcode returned is that of the write that this status applies to.

**Table 9 Get Write Status Info Byte Definition** 

Value	Status
4 – 65535	Reserved
3	Unrecognised Command
2	Length Mismatch
1	Checksum Mismatch
0	Success

# 10.3.16 Get Command Set Version (Opcode 0x0e)

Type: Get

**Bytes Returned:** 0 (Major Revision Number), 1 (Minor Revision Number), 2 (Sub-minor Revision Number)

**Description:** Returns three bytes, all unsigned integers. The first byte returned is the major revision number, the second is the minor revision number, and the third is the subminor. This offers a method of determining the supported commands of a specific storage device with Ethernet interface.

#### 10.3.17 Disable External Loopback (Opcode 0x0f)

Type: Set

**Description:** This command explicitly disables the external loopback mode of the storage device with Ethernet interface. Once disabled, the storage device with Ethernet interface resumes normal network behavior. This command is ignored if the loopback mode is disabled.

#### 10.3.18 Reset Device (Opcode 0x10)

Type: Set

**Description:** This command MAY be used to request a soft reset of the storage device with Ethernet interface.

#### 10.3.19 Reset Network Interface (Opcode 0x11)

Type: Set

Parameter Byte: 0 (Interface Select)

**Description:** This command MAY be used to reset the specified interface. The interface is brought down and then brought back up, restoring the saved configuration for that interface. In the case where the interface is set for DHCP, a fresh DHCP request will be made, and for static configurations the configured IP address, Netmask and Gateway will be reinstated. The parameter for this command is a single byte unsigned integer, the value determining the interface to reset. Parameter values specifying interfaces that do not exist on the storage device with Ethernet interface cause the command to be ignored.

#### 10.3.20 Set Device IP Address (Opcode 0x12)

Type: Set

Parameter Bytes: 0 (Interface Select), 1 (Config), 2-18 (Address)

**Description:** This command MAY be used to set the IP address of the specified network interface on the storage device with Ethernet interface. Byte 0, detailed in Table 10, is a bit field used to specify a protocol version, an assignment type, set a gateway address, and provides a means to clear previous settings. The Clear Settings bit, if set, will remove all currently set configuration options for the specified interface, shutting off that interface. If the Clear Settings bit is not set, the command will modify the existing configuration, only changing the specified interface and IP version settings (i.e. Setting a static IPv4 address on eth1 will not change eth0's configuration or the IPv6 configuration on eth1). The Set Gateway bit, if set, allows a static gateway to be specified if the Assignment Type bit is also set. When specifying a gateway address, an IPv4 address should be located in address bytes 1-4, and IPv6 gateways should be located in address bytes 1-16. The Interface Select byte is a unsigned integer used to specify the interface desired. There are 17 address parameter bytes, in the case of Clear Settings being set, a DHCP configuration being set, setting a gateway address, or an IPv4 static address being set, the unused address bytes should be zero filled. Once modifications to an interface's IP configuration are complete, the interface must be reset for the new configuration to become active. An overview of the Parameter bytes can be found in Table 11.

**Table 10 Set Device IP Address Config Byte Format** 

Bit	Setting
4 – 7	Reserved
3	Clear Settings(0 = Modify, 1 = Clear)
2	Assignment Type (0 = DHCP, 1 = Static)
1	IP Version (0 = IPv4, 1 = IPv6)
0	Set Gateway (0 = No, 1 =Yes)



**Table 11 Set Device IP Address Parameter Bytes Format** 

Byte	Description (eth0)	Byte	Description (eth1)
0	Interface (Unsigned Integer)	1	Status Byte (see Table 4)
2	IPv4 Octet 1   IPv6 Hextet 1 (H)	3	IPv4 Octet 2   IPv6 Hextet 1 (L)
4	IPv4 Octet 3   IPv6 Hextet 2 (H)	5	IPv4 Octet 4   IPv6 Hextet 2 (L)
6	IPv4 Netmask Octet 1   IPv6 Hextet 3 (H)	7	IPv4 Netmask Octet 2   IPv6 Hextet 3 (L)
8	IPv4 Netmask Octet 3   IPv6 Hextet 4 (H)	9	IPv4 Netmask Octet 4   IPv6 Hextet 4 (L)
10	IPv6 Hextet 5 (H)	11	IPv6 Hextet 5 (L)
12	IPv6 Hextet 6 (H)	13	IPv6 Hextet 6 (L)
14	IPv6 Hextet 7 (H)	15	IPv6 Hextet 7 (L)
16	IPv6 Hextet 8 (H)	17	IPv6 Hextet 8 (L)
18	IPv6 Netmask		

#### 10.3.21 Get Device Network MAC (Opcode 0x13)

Type: Get

Parameter Byte: 0 (Interface Select)

Bytes Returned: 0 (Interface), 1-6 (MAC)

**Description:** This command returns the MAC of the specified network interface on the storage device with Ethernet interface. The Interface Select and Interface bytes are unsigned integers indicating the network interface. The MAC bytes contain the 48-bit code specific to the selected interface, if an invalid interface is selected the code will be all zeroes.

#### 10.3.22 Get Interface Link State (Opcode 0x14)

Type: Get

Parameter Byte: 0 (Interface Select)

Bytes Returned: 0 (Interface), 1 (Status)

**Description:** This command returns the link state of the specified network interface on the storage device with Ethernet interface. The Interface Select and Interface bytes are both unsigned integers indicating the network interface, and the Status byte is defined in Table 12.

**Table 12 Get Interface Link State Returned Bytes Format** 

Byte	Bit	Setting
0	0 – 7	Interface (Unsigned Integer)
1	1-7	Reserved
1	0	Link (0 = Down, 1 = Up)

#### 10.3.23 Get Firmware Version (Opcode 0x15)

Type: Get

**Bytes Returned:** 0 (Major Revision Number), 1 (Minor Revision Number), 2 (Sub-minor Revision Number)

**Description:** This command returns three bytes, all unsigned integers, indicating the version of firmware currently installed upon the storage device with Ethernet interface. The first byte returned is the major revision number, the second is the minor, and the third is the sub-minor.

#### 10.3.24 Get Data Protocol Version (Opcode 0x16)

Type: Get

**Bytes Returned:** 0 (Major Revision Number), 1 (Minor Revision Number), 2 (Sub-minor Revision Number), 3, 4 (Protocol)

**Description:** This command returns 5 bytes, 3 unsigned 8-bit integers, and 1 16-bit unsigned integer. The first byte returned is the major revision number, the second is the minor, the third is the sub-minor, and the remaining two bytes are an integer code used to indicate the specific protocol used by the storage device with Ethernet interface. Table 13 defines the Protocol integer.

**Table 13 Get Data Protocol Version Protocol Enumeration** 

Value	Status
1 – 65535	Reserved
0	Kinetic

## 10.4 I2C implementation requirements

#### **10.4.1 I**<sup>2</sup>**C** signals

See 9.2

#### 10.4.2 Clock stretching

Host devices need to support clock stretching. It is expected that storage device with Ethernet interface make use of clock stretching. Failure to properly handle clock stretching MAY lead to corrupt transactions due to a loss of synchronization between the Master and Slave.



#### 10.4.3 Power down isolation

A storage device with Ethernet interface in the powered down state SHOULD NOT interfere with the I²C communication between the host and other devices. Some I²C controllers MAY require additional circuitry to isolate the I²C clock and data signals so the storage device with Ethernet interface does not load the bus when the storage device with Ethernet interface not powered. This is an issue that needs to be addressed by the storage device with Ethernet interface.

# **11 FAQ**

Q: Is there any software needed (Driver's etc.)?

A: The storage device with Ethernet interface uses standard Ethernet communication protocols

Q: Is there a physical keying mechanism to prevent insertion of the storage device with Ethernet interface in a SAS/SATA slot or vice versa? If not, can this cause damage to the system?

A: There is no physical keying mechanism to distinguish between different drive types. Signal locations and protocol prevent damage to the system and the device.

Q: How are the drives presented on the network?

A: Each drive has two IP addresses.

For additional FAQ regarding the Storage device with Ethernet interface refer to wiki FAQ:

https://developers.seagate.com/display/KV/FAQ



# **12 Revision History**

Version	Date	Author	Changes
1	12/20/2013	Alvin Cox,	Initial Public Version
		Asghar Riahi	
2	04/10/2014	Alvin Cox, Asghar Riahi	Updates to address initial feedback from the Incubation Committee
3	08/21/2014	Alvin Cox, Asghar Riahi, Bryan Wyatt	Added the following sections: I <sup>2</sup> C, FAQs, and revision history plus PRESENCE DETECT, and figures and tables lists.
4	11/06/2014	Alvin Cox, Asghar Riahi, Bryan Wyatt	Added several new I <sup>2</sup> C Commands, updated some existing I <sup>2</sup> C commands