

USASPEC PA11-HON2Y HONDA iPod INTERFACE OWNER'S MANUAL

KEY FEATURES

The New PA11-HON2Y interface connects iPod products directly to Honda/Acura audio system. Its on-board software translates the factory radios external CD Changer controls functions into commands that the iPod understands. This interface enables the iPod to provide the following benefits:

1. Direct connection of the iPod to Honda vehicle audio system for optimum sound quality
2. Two playback modes:
Hybrid mode: select songs and playlist on the iPod using the CD Changer buttons on the radio
Direct Mode: Search and select songs directly on the iPod using the clickwheel and select button on the radio.
3. Maintain current playlist when switching from portable use to in-car use.
4. Charges the iPod internal battery — and to prevent battery-drain, charging automatically ends one hour after iPod is paused
5. Auxiliary audio input [connect an audio device (mp3, DVD, Game, SAT radio etc) and listen to it on the factory system]
6. Plug-n-Play: This complete package includes installation cables, mounting screws and user's manual.

COMPATIBILITY

The PA11-HON2Y interface is compatible with iPod (G3*, G4, G5) iPod Mini, Nano, Photo, Video models featuring a dock connector. The functionality and features of the iPod interface described in this owner's manual are confirmed with software version:

iPod	iPod Nano	iPod Photo	iPod Video	iPod Mini
Firmware v2.3	firmware 1.1.1	Firmware 1.2.1	firmware 1.1.1	firmware v1.4.1
firmware v3.1.1 (G4)				

Please visit www.apple.com/iPod and update the firmware on your iPod.

* G3 iPod is not compatible with Hybrid Mode. G3 iPods will be in playlist mode when Dip switch #2 is at the "ON" position.

Future firmware updates for your iPod, iPod Mini, iPod photo or iPod video may affect the features and functions described in this owner's manual.

Important: Display of artist, song title information, track search and artist, song title, album or genre is not displayed on the Honda radio. Radio will show Track and disc number. (CD Changer display mode)

The PA11-HON2Y will **co-exist** with Honda/Acura **internal/external 6 disc CD changer, XM, MP3, Navigation options.** — See the PA11-HON2 if you don't have any of these factory option.

2. HYBRID MODE, DIRECT MODE AND AUX. OPTION

The PA11-HON2Y provides **two ways** of controlling the iPod through the car radio, namely **Hybrid mode** (formerly Playlist Mode) and **Direct Mode**.

2-1 DIRECT MODE:

Search and select music on the iPod **directly just as you would in portable use**. Music will playback through your car stereo. Use the track up/down, fast forward and reverse buttons on your Honda radio or steering wheel to control music playback. **All control functions on the iPod will still be available**. Please see section 4 of this manual for additional information

2-2 HYBRID MODE:

In hybrid mode, the songs on the iPod are accessed exactly in the same way as in Playlist mode is explained in the owner's manual. But, iPod screen is NOT LOCKED to "OK to disconnect" and iPod control keys are also fully functional. Therefore, while playing your iPod at any DISC location of the radio, you can manually change songs, change artist, change album, fast forward, and fast reverse etc. using the iPod buttons. (See Playlist Naming in section 4 of this manual). Dip switch #2 on the PA11-HON2Y interface is for mode selection. The "ON" position is for **Hybrid Mode** and the "OFF" position is for **Direct Mode**. It is preset to "ON" (**Hybrid Mode**) at the factory.

Warning: Disconnect the iPod from the PA11-HON2Y before switching DIP switch #2 from one mode to the other.

2-3 ADDITIONAL "AUXILIARY INPUT" SELECTION (optional)

PA11-HON2Y interface adapter is also capable of connecting an Auxiliary audio source to your Honda radio, including the iPod. The additional audio source connects to the RCA input jacks labeled "AUX INPUT". If you choose to use the "AUX INPUT", DIP switch #1 at the side of the interface box must be set to the "OFF" position (it is preset to "ON" at factory).

The audio source (XM radio, DVD player, MP3 Player, Game system etc.) connected to the "AUX INPUT" can be accessed at CD 6 Track1 after selecting CD Changer mode on the Honda radio. CD 1 to CD4 are for accessing Playlist and CD 5 is for accessing all songs on the iPod.

2-4 AUXILIARY INPUT OPERATION

If the "AUX INPUT" option is selected, the radio will display "CD 6 Track 1" when **CD/AUX** button is pressed. "CD 6 Track 1" gives access the audio source connected the AUX INPUT port. Adjust VOLUME, BASS, and TREBLE etc. as you would normally do for the other program sources on the radio.

3. CONNECTING & PLAYING THE iPod IN DIRECT MODE

The procedures for connecting and disconnecting the iPod to your PA11-HON2Y interface adapter are described in this section. Please follow these instructions to avoid connectivity problems or synchronizations errors between the iPod and Honda radio. When the iPod is connected to the interface, the iPod's screen will go blank for a few seconds before the normal screen returns. Set the source on the radio to CD Changer, the audio from the iPod will be played back at DISC 5 Track1. Adjust VOLUME, BASS, TREBLE etc as you normally do for the other programs sources on the radio. If for some reason you experience sound level to be too high and the music sounds distorted, you will need to turn "Sound Check" **ON** in iPod™ menu "Settings".

4. CONNECTING & PLAYING THE iPod IN PLAYLIST MODE

4-1. Connecting the iPod to the interface

Turn your HONDA radio **ON** before connecting your iPod. After connection, the iPod will take a few moments to change to external control mode.

4-2 Selecting iPod Mode on Honda radio

Press the “**CD/AUX**” on the radio repeatedly to go to CD Changer mode and “CD 6- TRK-x” appears on the radio display (x is the track number for the “Now Playing” song on the iPod). This display confirms that iPod mode has been completely synchronized and activated. Synchronization timing varies according to the number of playlist on your iPod. If the iPod was playing previous to turning the Radio’s ACC power OFF, and the iPod was not disconnected, playback resumes from where it stopped.

4-3 Disconnecting the iPod from the interface

If the iPod was disconnected during playback in iPod mode, the radio will display “EJECT”. After disconnecting, wait until the iPod screen changes from the external control mode screen back to the normal menu before attempting to reconnect to the interface.

*Tip: If you press and hold the **PLAY/PAUSE** button on the iPod, you may get the normal iPod menu back faster.*

4-4 iPod Song Playback

All audio tracks on your iPod will be played (All Play) at Disc 6 if the AUX option is NOT selected. Track order is determined by the default order on your iPod. Selecting DISC 1 to DISC 5 on radio will allow playback of 5 playlist on the iPod. Please refer to “Playlist naming” in this manual for more information regarding available and unavailable playlist. Every time the iPod is connected to the PA11-HOND2Y, playback begins at the “Now Playing” song at DISC 6 by default. If the iPod was playing any of its playlist right before connection, the same playlist will continue to play and repeated at DISC 6 but the iPod will switch to “ALL” as soon as the **Fast Forward (or SEEK/SKIP) ►►** button is pressed.

4-5 SELECTING A PLALIST

Press DISC ▲ or DISC ▼ button to select a playlist. The selected playlist will begin playing and the playlist number and track number will be displayed. In rare cases, this may take up to a few seconds to complete synchronization. After playing the last song in the current playlist, playback will start again from the first track on this playlist.

4-6 Playlist Naming

Once the iPod™ is connected to your HONDA radio via the interface, the iPod interface will scan all available playlist on the iPod for designated “HONDA” playlist which are created for direct access using the “DISC” button on the HONDA radio. Therefore, you will need to name your playlist(s) using the letters “HONDA” and the number corresponding to that DISC. The following is an example of correct playlist(s) naming:

Preset #'s	Playlist(s) names
DISC1	HONDA1
DISC2	HONDA2
DISC3	HONDA3
DISC4	HONDA4
DISC5	HONDA5
DISC6	ALL SONGS on iPod (this is a designation not a playlist name)

Naming a playlist in iTunes™ for the PA11-HON2Y interface must be exactly as shown. HONDA must be in **capital letters** and there can be **no spaces** between HONDA text and the DISC number. However, you may add any text after the correct name and number has been assigned.

The following is an example of correct playlist naming with additional text:

DISC1	HONDA1_Jazz
DISC2	HONDA2_Rock
DISC3	HONDA3-Reaggae
DISC4	HONDA4_Salsa”
DISC5	HONDA5-Rap”

Note 1: If no designated HONDA playlist were created, the PA11-HON2Y interface automatically relates the first five playlist on the iPod to DISC number 1 to 5 regardless of playlist naming.

Note 2: If less than five designated HONDA playlist were created, the PA11-HON2Y interface automatically fills up the rest of the DISC numbers beginning with the first available playlist on the iPod.

Example: If only three designated **HONDA1**, **HONDA3** and **HONDA5** playlists were created, the DISC numbers on the radio would be:

DISC1	HONDA1
DISC2	(1 st available playlist on the iPod)
DISC3	HONDA3
DISC4	(2 nd available playlist on the iPod)
DISC5	HONDA5

Warning: The PA11-HON2Y does NOT recognize a playlist that contains no audio tracks regardless of playlist naming. The PA11-HON2Y does not recognize the “On-The-Go” playlist on your iPod

4-7 PLAYBACK CONTROL FUNCTIONS

You can control playback with several functions. These functions are generally cancelled when you press select radio buttons; disconnect the iPod, or POWER OFF the radio or ACC.

Scan

Press the **SCAN** button, each track in the current playlist will play for 10 seconds. If **SCAN** is pressed at DISC 6, all songs on the iPod will play for 10 seconds each.

Random (Shuffle)

Press the "RANDOM" button (RND) on the radio, songs within a playlist will playback in random order. The track number display will change to start from 1 as it does on the iPod. The radio will continue to play this way until "RND" is deactivated.

Repeat

Repeat of song being played is **NOT** supported.

Track Up and Down

Press the track up (**Skip ►►**) button to advance to the next track in the playlist. Press the track down (**Skip ◄◄**) button to move to the beginning of the track that's being played. Press the **Skip ◄◄** button twice to go to the previous track.

If the track up OR track down buttons is pressed quickly in repetition, the track numbers displayed may change unevenly. You may also hear short bits of audio during repeated presses of track up and track down buttons.

If your HONDA radio currently display a maximum of two digits for track numbers, then track number 100 will be displayed as 01, Track 101 displayed as 02, track 102 as 03

Fast Track Search (x10)

Press the Seek (**◄◄►►**), it will advance or retreat through the tracks in the playlist in increment of 10 (i.e. 04, 14, 24...). When you reach the end of the playlist, the search will stop at track 1, and then continue by increments of 10 (i.e. 19, 29, 1, 11).

Press and hold the **Fast Forward** or **Fast Reverse** buttons for more than 4 seconds; the search will jump to the last track or the first track of the playlist. If you are in scan mode, the mode will be cancelled.

Fast Forward/Fast Reverse Play

This function applies **only** in **random mode**. Engaging or disengaging the random mode does not stop playback of the current song, you can change in or out of random mode to do the fast track search (x10) function, or the fast forward/fast backward play function. **Press and hold** the Forward or backward button will cause only the current track to skip through at high speed.

During fast forward, when the end of the current track is reached, the iPod will start playing the next random track at normal speed. During fast backward, when the start of the current track is reached, the track will start playing again at normal speed. To continue fast forward or fast reverse play, release the button and press it again.

CHANGING SOURCE TO AM/FM/CD/CASSETTE

when a source other than the iPod (i.e. Radio, Cassette etc) is selected on the radio, the iPod will pause.

5. INSTALLATION INSTRUCTIONS

1. Remove the radio from the dash
2. Disconnect existing CD Changer or single CD from the radio connectors if there is one
3. Set DIP switch #2 to "OFF" position only if Direct Mode is preferred
4. If the vehicle is equipped with Navigation and/or XM receiver, unplug the Navigation/XM connector from radio and plug the 14-pin Female connector on the CAS-H2Y.
5. Connect the 14-pin male connector of the CAS-H2y to the radio.
6. Connect the round 8-pin DIN plug on the other end of the CAS-H2Y to the PA11-HON2y interface box labeled "RADIO" (Do not connect your iPod to PA11-HON2y prior to completion of this installation step!!!)
7. **Optional:** Connect the audio output of your auxiliary device to AUX input jack on PA11-HON2Y if AUX option is selected through DIP switch #1.
8. Plug CB-PA14 iPod cable to the PA11-HON2Y adapter box labeled "iPod"
9. Route the dock connector (4ft long) to where the iPod will reside
10. Connect the iPod to the dock connector and test operation
11. Reinstall Radio
12. Enjoy the Music!

6. VEHICLE COMPATIBILITY

The PA11-HON2Y is applicable to the following Honda Vehicles that are equipped with factory Navigation, factory XM, external CD Changer and MP3 Player---

HONDA	ACURA
2003-08 Accord‡	2005-07 RL
2006-08 Civic	2004-08 TL
2005-08‡ CRV	2005-07 MDX
2003-08 Element†‡	2004-08 TSX
2007-08 Fit	2007-08 RDX
2005-08 Odyssey‡	
2006-08 Pilot‡	
2006-08 Ridgeline‡	
2004-08 S2000‡	

‡ including factory Navigation, XM, MP3 or external CD Changer

† **2003-06 Element.** It is possible that these vehicles may have an older radio with a different 14-pin connector—We can't determine which radio plug is available in your car and because of that it is necessary to remove the radio to verify the connector—this is only way to guarantee compatibility. Failure to remove the radio may result in your ordering the wrong part.

Note1 The PA11-HON2Y will **co-exist** with Honda/Acura factory Navigation systems, XM Radio, internal/external CD Changer (see FAQ below), MP3 player in above listed model/year vehicles. Any of the above options will continue to operate.

FREQUENTLY ASK QUESTIONS:

Will the PA11-HON2Y disable my in-dash 6-disc cd changer radio?

NO—the PA11-HON2Y does not disable or interfere with normal operation and functions of the in-dash 6 cd changer that is part of the radio.

What do you mean by “external CD Changer”?

An **external cd changer** is one that is not part of the radio. In the past most factory radios did not have a built-in cd changer or a changer that was integrated to the radio. When the cd changer is part of the radio it is referred to as an Internal cd changer or cd changer radio--- when the changer is not part of the radio (physically) it is referred to as an external cd changer and are separate boxes mounted in the trunk, center armrest, glove box, under the front seat etc.

How do I access the iPod from the radio?

Depending on the vehicle, you may have to hit the “CD” button once or twice until “CD/AUX” or “XM” appear on the screen; others use the “CD/TAPE” button or the “CD” button.

Will I see iPod text information displayed on the radio?

NO—the PA11-HON2Y does not display text information on the radio. The radio display will default to CD mode (Track number and Disc numbers)

Will I still be able to use the iPod clickwheel?

YES—set the PA11-HON2Y to **direct mode** or **Hybrid mode** to have full control using the iPod clickwheel—in addition to being able to use the steering wheel audio control or radio controls for track up, track down, Fast Forward and Fast Rewind.

I'm concerned about safety—can I just stow the iPod in the glovebox and control it from the radio?

YES- set the PA11-HON2Y to Playlist mode and control the iPod using the CD Changer controls buttons on the radio. You create playlist in iTunes or the PA11-HON2Y will automatically assign the first 5 playlist to the preset buttons on the radio.

I have Honda Factory XM installed; can I still use the PA11-HON2Y?

YES, the PA11-HON2Y allows you to retain factory XM without having to purchase an additional harness. The harness included with the PA11-HON2Y allows retention of all Honda factory options including XM radio.

Will the PA11-HON2Y work my iPod Video?

YES, the PA11-HON2Y supports all iPods with dock connectors including the iPod video--- **the PA11-HON2Y will not work with G1/G2 iPods (10G/15G) or iPod shuffle or G3 in Hybrid mode**

Note: Video Playback on Navigation screen is possible using a Vehicle specific interface (sold separately)

Does the PA11-HON2Y work with my Navigation system and do I need to purchase anything additional?

YES, the PA11-HON2Y will **co-exist** with Honda/Acura factory Navigation systems and no additional part required.

I leave my iPod connected even when I'm not in my car--- will the iPod charging drain my battery?

NO—the PA11-HON2Y has a charging feature that stops one hour after the iPod is paused—(the iPod will pause when the radio and/or car is turned off)

Will I be able to connect my MP3 player (not an iPod) or DVD Player with the PA11-HON2Y installed?

YES, the PA11-HON2Y has an auxiliary audio input port for you to connect any audio device in addition to the iPod. The auxiliary audio device connects to the Left-Right RCA inputs for a clean audio path to the Honda stereo.

Note: iPod connection is not required to use the Auxiliary input function. In other words you don't need an iPod to use this interface as an auxiliary input adapter.

How difficult is it to install? Can I do it myself or do you recommend a professional?

The PA11-HON2Y is a plug-n-play install—see installation diagram and instructions above. Remove the radio, use the supplied cables to make the connections and your done—no wire cutting or splicing. Plug-n-play!

Seek professional help if you don't feel comfortable taking the dash apart to gain access to the 14-pin connector.

Any local pro can install this for you in less than an hour.

What are the differences between the PA11-HON2 and the PA11-HON2Y?

They are slight differences between the two interfaces, mainly the PA11-HON2Y has updated software that fixed small issues with the TL and others—it also includes the 2-port BUS cable on the main harness—and because of that the CAS-HON2Y is no longer necessary to retain Navigation, XM etc.

Which of the two interfaces should I buy—the PA11-HON2 or the PA11-HON2Y?

Both interfaces work in the same vehicles, however if you have factory XM, Navigation, external CD Changer, MP3, then the PA11-HON2Y is required. **The PA11-HON2 is discontinued.**

Disclaimer: All products sold by Discount Car Stereo.com are tested and optimized for vehicles in the United States. You may, at your own risk, purchase and install this part in vehicles outside the USA however; Discount Car Stereo.com will not be liable for damage or compatibility issues that may arise. Products purchased for vehicles outside the US are not returnable. It is the customer's responsibility to retain an installation technician with adequate knowledge and experience of the vehicle into which the equipment will be installed.

This page was updated on:
January 22, 2008

iPod™ iPod™ Mini and iTunes™ are trademarks of Apple Computers Inc. registered in the USA and other countries.

HONDA is a registered trade mark of HONDA Co. Ltd

Design and specifications are subject to change without notice.

© 1995-06 Discount Car Stereo, Inc. All rights reserved. Information in this document is subject to change without notice. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies or mark holders.