M3 DS REAL USER MANUAL

Index:

1	Getting Started
2	What's Included
2	Main Menu
3	Running A Game
4	Game Saves
4	Cheat System
5	Running Homebrews
6	Boot Slot Option
7	
8	Setting Options
9	Skinning
	5

Getting Started

Before using the M3 DS Real it is best to get the latest firmware installed first. Take the system folder from the CD (or from the http://www.m3adapter.com/) and drag it onto the card. This system folder contains all the files needed for running of the card. Create a folder name "NDS" on the root of your M3 DS Real, this is where your games will be stored. Slot-2 Device are not require in order to run the M3 DS Real. Slot-2 device from these bundle solely act as an additional add on for your gaming experience. You may insert these Slot-2 devices according to your needs. These Slot-2 Bundle also allow you to connect to the internet via Wi-fi connection.



What's Included

The M3 DS Real Box Contain:

- A setup Disc
- A M3 DS Real Cartridge
- A T-Flash Reader
- A M3 Ds Real Holder case
- A Rumble Pack Device

In the GBA Expansion Pack Bundle Includes:

- A setup Disc
- A M3 DS Real Cartridge
- A T-Flash Reader
- A M3 Ds Real Holder case
- A Rumble Device
- A GBA expansion Device



In the Rumble Ram Pack Bundle Includes:

- A setup Disc
- A M3 DS Real Cartridge
- A T-Flash Reader
- A M3 Ds Real Holder case
- A Rumble Ram Device





Please be sure you are inserting your MicroSD Correctly

<u>Main Menu</u>

The Main Menu consist 7 options. Refer to the list below for their functions.



From the Main Menu you are also adjust the screen brightness. On the Bottom Left corner there is a 'sun' symbol, simply tab it with your DS pen to adjust the screen brightness. You may also Press Y to change the brightness.

To check your firmware version, tab the Top Right corner from the main menu.

Running Games

To run games tab on the game icon, or press A while the game icon is highlighted.

There will be a screen with a list of games; these are the games you have stored in the "nds" folder. You may also choose other directory where you have stored your games. Simply tab on the Folder Icon in the Game Menu located in the bottom left corner. It will ask you which directory you wish to load. To run a game simply tab on the game or press A on the highlighted game. If you wish to insert the Rumble Device or the Rumble Ram Device please insert it before you turn on your NDS, and make sure that your game is Rumble Ready. The

Rumble Device or the Rumble Ram Device will only rumble if the game is compatible. Once you have selected your game, you will see a menu with these options:

Cheat Switch Softreset Key SlowMotion Switch SlowMotion Level

From here you may activate any option you wish. After selecting the options tab "start" on the bottom left or scroll down with your D-pad until you highlight the start button then press A to start the game.

Game Saves

The Default saves for M3 DS Real ends with the extension ".0". The M3 DS Real also has a built in saves backup system. Simply Press Select when a game is highlighted on the game menu and a list of 5 options will appear.

Default -> 1 Default -> 2 1 -> Default 2 -> Default Blank

For example if you wish to backup your default .0 saves onto .1 save you would select the first option then press A. It will ask if you want to "Replace Save" click "OK" wait for a few second then you'll see "Backup Save Ok!" To Erase your default save press "Blank" you will be asked "The save data of "Default" will be erased?" Tab "OK" to proceed.



Cheat System

A few simple steps can activate Action Replay Codes. Cheats can also be downloaded from our website. Or you may wish to create your own cheat file. After having a cheat file you will have to drag the cheat file onto your M3 DS Real. You may create a folder name "cheats" to store your cheat files, which will become easier to find later on.

After you have drag the cheat database file onto your M3 DS Real, simply select this cheat file on the game menu. You notice when you select a game it will open up to a list of options.

Select File... Cheat Switch Softreset Key SlowMotion Switch SlowMotion Level

At this point tab on "select file" locate where your cheat file is stored. Once you find your cheat file tab it twice. A pop up will prompt Cheat Config it will ask you "Cheat file has been changed, Overwrite the '.gmc' config file?" Tab "ok" After that press on your Right D-Pad you will see the list of cheats available for the specific game you entered. Here just scroll and press A to select the cheats you desire. After selecting the cheats press Left on the D-pad then scroll to Start or tab Start to start the game with cheats.



At the bottom right corner you will see a message "[Y]- Download Play" In order to start Download Play you need to start the game with the "Y" button instead of the "start" button.

Enable RTS feature:

Real Time Save

Just make sure the "RT Save(L+R+SL)" or "RT Save(L+R+Y)" option at "RTS/soft reset" pulldown menu of the game configuration menu has been selected. (There is only 1 save file for a game by default. If users want to have more than one save file for the game, please press "select" when highlighting the game at the game list menu and Select the "create is1" or "create is2" option. In addition, if the capacity of the TF card is not enough for creating file, users may also delete selected files in the "My Card" menu.)

Confie	Cheat	Hard Street Street
Cheat Select File Cheat Switch	File: /s	ystem/cheat db
RT Save/Soft SlowMotion Si SlowMotion L	Rezet witch evel	Off Reset(L+R+B+A+X) Reset(L+R+B+A+Y) RT Save(L+R+SL) RT Save(L+R+Y) [Y]=Download play





Operation keys:

[up/down] = select [A] = confirm [B] = Exit and return to game

Function of the items:

SAVE (save the game status from memory to default save file .is0) LOAD (load the game status from default save file .is0 to memory)

SAVE BACKUP1 (save the game status from memory to save file .is1) LOAD BACKUP1 (load the game status from save file .is1 to memory)

SAVE BACKUP2 (save the game status from memory to save file .is2) SAVE BACKUP2 (load the game status from save file .is2 to memory)

MAIN MENU (Go back to the M3R main menu = soft reset)

Useful information:

Due to the restrictions of the system of nds, it's not easy to make it perfect. However, the load/save function is stable and we tested over 3000 of games, about 95% of games are able to use RTS function and all the status of those games can be restored and let me continue to play the game without so many problems so the overall performance of the RTS function is satisfied. To help users to use the RTC function smoothly, users may need to note the followings:

1. Please do not activate the RTS menu at the beginning of game boot up such as logo graphic is loading or showing. It's because the initial process of the game is usually still progress.

2. Please do not activate the RTS menu during which the data is being loaded or saved.

3. The graphic of a few games may not be able to restore perfectly upon loading back the save file data into memory; we suggest users may re-try to restore the game (load) at another moment. Usually, if users save the game at gameplay, please try loading back during gameplay and not from the main menu. Another example, if users save the game at the 3D state, we suggest loading the data back at the 3D state too.

4. The sound of a few games may temporary break upon loading back the save file data, we suggest closing the cover of the NDS for a second then re-opening it again. Usually, it will be able to recover without any problem in most cases.

Running Homebrew

Homebrew are run from the root of the M3 DS Real. You may also run Homebrew from a subfolder. To see these files tab on My Card this is a file explorer where you can see all your files on your M3 DS Real. Scroll down until you find the Homebrew that you wish to run.

Once you have the Homebrew highlight Press A to run it. You will be prompt with two icons: Slot-1 or Slot-2 Select which device you would like to run the homebrew. If you have a Slot-2 device you may select Slot-2 to run the homebrew.



Boot Slot Option

This is the option where you choose which slot you wish to run. Slot-1 for NDS Cart, Slot-2 for Gba Cart.



Running GBA Games

To run GBA Games from M3 DS Real, first make sure you have a Slot-2 device or the GBA Ram Pack Device inserted. Now turn on your DS once the M3 DS Real Main Menu appears tab on the GBA Icon, or scroll down with your D-pad and press A to enter the GBA Function. Once you enter the GBA Option you will see a list of games. From here simply select the game that you wish to run Press A or tab on the game to load the game.



Setting Options

Here you can set the Boot Menu On or Off and change the Skins for the M3 DS Real. Boot Menu On means when you turn on your NDS it will go to the default NDS setting screen. Boot Menu Off means when you turn on your NDS it will automatically boot M3 DS Real. Skins are stored under 'Skins' in the System folder. Once you have the skins in the 'skins' folder you may change the skin to the one you desire. You may also change your language from the setting menu.



<u>Skinning</u>

You may wish to create your own Skins for the M3 DS Real with your favorite Image Editor. All images must be in .bmp format. The dimension for the top and bottom screen image is 256x192 pixel.



Top background is named "TOP_DESKTOP" Bottom Background is named "DESKTOP" Important note the Top background currently only support 8bit BMP. While the Bottom background can be 24bit BMP.



Picture 1.1 Legends:

- 1. TOP_BAR
- 2. TOP_LINE
- 3. ABOUT_ON
- 4. MAIN_GAME_ON
- 5. MAIN_GBA_ON
- 6. MAIN_MYCARD_ON
- 7. MAIN_BOOT_ON
- 8. MAIN_MEDIA_ON
- 9. MAIN_PDA_ON
- 10. MAIN_SETTING_ON
- 11. BOTTOM_BAR



Picture 1.2 Legends:

1. MENU_BAR

2. MENU_LIST





Picture 1.3 Legends:

- 1. TABS_1
- 2. BUTTON_START_OFF



Picture 1.4 Legends:

- 1. TABS_2
- 2. SCROLL_BAR
- 3. OPTION_P_REJECT
- 4. OPTION_P_SELECT

Picture 1.5



Picture 1.5 Legends: 1. FOLDER 2. DS_FILE When you see a image file that has "ON" or "OFF" within their names this indicates that these images can have a Rollover Effect. For Example: With the "start" while it is unused it will be "BUTTON_START_OFF" when you press on it it will become "BUTTON_START_ON" In which case it means you will have to create 2 image in order for the RollOver Effect to work.



START

BUTTON_START_OFF

BUTTON_START_ON

The following Icons are capable of creating a 9 images animation effect. MAIN_GAME_ON / MAIN_GAME_OFF MAIN_MYCARD_ON / MAIN_MYCARD_OFF MAIN_BOOT_ON / MAIN_BOOT_OFF MAIN_MEDIA_ON / MAIN_MEDIA_OFF MAIN_PDA_ON / MAIN_PDA_OFF MAIN_SETTING_ON / MAIN_SETTING_OFF MAIN_GBA_ON / MAIN_GBA_OFF

After creating 9 images for the animation name it as follows: Example: MAIN_GAME_ON0.BMP, MAIN_GAME_ON1.BMP, MAIN_GAME_ON2.BMP, MAIN_GAME_ON3.BMP,......MAIN_GAME_ON9.BMP. You may have less then 9 images just be sure to name them correctly. Maximum number of images use in the animation effect is 9.

Once you have the whole skin created put all the images into a folder call Skin1, Skin2, Skin3, or Skin4. This Skin folder will have to go under the system folder.

