
Orbit Support Pack for Excel®





user manual



Information in this document is subject to change without notice. Companies, names and data used in examples herein are fictitious unless noted otherwise. No part of this document may be reproduced or transmitted in any form or by means, electronic or mechanical, for any purpose, without the express permission of Solartron Metrology.

© 2006 Solartron Metrology Ltd. All rights reserved.

Orbit is a trademark of Solartron Metrology Ltd.

Microsoft®, Windows® 98, Windows® ME, Windows® 2000, Windows® XP, Windows NT® and Excel® are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

All other brand names, product names or trademarks belong to their respective holders.

Orbit Support Pack for Excel® is not sponsored, affiliated or endorsed by the Microsoft® corporation.

ORBIT SUPPORT PACK FOR EXCEL®

SOLARTRON METROLOGY LTD. ("Solartron")

IMPORTANT - PLEASE READ CAREFULLY.

By installing, copying or otherwise using the Orbit Support Pack software ("Software") you agree to be bound by all the terms and conditions of the Licence Agreement. If you are the original purchaser of the Software and do not agree with all of the terms and conditions of the Licence agreement, promptly return the unused Software to the place from which you obtained it for a full refund.

Solartron Orbit Support Pack for Excel® End User Licence Agreement

GRANT

Solartron grants to you a non-exclusive licence to use the Software and the accompanying documentation on the following conditions.

The Software may be used only on a single computer and by a single user at any one time. The Software may be stored on a storage device such as a network server, provided you use technical or procedural means to prevent usage by more than one person at anyone time.

The Software may be copied for archive or backup purposes only.

No copies may be made of the documentation.

The Software may not be modified, translated, decompiled, disassembled or reverse engineered except to the extent permitted by the relevant English law.

No derivative works may be created based on the Software.

The end user may not sub-license, rent, lease, grant a security interest in or transfer rights to the Software, except as set out below.

No proprietary notices, trade marks or copyright notices may be removed from the product.

TITLE

Title, ownership and intellectual property rights in the Software shall remain the property of Solartron.

COPYRIGHT

The Software is owned by Solartron and is protected by copyright laws and international treaties. Except as provided for above, copying of the Software is expressly forbidden.

TERMINATION and TRANSFER

This licence will terminate automatically if you fail to comply with the limitations set out herein. On termination, your rights to use the Software will cease. Failure to cease using the Software and to destroy all copies of the Software and documentation after infringement may lead to civil proceedings being taken against you.

You may transfer the Software and the accompanying written materials to a third party on a permanent basis, provided you retain no copies and the recipient agrees to be bound by the terms of this agreement.

LIMITED WARRANTY

Solartron warrants that the product will perform substantially in accordance with the accompanying written materials for a period of ninety days from the date of receipt.

Solartron's entire liability and your exclusive remedy shall be replacement of the Software upon return of the media to Solartron together with your invoice. This warranty is void if failure of the Software is due to accident abuse or misapplication. Replacement Software will be warranted for the remainder of the ninety day period and according to the same conditions as the original.

Solartron does not warrant that the Software will meet your requirements or that the operation of the Software will be uninterrupted or error-free or that defects in the Software will be corrected.

In no event shall Solartron be liable for any damages whatsoever (except personal injury or death resulting from Solartron's negligence) including, without limitation, consequential loss, damages for loss of profits, computer malfunction or loss of information arising out of the use or inability to use the Software or from errors or deficiencies in it or in the disk(s) on which it is supplied.

The express terms of this Agreement are in lieu of all warranties, conditions, undertakings, terms and obligations implied by statute, common law, trade usage, course of dealing or otherwise all of which are hereby excluded to the fullest extent permitted by law. In no event shall Solartron's liability exceed the amount paid by you for the Software. This does not affect your statutory rights.

MISCELLANEOUS PROVISIONS

This agreement shall be governed by English law.

Index

1.0	Introduction	2	3.0	The Orbit Network Link	6
	This manual	2		Getting started	6
	PC system requirements	2		Setting up the Link	6
				Edit Link settings	7
2.0	Installation	3		Orbit Network settings	8
	Overview	3		Opening the Link	9
	Installing the Orbit controller	4		The Orbit toolbar	9
	Connecting the Orbit Network	4			
	Installing the software -		4.0	Examples	10
	Orbit Support Pack for Windows®	4			
	Orbit Support Pack for Excel®	5	5.0	Glossary	11

Return of Goods

1.0 Introduction

Introduction

The Orbit Support Pack for Excel® software enables you to take readings from up to 31 Orbit Modules forming an Orbit Network and place them in cells of an Microsoft® Excel® spreadsheet.

The program is designed to work with the Solartron Orbit Controllers (Orbit Network Cards, Orbit RS232 Interface Module and Orbit USB Interface Module).

This manual

This manual describes the installation and preparation and also provides information and guidance on using the software.

PC System Requirements

PC Hardware Requirements

- Personal or Multimedia computer with a Pentium processor running at 700 MHz or above with 128 MB or more RAM
- An available PCI slot, COM port or USB port.
- Microsoft Windows® 32 bit operating system (Windows® 98,Windows® ME, Windows® 2000, Windows® XP, NT4® (SP6) or later)
- VGA or higher resolution video adaptor (Super VGA, 256-colour recommended)
- Microsoft® Mouse or compatible pointing device

PC Software Requirements

 Microsoft® Excel® 97, Excel® 2000, Excel® 2002 or Excel® 2003

2.0 Installation

Overview

This section will guide you through the steps required to complete a successful installation of the Orbit Support Pack for Excel® software.

Install the Orbit Support Pack for Windows® software (freely downloadable from www.solartronmetrology.com)

Û

Install the Orbit controller(s)

 $\hat{\Pi}$

Connect the Orbit module(s)

 $\hat{\mathbf{U}}$

Install the Orbit Support Pack for Excel® software

2.0 Installation (cont.)

Installing the Orbit controller

Refer to the appropriate Orbit controller installation documentation.

Connecting the Orbit Network

Connect the modules that will form the Orbit Network to the Orbit controller. Please refer to the Orbit Network Measurement System Network Card and Driver manual (part no. 501620).

Installing the Orbit Support Pack for Windows® software

Before you can use the Orbit Support Pack for Excel® software, you must have the Orbit Support Pack for Windows® software installed on your computer; this is supplied on the Installation CD in the OWSP folder. Refer to the Orbit PCI MKII Network Card manual (part no. 502566) for Orbit Support Pack for Windows® software installation instructions. If you already have the Orbit Support Pack for Windows® software installed, proceed to the next page - Installing the Orbit Support Pack for Excel® software.

Refer to the readme.txt file for details of where the Orbit Support Pack for Excel software files are installed on your system.

2.0 Installation

2.0 Installation (cont.)

To install the Orbit Support Pack for Excel® software

- Insert the Orbit Support Pack for Excel® software disk into the appropriate drive
- Using the Windows® Start button, select Run
- Select Browse and locate D: SETUP.EXE (where D: is the CD drive). Select Open, then click
 OK

The installation is now complete!

The Orbit Support Pack software has loaded an Excel Add-In. This can be accessed via the Orbit menu that has now been added to the Excel toolbar.



To disable the Orbit Add-In & remove the Orbit menu from the Excel toolbar: In Excel, select **Tools, Add-Ins** & unclick the **Orbit Link** check box. This will remove the active mark.



To enable the Orbit Add-In and add the Orbit menu (having disabled it from the Excel toolbar):

In Excel, select Tools, Add-Ins & click the Orbit Link check box.

3.0 The Orbit Network Link

Getting started

- Open Excel
- Select Orbit from the Excel toolbar

The Orbit Support Pack for Excel software works via the Orbit Network Card, the Orbit RS232 Interface Module or the Orbit USB Interface Module. The communication between the Orbit Network and the spreadsheet is referred to as the **Link**.

The Link can be open or closed.

When the link is open, readings can be obtained from the Orbit module(s) & placed within cells of your spreadsheet. When closed, readings cannot be taken.

Setting up the Link

The Link has to be configured before communication with the Orbit Network can begin.

When working with an Excel file (workbook) that has not previously been used with the

Orbit Support Pack software, you must configure the Link via **Edit Link Settings** before taking readings.






The Orbit Link Settings are saved with the workbook. Ensure you save the workbook to preserve your current setup.

3.0 The Orbit Network Link (cont.)

Edit Link settings

When **Edit Link Settings** is selected, the *Orbit Link settings* dialogue box opens which allows you to change how and where readings are placed in the Excel worksheet.

Worksheet Name	Lists the names of the available worksheets in the active workbook. Use this control to select the destination worksheet for your Orbit readings				
Initial Cell Address	Sets the cell in which the first of the Orbit readings is to be placed. The address can be in A1, \$A\$1 or 'Name' format				
Place next reading	Use this control to select where subsequent readings will be placed. The choices are next row, next column, same row or same column				
Stop after X readings	Sets the number of readings to take before automatically closing the Orbit Link				
Don't Stop	Use this control to override the automatic closing of the Orbit Link				
• Units	Sets the unit of measure for all the Orbit readings placed on the spreadsheet				
Sample On	Selects the event that triggers Orbit readings.	• SPACEBAR	Using keyboard functions		
		• ENTER			
		• ENTER (numpad)			
		• TIMER	Automatically using the PC system timer		
Delay (seconds)	Sets the delay between subsequent readings when Sample On is set to TIMER . (1 to 9999 seconds, 0 for continuous readings)				
Set up Orbit Network	Calls up the Orbit Network Settings dialogue box				




3.0 The Orbit Network Link (cont.)

Orbit Network settings

This dialogue box allows you to add and remove Orbit modules on an Orbit Network

- Select the Orbit Network you wish to use from the Orbit Network Name listbox
- Select the Orbit module number (1 to 31) that you wish to use (usually starting with number 1)
- Select New
- Press the tip of the first probe that you want to use. The 10 character Orbit module ID will be saved. (The Orbit module number will be increased by 1)
- Repeat steps 2 to 4 for all other probes to be used
- To remove an Orbit module, select the appropriate Orbit module, select Clear and the 10 character Orbit module ID will be replaced with 'Empty'
- Select OK



3.0 The Orbit Network Link (cont.)

Opening the Link

To receive readings from modules on the Orbit Network, the Link needs to be open. From the Excel toolbar, select **Orbit**, **Open Link**. You are now ready to take readings from the Orbit Network.



When Excel has created a successful link with the Orbit Network, the Orbit toolbar will appear on your spreadsheet.

The Orbit toolbar

Zero readings	While the link is open, the used to set the current reading(s) to zero. All subsequent readings will be referenced to this zero datum. This action cannot be undone.		
Take readings	Click (or press the key that you have assigned to trigger a new reading) to place readings in your spreadsheet. If Sample on has been set to TIMER, this button		
	will start the timer.		
• Restart	Clicking the Restart button will set the current destination cell address to the initial cell address that was set via the <i>Orbit Link Settings</i> dialogue box.		
Close Link	Click to close the link. This will also stop the timer when Sample On is set to TIMER . If the active key is pressed after the Link has closed, it will return to its original function and not take any more readings from the Orbit Network.		

4.0 Examples

Included examples

The Orbit Support Pack for Excel® disk contains three examples to help you get started.

The examples are designed to show different aspects of the Orbit Support Pack Add-In.

After loading the example you will need to assign the Orbit module (refer to page 8 Orbit Network settings).

Example 1

Takes 5 readings from an Orbit module. A new reading is taken each time the spacebar is pressed.

The individual readings are displayed in a table, together with the mean. The reading values are also displayed on a bar graph.

Example 2

Automatically takes readings from any two Orbit modules every second.

The readings are then placed in a worksheet called 'Reading', and a two column graph is shown on a worksheet called 'Graph'.

Example 3

Automatically takes continuous readings from an Orbit module.

The reading is placed in a cell in the worksheet. The Limits table allows you to enter your upper and lower limits. The graph shows a simple column display that changes colour (from red to green) when the reading is within limits.

5.0 Glossary

Terms used in this manual

• Add-In	Components that can be installed on your computer to add commands and functions to Microsoft Excel	
• Link	The communication between the Orbit Network and the Excel spreadsheet	
Orbit Link Settings dialogue box	Allows you to change how and where the readings are placed in the Excel worksheet	
Orbit menu	When the Orbit Add-In is present, the menu is added to the Excel toolbar	
Orbit module	Any device which connects to the Orbit Network and communicates using the Orbit Network protocol	
Orbit module ID	Each Orbit Module has a unique 10-character ID to identify it on the Orbit Network	
Orbit Network controller	A device that can communicate with Orbit modules using the Orbit Network protocol. Current Orbit Network controllers are: Orbit Network Card - two-channel card for PC's Orbit RS232 Interface Module - single channel module for any device with an RS232 port. Orbit USB Interface Module - single channel module for any device with a USB port	
Orbit Network Settings dialogue	Allows addition and removal of modules on the Orbit Network	
Orbit toolbar	When the Orbit Network Link is active the toolbar appears on the spreadsheet	