



User Guide

Contents

Welcome	2
Set Up	1
The Home Page	7
Using the Main Features	9
Backing Up and Recovery	
Backup	
Recovery	
Configuring Media Players TwonkyMedia	
SlimDevices SqueezeCenter 7.3	
Firefly	
iTunes Windows Media Player	
Linn DS Series	
Nokia N800	
Wii	
Sonos	
Importing photos from your camera	
Using a Wi-Fi Photo Frame	19
Manage Podcasts	20
Configuring Photo and Video Sharing	21
DynDNS Control	22
Password Control	22
Advanced Settings	
Recording Settings	
Metadata Options Run Script	
Network Configuration	
Adding Wireless Support	
RAID	
Trouble Shooting Guide	
Specification and Features	31
Licensing	32
Warranty	33

Welcome

Congratulations on your purchase of XiVA's musicm8 product, and welcome to the XiVA community. Because the XiVA team have done their utmost to ensure that your musicm8 is of the highest quality, your machine should provide you with years of excellent service as the heart of your digital home.



What is musicm8?

musicm8 is a Network Attached Storage solution to securely store music, movie and picture files on a typical home network, with a usable storage capacity of 1TB (terabyte), or almost 10,000 songs.

Simple NAS devices are in significant demand as home storage needs grow. However, musicm8 is a world first by using XiVA's proven CD conversion technology; musicm8 incorporates a slot load CD drawer and CD recording engine.

For a user who wants to store all their music files on a network device, this provides the means to simply insert and record a CD unattended, with no PC required and have it available to all their music devices and PCs throughout the home without any configuration or set up.

Compatible devices

Archos - Buffalo - B&O - Denon - D Link - iTunes - iPod Escient - Linn DS - Logitech - MCE -Naimnet - Netgear Philips - Pinnacle - PS3 - Roku - Slim Devices - Sonos - Sony - Xbox 360 - Yamaha and any media player or device that can browse a network share

Set Up

What's in the box?

- musicm8
- Power supply and cable
- Ethernet cable

musicm8 Default Settings

Your musicm8 has been preconfigured with XiVA's recommended default settings, for ease of use and quick set up.

What you need

A way to plug your musicm8 into your home network; a direct connection into your router or network switch is perfect, but you can treat your musicm8 like a computer and plug it into any other Ethernet connection in your home.

If you need to place your musicm8 in a room which does not have an Ethernet socket, we recommend you use a 'Homeplug' device, for example:

http://catalog.belkin.com

Note: a broadband connection is required. Dial-up internet connection is not supported.

Please ensure that the disc slot is not obstructed. When a disc has been recorded, it is automatically ejected from the slot. If the slot is blocked when the disc is ejected, this can result in damage to the drive.

Default Encoder Settings: MP3 320 kbps

musicm8 Default Shares

<u>\\musicm8\shared\Muslc</u>

\\musicm8\pictures

\\musicm8\shared\Playlists

\\musicm8\video

\\musicm8\databackups

These settings can be changed and new shares can be added at any time via the musicm8 web interface.

Set Up in 4 Quick Steps

Step 1 - Connecting the unit up.

Connecting the Ethernet cable to the musicm8

Connect your supplied Ethernet cable to a spare port on your router.

Then connect it to your musicm8 as shown below. Do this before you plug the power supply into your musicm8.



If you are unsure where to connect your Ethernet cable to your musicm8, the port is marked on the back of your unit with the LAN network symbol

]
古	Ь

When connected, you should see a green light on your musicm8 network port.

Connecting the power supply to your musicm8

Connect your power supply to a mains power socket. (Plugs vary in each country)

Connect the power supply output to your musicm8 unit.



Your musicm8 power connection is labelled DC IN and is located near the middle on the rear of your unit.

musicm8 Rear Panel



Note:

In most cases only the network LAN port connection will be used.

USB connections can be used to back up your media collection. See the backup section on page 10.

Use of the USB connections for any other purpose is not supported.

Power up your musicm8

Press the power button briefly to turn on your musicm8.

The power button is located just below the cd slot on the front of the unit.

You will see the small, blue light on the front of the unit glow when it turns on. After a few moments, your musicm8 will beep to let you know that it has started up.

For most media players no further configuration of musicm8 is required.

Set Up in 4 Quick Steps

Step 2 - Optional

Step 3

Configure your musicm8 with the web interface

Depending on your operating system and network setup, there are a few ways to connect to the musicm8 web interface.

Open a web browser - Internet Explorer, Firefox, and Safari are all great choices - and verify that you have an active Internet connection by visiting any website (we recommend checking out <u>www.XiVA.com</u>).

Note: Google Chrome is not yet supported.

Then, in the location bar of your web browser, type "musicm8" (without quotes) and choose "go" or hit enter on your keyboard. You will then be prompted for a user name and password which is:

Username: admin Password: musicm8

If you do not see the web interface appear in a few moments, try typing "musicm8.local" or "//musicm8" into the location bar. Again; no quotes.

You may have to directly type the IP address of your musicm8 into the location bar instead. If this is the case, and you don't know your musicm8's IP address, you can download the XiVA IP Tool from:

XiVA.com/musicm8/downloads/musicm8iptool.zip

If the musicm8 web interface does not appear after following these steps, please refer to the troubleshooting guide on page 42.

Recording your first CD with musicm8

Recording CDs is quick and easy - just insert the disc into your musicm8 and walk away!

In a few minutes, your musicm8 will beep and gently eject the disc. A few moments after that, your CD will have been encoded and be available for playback via your selected media player.

Make sure nothing is blocking the disc slot. If the unit ejects the CD and the slot is obstructed, the drive could be damage.

Set Up in 4 Quick Steps

Step 4 - Optional

Connecting to your musicm8's shared folders

musicm8 does exactly what its name suggests. It is a server which makes your music available throughout your home.

It does this by storing and accessing your music through shared folders, as well as letting you listen to your music through a wide range of media players.

After successfully connecting your musicm8 to your network, it's easy to connect to your musicm8's shared folders.

Microsoft Windows XP and Vista (all versions)

Navigate to **My Network Places** in Windows XP or **Network** in Windows Vista. Folders with titles such as **Shared on musicm8** and **Pictures on musicm8** should appear in the window. If not, click on **Add a Network Place** in the left pane of the window, and follow the next steps:

- Choose Next in the Add Network Place Wizard.
- Select Choose Another Network Location and click Next.
- Choose Browse in the next window. You should then see a folder icon titled

Shared on musicm8. If not, continue on to the next step.

- Click on Entire Network then Microsoft Windows Network then
 Workgroup.
- Click on Shared on musicm8 and choose OK, then click Next.
- Click **Next** again, and click **Finish**. You should now see **Shared on musicm8** in the **My Network Places** window.

Mac OS X

Navigate to musicm8 by selecting **Go** from your desktop.

Select **Connect To Server**. You will be prompted to enter the address of musicm8.

In most cases **<u>smb://musicm8</u>** will take you to your musicm8 shared folders.

In some cases you may need to enter the IP address of

your musicm8. When prompted for the address type

smb://192.168.1.20 or whatever your musicm8 IP address is.

Simple Configuration Settings

Setting the Date and Time

Open the **Miscellaneous** menu and click **Set date and time.**

Set the system date and time by changing the values in the drop down menus and clicking the **Update** button.

To Update your XiVA Software

From the Updates menu on the left sidebar, select **Check for Updates** to see if there is a more recent version of the software for your musicm8.

To download and apply any available automatic updates, click **Auto Updates**.

To check for the latest software updates available for musicm8, visit

http://www.xiva.com/musicm8

Follow the steps listed to download and install updates.

Using the Interface

Getting to the Interface is as simple as opening as browser and typing 'musicm8'.

You will see the following screen:



The Home Page

Most of the major functions are in the basic menu; click **Show Advanced Menu** to view all available options. Each is detailed within this manual.

Top Navigation Bar

View Photos – will open a photo gallery page with a slide show effect.

Play Music – will open the musicm8 silverplay music player to allow you to play all of your music from any computer on your LAN. **NOTE**: this playout is password protected with the password **musicm8** – the username is blank.

The top navigation bar also allows you to configure and use the additional servers installed on your musicm8 device. **Please refer to Configuring Media Players with your musicm8** on page 17 before changing these settings.

 $\ensuremath{\mathsf{Twonky}}$ – Opens the Twonky vision pages should you need to set any advanced options

 $\ensuremath{\textbf{Squeezecenter}}$ – opens the Squeezecenter pages should you wish to change any advanced options

Firefly – opens the Firefly media server pages for advanced configuration

Please ensure you know what you are doing when viewing the server pages – changing these options away from the preconfigured defaults could affect the performance of your system!

Browse Menu

Located in the left sidebar, the **Browse** menu gives access to all the music, video and pictures stored on your musicm8 and enables you to stream or download content from any PC on your network.

To access your music, select **Browse Music** from the menu. Your music collection will be displayed in a directory listing all artists. To select an artist, click on their name. To stream a track, simply click on it and it will play in the window.

To download a track choose Save As.

For the best browsing experience XiVA recommends using Squeezecenter or TwonkyMedia, but you can use your preferred media player.

Copying your music from your computer to musicm8

After connecting to your musicm8's shared folders using the previous steps, it's easy to copy music already on your computer to the musicm8. By copying your existing music to your musicm8 share you are now enabling your music to be shared over your home network for playback via a wide selection of media players. Simply select the files and/or folders you want to copy, copy them and paste them into your musicm8 shared folder.

Windows 2000, XP, Vista

- Go to the files or folders of music that you wish to copy.
- Highlight the file or files you wish to copy. If you need to highlight more than
 one file, you can hold down the CTRL or Shift keys on your keyboard or drag a
 box around the files you wish to copy.
- Once highlighted, you can either right-click one of the highlighted files and select **Copy**, or if you're in My Computer or Windows Explorer you can click **Edit** at the top of the window and choose **Copy**.
- Move to the Shared folder on your musicm8 and either right-click in the folder and choose Paste, or click Edit and click Paste.

Mac OS X

- Go to the files or folders of music that you wish to copy.
- Highlight the file or files you wish to copy. If you need to highlight more than one file, you can hold down the Command (Apple) or Shift keys on your keyboard or drag a box around the files you wish to copy.
- Once highlighted, you can either right-click (Control-click) one of the highlighted files and select **Copy**, or you can click **Edit** at the top of the window and choose **Copy**.
- Move to the **Shared** folder on musicm8 and either right-click in the folder and choose **Paste**, or click **Edit** and click **Paste**.

Using the Main Features

To Record a Disc:

Insert the disc into the drive; musicm8 will record it and then eject it automatically once the recording is complete.

Make sure the disc slot is not obstructed or it could be damaged when the disc is ejected.

If the CD is not successfully looked up on the internet, it will appear in your music library under **Unknown**.

To Backup

Connect your backup drive to any spare USB socket.

Go to **Basic menu > Backup** and press **OK** at the dialog box.

To set to Flac

Go to **Advanced Menu > Encoding Options** , check the **Flac** box and press update.

To set up a Sonos system

Open **Sonos > Add New** and type **//musicm8**, then press **OK**.

To set up a Squeeze Box

Go to your **Squeeze box > Settings > Music Library** and hit **OK** when you see 'musicm8' displayed

To view in iTunes

Open **iTunes** and from the left panel select **musicm8**. All of your content will be displayed.

Add a favorite podcast feed

From **Basic Menu > Manage Podcasts**, copy and paste your feed into the text box and hit **Add.**

Power Off

This option allows you to power off your musicm8.

You will be prompted for confirmation. To power off click Yes.

To return to main menu select No.

Are you sure?



Backing Up and Recovery

Backup

Backup musicm8 allows you to perform a complete backup of you musicm8 contents to a USB hard drive.

To perform a back up you must first connect a USB hard drive.

You may use any off the shelf USB device formatted as NTFS or FAT32.

Most USB drives come preformatted with FAT32 but check with your manufacturer if you are unsure.

On the Home Page sidebar menu, click **NAS** and select **Backup Now**.



Select Backup Now?

You will now see the message Backing Up musicm8...

Please be patient as this may take a long time

You can continue to use the musicm8 while the backup is running.

To view progress, just click the **Space** option on the menu and you will see a progress bar.

All files will be backed up to a folder called $\ensuremath{\textit{musicm8}}$ on your selected USB hard drive.

Recovery

Recovery is as simple as a Drag 'n Drop.

- Open Windows Explorer and navigate to the USB to which you backed up your media.
- Select the media you want to recover.
- Either drag it to the required location on your musicm8 or copy and paste it.
- Once your media have been copied, you can continue to use them as before.

Configuring Media Players

TwonkyMedia

Note: Twonky is pre-configured. No additional configuration is required to serve your music to a wide selection of media players.

- Select **Twonky** from main musicm8 web interface.
- On the Twonky Home Page, click the *P* spanner icon.
- Twonky Server set up page will be displayed.
- From the Twonky Server set up menu select Sharing from the Basic Set Up tab.
- Content Location 1 will be listed with the default path to your musicm8 music share: /media/Music
- If you wish to add another collection click **Browse** on Content location field 2.

Twonky has been configured to rescan your music collection every 60 minutes to allow for optimal user convenience.

You can manually configure your rescan interval by selecting **Server Set Up** then select **Sharing** from the **Basic Set Up** tab. Here you will see the **Rescan in Minutes** menu. Enter the interval in minutes that you want Twonky to rescan your selected folders.

You can find which version of Twonky you are currently running from the main Twonky UI.

Further Twonky setup information and troubleshooting steps are available from the Support section of the Twonky Media web interface.



- Browse to the collection you want to add.
- Select Rescan Content Directories and then Save Changes.

Twonky Server is now configured.

Configuring Media Players

SlimDevices SqueezeCenter 7.3

Note: Slim SqueezeCenter is pre-configured. No additional configuration is required to serve your music to a wide selection of media players.

Select **SqueezeCenter** from the main musicm8 web interface.

Slim Squeeze Center set up menu will now be displayed.

From Slim Squeeze Center set up menu select **SqueezeCenter Settings** from the **Settings** tab.

Under the **Music Folder** section you will see the default path to musicm8 share **/media/music**

Slim Squeeze Center is now configured.

If you have added new content to your share select **Rescan Music Library** select **Look For New And Changed Music** from the drop down menu then select **Rescan**.

Further Slim Server setup information and troubleshooting steps are available from the Help section of the Slim Server web interface.

Once Slim Squeeze Center has been successfully configured, connect to Squeeze Network using the Squeezebox remote.

Select Music Library using the Squeeze remote.

musicm8 will be listed as a Library.

You can now browse musicm8 content from Squeezebox

Select musicm8.

Note: musicm8 installs by default an auto scan utility to ensure that every time you record a CD it is immediately added to your squeezenetwork.



LANGUAGE

Choose the language that you'd like to use If you find problems or would like to contrib

English 💙

MUSIC FOLDER

You can specify a folder containing music filcan leave this field blank if you are importin

/media/Music

PLAYLISTS FOLDER

You can enter the path to a directory where save playlists.)

/media/Playlists

Configuring Media Players

Firefly

Note: Firefly is pre-configured so no additional configuration is required to serve your music to a wide selection of media players.

Select Firefly from main musicm8 web interface.

You will be prompted for a username and password.

Leave the username blank and enter **musicm8** as the password.

You will see the Firefly web interface.

Firefly requires minimal setup.

Click on the **Configuration** tab from the Firefly main menu.

The main fields will be pre-filled with musicm8's default settings.

musicm8 Default: MP3 Directory: /media/Music

Once configured, click **Submit**.

Once Firefly DAAP has been configured you can stream your musicm8 content through iTunes.

Further Firefly help and support is available from <u>www.fireflymediaserver.org/</u>

Configuration

Show advanced config

Config File Location	/usr/local/etc/mt-daap	d.cor
Server Name	musicm8	
Logfile	/var/log/mt-daapd.log	
Admin password	musicm8	- 0
Music Password		
Extensions	.mp3,.m4a,.m4p	
Playlist File		
Flayilse i lie		
Database	<u>L</u>	
•	0 - Normal	
Database	0 - Normal 1800	

Scan Type	0 - Normal	
Rescan Interval	1800	
Always Scan	Yes 💌	
Save	Cancel	

Configuring Media Players

listed as a shared library in iTunes.

iTunes

LIBRARY Music Movies TV Shows Podcasts Radio STORE iTunes Store SHARED PlayLISTS Party Shuffle Serius

To access musicm8 through iTunes, simply open iTunes. You should see musicm8

To play back musicm8 content through iTunes select musicm8 from the Shared Library menu and select a track.

Windows Media Player

To access musicm8 through Windows Media Player, select **Library** from Windows Media Player Menu, right click and select **Media Sharing**.



From the Media Sharing menu select musicm8 from the list of devices and select **Allow**. Your musicm8 content will now be shared to your Windows Media Player Library.

Alternately navigate to **My Network Places**. musicm8 will be listed as a shared Media Library. Double clicking on musicm8 will open your musicm8 content in Windows Media Player.

Configuring Media Players

Linn DS Series

Linn DS series requires Twonky Media to be configured from the musicm8 web interface (see page 11).

- Once Twonky Media has been successfully configured, run LinnGui software or connect with your handset;
- Select your Room



Select Source;

musicm8 will be listed as a Library. You can now browse musicm8 content.

Nokia N800

The Nokia N800 can be used as a standalone playback device or as a remote control for UPNP media players.

To setup the Nokia N800 with musicm8 follow the steps listed.

Download and install Media Streamer on your N800.

Media Streamer can be found at the following location:

http://tableteer.nokia.com/tableteer/os2008/feat_mediastreamer.xhtml

Once installed Media Streamer will be listed under Extras.

Select Media Streamer.

musicm8 will be listed as a server in the **Media Servers** window. Select **musicm8**.

From the right hand window select Now Playing.

All available playback devices will be listed from the drop down box in the **Now Playing** window.

Select a playback device.

Configuring Media Players

Wii

Open the web page of musicm8 in your pc browser by typing musicm8. Take a note of the IP address on the bottom left corner of the screen it will look something line 192.168.1.20

Head on over to your TV with your Wii attached

Ensure you have the Wii connected to your network. If it is not then please consult the Wii manual to do so.

Click Internet > Start > WWW

Type the following web address:

http://youripaddress:3689/FirePlay.html

e.g. http://192.168.1.20:3589/FirePlay.html

Username <blank> Password: musicm8

Click the Add to favorites icon and you are all set.

In use, just go to **Internet > favorites**, click the **Fireplay** icon and use the Wiimote to navigate your music which will be played back on your TV speakers

Wii.

Configuring Media Players

Sonos

Configuring musicm8 with Sonos can be done in two ways

Sonos Desktop Controller

From the main Sonos Desktop Controller Menu select Music from the drop down menu then select **Set Up Music Library**.



From the Set Up Music Library menu select Add A Share.

You will see the Sonos Set Up Wizard.

From the Sonos Set Up Wizard select.

Add Music Stored In Folders That Are Currently Stored On My Network and select Next.

musicm8 will be listed as a Network share.

Browse to \\musicm8\Music and select this location.

You can now browse musicm8 content once your music file indexing is complete.

Configuring Media Players

Sonos Remote

Press Music.

System Settings.

Music Library Management.

Music Library Setup.

Add New.

You will see musicm8 displayed in-screen. Click your centre button to add.

If not shown:

Press New.

Key in the full path to the musicm8 music folder:

\\musicm8\Music

Enter Add.

NOTE: Your musicm8 automatically builds a playlist called **recentlyadded**. **m3u** which is a playlist of the music you have added in the last 30 days. For large collections this is invaluable to listen to your most recent additions. To use it, on your Sonos remote go to **Music Library** > **Imported Playlists**, select **RecentlyAdded** and play it!



Importing photos from your camera

Backup and loading your photos is fully automated by musicm8. Simply remove the memory card or USB device from your camera and insert it in the front slot of the musicm8 unit.

All of your photos will then be imported to your **pictures** folder, in a subfolder called **usbreader**, so you can be sure they are backed up and available to anyone on your network.

The process is entirely automatic and only takes a minute or so. You will be notified when it has finished by three short bleeps from the unit, at which point you know that everything has been successful and you can remove your media card.

The process will not remove the pictures from your camera, but will provide a back up and it will only update the photos not previously transferred to the musicm8 storage system

Using a Wi-Fi Photo Frame

Your musim8 also supports all of your photo collection and acts as a server, 'pushing' your photos out across your network.

If your photo frame is a UPNP wireless type, simply set it up to look for content in **//musicm8/pictures** and you are all set.

Manage Podcasts

You can add your favorite podcasts to your musim8 and each new episode will download automatically on a daily basis to your system and be available to all devices on your network.

In the Main Menu on the left sidebar, click Manage Podcasts

Podcast Manager

Please enter your feed into the text box below and then click 'add podcast'

Feedname

Add

You have the following Podcasts set up:



Add any podcast feed URL into the text box and click Add

Each new episode will now be downloaded to your music folder in the **podcasts** subdirectory.

Configuring Photo and Video Sharing

Video Sharing

To configure video sharing from your musicm8 simply add Video content to a shared folder on your musicm8 and add the folder path to be shared to Twonky Media through the musicm8 web interface.

- Select **Twonky** from the musicm8 web interface.
- Select **Sharing** from the **Basic Set Up** menu.
- Under Content locations select an unused directory. If all directories are in use select Add New Content Directory.
- Input the path to your shared video folder. musicm8 default video share is /media/video.
- From the media type drop down select Video-only.
- Click Save Changes.

Your video directory has now been successfully added.

Twonky Media will now serve your video files to a selection of media players.

Photo Sharing

To add Photo Sharing, follow the same procedure adding the default musicm8 share **/media/pictures**.

When configured with musicm8 default setting, your Twonky interface should look like this:

(OP)	IONT.	1.00.21	none
CUIII		Locat	

/media/Music	
Music-only 💽 Browse	
/media/pictures	
Pictures-only 🔽 Browse	
/media/videos	
Video-only 🛛 Browse	
⊻	
All content types 💌 Browse	
Add new content directory	

DynDNS Control

DynDNS is a service provided by www.dyndns.org and allows your musicm8 to be accessed across the web.

To enable DYNDNS, click this option and follow the onscreen instructions to sign up for a free DYNDNS account – this will assign a simple URL to your box that you can access from anywhere.

This menu option simply allows you to set this ability On or Off.

DYNDNS configuration

After signing up for an Dynamic DNS account, simply key your details into the **DYNDNS Configuration Manager** by selecting **DYNDNS Config** from the NAS menu. Click Update to save the details.

Password Control

The web interface of your musicm8 is protected by a password. To disable this protection, open the NAS menu and select **Password Off**.

To re-enable it, select **Password On**.

Advanced Settings

Recording Settings

All Recording settings are accessed via the Recording tab on the left sidebar.

Change Encoder Settings This menu allows fully customizable recording.

Select a codec - MP3, FLAC or WAV by clicking the relevant radio button.

MP3: When recording to MP3 the bitrate is configurable by the MP3 bitrate drop down menu. The available bitrates are 128kbps, 192kbps, 256kpbs or 320kbps.

FLAC: When recording to FLAC the compression level is configurable by the FLAC compression level drop down menu. The available compression levels are 1 to 8.

WAV: When recording to WAV be aware that no metadata is written to the WAV file.

You also have the option to dual encode to either FLAC + MP3 or WAV + MP3.

FLAC + MP3 selected musicm8 will encode to both FLAC and MP3. MP3 files will be stored in <u>\\musicm8\shared\MP3</u>. FLAC files will be saved to <u>\\musicm8\shared\Mp3</u>. Music

WAV + MP3 selected musicm8 will encode to both WAV and MP3. MP3 files will be stored in <u>\\musicm8\shared\MP3</u> WAV files will be saved to <u>\\musicm8\shared\MP3} WAV files will be saved to <u>\\mus</u></u>

Your files are stored this way to avoid duplicate entries when files have been indexed.

A detailed overview of audio compression can be found at en.wikipedia.org/wiki/Audio data compression

If you have made changes to your encoder type and wish to save the changes click Update. The new encoder settings will now be used when recording audio CDs.

Default encoder settings: MP3 320kbps; FLAC compression level 5.

Metadata Options

Click **Metadata Options** to select how musicm8 creates the folder structure and filename and metadata of each disc recorded.

There are three Options available

Filename Options

Track## - TrackName.ext
 Artist - Album - Track## - TrackName.ext
 Artist - Album - Genre - Track## - TrackName.ext

Eject disc on no metadata found



Option 1: Track ## - TrackName.ext

This option will create a file with track number followed by track name, followed by the file extension.

e.g. 01. A Message To You Rudy.mp3

Option 2 : Artist - Album - Track##TrackName.ext

This option will create a file with artist name, followed by the album name, followed by the track number, followed by the track name followed by the file extension.

e.g The Specials - Greatest Hits - O1- A message To You Rudy.mp3

Option 3: Artist - Album - Genre - Track## - Track Name.ext

This option will create a file with the artist name, followed by the album name, followed by the genre, followed by the track number followed by the track name followed by the file extension.

e.g. The Specials - Greatest Hits - Ska -O1- A message To You Rudy.mp3

The default setting is Option 1 Track ## - TrackName.ext

Eject disc on no metadata being found

When this option is checked, musicm8 will automatically eject a disc if no album information has been found via internet lookup, and will give you an audible indication of this.

By default, this setting is disabled, and the CD will be recorded into the Unknown section.

Recording Status

Recording Status displays the status of the disc currently being recorded. If there is no disc in the CD drive status will display

No CD in drawer...

When a disc has been loaded and a metadata lookup is being performed Recording Status will display

Disc found, waiting for data...

When a disc has been loaded and a metadata lookup has been successful recording will begin. Recording Status will display the CD artist, album name, track number and track length.

Recording Status will also display the progress of each track as it is being recorded and the overall time remaining to record disc.

If at any point you wish to cancel recording, click Stop. Recording will stop and the disc will be ejected, deleting any temporary files.

Encoder Status

Encoder Status displays the status of the current encode process. Your musicm8 initially records audio CDs to an uncompressed lossless (WAV) format and encodes on-the-fly as a background process.

If there are no encode processes currently running, Encoder Status will display

Waiting...

When encode processes are running, Encoder Status will display the path to the file currently being encoded.

Encoder Status also displays estimated time and remaining time in seconds for the file to be encoded.

Run Script

Run script feature is designed to run XiVA approved script. XiVA scripts perform a wide range of functions from software updates to bug fixes.

XiVA regularly release new script. Script and instructions on how to run a scripts can be found by contacting musicm8 support.

http://www.xiva.com/musicm8

IMPORTANT: Only script that have been approved by XiVA should be run using this facility. Script from other sources may be damaging and will void your musicm8 warranty.

Network Configuration

Changing Network Settings

Your musicm8 requires a network IP address. To change the settings, open the **Network** menu on the left sidebar and select **Change IPb**.

The IP address can be assigned automatically by checking **Use DCHP?** This will assign a dynamic IP address for the musicm8 on your network. **Use DCHP?** is checked as a default setting.

The IP address of your musicm8 can be assigned manually instead.

If you wish to manually configure the IP settings of musicm8 you can do so by deselecting **Use DHCP?** and supplying the rest of the settings yourself.

When manually configuring IP settings, Netmask and Gateway are both required as well as both DNS servers. If you have only one DNS server, you must enter the same address for both DNS Server 1 and DNS Server 2.

Select Update to apply changes.

IP Settings

Use DHCP?	(overrides values below)
IP Address:	
Netmask:	
Gateway:	
DNS Server 1:	172.20.80.1
DNS Server 2:	172.20.80.2
Update	

Network and Shared Folders

Within the Network menu, the following options are available.

View Network Hosts

View Network Hosts displays all other Universal Plug and Play storage devices currently connected on your network.

Change Workgroup Setting

Your musicm8 will automatically be assigned to an existing workgroup, most likely MSHOME. If you wish to change the workgroup your musicm8 is assigned to, enter the new workgroup in the Set Workgroup Name box and click Update to apply the changes.

Note: Changing workgroup is not recommended unless you have previous experience with workgroup settings.

Create a Shared Folder

To create shared folders on your musicm8 select **Create a Shared Folder** from the Network menu.

Existing Shares

- shared
- video
- pictures
- music
 databackups
- databackups
 JamesTestUi

New Share Name



In the **New Share Name** field type the name you wish your share to have. Click **Update**. The share will now be created at the following location:

\\musicm8\shared

Delete a Shared Folder

To delete a shared, folder from your musicm8 select **Delete a Shared Folder** from the musicm8 Network menu.

Existing Shares		
Select share to delete:	video	~
Delete this share		

You will see a drop down box which lists all existing shares. Select which share you wish to delete form the drop down box then click **Delete this share**.

Be aware that this will also delete any content, eg music, saved in this share.

The selected shared will now be deleted.

Adding Wireless Support

Connecting your musicm8 to your Squeezbox

musicm8 can be connected directly to your **Squeezebox**, making it wireless through the bridge function in the Squeezebox

To connect the musicm8 and the Squeezebox together:

• With the Squeezebox turned off, connect your powered on musicm8 to the Squeezebox with a crossover Ethernet cable

For information on crossover cables, see this link <u>http://en.wikipedia.org/wiki/Ethernet_crossover_cable</u>

• Then power up the Squeezebox, when prompted in the settings for the **Bridge to Ethernet** option, set this to **yes**, then continue with the remaining settings (if you have already configured your musicm8 for use with squeeze, these should not need to change)

You will then be able to access your musicm8 as you would normally.

Connecting your musicm8 using a Belkin Wireless G Gaming Adapter

For information about this device, please see this link <u>http://catalog.belkin.com/IWCatProductPage.process?Product_Id=154416</u>

- Connect your Wireless G Gaming Adapter to a computer on your home network via the supplied USB cable.
- Insert the supplied Belkin Wireless G Gaming Adapter set up CD. Follow the set up wizard to configure your Belkin Adapter.
- Once configured, with your musicm8 powered off, connect your Belkin Gaming Adapter to your musicm8 with an Ethernet cable.
- Power on your musicm8

You will then be able to access your musicm8 as you would normally.

RAID

What is RAID?

RAID is a technology that supports the integrated use of two or more hard disk drives in various configurations for the purposes of achieving greater performance.

If you have chosen optional RAID support, settings can be configured through the web interface by selecting RAID.

For further technical information on RAID please visit:

en.wikipedia.org/wiki/RAID

RAID Configuration

musicm8 uses RAID technology to perform a scheduled backup your musicm8 contents to a USB hard drive. RAID expects the USB drive to be formatted with VFAT. When RAID is enabled for the first time musicm8 will back up its complete contents to your selected USB hard drive, please allow time for this process to complete.

Once the initial back up is complete musicm8 will then perform a check every 15 minutes for new or changed files and back up any additions or changes accordingly to your selected USB hard drive.

To enable RAID

From the musicm8 Home Page, click NAS and select RAID from the submenu. From the RAID configuration page check Enable RAID radio button



Click update. You should see the message Settings updated... .

If you wish to disable RAID simply check **Disable RAID** radio button and click update.

For advanced RAID configuration details visit:

http://www.xiva.com/musicm8

Trouble Shooting Guide

Q. I have typed musicm8 into a web browser on a PC connected to the network and do not see the musicm8 web interface?

A. First type http://www.google.com/ into your web browser. If you can see the Google search page, then continue to the steps below.

If you cannot see the Google search page, verify your router is working properly and you have an active internet connection.

Verify your supplied Ethernet cable is connected correctly to your musicm8.

Verify your Ethernet cable is connected correctly to your router.

Verify your unit is powered on.

If your unit is correctly connected and powered on, type musicm8 into a web browser. If you do not see the musicm8 web interface follow the next link to download the XiVA musicm8 Locator Tool, which will provide the IP address of your musicm8 unit:

http://www.XiVA.com/musicm8

In a web browser enter your IP address in the address bar. (The IP address will look a bit like 192.168.1.20.)

You should now see the musicm8 web interface. If the IP address does not display the musicm8 web interface, then contact the XiVA support team.

USB Ports

The USB ports on this unit are intended for use to back up your media collection to a connected USB storage device. Use for any other purpose is not supported.

Diagnostic Files

Diagnostic files are created to help in the support process. All actions carried out by musicm8 are logged in one of the following files:

View Running Processes

From this menu you can view all system processes currently running on musicm8.

List hardware

From this menu you can view the current hardware configuration of musicm8.

View Error Log

From this menu you can view any error logs generated by musicm8.

View Record Log

View all of the activity of each CD you have recorded

View Backup Log

View all details of each back up process, its files and its progress

If at any point you need to contact XiVA Support you may be asked to provide these files.

Miscellaneous

Reboot musicm8

This menu allows you to Reboot your musicm8.

You will be prompted with the message Are You Sure? Yes/No. To Reboot click Yes. To return to main menu, select No.

Specification and Features

- Linux OS
- Atom 1 GHz processor/1024MB RAM
- Integrated slot load Panasonic DVD drive
- Automated Recording
- Ripsure error correction
- FLAC and MP3 options with configurable bit rate
- Dual encoding
- High quality metadata and cover art
- 1TB storage
- Optional RAID protected storage
- Web browser configuration
- Auto network share
- Full iTunes DAAP support
- Configurable path to record to allow additional NAS devices
- Integrated UPnP server Slim Squeezecenter 7 and Twonky
- DLNA Compliant
- Full backup ability
- Support for Video and photo UPnP streaming
- Shared folders for video, audio and photos
- Optional USB expansion system
- Network, VGA, USB, PS2
- Camera picture sync

- Recently added playlist generation for Sonos
- Size: 23 x 23 x 19 CM
- Black or white casing
- 110 240 V
- Power requirements 28 W when idle, 33 W when recording a CD.
- ROHS and CE Compliant
- Wake on LAN
- Auto power recovery

Licensing

Certain elements of musicm8 are licensed under GPL, which supports the distribution of open source software. Consequently some of the code base is available to download freely and may be modified or reused in any third party device.

CentOS is distributed under its GPL conditions.

FLAC is distributed under the BSD license.

GD3 is used under license form Get Digital data.

TwonkyMedia is used under license from Packet Video.

Slim Squeezecenter is used under its GPL conditions.

Firefly is used under its GPL conditions.

All other software is Powered by Ripstation from Formats Unlimited, Inc and \circledast 2009

Contact

Imerge Ltd Unit 6, Bar Hill Business Park Saxon Way, Bar Hill, Cambridge, CB23 8SL United Kingdom

Tel +44 (0)1954 783600 Fax +44 (0)1954 783601 Email: hello@XiVA.com

Warranty

XiVA's musicm8 product comes with a 2-year limited warranty (unless othewise stated in local law), valid from the date of purchase. XiVA warrants in good operating condition for the warranty period. XiVA warrants your musicm8 against any defect in material and workmanship, under normal use, for the designated warranty period. This warranty does not include non-XiVA installed software and/ or components. If the musicm8 malfunctions during the warranty period, XiVA (or its distribution partner) will, at its discretion, repair or replace the product at no charge, provided the product has not been subject to any misuse, abuse or non-XiVA authorised alterations, modifications or repairs.

All expressed and implied warranties for the musicm8 product are limited in duration to the above period.

Under no circumstances shall XiVA be liable in any way to the user for damages, including (but not limited to) lost data, lost information or other incidental or consequential damages arising out of the use of, or inability to use, the musicm8 product. Additionally, XiVA reserves the right to revise or update its products, software, or documentation without obligation to notify any individual or entity.

The warranty does not cover:

- Physical damage (however caused)
- Theft
- Loss
- Loss of data and data corruption
- General wear and tear

 Software configuration issues (after the first successful boot up, from date of delivery)

Software viruses

If you have modified or adapted your system without the specific permission of XiVA, or where any maintenance work has been carried out by an unauthorized third party, your warranty is considered to be null and void.

The warranty is void if:

- The product was operated/stored in abnormal use or maintenance conditions
- The product is repaired, modified or altered by an unauthorized person

• The product was subjected to abuse, neglect, electrical fault, improper packaging, accident or acts of nature

• The product was installed improperly

• The serial number of the product is defaced or missing

As a storage mechanism, under various circumstances, such as damage from extreme conditions, eg floods, power fluctuations, or physical misuse or abuse, the data on the hard disk may be inaccessible through normal operation. However under such circumstances, the data may be recoverable through extraordinary means offered by a specialized data recovery service. XiVA does not offer any data recovery services. If you are unable to access data on your drive due to damage such as that mentioned above, you may wish to consider contacting an independent data recovery service.

Returning a machine

When returning a product to XiVA (or its distribution partner), you must include a proof of purchase. Return requests cannot be processed without this. Shipment of a returned musicm8 is entirely the responsibility of the purchaser.

When it is necessary for a musicm8 to be returned to XiVA (or its distribution partner) for repair, you will be issued with Return Material Authorization (RMA) paperwork that explains the terms on how the goods should be returned.

The RMA number must be clearly displayed on the outside of the return packaging. Packaging suitable for containing a fragile device must be used.

Note: any musicm8s which are returned to XiVA which do not have an RMA number clearly visible on the packaging, or are poorly packaged, will not be accepted.

Warranty Validation

Please retain your purchase receipt as proof of purchase in order to get warranty support. All defective products should be returned with a copy of your proof of purchase. In no event shall XiVA's liability exceed the price paid for the product from direct, indirect, incidental or consequential damages resulting from the use of the product, it's accompanying software or it's documentation. XiVA does not offer refunds for any product.

Further information

Further to the warranty information contained within, if you have any other issues or queries then please do not hesitate to contact XiVA at:

Tel +44 (0)1954 783600

Normal business hours are 9am - 6pm GMT

Or visit us at http://www.XiVA.com/musicm8

WEE Declaration of Conformity

- The equipment that you have purchased has required the extraction and use of natural resources for this product.
- The equipment may contain hazardous substances which could impact and the
 environment
- In order to avoid the dissemination of those substances in our environment and to diminish the pressure on the natural resources , we encourage you to use the appropriate take-back systems
- The take-back systems will reuse or recycle most of the materials of your end life equipment in a sound way.
- The crossed out wheeled bin symbol invites you to use those systems.
- If you need more information on the collection, reuse and recycling systems please contact your local or regional waste administration

CE Declaration of Conformity

In accordance with the following Directive(s):

2006/95/EC The Low Voltage Directive 2004/108/EC The Electromagnetic Compatibility Directive

Equipment Networked Attached Storage device with CD recording engine

Model Number XXXXXXX

is in conformity with the applicable requirements of the following documents

Ref.No: EN60950-1:2002 Title: Safety of Information Technology Equipment Edition/date: 22/2/2002