

MyDataZone User's Manual

MyDataZone is a DataTraveler Secure tool that enables you to create and access a user defined password-protected area called a Privacy Zone, on your DataTraveler Secure drive.

This document will help you get started with MyDataZone, and it includes some important frequently asked questions (FAQs). For the latest FAQs, visit the DataTraveler Website at <u>www.kingston.com/support/faqs/datatraveler</u>.



TABLE OF CONTENTS

1 System		em	3
	1.1	Requirements	3
	1.2	Recommendations	3
2	Dow	nloading and Installation	4
3 Getting Started			5
	3.1	Creating the Privacy Zone	5
	3.2	Using your Privacy Zone	8
	3.3	Logging Out of Your Privacy Zone	10
	3.4	The Trust Option	11
4	Cust	tomizing Your Settings	12
	4.1	Desktop	12
	4.2	Changing Your Password	13
		4.2.1 With the Change Password Button	
		4.2.2 Lost Password	14
	4.3	Changing the Size of the Privacy Zone	14
5	Troubleshooting		15
	5.1	Preventing Data Loss	15
	5.2	Open Connection Error	15
6	FAQ	S	16



1 System

1.1 Requirements

- Pentium II 266MHz Processor
- 2MB free disk space
- Operating Systems: Windows Vista[™], Windows XP[®] SP1 and above, Windows 2000[®] SP4
- USB Port 2.0/1.1

1.2 Recommendations

- Graphic accelerator that supports 24-bit color depth for best-quality graphics
- 96 DPI video setting
- Disable Windows ReadyBoost[™] in Windows Vista*

^{*} Although your DataTraveler[®] Secure is enhanced for ReadyBoost, MyDataZone will not operate properly if ReadyBoost cache is enabled on the drive. However, you may enable ReadyBoost cache on a separate drive.



2 DOWNLOADING AND INSTALLATION

MyDataZone is supported on DataTraveler[®] Secure Firmware versions 6.0 and higher. You can check your DataTraveler[®] Secure Firmware version by starting MyDataZone and going to, Settings>About.

For the latest version of MyDataZone, go to <u>www.kingston.com/support/downloads</u>.



3 GETTING STARTED

CAUTION! When you create your Privacy Zone, the DataTraveler[®] Secure will be formatted and ALL data will be lost. Backup your files before creating your Privacy Zone.

3.1 Creating the Privacy Zone

- 1. Select the removable disk drive letter (i.e. E:\) assigned to your DataTraveler[®] Secure, and double-click the MyDataZone icon.
- 2. Select your preferred language in the MyDataZone Language Selector window (Figure 1) using the dropdown list and click **OK**.

MyDataZone Language Selector	×
Welcome to MyDataZone! Click 'OK' if you can read the welcome message or select another language.	LER®
English	
🖵 Don't show this message next time	
OK Exit	

Figure 1: Language Selection Window

3. Click **OK** to continue after you have read the MyDataZone Welcome window (Figure 2).



Figure 2: Welcome Message



4. When the MyDataZone windows appears, move the DataTraveler[®] Secure slide bar up or down to designate the size of your new Privacy Zone (Figure 3).

Note: The Privacy Zone maximum size is limited. 1% of the total capacity of your DataTraveler[®] Secure is kept free to store the MyDataZone application, future upgrades, and future applications without hindering operation.

😽 MyDataZone Format		
MyDataZone Format	Kingston	
Setting DataTraveler Secure's Privac	zy Zone	
To set the size of your Privacy Zone, please enter a password, select the size you need using the slider on the right, and click 'OK'. Password: **** Confirm Password: **** Hint	DataTraveler Secur Size: Privacy Zone Size: New Size:	e 1.87 GB 0 712 MB
-	Format	Iancel

Figure 3: MyDataZone Format Window

- 5. Enter the following information into the relevant fields:
 - a. Your password (required)
 - b. The same password to confirm (required)
 - c. A hint to remind you of your password (optional)
- 6. When you have completed steps 4 and 5, click **Format**.
- 7. The MyDataZone Format Warning window is displayed (Figure 4). To proceed with the format operation, click **OK**.



Figure 4: MyDataZone Format Warning Window



8. A formatting progress bar is displayed (Figure 5) while DataTraveler[®] Secure is formatted.

	🖏 MyDataZone Format			×
	MyDataZone F	ormat	🖁 Kingston	
	Setting DataTra	weler Secure's Privacy 2	Zone	
Progress Bar ———	To set the size of your P password, select the size the right, and click 'OK'. Password: *** Confirm Password: *** Hint	rivacy Zone, please enter a Format Complete Format successful OK	DataTravel Size: ivacy Zor ew Size:	er Secure 1.87 GB ne Size: 712 MB 712 MB
			Format	Cancel

Figure 5: Progress Bar

After the format is complete, a Format successful message will display (Figure 5). Click **OK** to continue. You can now login to your DataTraveler[®] Secure Privacy Zone.



3.2 Using your Privacy Zone

1. After you have created a Privacy Zone, MyDataZone automatically prompts you to login. Alternatively, you can select the removable drive letter (i.e. E:\) assigned to your DataTraveler[®] Secure and double-click the MyDataZone icon (Figure 6).

MyDataZone Login	
Password:	
Trust this computer	USD DATAT RATELER
Settings	OK Cancel
🕨 Hint	

Figure 6: Login Screen

2. To login to your Privacy Zone, type in your password and click **OK**. If you enter the incorrect password, an error message is displayed as shown in (Figure 7).



Figure 7: MyDataZone Error Message

MyDataZone automatically blocks all access to your data in the Privacy Zone after a predefined number of invalid password verification attempts. MyDataZone allows up to 10 password verification attempts. If your Privacy Zone becomes blocked for further access, follow the directions provided in the dialog boxes to reformat your Privacy Zone.



If you forget your password, click **Hint** to display the Hint field in the MyDataZone Login window (Figure 8).

😽 MyDataZone Login	
Password:	. 🍘
Trust this computer	USB DATATRAVELER®
Settings	OK Cancel
💙 Hint	

Figure 8: Password Hint

3. After a successful login, MyDataZone will display a confirmation message (Figure 9). Click **OK** to enter the Privacy Zone.



Figure 9: Successful Login

All data stored onto the DataTraveler[®] Secure will be password protected once you logout of the Privacy Zone.



3.3 Logging Out of Your Privacy Zone

- 1. Save and close all files that you have accessed on your DataTraveler[®] Secure.
- 2. To logout of the Privacy Zone, select the removable disk drive letter (i.e. E:\) assigned to your DataTraveler[®] Secure, and double-click **Logout MyDataZone** (Figure 10).




Figure 10: Privacy Zone View

3. The MyDataZone Logout confirmation is displayed below (Figure 11). Click **OK** to logout of the Privacy Zone.



Figure 11: Logout Confirmation Window



3.4 The Trust Option

When data is protected with the Trust option, you can designate specific computers (for example, your personal workstation or home computer) as trusted computers, eliminating the need to enter a password each time you plug in your DataTraveler[®] Secure. This is particularly convenient, for example, if you use your DataTraveler[®] Secure frequently at a specific workstation or if you back up your DataTraveler[®] Secure on your computer on a regular basis.

1. To designate a workstation as a trusted computer, select the **Trust this computer** checkbox in the MyDataZone Login window and login with your password (Figure 12).

When the Trust option is enabled, the MyDataZone Login window is displayed each time you insert your DataTraveler[®] Secure, but there is no need to enter your password.

👪 MyDataZone Login	
Password: ***	
Trust this computer	USB DATATRAVELER®
Settings	OK Cancel
🕨 Hint	

Figure 12: Implementing the Trust Option

2. To disable the Trust option, clear the **Trust this computer** checkbox in the MyDataZone Login window. A warning message is displayed (Figure 13).



Figure 13: Revoke Trust Warning

3. Click **OK** to return to the MyDataZone Login window where you can access the Privacy Zone using your password, or reactivate the Trust option.



4 CUSTOMIZING YOUR SETTINGS

4.1 Desktop

- 1. To customize MyDataZone for your desktop, click **Settings** in the MyDataZone Login window (Figure 12).
- 2. Select the following options to configure your MyDataZone Settings (Figure 14):
 - No login confirmation
 - No logout confirmation
 - No welcome window on startup
 - Language selection

Note: A tool tip for each option is displayed as your mouse pointer passes over it.




Figure 14: MyDataZone Settings Window

3. Click **OK** to activate the options selected.



4.2 Changing Your Password

4.2.1 With the Change Password Button

To change your password using the Change Password button:

- 1. Click Change Password in the MyDataZone Settings window (Figure 14).
- 2. When the Change Password dialog box (Figure 15) is displayed, type in the current (old) password, the new password, and the new password once again for confirmation. It is recommended to use a hint in case you forget or lose your password.

MyDataZone Change Password	
To modify your password, please enter you current password, and then enter your net password in the fields provided. You may a enter a new hint for your new password. O 'OK' to apply the changes or 'Cancel' to keep the current password. Old Password:	w Iso
New Password:	
Confirm Password:	
Hint	
0	Cancel

Figure 15: Change Password Dialog Box

3. Click **OK**. A confirmation message is displayed (Figure 16).



Figure 16: New Password Confirmation Message



4.2.2 Lost Password

If you lost your password, you can change the password by formatting the Privacy Zone as described in Section 3.1, step 4-5.

CAUTION! DataTraveler[®] Secure will be formatted and ALL data will be lost.

4.3 Changing the Size of the Privacy Zone

CAUTION! Changing the size of your Privacy Zone requires formatting your DataTraveler[®] Secure, causing ALL secured and non-secured data to be lost.

To change the size of the Privacy Zone:

- 1. Click **Format** in the MyDataZone Settings window. The MyDataZone Format window is displayed, as shown in (Figure 3 of page 6).
- 2. Enter the new password and confirm it by entering it a second time.
- 3. Enter a hint in case you forget your password.
- 4. Set the new size of your Privacy Zone using the slide bar.
- 5. Click **OK**. The MyDataZone Format Warning window is displayed, as shown in (Figure 4 on page 6).
- 6. Click **OK** to reformat your DataTraveler[®] Secure and create a new Privacy Zone.

To remove the Privacy Zone:

- 1. Click **Format** in the MyDataZone Settings window. The MyDataZone Format window is displayed, as shown in (Figure 3 of page 6).
- 2. Set the size of your Privacy Zone to 0% using the slide bar.
- 3. Click **OK**. A message is displayed (Figure 17) warning you that your DataTraveler[®] Secure will not have a Privacy Zone.



Figure 17: Removing the Privacy Zone

- 4. Click **OK**. The MyDataZone Format Warning window is displayed, as shown in (Figure 4 of page 6).
- 5. Click **OK** to reformat your DataTraveler[®] Secure and create a new Privacy Zone.



5 **TROUBLESHOOTING**

5.1 Preventing Data Loss

Close all files and applications **on the drive** prior to MyDataZone login/logout or system shut down. If you attempt any of these tasks prior to saving your data, file modifications may be lost.

5.2 Open Connection Error

If an open connection error message is displayed (Figure 18) click OK and...

- a. Close open files and/or applications on the DataTraveler Secure and retry login, logoff, system restart or shut down.
- b. If you're using Windows Vista[™], make sure ReadyBoost[™] cache is not enabled on the DTSecure drive. After disabling ReadyBoost, reinsert the drive and try again.

Error	
8	Another application has an open connection to your DataTraveler Secure. Close all applications and documents open on the DataTraveler Secure and try again.

Figure 18: Open connection error message



6 FAQs

To see the latest FAQs, go to the DataTraveler[®] Secure website at <u>www.kingston.com/support/faqs/datatraveler</u>. Several FAQs are listed below for quick view.

- **Q:** Every time I insert a DataTraveler Secure drive into a Windows Vista computer, an AutoPlay dialog appears with an option to "Speed up my system using Windows ReadyBoost." What is this feature?
- A: ReadyBoost is a Windows Vista feature which has the ability to utilize USB flash drive storage space to improve system performance. Although DataTraveler Secure is enhanced for ReadyBoost, MyDataZone software does not support it. Make sure ReadyBoost cache is not enabled on the DataTraveler Secure if you intend to use MyDataZone.
- **Q:** How do I know if I am working in the Privacy Zone?
- A: If you are working in the Privacy Zone, all file/ folder names located on the root will be highlighted with an orange background. (This visual indication may not be experienced if you have selected Windows classic folders or if you are using Microsoft Vista[™]).
- **Q:** I accidentally deleted MyDataZone from my DataTraveler[®] Secure. How can I access data in my Privacy Zone?
- A: Download the latest copy of MyDataZone via the Web at <u>www.kingston.com/support</u> to your DataTraveler[®] Secure. The Privacy Zone previously created will now be accessible.
- **Q:** Can I use more than one DataTraveler[®] Secure with MyDataZone simultaneously?
- A: Yes.