

# **BOXING SCORING SYSTEM 2013**

Hardware Components User Manual

# 3475.554.02

Version 1.0 Edition August 2013

#### Caution and safety precautions

- Never use any other charger than the supplied or a type approved by Swiss Timing. This could
  destroy the battery, cause damage to unit, and possible cause personal injury due to fire or/and
  electrical shock.
- Never bypass a power cord ground lead by breaking off the ground pin, or by using inappropriate extension cords or adapters.
- Never plug a power cord into the AC power source until you have made sure that all installation, cabling and power levels, are proper, and that the applicable procedures in this manual have been followed.
- Protect the equipment against splashing, rain and excessive sun rays.
- Never use the device if it is damaged or insecure.
- Verify the selection of the power distribution.
- Verify that the voltage quoted on the rating plate is the same as your voltage. Connect the appliance only to power sockets with protective earth. The use of incorrect connection voids warranty.
- This program may be modified at any time without prior notification.
- Do not open the case; there is nothing that needs servicing inside it. Nevertheless, if the case must be opened, you must call for some qualified personnel. The power supply cable must be disconnected before opening the case.
- During the transport of all Swiss Timing equipment delivered with a reusable carry case, the said case should be used at all times. This is imperative to limit the damage, such as shocks or vibration that can be caused to the units during transport.
- The same cases should also be used when returning equipment to Swiss Timing for repair. Swiss Timing reserves the right to refuse all guarantees if this condition is not fulfilled.
- If the installation includes a horn, be sure to maintain a sufficient security distance from the public.

#### **Documentation Updates**

Swiss Timing Ltd. reserves the right to make improvements in the products described in this documentation at any time without prior notice. Furthermore, Swiss Timing Ltd. reserves the right to revise this documentation in its content at any time and without any obligation to notify any person or organization of such revision.

#### Disclaimer

The information provided in this documentation has been obtained from sources believed to be reliable, accurate and current. However, Swiss Timing Ltd. makes no representation or warranty, express or implied, with respect, but not limited to, the completeness, accuracy, correctness and actuality of the content of this documentation. Swiss Timing Ltd. specifically disclaims any implied warranty of merchantability, quality and/or fitness for any particular purpose. Swiss Timing Ltd. shall not be liable for errors contained in this documentation or for incidental or consequential damages in connection with the supply, performance or use of this documentation.

#### Environment



This symbol indicates that this product should not be disposed with household waste. It has to be returned to a local authorized collection system. By following this procedure you will contribute to the protection of the environment and human health. The recycling of the materials will help to conserve natural resources.

#### Copyright

© Swiss Timing Ltd..

All rights reserved.

This documentation may not, as a whole or in part, be copied, translated, reproduced, transmitted or reduced and/or stored to any electronic medium or machine-readable form without the prior written consent of Swiss Timing Ltd..



# TABLE OF CONTENTS

			1
HAR	DWARE	E COMPONENTS	2
2.1	System	ר Overview	2
2.2	Contro	ller	3
	2.2.1	Specifications	3
	2.2.2	Front Panel Elements	4
	2.2.3	Back Panel Elements	5
2.3	Boxing	Scoring Keypad 2013	5
	2.3.1	Specifications	5
	2.3.2	Scoring Panel	6
	2.3.3	Connectors	6
INTE		NECTIONS	7
3.1	Conne	cting the Keypads to the Controller	7
3.2	Conne	cting the Controller to a PC	7
	3.2.1	Software Requirements	7
	3.2.2	Cabling the Controller	7
	3.2.3	Important Note on the USB Power Supply	7
BAS		RATION	8
4.1	Switchi	ing On	8
4.2	Enterin	ng a Score	8
4.3	Adjusti	ng the Keypad Backlight	8
4.4	Updatii	ng the Firmware	9
APP	ENDIX		11
5.1	Abbrev	viations and Symbols	11
5.2	Index o	of Tables and Figures	11
5.3	Versior	n History	11
	2.1 2.2 2.3 INTE 3.1 3.2 BAS 4.1 4.2 4.3 4.4 4.3 4.4 5.1 5.2	2.1       System         2.2       Contro         2.2.1       2.2.1         2.2.2       2.2.3         2.3       Boxing         2.3.1       2.3.2         2.3.2       2.3.3         INTEECONN         3.1       Conne         3.2       Conne         3.2       Conne         3.2.1       3.2.2         3.2.3       3.2.2         3.2.3       Senterin         4.1       Switch         4.2       Enterin         4.3       Adjusti         4.4       Updati         5.1       Abbrev         5.2       Index of	2.2       Controller

## **1 INTRODUCTION**

#### **About This Document**

This document is intended as a hardware manual for the Boxing Scoring System 2013 (BSS2013).

#### **Related Documents**

This document is part of the BSS2013 end user documentation. The end user documentation furthermore includes:

BSS2013 WinBPM 3.0 Software Manual

#### About BSS2013

The BSS2013 is a mixed hardware/software system for managing and performing boxing events in accordance with the current AIBA Technical Rules for all 3 programs AOB, APB and WSB. The system comprises the following features:

- Complies with the latest AIBA technical and competition rules
- Processing of Boxing-specific data such as bout number, date, weight category, data of the red and blue corner and judges data
- Definition of free weight categories without additional software
- Electronic draw of Boxers and Judges including presentation on external screens
- Random and hidden selection of 3 out of the 5 judges
- Layout of Public Displays is basing on current AOB rules
- Processing of judges scores after each round
- Input of warnings by the supervisor
- Complete set of required lists; immediate availability
- Improved list feature (configurable layout of lists, integration of sponsor and event logos)
- Numerous adjustable parameter settings available (i.e. number of bouts per session, number of rounds, judges per bout, list layout etc.)

#### Scope of Supply

The standard delivery encompasses the following components:

- - 1x BSC2013 Controller
- 5x BSK2013 Keypads
- 5x 15m SUB-D9 Cables
- - 1x 5m USB A-B Cable
- - 1x WinBPM application and USB-Serial-Driver on CD
- - 1 x USB security dongle (not included if recipient owns a system from 2007 or later)



## 2 HARDWARE COMPONENTS

This chapter provides information on the individual hardware components of the BSS2013. Generally, the system consists of two main hardware components:

- 1x Keypad Controller 2013 (BSC2013)
- 5x Boxing Scoring Keypads 2013 (BSK2013)

These components are connected to an operator PC or laptop which runs the WinBPM application. The WinBPM application constitutes the software part of the BSS2013.

#### 2.1 System Overview

The following drawing shows the individual system components and their connections.




Figure 1 – BSS2013 system scheme

#### 2.2 Controller

The Controller (BSC2013) serves as an interface for the five individual scoring keypads (BSK2013). The controller is connected to the operator's PC/Laptop via USB.

## 2.2.1 Specifications

Dimensions	260x42x142mm
Weight	520g
Degree of protection	IP20, suitable for indoor use only
Power supply	5VDC via USB port
Connectors	Front Panel: USB Typ B port, USB 2.0 compatible, 5VDC power supply Back Panel: Sub-D9m plug (with 5VDC power source)



#### 2.2.2 Front Panel Elements

The following overview explains the individual elements on the front panel of the BSC2013.




Figure 2 - BSC2013 front panel

#	Element	Description
1	PC-USB port	Used to connect the BSC2013 to the Scoring-Laptop or Scoring-PC; Also provides the power supply for the system <b>Note:</b> Refer to section 3.2 for important information on using the USB power supply
2	INF LED	Flashes (with 1Hz) while the controller boots; Illuminates continuously during normal operation, with a short flashing whenever keypad data are transferred via USB connection
3	Keypad LEDs 15	Illuminates while the Keypads (BSK2013) are connected to the Controller (BSC2013); flashes when data is received from a connected keypad
4	Power LED	Illuminates while the BSC2013 is supplied with sufficient power (>4.6V) from the USB port; Begins to flash (5Hz) when the USB supply voltage falls below 4.5V.

Table 1 - BSC2013 front panel elements

#### 2.2.3 Back Panel Elements

The back panel provides the D-Sub 9 plugs 1...5. These are used to connect the supplied Boxing Scoring Keypads (BSK2013).



Figure 3 - BSC2013 back panel

#### 2.3 Boxing Scoring Keypad 2013

The five Boxing Scoring Keypads 2013 (BSK2013) serve as score input terminals for judges. The keypads are designed in accordance with the current AIBA rules.

Each keypad is equipped with all necessary buttons to select and confirm scores. Furthermore, the keypads feature backlit scoring indicators and a built-in vibration mechanism that provides a haptic feedback to the judge in the following events:

- 1x short vibration: properly selecting and confirming a score
- 2x short vibrations: incorrectly selecting or confirming a score

#### 2.3.1 Specifications

Dimensions	75x46x138mm
Weight	140g
Degree of protection	IP20, suitable for indoor use only
Power supply	3.3VDC (internally converted from 5VDC)
Connectors	Back panel: Sub-D9f port (with 5VDC power inlet)



#### 2.3.2 Scoring Panel

The following overview explains the individual elements on the scoring panel of the BSK2013.




Figure 4 - BSK2013 scoring panel

#	Element	Description
1	Score indicator	Indicates the currently selected score for each corner
2	Score selector (increase)	Increases the score by one point when pressed
3	Score selector (decrease)	Decreases the score by one point when pressed
4	OK/Confirmation button	Confirms and sends the selected score when pressed

Table 2 - BSK2013 scoring panel elements

#### 2.3.3 Connectors

Each Boxing Scoring Keypad provides a single D-Sub 9 port to connect it to the Controller. The operating power for the BSK2013 is supplied through the connection cable.

# **3 INTERCONNECTIONS**

#### 3.1 Connecting the Keypads to the Controller

Connect each of the five Boxing Scoring Keypads to the Controller using the provided serial cables.

**Note:**It doesn't matter in which sequence you connect the keypads to the controller as the assignment of a controller to a particular judge is done later from within the WinBPM application.

#### 3.2 Connecting the Controller to a PC

#### 3.2.1 Software Requirements

Make sure to install the supplied WinBPM application before connecting the Controller to the PC/Laptop. The WinBPM application installer contains a driver component that is needed for the operating system to properly set up the Controller.

#### 3.2.2 Cabling the Controller

Connect the Controller to a free USB socket on the Scoring-Laptop or PC using the provided USB cable. The USB connection is used for data transfer and power supply of the BSC2013.

#### 3.2.3 Important Note on the USB Power Supply

A sufficient USB supply voltage is crucial for the operation of the Boxing Scoring System 2013. Thus it is recommended that you connect the Controller directly into an available USB socket on the Scoring-Laptop/PC.

If you plan to operate the system via USB hub, ensure that the USB hub is provided with an active power supply. Else, sufficient power may not be supplied to the Controller.

**Note:** The power LED on the front panel of the controller will start to flash when the supply voltage falls below 4.5V.



## 4 BASIC OPERATION

#### 4.1 Switching On

The Controller switches on automatically when power is provided via USB connection (e.g. when connecting the controller to a running PC). When switched on, the Controller will enter a bootloader mode for approx. 10 seconds.

The system becomes fully operational once the keypad LEDs finally illuminate on the Controller.

#### 4.2 Entering a Score

To adjust the score for the red and blue corner, use the according [Up] and [Down] buttons on the Boxing Scoring Keypad. The currently adjusted score is indicated by the LEDs located just above the scoring buttons.

To confirm a score, press [OK] on the keypad. This will send the score to the Scoring-Laptop/PC. Your confirmation is indicated by a short vibration of the keypad.

#### 4.3 Adjusting the Keypad Backlight

You can adjust the brightness level of each keypad's backlight. To increase the brightness of a keypad, press the blue [UP] button repeatedly while keeping [OK] pressed. To lower the brightness level, press the blue [Down] button repeatedly while keeping [OK] pressed.

#### 4.4 Updating the Firmware

It may become necessary to update the internal firmware of the Boxing Scoring System 2013. In this case, Swiss Timing will probably contact you and send you the firmware file along with the necessary firmware installer.

If not otherwise specified, proceed as follows to update the system firmware:

- 1. Extract the provided zip-folder to the hard disk of the operator PC/laptop.
- 2. Open the Windows Device Manager and expand the node "Ports" to see all available ports (see following screenshot).




Figure 5 - Ports node in the device manager

3. Within the "Ports" section, find the entry "USB Serial Port" (or similar) and write down the indicated port number, given in exclamation marks.

**Note:** If you cannot find the entry, try to reconnect the Boxing Scoring Controller to another USB port, or reinstall the supplied WinBPM application.

4. Using a text editor, open the installer batch file provided inside the firmware folder that you've extracted earlier.



5. In the batch file, replace the COM port number (e.g. 'com1' as in the following screenshot) with your noted port number from the Device Manager (e.g. 'com2').

	C:\Users\tv\Downloads\bsc2013-1.3.1.bat - Notepad++				
<u>D</u> atei	Datei Bearbeiten Suchen Ansicht Kodierung Sprachen Einstellungen Makro Ausführen Erweiterungen Fenster ? X				
📄 bsc2	2013-1.3.1.bat				
1	§echo off				
2	echo programming user application "bsc2013" v1.3.1				
3	echo target: BSC2013 device (Boxing Scoring Controller) with ATMEGA128L @8MHz				
4	echo connected BSC2013 device to USB (or RS232 port), press any key when ready				
5	echo.				
6	echo bootloader timeout = 10sec				
7	echo.				
8	pause				
9	9 avrdude -v -p m128 -c avr910 -P(\\.\com1-b 19200 -x devcode=0x43 -e -u -U flash:w:bsc2013-1.3.1.hex:i				
10	echo finished				
11	11 pause				
12					
,					
Batch file	e length:411 lines:12 Ln:1 Col:1 Sel:0 Dos\Windows ANSI INS				

Figure 6 - Firmware update batch-file

- 6. Save and close the batch file.
- 7. Now reconnect the Controller to the PC/laptop and launch the batch file within 10 seconds after connecting the Controller.
- 8. If the update was successful, you will see a terminal window similar to the one in the following screenshot. You can now close the terminal window.

C:\Windows\system32\cmd.exe	
avrdude: erasing chip avrdude: reading input file "bsc2013-1.3.1.hex" avrdude: writing flash (12664 bytes):	^
Writing   ###################################	
avrdude: 12664 bytes of flash written avrdude: verifying flash memory against bsc2013-1.3.1.hex: avrdude: load data flash data from input file bsc2013-1.3.1.hex: avrdude: input file bsc2013-1.3.1.hex contains 12664 bytes avrdude: reading on-chip flash data:	
Reading   ###################################	
avrdude: verifying avrdude: 12664 bytes of flash verified	
avrdude done. Thank you.	
finished Press any key to continue	-

Figure 7 - Terminal window

# 5 APPENDIX

## 5.1 Abbreviations and Symbols

Abbreviations	
BSS2013	Boxing Scoring System 2013
BSK2013	Boxing Scoring Keypad 2013
BSC2013	Controller 2013

### 5.2 Index of Tables and Figures

#### Index of Tables

Table 1 - BSC2013 front panel elements	.4
Table 2 - BSK2013 scoring panel elements	.6

## Index of Figures

Figure 1 – BSS2013 system scheme	.2
Figure 2 - BSC2013 front panel	.4
Figure 3 - BSC2013 back panel	.5
Figure 4 - BSK2013 scoring panel	. 6
Figure 5 - Ports node in the device manager	. 9
Figure 6 - Firmware update batch-file	10
Figure 7 - Terminal window	10

## 5.3 Version History

Version	Date	Modifications since last version
1.0	14.08.2013	Initial version



NOTES

SWISS TIMING LTD

P.O. Box 138, rue de l'Envers 1 2606 Corgémont, Switzerland www.swisstiming.com Phone +41 32 488 36 11 Fax +41 32 488 36 09 info@swisstiming.com