

TVRMobile V2.0 User Manual

Copyright © 2013 UTC Fire & Security Americas Corporation, Inc.

Interlogix is part of UTC Climate Controls & Security, a unit of United

Technologies Corporation. All rights reserved

Trademarks and patents

The TruVision and UltraView names and logos are trademarks of

UTC Fire & Security.

Other trade names used in this document may be trademarks or registered trademarks of the manufacturers or vendors of the

respective products

Manufacturer UTC Fire & Security Americas Corporation, Inc.

2955 Red Hill Avenue, Costa Mesa, CA 92626-5923, USA

Authorized EU manufacturing representative:

UTC Fire & Security B.V.

Kelvinstraat 7, 6003 DH Weert, The Netherlands

Contact information For contact information, see www.utcfireandsecurity.com or

www.utcfssecurityproducts.eu

Content

Introduction 4 Overview 4 System requirements 4 Software setup 4 Installing the TVRMobile app on a phone 4 Log in 5 Create a user 5 Log in 5 Main menu icons 5 Device management 6 Devices that can be connected 6 Add a device 6 Modify a device 7 Delete a device 7 Live view 7 Start live view 8 Stop live view 9 Favorite devices and cameras 9 Full-screen live view 10 PTZ control 10 Set a preset 11 Call up a preset 11 Playback 11 Start playback 12 Stop playback 12 Full-screen playback 12 Relay outputs 13 Configuration 13 Password protection 13 Update software 14 Get help 14

TVRMobile V2.0 User Manual

3

Troubleshooting 14

Introduction

Overview

The TVRMobile is an Android and iPhone application that can be used over a wireless network to remotely view live video, play back recorded files, and control alarm outputs from DVRs, NVRs, IP cameras, and PTZ cameras. It can also be used to control PTZ cameras.

Once installed on your mobile device, you can easily log on to the front-end device via Wi-Fi, 2G, 3G, or 4G. If there is no public IP available, you can use a dynamic name or by forwarding ports to the public IP router.

System requirements

Table 1: TVRMobile system requirements

Android Phone: Android OS V2.3 or higher iPhone: iOS 4.3 or higher	
100	
Main stream and substream	
2 to 8 fps (depending on the performance of the mobile device)	
QCIF, up to 5 megapixels if supported by the device	
Video and audio	
32 Kbp to 16 Mbps (depending on the network environment)	

Software setup

The phone must be connected to the internet before installing the TVRMobile application.

Installing the TVRMobile app on a phone

- Go to the Android Market or the Apple Store web site and search for the TVRMobile application.
- 2. Download it.

4

3. On your phone's home screen, tap to open the app.

Log in

Create a user

- 1. Tap on the home screen to open the TVRMobile application.
- 2. Enter your user name.
- Enter your password and confirm it. Tap Register. The live view screen opens.

Note: See "Password protection" on page 13 for further information on managing passwords.

Log in

- 1. Tap on the home screen to open the TVRMobile application.
- 2. Enter password (if required). The live view screen opens.

Main menu icons

The main menu icons are always easily available. Simply tap the icon on the top of the screen to display them.



Table 2: Main menu icon description



Live view: Access live view, control PTZ, manage relay outputs, enable/disable bi-directional audio.



Remote Playback: Playback recorded video.



Devices: Display the device list, add/delete/modify devices, view device information.



Configuration: Configure passwords and update software. Access Help.

TVRMobile V2.0 User Manual

5

Device management

The device list is empty by default. You must first add the required devices to the TVRMobile device list before you can access them. Once the device has been successfully added, the app obtains the device's camera information.

Note: Up to 100 devices can be added to the application.

Devices that can be connected

This app provides support for following devices:

- TruVision TVR 10, 11, 40, 41, 60 digital video recorders
- TruVision TVN 20, 21, 50 network video recorders
- TruVision TVC-N, TVC-M IP box cameras
- TruVision TVD-N, TVD-M IP dome cameras
- UltraView UVP-N, UVP-M IP PTZ cameras

Add a device

- 1. Tap and select at to enter the Device Management interface.
- 2. Tap to add a new device.



- 3. Enter the name of the device to be linked, such as a TruVision DVR or TruVision IP cameras. The name can have up to 16 alphanumeric characters. Default name is Device01.
- 4. Under Register Mode, select either ezDDNS or IP/Domain.
 - **ezDDNS**: When the device is registered in the ezDDNS server, you need to enter the registered ezDDNS server address and device domain name.
 - **IP/Domain**: Manually access the device using a fixed IP address or a domain server. You need to edit the IP address or domain address.
- 5. Enter the user name and password (if required).
- 6. Tap 🖥 to confirm the settings. The device is added to the device list.

- 7. Tap to exit and return to the previous page.
- 8. Tap to access another main menu icon.

Modify a device

- 1. In the **Device Management** interface, select the device you want to modify. The Device Information screen appears showing the device parameters.
- 2. Tap to modify the parameters of a device. Enter the new parameter values.
- 3. Tap 🗏 to confirm the settings.

Delete a device

1. In the **Device Management** interface, select the device you want to delete and press the name until the **Hint-Delete device** pop-up dialog box appears.



2. Tap Confirm. The device disappears from the list.

Live view

Once the parameters of the device have been configured in TVRMobile, you can access live video directly, manage the device alarm outputs, as well as control PTZ cameras. See Figure 1 on page 8 for the live view screen.

Up to 16 cameras can be viewed live at the same time. If a selected device has more than 16 cameras, only the first 16 cameras will be displayed.

To enter live view, tap = and select . The live view interface appears (see Figure 1).

Note: The display format is one video tile by default.

Figure 1: Live view interface



Icon	Description
<u></u>	Capture a video snapshot of the selected camera image.
	Switch between main stream and substream for the selected camera.
G.	Stop all live views.
2 / 1	Start/stop bi-directional audio.
*	PTZ control.
\$ / \$	Enable/disable alarm output management.

Start live view

- 1. In the live view interface, tap = to display the list of devices available.
- 2. Select the desired devices. You can either:

Tap the check box of a device with associated several cameras to select all of its cameras.

- Or -

8

Only tap the check box(s) of the desired cameras associated with a device.



3. Tap Start live view to start live viewing from the selected camera(s).

Stop live view

There are two methods to stop live view:

Stop all cameras: Tap **I** to stop live view for all cameras.

Stop a specific camera: Tap and hold the live view screen of the desired camera. This icon appears at the top of the screen. Drag the selected camera's screen upwards until the icon changes to , and release the camera screen.

Favorite devices and cameras

You can group the most important or frequently used devices and cameras in a Favorites folder so that, for example, they can be easily and quickly accessed in live view. More than one device can be saved in a favorite group.

To configure favorite cameras:

- 1. In the live view interface, tap = to display the list of devices available.
- 2. Check the desired devices. You can either:

Check a device to select all of its cameras.

— Or —

Check only specific cameras associated with a device.

3. Tap to add the selected cameras to the Favorite group.




- 4. In the pop-up dialog box, enter the name of the Favorite group.
- 5. Tap **Confirm** to save the settings. The favorite group is listed under devices and is identified by a star in its device icon.



To delete a device from the favorite list:

- 1. In the live view interface, tap to display the list of devices available.
- 2. Press the device to be deleted until the **Delete** pop-up dialog box appears.



3. Tap Confirm to delete.

Full-screen live view

When using live view in multiview format, you can easily watch a specific camera image in full-screen view by double- tapping on the desired image. Double-tap again to return to the multiview format.

PTZ control



Move your finger on-screen to pan left/right and tilt up/down camera movement. Pinch you fingers apart or together to zoom in or out.


Quit PTZ control mode by tapping 🔊.

Table 3: PTZ icon description



Set a preset


- 1. In PTZ mode, move the selected camera view to the desired position.
- 2. Tap . The following dialog box appears:



- 3. Enter the preset number. It can be between 1 and 256.
- 4. Tap Set to save the preset setting.

Call up a preset

- 1. In PTZ mode, move the selected camera view to the desired position.
- 2. Tap ... The following dialog box appears:




- 3. Enter the preset number. It can be between 1 and 256.
- 4. Tap Call to move to the preset position.

Playback

You can search recorded video files on the remote storage device for playback. Drag the timeline bar to modify the playback time.

TVRMobile V2.0 User Manual

Figure 2: Description of the playback interface



Start playback

- 1. Tap and select . The remote playback screen appears.
- 2. Tap to display the list of devices available.
- 3. Tap the start and end date/time nodes to set the start and end date and time for playback search.



- 4. Select a device and a camera for playback.
- 5. Tap Start playback to start playback.

Stop playback

There are two ways to stop playback. You can:

- Tap

 to stop playback.
 - Or —
- Drag the playback window upwards to the top of the screen. A iii icon appears. When it changes to iii, release the window. It is then deleted.

Full-screen playback

During playback, rotate the phone to landscape position to get full-screen mode. Press the playback toolbar and drag to reposition it.

12 TVRMobile V2.0 User Manual



Relay outputs

You can easily enable/disable up to four relay outputs.

To enable/disable relay outputs:

1. In the live view interface, tap = and select =. The relay output buttons appear.



2. Tap the desired relay outputs to enable or disable .

Configuration

Password protection

The application does not have password protection by default. By setting up password protection, you ensure that only persons knowing the password can access the TVRMobile application.

To enable password protection:

- 1. Tap and select to enter the Configuration interface.
- 2. Tap Turn Password On to enter the password interface.
- 3. Enter the password information and tap 🗏 to save the settings.

To disable password protection:

- 1. Tap = and select to enter the Configuration interface.
- 2. Tap Turn Password Off to enter the password interface.
- 3. Enter the password information and tap 🗏 to save the settings.

To modify a password:

- 1. Tap = and select to enter the Configuration interface.
- 2. Tap Modify Password to enter the password interface.
- 3. Enter the password information and tap 🗏 to save the settings.

Update software

When there is a new version of the TVRMobile application available in the App Store, the software will automatically prompt you to update the software. You can update the software immediately when prompted or update it later.

To update the software:

- 1. Tap = and select to enter the Configuration interface.
- 2. Tap Software Update.
- 3. Tap **Confirm** on pop-up notification. This will take you to the app store.
- 4. Update with the new version of the app.

Get help

Online instructions for using the application can also be found under **Configuration** > **Help**.

If you continue to have problems, please contact your local supplier.

Troubleshooting

1. Which devices are supported by the TVRMobile software?

A device requires H.264, MPEG-4 or MJPEG video compression to be compatible with this software. Examples of devices that can be used with this software are embedded DVRs, NVRs, IP cameras, and IP speed domes.

2. Why does the mobile client software prompt 'Login failed' when trying to access the device via Wi-Fi?

Please check the network settings of the device being accessed. It is also important to ensure that the device is always online and accessible.

3. Why does the mobile phone respond slowly during live view and the video images freeze?

This problem may be due to the lower performance of your mobile device. Try reducing the number of cameras viewed at the same time, or decreasing the frame rate and resolution. See Table 4 below for guidelines.

Table 4: Video recommendations

Resolutions	Recommend number of cameras	Recommend frame rate
CIF	1	8 fps or lower
QCIF	4	8 fps or lower