

X-Audio 2000 Portable weatherproof outdoor audio system

Introduction:

Thank you for buying the X-Audio portable weatherproof outdoor audio speaker system.

We take great pride in designing each of our products. Our goal is to provide high-end rugged products. We strive to improve our quality by using up-to-date high performance technology.

At X-Systems we reinvest 100% of our earnings back into the company. This enables us to support research and development to ensure our reliability in the future.

We advise you to read this manual carefully as we will guide you through the functions of the system. Instructions about the navigation system will be given and in about 2 minutes you will enjoy the possibilities of this all-round product.

Please read through the User's Manual before using. When you use the product, we think you have read through this manual.

The information provided in this manual, is as accurate as possible after being revised carefully. If any printing error or translating mistake occurred in the manual, our company would not bear the outcome due to such mistake or error.


The X-Audio is hi-tech product, including operating system and the software provided by the third parties. The producer has fulfilled its obligation in the manufacturing of hardware and in the developing and applying of software to ensure the product works normally. If there is something wrong with the product, the producer will shoulder the repair responsibility against the quality warrant and will not make any compensation to the property and economy losses incurred from using the product.

The ownership and copyright of the manual belong to our company. The manual is not allowed to replicate or translate in whole or in part for any commercial activity. Our company reserves the final explanation right to the manual contents.

Index:

- Included in box checklist
 First use guide
 Introduction overview
 Specifications overview
 Operating system features
 Indicator overview
 Operation steps
 Trouble Shooting

Included in box checklist:



The X-Audio box should contain the following below listed items after unboxing.

- One X-Audio mobile weatherproof outdoor audio system.
- Micro USB cable
- 3.5mm AUX cable
- User's manual

If any of the above articles is broken or missing, please contact immediately the distributor or retailer where you purchased the X-Audio.

First use guide:


This paragraph is important to read before using the X-Audio audio system. To make sure all functions are ready for use, you must go through the 7 steps below.

- 1. Check that all the items are in the box.
- 2. Before the first use: charge your battery for three hours. Make sure to use the full battery after charging for the first time. After the first cycle, red light will indicate the amount of charging time.
- 3. Turn on your X-Audio and it will be automatically in Bluetooth mode and ready for connection. Now the blue indicator will flash.
- 4. Open the Bluetooth of your X-Map, X-Tel, X-Tab or any other mobile Bluetooth device, search the audio speaker device and connect with it.
- 5. Blue light remains glowing to indicate a successful connection.
- 6. Run the music player of your device, and let the sound come from your X-Audio .
- 7. Enjoy your X-Audio speaker.

[Relative information] Usually you don't need to input a password for most of Bluetooth devices, but due to the variations of Bluetooth version, sometimes, you need to input the default password of "0000" (four zero) if it's required.

The installation, repair should be made by our company authorized personnel or professional maintenance person from the distributor or retailer. Without our company's permission, do not install, disassembly and assembly, or repair. Otherwise, you will lose the warranty service right.

Introduction overview:



1.Power button	Turn on/off the X-Audio speaker system.
2. Micro USB port	Power X-Audio with DC 5V micro USB cable.
3. Hand strap	Hang or hold your X-Audio anywhere.
4. Stereo jack	3.5mm Stereo AUX Jack.
5. Volume down	Long press for decreasing volume.
6. Volume up	Long press is for increasing volume

7. Play & Answer button	Short press for play or pause. Short press of 1 second to answer the call, and long press for 3 seconds for a rejecting call. Invalid in the AUX-in mode.
8. LED indicator	Indicates the various modes of the X-Audio.
9. NFC area	Hold NFC device here to prepare with X-Audio.

Specifications overview:

Channel	2.0 Channel stereo
RMS	6.7 Watts
Amplifier	Digital Amplifier
Driver	Full range 40mm 4 Ω × 5W×2
Sensitivity	78 db
S/N	≥70db
Frequency response	45Hz-18KHz
Bluetooth® chipset	CSR
Bluetooth® version	V4.0 EDR
Bluetooth® Distance	10M(±3M)
Supported protocol and profile	A2DP, AVRCP, HFE and HFP
Interface	USB port and AUX in Jack
Playback time	Various from 12 till 6 hours
Battery	Built-in rechargeable 1400mAh Lithium battery
Battery Charging port	DC 5V port
Charging time	Follow the red light indication
Temperature	Operating Temperature : $-10^{\circ}\!$
Working humidity range	-
Size	L 151mm x W 65mm x H 66mm
Weight	480g

Operating system features :

Audio speakers	Provide clear sound anywhere and everywhere.
Bluetooth	This X-Audio speaker can be connect with the Bluetooth devices.
NFC	This X-Audio speaker can be connect with the NFC devices.
AUX	This X-Audio speaker can be connect with an AUX source.
Memorize devices	This X-Audio speaker can be connect with multiple devices.
Hands-free calling	Answer or reject phone calls from your phone.
Equalizer	Adjust your X-Audio sound experience.

Indicator overview:

No colour	X-Audio isn't in working status.
Blue indicator flashes	X-Audio is in status of waiting for connecting.
Green indicator glowing	X-Audio is connected with AUX cable source.
Blue indicator glowing	X-Audio is connected with a Bluetooth® source.
Red indicator flashes	Battery voltage is lower than 3.3v, need to charge your X-Audio.
Red indicator glowing	Red indicator is on when charging, and off when fully charged.



【Note】 This X-Audio adopts built-in, unchangeable Lithium battery. In order to avoid fire and burning, please do not poke, bump or take it apart or throw it into fire or other dangerous substance for electronics or lithium!

Operation steps:

AUX-in setting

- 1. Turn on your X-Audio and it will be automatically in Bluetooth mode and ready for connection. Now the blue indicator will flash.
- 2. Take the standard in box supplied 3.5mm Aux cable for connecting the X-Audio with other non-Bluetooth audio source.
- 3. Plug one end of the audio cable to the AUX input jack of the X-Audio speaker and the other end connect to audio source AUX output jack. The green indicator will remains glowing.
- 4. Your X-Audio will disconnect the Bluetooth function and switches to the external sound source, as the external source of AUX-in mode is prior.
- 5. Run the music player of your device, and let the sound come from your X-Audio .
- 6. Enjoy your X-Audio speaker.

NFC setting

- 1. Make sure your mobile device has NFC function.
- 2. Start your NFC from settings interface of your device.
- 3. Hold your mobile phone to the X-Audio NFC area of the speaker. Your X-Audio speaker will power on automatically. The indicator will flash.
- 4. Five seconds later, tap your mobile device to NFC area again to activate NFC pairing. Choose yes when your X-Audio is showed: "Pairing with Bluetooth"?
- 5. Your mobile device will indicates "Paired with speaker"
- 6. Run the music player of your device, and let the sound come from your X-Audio.
- 7. Tap your mobile device to NFC area again to disconnect Bluetooth.
- 8. Enjoy your X-Audio speaker.

Bluetooth setting

- 1. Turn on your X-Audio and it will be automatically in Bluetooth mode and ready for connection. Now the blue indicator will flash.
- 2. Open the Bluetooth of your X-Map, X-Tel, X-Tab or any other mobile Bluetooth device, search the audio speaker device and connect with it.
- 3. Blue light remains glowing to indicate a successful connection.
- 4. Run the music player of your device, and let the sound come from your X-Audio .
- 5. Enjoy your X-Audio speaker.

Two playback devices setting

- 1. Follow step one to pair your Bluetooth-enabled playback device 1 to your X-Audio.
- 2. Press and hold the play/pause button for two seconds to disconnect the Bluetooth connection with device 1. Then the X-Audio speaker will memorize the mac address of the playback device 1.
- 3. Follow step one to pair your Bluetooth-enabled playback device 2 to your speaker.
- 4. Then pair your Bluetooth-enabled device 1 again. Now you can play music by two playback devices.
- 5. Run the music player of your device 1 or 2, and let the sound come from your X-Audio.
- 6. The other playback device cannot play the audio when one playback device is in active use. You need to pause one device if you want to play music by other device.
- 7. Enjoy your X-Audio speaker with two devices.

Notebook or PC setting (Windows)

8. Turn on your X-Audio and it will be automatically in Bluetooth mode and ready for connection. Now the blue indicator will flash.

- 9. Open the Bluetooth of your notebook or PC by "Start Setting Control Panel", search the audio speaker device and connect with it.
- 10.Blue light remains glowing to indicate a successful connection.
- 11. Run the music player of your device, and let the sound come from your X-Audio .
- 12.Enjoy your X-Audio speaker.

Mac or Macbook setting (Apple)

- 1. Turn on your X-Audio and it will be automatically in Bluetooth mode and ready for connection. Now the blue indicator will flash.
- 2. Open the Bluetooth of your Mac or Macbook by "System preferences Bluetooth Turn Bluetooth on", search the audio speaker device and connect with it.
- 3. Blue light remains glowing to indicate a successful connection.
- 4. Run the music player of your device, and let the sound come from your X-Audio .
- 5. Enjoy your X-Audio speaker.

【Remark】 In the case of your notebook without Bluetooth function. Please buy the Bluetooth® adaptor additionally. We suggest the adaptor with Bluetooth 4.0 version for high quality audio experience. After installing please start the Bluetooth® from the "Control Panel" or the shortcut of your desktop, please search for connecting, and the instruction steps are the same as the first case.

[Note] Your speaker will power off automatically within 15 minutes if you did not pair it with any playback device or audio source in order to save energy. You need to power on speaker again when using.

Bluetooth® compatibility X-Audio can be compatible with most of Bluetooth devices with various different brands and models that have no affiliation with us, but some individual Bluetooth® devices may have compatibility problem with the X-Audio.

If your X-Audio speaker is already paired with over 8 playback devices. There will be 2 or more seconds delay for scanning and pair with new playback devices. Because your speaker need to scan the previous paired devices firstly to re-pair with them automatically. Or simply to hold the previous track and next track button at the same time for 3 seconds to clean all the memory devices and resume default settings.

Trouble Shooting:

Problem	Solution
Speaker will not turn on	Make sure your speaker battery has sufficient power.
Paired Bluetooth device will not connect	 If your device requires a pass code, make sure to input "0000" four zero. Turn the X-Audio speaker off and back on. Remove the X-Audio speaker from the pairing list on your Bluetooth device pairing list (consult the device owner's manual for assistance). Then pair the device and the
Speaker indicates a connection, but it not playing music	 speaker again. Turn off or disable Bluetooth on all other paired devices nearby and reconnect the device you want to listen. Turn the X-Audio speaker off and back on.
Can not pair the X- Audio with my Bluetooth device	 Make sure your X-Audio is discoverable. Your Bluetooth device maybe out of range-try to move closer to your speaker. Make sure your Bluetooth device supports the transfer of audio. Reset your Bluetooth speaker.
No audio from a Bluetooth device	 Make sure your X-Audio is not muted and the volume is up. Make sure your Bluetooth device is playing audio and volume is up. Your Bluetooth device may be out of range, move closer and try. Turn your Bluetooth speaker off and back on.
Poor sound quality from a Bluetooth device	 Your Bluetooth device may be out of range, move closer and try again. Move your Bluetooth device and /or X-Audio u speaker from any device that generates electromagnetic interference, such as another Bluetooth device, cordless phone, microwave oven or wireless router. Try to turning off WIFI to improve audio quality. Make sure your music file is not poor quality. Turn your Bluetooth speaker off and back on.
No Audio from AUX source Poor sound quality	 Make sure your connected device is on and playing. Make sure you speaker is in AUX in mode. Make sure the audio cable is correctly inserted. Increase the volume level on the device and speaker. Reduce the volume level on the AUX source.
from AUX source	 Make sure the 3.5mm audio cable is fully inserted into the speaker and device. Make sure your audio source and music file is not of poor quality or has a very have bass.