



# nabi 2 User Manual

Updated: 09/26/2012

# Contents

---

<b>01</b>	<b>At a Glance</b>	<b>06</b>
1.1	About nabi	06
1.2	What's New on Monarch OS	06
1.3	Overview	08
1.4	Home Screen	09
1.5	Touch and Navigation	12
1.6	Sleep Mode	13
1.7	Status Icons	14

---

<b>02</b>	<b>Getting Started</b>	<b>16</b>
2.1	What's in the Box	16
2.2	Charging nabi	16
2.3	nabi™ Setup	18

---

<b>03</b>	<b>Basics for nabi™ Mode</b>	<b>21</b>
3.1	About nabi™ Mode	21
3.2	Settings	22
3.3	Connecting to Wi-Fi	23
3.4	Customizing the Home Screen	23
3.5	Using the On-Screen Keyboard	26
3.6	Switching and Adding Kids	27
3.7	Using the Camera	28
3.8	Using Gallery	28
3.9	Playing Music	29
3.10	Preloaded Apps	30
3.11	Switching to Mommy/Daddy Mode	31

---

<b>04</b>	<b>Basics for Mommy/Daddy Mode</b>	<b>32</b>
4.1	About Mommy/Daddy Mode	32
4.2	Android 4.0 Basics	32
4.3	Switching Between Modes	35
4.4	Settings	35
4.5	Wi-Fi	36
4.6	Using the Camera	36
4.7	Using the On-Screen Keyboard	37
4.8	Managing nabi™ Mode Apps	38
4.9	Using Apps	39

---

<b>05</b>	<b>App Zone</b>	<b>43</b>
5.1	About App Zone	43
5.2	Browsing and Searching	43
5.3	Purchasing and Downloading Apps	44
5.4	Updating Apps	45
5.5	Managing Credit Card Information	45
5.6	Writing Reviews	45
5.7	Managing nabi™ Coins	45

---

<b>06</b>	<b>Spinlets+ Music</b>	<b>47</b>
6.1	About Spinlets+ Music	47
6.2	Creating and Managing Spinlets+ Music Account	47
6.3	Finding Music	48
6.4	Purchasing Music	48
6.5	Downloading Music	49
6.6	Listening to Music	50
6.7	Creating Playlists	50
6.8	Transferring Music	51

---

<b>07</b>	<b>Spinlets+ TV</b>	<b>52</b>
7.1	About Spinlets+ TV	52
7.2	Finding Videos	52

---

<b>08</b>	<b>Fooz Kids on nabi</b>	<b>53</b>
8.1	About Fooz Kids	53
8.2	Fooz Kids™ University and N-SITE	53
8.3	Fooz Kids™ Web, Videos and Crafts	54
8.4	Fooz Kids™ Books	54
8.5	Switching Kid Accounts	54
8.6	Parental Dashboard	55

---

<b>09</b>	<b>Chore List</b>	<b>57</b>
9.1	About Chore List	57
9.2	Adding Chores	58
9.3	Editing Chores	58
9.4	Managing Chores	58
9.5	Viewing Chore List in nabi™ Mode	59
9.6	Purchasing nabi™ Coins	59

---

<b>10</b>	<b>Treasure Box</b>	<b>60</b>
10.1	About Treasure Box	60
10.2	Searching and Browsing	60
10.3	About nabi™ Coins	61
10.4	Earning nabi™ Coins	62
10.5	Redeeming nabi™ Coins	62

---

<b>11</b>	<b>nabi™ Sync</b>	<b>63</b>
11.1	About nabi™ Sync	63
11.2	Setting up nabi™ Sync	63
11.4	Compatible File Formats	69
11.5	Using My Library	69
11.6	Software Updates	70

---

<b>12</b>	<b>nabi™ Cloud</b>	<b>71</b>
12.1	About nabi™ Cloud	71
12.2	nabi™ Cloud Settings	72
12.3	Adding and Deleting Folders	73
12.4	Uploading and Deleting Files	73
12.5	Using Folders on nabi	73

---

<b>13</b>	<b>nabi™ MD</b>	<b>75</b>
13.1	About nabi™ MD	75
13.2	Using nabi™ MD75	

---

<b>14</b>	<b>nabi™ MD</b>	<b>76</b>
14.1	Battery and Charging	76
14.2	Wi-Fi	76
14.3	Screen	77
14.4	Speaker and Microphone	78
14.5	Transferring Files	78
14.6	Storage	80
14.7	nabi™ Account Management	80
14.8	Resetting nabi	80
14.9	Over the Air Software Updates	82
14.10	Extending Battery Life	82

---

<b>15</b>	<b>Connecting to Devices</b>	<b>83</b>
15.1	Connecting to TV	83
15.2	Connecting to Bluetooth Devices	83

---

<b>16</b>	<b>Important Safety and Handling Information</b>	<b>84</b>
-----------	--	-----------

---

<b>17</b>	<b>Fuhu One (1) Year Limited Warranty</b>	<b>88</b>
-----------	---	-----------

---

# 01 At a Glance

## 1.1 About nabi

nabi is the world's fastest and most powerful seven-inch tablet, made just for kids. As parents ourselves, we designed nabi and the Monarch OS using "Learn. Play. Grow ... for Life" as our guiding principle to deliver rich, engaging experiences for your children. This user manual will walk you through all of the features in detail, but feel free to email us at [nabicares@nabitablet.com](mailto:nabicares@nabitablet.com) if you have any questions.

## 1.2 What's New on Monarch OS

nabi™ Monarch OS has more than 150 new features. Its easy-to-use and intuitive user interface keeps nabi™ years ahead. Key Monarch highlights include:

**"This is the coolest app ever! I want it, Mom!"**



App Zone presents more than 500 mom-selected, kid-approved apps and games categorized and filtered by age. Apps include parental advisory guidance and ratings.

**"Check out all my new songs!"**



Music to their ears and yours – Spinlets+ Music is the most comprehensive music solution for kids. It features more than 9,000 children's albums and 19 million tracks from all genres, as well as an integrated music player and the ability to sync with your computer.

**“I can watch all my favorite TV shows?!”**



Saturday morning shows are always on. Spinlets+ TV offers unlimited instant streaming of more than 700 hours of Cookie Jar shows like “Strawberry Shortcake,” “Paddington Bear,” “The Busy World of Richard Scary,” “Horseland” and much more.

**“I wanna be a Fozz Kid!”**



nabi is designed especially for learning. Fozz Kids™ University provides state-standardized, core curriculum in English, Math, Science and Social Studies for K to 5th grade. You can also track your child’s development with N-SITE, which provides a detailed understanding of skills mastered and areas in need of improvement.

**“Wow! I get coins for cleaning my room?! I’m gonna use them to get that new app!”**



Chore List encourages children to be more responsible and make good choices. You can reward your kids for completing their chores with nabi™ Coins, which they can redeem for apps, games, music and accessories in Treasure Box.

**“Can you save my stuff, Mom?”**



Your content on nabi ... made easy. Back up and transfer your nabi™ apps, photos, music and videos from your computer to the cloud and from the cloud to your nabi with nabi™ Cloud and nabi™ Sync.

## 1.3 Overview

### Front View:



1. **Charging Indicator:** Displays the charging status.
2. **Front-Facing Camera:** Takes photos and records videos.
3. **Touchscreen Display:** Enables direct interaction with the tablet.

### Back View:



1. **Kinabi™ Grid:** Allows you to fully personalize your nabi using Kinabis.
2. **Stereo Speakers:** Play audio from songs and other media.

## Angle View (Ports and Buttons)



1. **Power/Lock Button:** Press down and hold the **Power Button** for three seconds to turn nabi on or off. Short press the **Power Button** to put nabi to sleep or to wake it from sleep mode.
2. **Volume Buttons:** Press the **Volume + Button** to increase the sound level of apps, movies, songs and other media; press the **Volume – Button** to decrease it.
3. **Microphone:** Use to speak or to record an audio message.
4. **5mm Headset Jack:** Use to connect headphones or external speakers.
5. **Mini HDMI Port:** Plug in a Mini HDMI cable to view photos or videos on an HDTV.
6. **Micro USB Port:** Use to transfer files to or from a computer with a Micro USB cable.
7. **MicroSD Card Slot:** Insert a MicroSD card to expand memory or access external content.
8. **Power Charger Port:** Insert the USB charging cable plug to charge the battery.

### 1.4 Home Screen

The home screen is where you will find your apps and folders. nabi™ Mode and Mommy/Daddy Mode have different home screens and different options for management and customization. For more information about nabi™ Mode, please visit **Section 3**. For more information about Mommy/Daddy Mode, please visit **Section 4**.

## nabi™ Mode Home Screen



1. **All Apps Icon:** Tap to view all of your applications and widgets on the All Apps screen.
2. **Screen Panel Indicator:** nabi™ Mode comes with nine screen panels; this indicator displays the position of the current screen within the nine panels.
3. **Status Bar:** Displays Status Icons that show battery power, time and Wi-Fi. For more information on Status Icons, please visit **Section 1.7**.
4. **Back Key:** Tap to return to the previous screen.
5. **Home Key:** Tap to return to the home screen.
6. **Menu Key:** Tap to display the menu for the current screen. Tap to go to Mommy/Daddy Mode.

## Mommy/ Daddy Mode Home Screen



1. **All Apps Icon:** Tap to view all of your applications and widgets on the All Apps screen.
2. **Shortcuts:** App icons that open your favorite or frequently used applications; shortcuts can be placed on the home screen for quick access.
3. **Status Bar:** Displays app notifications and Status Icons that show battery power, time and Wi-Fi. For more information on Status Icons, please visit **Section 1.7**.
4. **Back Key:** Tap to return to the previous screen.
5. **Home Key:** Tap to return to the home screen.
6. **Recents Key:** Tap to view a list of recently used apps on the Recents screen.

### Orientation:



nabi can be viewed in either portrait or landscape orientation. For most screens, you can automatically change the screen orientation by rotating your nabi. Some applications and screens are limited to either portrait or landscape orientation.

You can also disable auto-rotation:

**In nabi™ Mode:** Tap **Menu Key**  > **Settings** > **Auto-Rotating**, then tap and slide the switch to **Off**.

**In Mommy/Daddy Mode:** Tap **All Apps Icon**  > **Settings Icon**  > **Display** > **Auto-rotate screen** and deselect this option.

## 1.5 Touch and Navigation

### Tap:

When you need to select an item on the screen, simply touch the item once with your finger.



### Tap and Hold:

To select icons you want to move on the screen, tap and hold down.



### Drag and Drop:

Move an item across the screen by tapping and holding the icon, then drag it to any open spot. Release your finger to drop the item in its final position.



### Swipe:

To move vertically or horizontally across the screen, simply swipe your fingers left and right or up and down on the screen.



### Zoom In and Out:

Using two fingers, pinch the screen together to zoom in or apart to zoom out. When viewing photos or a web page, double-tap the screen to zoom in; double-tap it again to zoom out.



## 1.6 Sleep Mode

Sleep Mode helps save battery power when nabi is not being used. To manually put nabi into Sleep Mode, short press the **Power Button** to turn the screen off. To wake nabi from Sleep Mode, short press the **Power Button** and unlock the screen. nabi will automatically go into Sleep Mode when it has not been in use for a while.

You can adjust the Sleep Mode settings in Mommy/Daddy Mode by tapping **All Apps Icon**  **> Settings Icon**  **> Display > Sleep.**

## Using the Lock Screen

To unlock the screen, tap and hold anywhere on the screen. Drag your finger in any direction, as shown by the **Open Lock Icon** .



You can also access the Camera app from the lock screen. To open the Camera app from the Lock screen, tap the **Camera Icon**  located on the bottom left corner of the screen.

## 1.7 Status Icons

The Status Bar on the bottom of your screen displays app notifications and Status Icons that show battery power, time, Wi-Fi and more.

Status Icons	
	Battery is charging
	Battery is full
	Battery is low
	Battery is partially drained
	Battery is very low
	Bluetooth file sharing
	Bluetooth is on
	Connected to a Wi-Fi network

---

**Notification Icons (Only in Mommy/ Daddy Mode)**

---

	Downloading data/ Download complete
	Music is playing
	Software update available
	Tablet is connected via USB cable
	Uploading data
	Spinlets+ Music is playing
	Spinlets+ song is downloading

---

**Please note:** Notification icons only display in Mommy/Daddy Mode. If you are not sure what a notification icon means, tap the icon for a tip.

# 02 Getting Started

## 2.1 What's in the Box

The following items are included with nabi:



nabi™ Tablet with Red Bumper



Micro USB Cable



USB Power Adapter



USB Charging Cable



Quick Start Guide

## 2.2 Charging nabi

### Battery

nabi uses a rechargeable Lithium-Polymer battery. The battery will be partially charged when you open your nabi. However, we recommend fully charging your nabi for four hours after taking it out of the box.

### Charging the Battery

There are two ways to charge nabi: You can connect nabi to an electrical outlet or you can charge nabi by connecting it to your computer.

**Connect to an electrical outlet:** Plug the tip of the USB charging cable into the nabi power charger port and plug the other end into the USB Power Adapter. Then plug the USB Power Adapter into an electrical outlet.



**Connect to a computer:** Plug the tip of the USB charging cable into the power charger port on nabi, and plug the other end into the USB port on your computer.



**Please note:** Only the USB charging cable will charge nabi when connected to a computer. A Micro USB cable will not charge nabi. Only use the Micro USB cable for transferring files onto nabi.

**Important:** When charging nabi via a computer, it may take longer to charge. The computer may not provide enough power to charge nabi. If this is the case, switch to the wall charger and connect nabi to an electrical outlet.

If the battery is completely depleted, nabi may display the battery-charging screen indicating that nabi needs to charge for 15 minutes before you can use it. Leave nabi plugged in so it can charge while you use it.



## Charging Light Indicator

When the battery is charging, the charging indicator will display an orange light. Once it's fully charged, the light will turn green.

## Extending Battery Life

To extend the battery life of your nabi, fully charge the battery for four hours prior to using nabi for the first time. Charge for up to four hours whenever the battery is depleted.

**⚠ Caution:** Only use a nabi™ USB Power Adapter and USB charging cable to charge your device. Using a different charger may damage your nabi.

**Please note:** Only a Fuhu Authorized Service Provider should replace the battery. Any attempt to remove or replace your battery, other than through an Authorized Service Provider, may damage your nabi and will void your warranty.

## 2.3 nabi™ Setup

When you power on nabi for the first time, you will see the nabi™ Welcome screen. Before you set up your nabi, you can watch a video that will briefly walk you through some of the newest nabi™ features.



To set up nabi, simply follow these step-by-step instructions:

### Step 1: Terms and Conditions



Please read the Terms and Conditions carefully before you start using your nabi. Once you are done, tap **Agree** to continue.

### Step 2: Wi-Fi Setup



nabi will automatically detect nearby Wi-Fi networks. Tap to select your preferred network and enter a Wi-Fi security password if required. If you have a closed network, simply tap **Add a Network** to add your Wi-Fi network. Once nabi has connected to your network, you will see “Connected to Internet” underneath your network’s name. Tap **Continue** to proceed to Step 3: Sign Up/Sign In.

**Please note:** Although Wi-Fi is not mandatory for the initial setup, it is strongly recommended so you can enjoy the full nabi™ experience right away. To learn more about Wi-Fi settings, please visit **Section 4.5**.

### Step 3: Sign Up/Sign In



You are required to create a nabi™ ID before you can use nabi for the first time. With a nabi™ ID, you will be able to control the apps and games available for your child to use, register for nabi cares online support, shop for apps and games with one-tap buy and much more.

Simply follow the on-screen instructions to create your nabi™ ID. Check the box next to **Mom** to display Mommy Mode on nabi; check the box next to **Dad** to display Daddy Mode.

You may already have a nabi™ ID created if you are a Fozz Kids™ user or if you own more than one nabi. If this is the case, you will be required to Sign In. To Sign In, simply tap the **Sign In** link on the lower left corner of the Sign Up window.