



CombiSol project

Solar Combisystems Promotion and Standardisation

D6.3: Guidelines for manufacturers and installers

Editor:

Jan Erik Nielsen (PlanEnergi)

Contributions from

Alexander Thür, Johann Breidler, Gabriele Kuhness (AEE INTEC)
Thomas Letz, Guillaume Pradier, Xavier Cholin (INES Education)
Philippe Papillon, Mickael Albaric (CEA Ines)
Chris Bales (SERC)
Barbara Mette, Jens Ullmann (ITW)

(2010)

Date 19/1/2011	Version	DRAFT	Revision	1
----------------	---------	-------	----------	---







CONTENTS

Fig	jure lis		3
nt	roducti	on	4
1	Guide	lines for manufacturers	5
1		neral	
1		pers and procedures	
•	1.2.1	System specific design guidelines for the installer	
	1.2.2	User manuals	6
	1.2.3	Installer manuals	
	1.2.4	Service and maintenance	
1	.3 Co	mponents	
	1.3.1	Collector	
	1.3.2	Storage	
	1.3.3 1.3.4	Controller and sensors	
	1.3.4	Expansion vessel and over temperature protection	
	1.3.6	Back-up heater	
	1.3.7	Hot water units	
	1.3.8	System	
	1.3.9	Installation	. 10
2	Guide	lines for installers	11
2	.1 Ge	neral	.11
2	.2 Pa	per and procedures	.11
	2.2.1	Documents for the user	
	2.2.2	Service and maintenance	. 11
2	.3 Co	mponents	.12
	2.3.1	Collector	
	2.3.2	Storage	
	2.3.3	Controller and sensors	
	2.3.4 2.3.5	Solar loop Expansion vessel and over temperature protection	. 12
	2.3.6	Back-up heater	
	2.3.7	Hot water units	
	2.3.8	System	
	2.3.9	Installation	. 15
3	Biblio	graphy	16





Figure list

Figure 1: System layout (good example) [[3]]	5
Figure 2: Pipe connection with thermo-siphon heat trap [[3]]	6
Figure 3: Collectors with good emptying behaviour [[2]]	
Figure 4: Temperature sensors fixed correctly [[3]]	8
Figure 5: External pipe insulation good quality of insulation and protection	8
Figure 6: Connecting the expansion vessel [[2]]	9
Figure 7: Stagnation cooler - example [[2]]	9
Figure 8: Domestic hot water unit - example, placed directly to the unit [[2]][2]	10
Figure 9: Ökofen unit with all-in-one - example, placed directly to the unit [[2]]	10
Figure 10: System layout (good example) [[3]]	11
Figure 11: Collectos with good emptying behaviour [[2]]	12
Figure 12: Temperature sensors fixed correctly [[3]]	12
Figure 13: External pipe insulation good quality of insulation and protection	13
Figure 14: Connecting the expansion vessel [[2]]	13
Figure 15: Stagnation cooler - example [[2]]	13
Figure 16: Temperature resistant collection tank made of metal (left) but not temperature resistant coll	ection
tank made of plastics (right) [3]	14
Figure 17: Good example of insulated pipe connections and combination of thermo-siphon heat trap	s and
insulation of pipes and all other cold bridges like air vent and thermometer. Could however be be	etter if
already from the manufacturer these heat traps were integrated/pre-assembled in the store unit. [[3]] 15
Figure 18: Switch controlled circulation pump - connected to switches in kitchen and bath room [[3]]	15





Introduction

The guidelines given here are based on lessons learned in the CombiSol Project:

- Guidelines for best practise [D2.1]
- Guidelines for design and dimensioning [[1]]
- Trend analysis for "standardised systems": Where is the market going [[2]]
- 70 installed systems have been evaluated and analysed: Where are the weak points; where to take special care [[3]]
- 40 solar combisystems were monitored and analyzed by energy balances on a monthly basis [[4]]

The results from the systems evaluated and conclusions from the analysis done show that there are "room for improvements", both at product and installation level - so the guidelines here are indeed relevant.

The trend analysis shows that standardised integrated system units are now showing up in the market - it is expected that this trend in general will lead to improved system performance.





1 Guidelines for manufacturers

1.1 General

The main focus for product and system improvements should not be on increasing the solar gains but much more on **reducing heat losses in solar combisystems.**

Integrated / standardised systems/units with pre-installed closely connected components and one common controller are recommended.

1.2 Papers and procedures

1.2.1 System specific design guidelines for the installer

Manufacturer should provide detailed and understandable guidelines for - and examples of - system layout.

Drawings of example system layouts should be given for at least:

- Installation in connection with fast reacting oil or gas back-up
- Installation in connection with slower reacting biomass back-up




Figure 1: System layout (good example) [[3]]

Manufacturer should provide rules for sizing the system and its components depending on the space heating and hot water load (estimated annual energy consumption of the house):

- Specification of collector and storage size depending on the energy consumption of the house
- Specification of pump, piping and heat exchangers depending on collector and storage size
- Specification of size of expansion vessel and pressure setting depending on collector size (and type),
 piping and height difference between collectors and expansion vessel





Double tank solution should normally be avoided - as it typically increases the system losses more than the system gain.

As much system integration as possible is recommended:

- pre-assembled components
- integrated back-up
- one integrated controller for both solar and back-up system.

1.2.2 User manuals

Manufacturer should provide a complete, but simple and understandable user manual describing:

- the functioning of the system
- · user control possibilities with recommendations for settings
- how the user detect if the system is not operating properly

The user manual should also include:

- · recommendation to make a service contract with installer
- notice that the installer should fill out a commissioning check and supply the user and the manufacturer with copies

1.2.3 Installer manuals

Besides the system specific design guidelines, a detailed installation manual should be available. Included here should be specifications how to avoid cold bridges and instructions on how to make the necessary heat traps.



Source: Ines Education / France Figure 2: Pipe connection with thermo-siphon heat trap [[3]]

It is recommended that the heat traps are pre-installed to the tank.





Examples of editable detailed system layouts should be made available for the installer, making it easy for him to provide to the user a detailed system layout of the specific system (important for future maintenance).

Installation guidelines for installing the collector field in a way with good emptying behaviour (over-temperature protection) shall be included in the installation manual.

The control of (the different configurations and operating modes of) the system should be explained in a clear and understandable way in the installation and user manuals. **Control settings should be specified.**

A commissioning check list should be provided to the installer. The manufacturer should agree with the installer that for all system installed, the installer should send a copy of this check list to the manufacturer and a copy should remain at the user.

1.2.4 Service and maintenance

Recommended requirements for service and maintenance should be provided - template for a service contract which the installer can offer the user should be provided. Special reminder to keep the description of the actual system layout and control available for future maintenance should be included.

1.3 Components

1.3.1 Collector

The **collector design should have good "emptying behaviour"**. Guidelines for connecting the collectors in series/parallel depending on the number of collectors should be given order to keep a good emptying behaviour, good flow distribution and low pressure loss for the whole collector field.



Figure 3: Collectors with good emptying behaviour [[2]]

1.3.2 Storage

Cold bridges to the tank should be avoided - especially in the upper part always heated by the back-up. Pre-installation of heat traps where possible is recommended. Insulated caps for unused connection should be provided.

1.3.3 Controller and sensors

Simple controller and/or controller leaving only few and logical choices to the installer should be used. Location of sensor should be clearly described - and suitable fixings/fittings for the sensors should be used for good thermal contact and secure fixing.







Source : AEE INTEC / Austria
Figure 4: Temperature sensors fixed correctly [[3]]

1.3.4 Solar loop

Manufacturer should deliver and/or give specifications for the piping including insulation - pre-insulated pipes are recommended. Materials used shall fit the max. temperatures - and for the part placed outdoor - fit the outdoor environment (solar radiation, rain, birds, insects, ...).

Manufacturer should deliver and/or give specifications for the pumps - use of high efficiency pumps is recommended.





Figure 5: External pipe insulation good quality of insulation and protection


1.3.5 Expansion vessel and over temperature protection

Manufacturer should deliver and/or give specifications for the expansion vessel. Rules for pressure setting depending on collector size (and type), piping and height difference between collectors and expansion vessel should be clear to the installer.

Specification how to install expansion vessel to avoid unnecessary heat loss should be given.







Right and false way for connecting a expension vessel in a solar thermal system

Figure 6: Connecting the expansion vessel [[2]]

Cases where "stagnation cooler" is needed should be specified - and manufacturer should deliver and/or give specifications for such cooler.




Figure 7: Stagnation cooler - example [[2]]

Specification for safety line from safety valve shall be given:

• Temperature resistant piping with right dimensions leading to temperature resistant container (preferably showing/indicating the fluid content).

1.3.6 Back-up heater

Units including solar and back-up systems are recommended - and this is the trend seen.

If manufacturer delivers only the solar part, recommendations and examples should be given how to connect to the different possible back-up systems. Interaction of solar and back-up controllers should be described. If certain back-up system types are not feasible with the solar system - this should be stated.

1.3.7 Hot water units

Separate hot water heat exchangers should be part of / close to the storage to avoid heat loss.





Domestic hot water – unit Name: "FWM35"



Figure 8: Domestic hot water unit - example, placed directly to the unit [[2]]

1.3.8 System

Manufacturer should aim at system integration and pre-assembling. This gives easier/cheaper installation and less risk of errors.




Figure 9: Ökofen unit with all-in-one - example, placed directly to the unit [[2]]

In general there should be focus on system heat losses (including especially cold bridges). Pre-installation of heat traps where possible is recommended. Insulated caps for fittings and unused connection should be provided.

1.3.9 Installation

It should be noted in the installer manual that it is very important that the solar system operates on as low temperatures as possible, hence the return temperature from the heat distribution system should be as low as possible. In the manual hints - or references to hints - should be given: How to check if the return temperature is higher than necessary - and how to lower it (with examples).

"On demand" hot water circulation system should be recommended.





2 Guidelines for installers

2.1 General

The main focus for product and system improvements should not be on increasing the solar gains but much more on **reducing heat losses in solar combisystems**,

Integrated / standardised systems/units with pre-installed closely connected components and one common controller are recommended.

2.2 Paper and procedures

2.2.1 Documents for the user

Installer should provide for the user

- System layout (principle diagram) installer should recommend the user to put it a visible place (see e.g. figure below)
- Description of the control of the system including which settings can be adjusted by the user
- Commissioning report including check list for insulation and heat traps
- Service manual, describing service intervals and service points the installers should offer the user a service contract
- Service contract




Figure 10: System layout (good example) [[3]]

2.2.2 Service and maintenance

Recommended requirements for service and maintenance should be provided to the user. Special reminder to keep the description of the actual system layout and control available for future maintenance should be included. Template for service contract should be provided for the installer.





2.3 Components

2.3.1 Collector

The **collector design should have good "emptying behaviour"**. Guidelines for connecting the collectors in series/parallel depending on the number of collectors should be given order to keep a good emptying behaviour, good flow distribution and low pressure loss for the whole collector field.




Figure 11: Collectos with good emptying behaviour [[2]]

2.3.2 Storage

Cold bridges should be avoided. Pre-installation of heat traps where possible is recommended. Insulated caps for unused connection should be provided.

2.3.3 Controller and sensors

Sensor location is critical - and immersion sleeves should fit the sensor diameter for good thermal contact. Sensors should be secured/fixed in the location.



Source: AEE INTEC / Austria
Figure 12: Temperature sensors fixed correctly [[3]]

2.3.4 Solar loop

Manufacturer should deliver and/or give specifications for the piping including insulation. Materials used shall fit the max. temperatures and for the part placed outdoor - fit the outdoor environment (solar radiation, rain, birds, insects, ...)








Figure 13: External pipe insulation good quality of insulation and protection

2.3.5 Expansion vessel and over temperature protection

Expansion vessel is to be put on the "cold side" and connected in the top (see figure) - or via heat trap. Pressure setting and dimensioning should be done according to manufacturer's instructions for the specific type and size of installation.



Right and false way for connecting a expension vessel in a solar thermal system

Figure 14: Connecting the expansion vessel [[2]]

Check if stagnation cooler is necessary - to be checked with manufacturer recommendations.




Figure 15: Stagnation cooler - example [[2]]

Safety line from safety valve shall be temperature resistant and lead to temperature resistant container.











Source: ITW / Germany - NOT OK

Figure 16: Temperature resistant collection tank made of metal (left) but not temperature resistant collection tank made of plastics (right) [3]

2.3.6 Back-up heater

Before installing the solar system in connection with an existing back-up boiler/unit it is recommended to investigate possibilities /relevance for exchanging this boiler / unit at the same time.

If existing boiler / unit is not exchanged - it should be assured that the control of the solar part of the system and the back-up system works without conflicts.

Units including solar and back-up systems are recommended.

2.3.7 Hot water units

Separate hot water heat exchangers should be part of / close to the storage to avoid heat loss.

2.3.8 System

Manufacturer should aim at system integration and pre-assembling. This gives easier/cheaper installation and less little risk of errors.

In general there should be focus on system heat losses (including especially cold bridges). Pre-installation of heat traps where possible is recommended. Insulated caps for fittings and unused connection should be provided.







Source: AEE INTEC

Figure 17: Good example of insulated pipe connections and combination of thermo-siphon heat traps and insulation of pipes and all other cold bridges like air vent and thermometer. Could however be better if already from the manufacturer these heat traps were integrated/pre-assembled in the store unit. [[3]]

2.3.9 Installation

The installer should check if the return temperature is higher than necessary - and take measures to lower it - guidelines from manufacturer should be followed.

"On demand" hot water circulation system should be recommended.



Source : AEE INTEC

Figure 18: Switch controlled circulation pump - connected to switches in kitchen and bath room [[3]]

The installer should check if e.g. the storage is fully insulated from the manufacturer - if not, the installer should finish the insulation. Especially insulation of the top part of the tank is VERY IMPORTANT.





3 Bibliography

- [1] Thür A. et al, 2010, D2.3 "Guidelines for Design and Dimensioning"
- [2] Thür A. et al, 2010, D2.4 "Updated State of the Art Report Of Solar Combisystems Analysed within CombiSol"
- [3] Thür A. et al, 2010, D5.4 "Summary of the Qualitative Evaluation of Solar Combisystems"
- [4] Letz T. et.al, 2010, D4.4 "Comparison of results of all monitored plants"