

panacom



Living & Loving Technology

PA-7700 USER MANUAL

PA-7700 MANUAL DEL USUARIO



PA-7700

2-LINE & LCD

BUSINESS
TELEPHONE

PA-7700 PHONE 2 LINES WITH DISPLAY

USER'S GUIDE

*Thank you for purchasing Panacom's 2-line PA-7700.
Please read the manual carefully before operating.*



Index

CAUTION	4
INTRODUCTION	4
Packaging Content	4
Requirements	4
Battery Installation or Replacement	5
Battery BackUp	5
PHONE INSTALATION	5
Clock	6
Speaker Function	6
Wall Mount Installation	7
MEMORY DIALING	7
Storing a Number in Upper Memory	7
Storing a Number in Upper Memory	7
CARE AND MAINTENANCE	8
PANACOM's RECOMENDATION	8

CAUTION

- Do not place product in moisture or hot environment.
- Avoid splashing water or impact on product.
- Overload operation will cause damage and shorten the life of the product.
- Normally clean the speaker using a soft dry cloth. Always before cleaning, disconnect the power line and all connection cables.

INTRODUCTION

Your Panacom PA-7700 two-line speakerphone is designed to meet your business needs at home or in an office environment.

Because your time is valuable, and we know you want to use your phone not read about it, this user manual presents installation and basic usage information up front, and discusses advanced features later in the book.


Packaging Content

Your Package should contain the following items:

1. Base Unit
2. Handset
3. AC power supply
4. Handset cord
5. 2 Gray telephone line cords with RJ11 plugs.

Requirements

2 modular jack USOC: RJ11C are required.



Battery Installation or Replacement.

1. Remove the base plate by pressing down the tabs and lifting it from the base.
2. Loosen the screw on the battery compartment door and open the door.
3. Insert the battery as shown in the diagram inside the battery compartment.
4. Close the battery door, tighten the screw and replace the base plate.

Battery BackUp

The installation of an optional 9V battery gives the phone normal performance despite any electrical failure or energy shutdown that may occur.

Without the battery backup the telephone wouldn't allow the functions of:

1. incoming calls.
2. Speaker will not work, you will have to use the handpiece.
3. The Phone will operate on the 1-line.


Note: With or without battery backup, whenever a power shutdown may happen the numbers stored in memory will not be lost.

PHONE INSTALATION

Your Two line phone can be placed on a level surface such as tabletop or desk, or you can mount it on the wall.

The desktop/tabletop installation illustration shows 2 phone lines on 2 modular jacks.

Connect each line cord to the telephone line jacks on the wall and the RJ11 jacks on the



backside of the base unit in LINE 1 and LINE 2.

Connect the curling cord into the handphone and to the left side of the base unit.

Connect the AC power adaptor in the backside of the base unit and to the power plug on the wall. Remember adjusting on it plastic lock.

Clock:, set the 12-hour display clock by pressing the SET button, and then the corresponding time. (0455, as on the example)

The Display:

The Display shows you information, such as the current time, the duration of a call, or the phone number you are currently dialing (the last 12 digits dialed appear in the display)

Display Item

Meaning

TONE

The TONE/PULSE is set to TONE.

TEMP TONE

The Temporary Tone feature is active

DATA PORT 1

The Data port is set to line 1

DATA PORT 2

The Data port is set to line 2

Low

If flashing –battery is low and needs to be changed, if not flashing battery is dead or not installed.

n

Represents the pound key (#)

A

Represents the asterisk key (*) in a number sequence.

[number (1-16)]

The number in brackets indicates the upper memory location of a phone number.

[number (1-16L)]

The number in brackets indicates the lower memory location of a phone number.

Speaker Function

To keep the best performance of the speaker functions avoid:

- Loud noises and echoes spaces. (The microphone may play those sounds).
- Placing the phone on any vibration surface.

Wall Mount Installation


Please follow the next steps.

1. Rotate the handset hook one-half turn.
2. Remove the base plate from the back by pressing down on the snap tabs located at the top, and then lifting it off.
3. Plug the telephone line cords into the phone jacks on the back of the unit; wrap the extra line cord around the cord wrap on the bottom of the base; and then thread the other cords through the bottom of the base.
4. Plug the power supply adapter into the 9V AC jack on the back of the unit, and then thread it through the bottom of the base.
5. Reverse the direction of the base plate and replace it by putting the tabs into the slots on the unit first, and then snapping the bottom tabs into place.
6. Connect the telephone line cords to the modular jacks on the wall.
7. Slip the mounting holes over the wall plate posts and slide the unit down firmly into place (wall plate not included).
8. Connect the AC power supply adapter to an AC outlet.
9. Plug the handset cord into the handset and into the unit, and then hang up the handset.

MEMORY DIALING

Each one of the 16 memory buttons on the phone contains an upper and lower memory location. This mean the phone maximum memory storage is 32 phone numbers. The lower memory is accessed by pressing the Lower button on the Memory Directory

You can store numbers with the phone off-



hook or on-hook, note that if no keys are pressed for 15 seconds, the memory feature automatically turns off.

Be careful when you store numbers with the phone off-hook, because if you don't follow the correct procedures, you might actually call someone instead of storing their number in memory.

Storing a Number in Upper Memory

You can storage 16 numbers in upper memory by following these steps:

1. Press STORE/IN (indicator lights turns on)
2. Dial the number to be stored
3. Press STORE/IN again (indicator lights turns on)
4. Press a Memory Location to store the number.
5. Record whose phone number it is on the memory directory (located under the plastic cover on the front of the unit)

Tip: if you make a mistake while entering a number into memory, wait 15 seconds for the feature to turn off, or press STORE/IN twice.

Storing a Number in Upper Memory

You can storage 16 numbers in upper memory by following these steps:

6. Press STORE/IN (indicator lights turns on)
7. Dial the number to be stored
8. Press STORE/IN again (indicator lights turns on)
9. Press Lower key followed by a Memory Location to store the number.
10. Record whose phone number it is on the memory directory (located under the plastic cover on the front of the unit)

Tip: if you make a mistake while entering a number into memory , wait 15 seconds for the feature to turn off, or press STORE/IN twice.

CARE AND MAINTENANCE

To keep Your Panacom PA-7700 two-line speakerphone working and looking good, follow these few simple guidelines:

- Avoid putting telephone near heating appliances and devices that generate electrical noise. (i.e., motors, fluorescent lamps.)
- Telephone should not be exposed to direct sunlight or moisture.
- Avoid dropping the handset and other rough treatment to the phone.

- Clean telephone with a soft cloth. (Remember to first unplug the phone from the wall outlet.)
- Never use a strong cleaning agent or abrasive powder, as this can damage the finish.
- Retain the original packaging for future use.

PANACOM's RECOMENDATION

At Panacom we strive to get you new technologies that are simple and friendly. Accordingly to that, we always try to give you exactly what you are looking for. This is why we have compiled a list of emergency numbers to be ready from the first moment.

Here they are:

In Argentina:

- Any type of emergency: 911
- Medical emergency: 107
- National Firemen Corps: 100
- Police: 101

In Chile:

- Any type of emergency: 911
- Medical emergency: 131
- National Firemen Corps: 132
- Police: 133

In United States of America:

- Any type of emergency: 911

In Uruguay:

- Any type of emergency: 911
- Medical emergency: 105
- Police: 109
- National Firemen Corps: 104

If you would like to comment about these lists and suggest new ones, you are invited to contribute in our website: <http://www.panacom.com>

PA-7700 TELÉFONO 2 LINEAS CON VISOR

GUIA DEL USUARIO

*Gracias por comprar su teléfono Panacom PA-7700 de 2 líneas.
Por favor lea este manual cuidadosamente previo al uso.*



Índice

CUIDADO	4
INTRODUCCIÓN	4
Contenido del Paquete	4
Requerimientos	4
Instalación de Batería	5
Baterías de Resguardo	5
INSTALACIÓN DEL TELÉFONO	5
Reloj	6
El Visor	6
Función Manos Libres	6
Instalación de Pared	6
DISCADO POR MEMORIAS	7
Guardando un Número en la Memoria Superior (Upper Memory)	7
Guardando un Número en la Memoria Inferior (Lower Memory)	7
CUIDADO Y MANTENIMIENTO	8
RECOMENDACIÓN DE PANACOM	8

CUIDADO

- No exponga el producto a altas temperaturas ni en un ambiente con humedad elevada.
- Evite los golpes al producto y el contacto con líquidos.
- Sobreexigir las operaciones del producto causará daños y reducción de la vida del producto.
- En caso de limpiar el producto, desconecte siempre la fuente de energía y el resto de los cables conectados.

INTRODUCCIÓN

Su teléfono con parlante de dos líneas Panacom PA-7700 está designado para cubrir las necesidades de su negocio ya sea en el hogar o en un ambiente de oficina.

Dado que su tiempo es valioso, y teniendo en cuenta que sabemos que usted quiere usar su teléfono y no leer acerca de él, este manual del usuario presenta la información de instalación y uso básico al principio, y entra en la discusión de rasgos avanzados más adelante.


CONTENIDO DEL PAQUETE

El paquete del teléfono debe tener los siguientes items:

1. Unidad Base,
2. Auricular,
3. Adaptador de Corriente,
4. Cable Rulo Telefónico,
5. Cable gris de línea con salida RJ11 (que soporta un número telefónico).

Requerimientos:

Dos entradas RJ11 hacia la instalación de cables de línea.



Instalación de Batería

1. Remueva la placa base presionando hacia abajo y levantando
2. Destornille y remueva la tapa de la batería.
3. Inserte la batería como muestra el gráfico.
4. Cierre la tapa de la batería y ajuste con destornillador.

Baterías de Resguardo

La instalación de una batería opcional de 9V le permite a su teléfono trabajar normalmente ante un eventual corte de energía eléctrica. Sin la batería de resguardo el teléfono no será operativo para:

1. Llamadas entrantes.
2. El altavoz no funcionará, deberá usar el auricular
3. El teléfono operará solamente en la línea 1.

Nota: con o sin batería de resguardo, ante un eventual corte de energía eléctrica, los números almacenados en la memoria no serán perdidos.


INSTALACIÓN DEL TELÉFONO

Su teléfono de dos líneas puede ser utilizado en una superficie como un escritorio o puede montarlo en la pared.

La instalación del teléfono de escritorio muestra 2 líneas en dos módulos de entrada.

Conecte el cable de línea del teléfono en las entradas modulares en la pared y la parte posterior de la unidad, en LINE 1 y LINE 2.

Conecte el cable rulo en el auricular y en la entrada del teléfono.



no, en la parte izquierda de la unidad.

Conecte el adaptador de corriente en la parte posterior de la unidad y el otro extremo en la salida de corriente de la pared. Recuerde ajustarlo en su traba correspondiente.

Reloj, Configure el reloj de 12 horas (Formato AM/PM) presionando el boton SET y luego la hora correspondiente. (0455, en el ejemplo mostrado)

El Visor,

El visor le muestra información como es la hora actual, duración de una llamada, el número telefónico que esta actualmente discando (aparecen los últimos 12 dígitos discados en el display)

Item	Significado
STONE	El TONO/PULSO esta configurado en TONO.
TEMP TONE	La característica de Tono Temporal esta activa
DATA PORT 1	La Data port está en la línea 1
DATA PORT 2	La Data port está en la línea 2
Low	Si destella es batería baja y necesita ser cambiada, si no lo hace es batería muerta o no instalada
n	Representa la tecla #.
A	Representa la tecla asterisco (*) en una secuencia de números.
[number (1-16)]	El número en corchetes indica ser un número de memoria superior
[number (1-16L)]	El número en corchetes seguido de L indica ser un número de memoria inferior.

Función Manos Libres

Para el mejor desempeño de este altavoz evite lo siguiente:

- Áreas con ruido de fondo. (el micrófono quizás levante estos sonidos).
- Colocar en superficies afectadas por la vibración.
- Áreas que puedan incluir un eco importante.

INSTALACIÓN DE PARED

Por favor siga los pasos gráficos.

1. Rote el gancho para el auricular en la unidad base.

2. Remueva la base localizada en la parte posterior, presionando y tirando hacia abajo.

3. Enchufe los cables telefónicos con la ficha RJ11a las salidas del teléfono en su parte posterior. Recoja el extra del cable y átelo debajo de la base.

4. Utilice la placa de la base, dándola vuelta y uniéndola a los espacios en la base de la unidad como se muestra en la imagen.

5. Ahora conecte los cables de la línea telefónica a la ficha RJ11 de la pared.

6. Conecte el adaptador de corriente en la salida trasera del teléfono 9V AC y en la entrada de corriente en la pared.


7. Coloque los agujeros de montaje sobre la placa de la pared y deslice firmemente hacia abajo hasta encastrar (la placa de la pared no está incluida).

8. Conecte el cable rulo al auricular y a la unidad del lado izquierdo. Luego cuélguelo.

DISCADO POR MEMORIAS

Cada uno de los 16 botones de memorias en el teléfono contiene una ubicación superior e inferior, por lo que se obtienen 32 números posibles para almacenar.

A la memoria inferior se accede presionando



el botón LOWER que se encuentra en el directorio de memorias.

Guardando un Número en la Memoria Superior (Upper Memory)

Puede almacenar hasta 16 números en la memoria superior siguiendo estos pasos:

1. Presionar STORE/IN (titila esta luz)
2. Discando el número a ser almacenado
3. Presionar STORE/IN de nuevo (titila esta luz)
4. Presionar el botón de la ubicación de la memoria para guardar el número.
5. Registre el número de quien está en el directorio de memorias (localizado debajo de la cubierta plástica en el frente de la unidad).

Consejo: Si comete un error cuando ingresa un número en la memoria, espere 15 segundos para cancelar la función, o presione STORE/IN dos veces.

Guardando un Número en la Memoria Inferior (Lower Memory)

Puede almacenar hasta 16 números en la memoria superior siguiendo estos pasos:

6. Presionar STORE/IN (titila esta luz)
7. Discando el número a ser almacenado
8. Presionar STORE/IN de nuevo (titila esta luz)
9. Presionar LOWER seguido de el botón de la ubicación de la memoria para guardar el número.
10. Registre el número de quien está en el directorio de memorias (localizado debajo de la cubierta plástica en el frente de la unidad).

CUIDADO Y MANTENIMIENTO

Para mantener su teléfono Panacom en buen estado de funcionamiento y con una buena apariencia, observe las pautas simples siguientes:

- Evite colocar el teléfono cerca de aparatos calentadores y dispositivos que generan ruido eléctrico (es decir, motores, lámparas fluorescentes, etc.)
- No exponga el teléfono a la luz solar directa ni a la humedad.
- Evite dejar caer el auricular y evite cualquier otro tratamiento brusco del teléfono.
- Limpie el teléfono con un paño suave. (Recuerde desconectar pri-

mero el teléfono del contacto de pared.)

- Nunca utilice un agente limpiador fuerte ni polvo abrasivo, ya que puede dañar el acabado.
- Conserve los materiales originales de empaque para utilizarlos en el futuro.

RECOMENDACIÓN DE PANACOM

En Panacom nos esforzamos para ofrecerte nuevas tecnologías manteniendo la simplicidad del producto agregando valor a tu compra. De acuerdo con esto, tratamos de darte exactamente lo que cada uno busca. Es por eso que hemos compilado listado de números de emergencia para que puedas tenerlos a mano desde el primer momento.

En Argentina:

- Todo tipo de emergencias: 911
- Emergencias médicas: 107
- Bomberos: 100
- Policía: 101

En Chile:

- Todo tipo de emergencias: 911
- Ambulancia: 131
- Bomberos: 132
- Carabineros: 133

En Estados Unidos de América:

- Todo tipo de emergencias: 911

En Uruguay:

- Todo tipo de emergencias: 911
- Ambulancias: 105
- Bomberos: 104
- Policía: 109

Si quieres comentar acerca de estos listados y sugerir nuevos, estás invitado a contribuir en nuestro sitio web: <http://www.panacom.com> .



INTERNATIONAL WARRANTY

Terms and Conditions

1. PANACOM warrants the operation of this product to be free from any manufacturing and/or material defect for a period of 12 months from the date of purchase by the user.
2. This warranty is limited to the repair and/or replacement of this product, according to our own criterion, free of charge within the stipulated term and it does not extend to consequential or incidental damages to other products that may be used with this unit.
3. The warranty shall be voided in the following cases: a) repair or attempt to repair by third parties not authorized by the company. b) in case of performing any type of cut in connection cables, plugs, connectors, or other adapters different from the original ones provided by the company.
4. To make this warranty effective, you shall contact the Authorized Service Center of your country and they shall carry out the pertinent procedure; said information is available at www.panacom.com. In order to start the necessary procedure to get said warranty, you shall hand in the Original Purchase Invoice where the purchase date, dealer name and product identification shall be stated clearly.
5. Transportation, freight, stay and/or insurance expenses, if any, are not covered by this warranty.

Authorized Service Centers:

Argentina

Elese Telefonía

Av. Santa Fé 2393 C1123AAF, C.A.B.A

Phone: (54 11) 45 82 66 38

Fax: (54 11) 45 82 76 96

E-mail: arg@panacom.info

Chile

Importaciones y Exportaciones X-Tech Ltda.

San Alfonso 637, Santiago de Chile

Phone/Fax: (56 2) 689-1721

E-mail: chile@panacom.info

Uruguay

Comunica S.R.L.

Constituyente 1873 C.P. 11.200 - Montevideo

Phone: (598 2) 403 5480

E-mail: uruguay@panacom.info

USA

Amaury International Corp

7286-90 NW 70th Street - Miami, FL 33166

Phone: 1(305) 887-7100

Fax: 1 (305) 887-9177

E-mail: usa@panacom.info

GARANTIA INTERNACIONAL

Términos y Condiciones

1. PANACOM garantiza el funcionamiento de este producto ante cualquier defecto de fabricación y/o vicio de material por el término de 12 meses contado a partir de la fecha de compra por parte del usuario.
2. Esta garantía se limita a la reparación y/o reemplazo de este producto, a nuestro criterio, sin cargo alguno dentro del plazo de vigencia y no se extiende a daños consecuentes o incidentales hacia otros productos que fueran utilizados con esta unidad.
3. La garantía queda anulada ante: a) reparación o intento de reparación por terceros no autorizados por la compañía. b) en el caso de realizar cualquier tipo de corte de los cables de conexión, fichas, conectores, u otros adaptadores distintos de los originales de fábrica.
4. Para hacer valer esta garantía se deberá remitir al centro de servicios autorizado de su país quienes gestionarán la misma, dicha información se encuentra www.panacom.com. Para gestionar dicha garantía deberá presentar la Factura Original de compra en la cual deberá constar claramente la fecha de compra, nombre del comercio e indentificación del producto.
5. No quedan cubiertos por esta garantía gastos de traslado, flete, estadía, y/o seguro si los hubiera.

Centro de Servicios Autorizado:

Argentina

Elese Telefonía

Av. Santa Fé 2393 C1123AAF, C.A.B.A Phone:

(54 11) 45 82 66 38

Fax: (54 11) 45 82 76 96

E-mail: arg@panacom.info

Chile

Importaciones y Exportaciones X-Tech Ltda.

San Alfonso 637, Santiago de Chile

Phone/Fax: (56 2) 689-1721

E-mail: chile@panacom.info

Uruguay

Comunica S.R.L.

Constituyente 1873 C.P. 11.200 - Montevideo

Phone: (598 2) 403 5480

E-mail: uruguay@panacom.info

USA

Amaury International Corp

7286-90 NW 70th Street - Miami, FL 33166

Phone: 1(305) 887-7100

Fax: 1 (305) 887-9177

E-mail: usa@panacom.info



www.panacom.com