





IMI CORNELIUS INC ■ One Cornelius Place ■ Anoka, MN 55303-6234

Telephone (800) 238-3600

Facsimile (612) 422-3246

INSTALLATION INSTRUCTIONS

"K" STYLE LID KIT, P/N 630000085

These "K" style kits apply to the following ice makers and are for use with ED/DF 150 dispensers:

Ice Maker	Size
Wilshire WCC500/700	14 1/2" Wide

Table 1. Loose-Shipped Parts			
Item No.	Part No.	Name	Qty.
1	620030602	Lid Assembly,	1
2	15303	Bracket	1
3	50904	RTV, Clear, 732, 3 oz. Tube	1
4	70217	#8 Sheet Metal Screw	6
5	91957	Label, Disconnect Before Cleaning	1
6	70188	Thumb Screw #8-32 \times 1/2"	1
7	620911301	Installation Instruction	1
8	22127	Bracket, Mounting	1
9	620030601	Cover, RH Assembly	1

- 1. Set Ice maker lid on the top of the dispenser and position it flush with the back and sides of the dispenser.
- 2. Using the slotted holes in the lid as a template, drill four (4) .140" diameter holes at the bottom of the slots (see detail A). Use extreme care not to drill into the hopper. Fasten the lid to the dispenser with four (4) #8 sheet metal screws, two on each side.
- 3. Seal the ice maker to the top of the dispenser as follows: (Flush with rear and left side)
 - A. Apply beads of RTV around the opening in the lid and inside the perimeter of the ice maker outline so that the ice maker will set on the RTV.
 - B. Set the ice maker onto the lid and position it as required.
 - C. Wipe away any excess RTV.
- 4. Remove the left rear screw (only) installed in step 2. Use that screw to install the mounting bracket (item 2 and install Item 9 to rear of dispenser and ice maker. Drill 9/64" diameter holes into the ice maker cabinet using the bracket as a template. Use extreme caution not to drill into any ice maker components (condenser, tubing, etc.). Secure the brackets using the screws provided.
- 5. Follow the ice maker manufacturers instruction to complete the installation of the ice maker including the bin thermostat if so equipped or required.

6. Place the lid (item 4) in position over the stainless steel flange and install the thumb screw (item 7).

Note: The back of the ice maker must be flush with the back of the lid (item 1).

