



1, 1.5, & 2 GPR SAFETY-FRESH® SERVER


OPERATING INSTRUCTIONS

INTRODUCTION

This server allows portable dispensing of 1, 1½, or 2-gallons of hot beverage. Coffee can be brewed directly into the server without removing the cover when used with an appropriate Bunn® coffee brewer. Place the server on a warming stand to keep the beverage hot at remote locations. The spill-resistant design lessens the chance of hot beverage burns and splashes.

USER NOTICES

The notices on this server should be kept in good condition. Replace unreadable or damaged labels.



USING THE SERVER

1. Lock the cover in place on the server by turning it clockwise as far as it will go.
2. Locate the center of the server cover directly under the funnel dripout of a Bunn® coffee brewer when brewing directly into the server.
3. The hot beverage is available at the faucet. The sight gage displays the remaining beverage in the server.
4. As the server is emptied, more may be added.

NOTE – Be careful not to overfill the server.

BUNN-O-MATIC CORPORATION
POST OFFICE BOX 3227
SPRINGFIELD, ILLINOIS 62708-3227
TELEPHONE: (217) 529-6601 FAX: (217) 529-6644


CLEANING

1. Turn the cover (c) counterclockwise as far as it will go to remove it for daily dishwasher cleaning.


NOTE – Bunn-O-Matic recommends CASCADE® dishwashing detergent for thorough cleaning. **DO NOT** use bleach.

CASCADE® is a registered trademark of Procter & Gamble Co., Cincinnati, Ohio.

2. Completely disassemble the cover assembly by removing inlet retainer (a), ball (b) early models only, the coffee outlet retainer (g), ball (f), airvent ball retainer (e) and ball (d) early models only. The ball retainers are removed by unscrewing them in a counterclockwise direction.
3. After thoroughly cleaning all parts, reassemble the cover assembly.
4. Clean all other surfaces with a damp cloth rinsed in any mild, non-abrasive, liquid detergent.
5. Clean the sight gage with a brush.
6. Thoroughly rinse the entire server after cleaning.



Early Models



Late Models

WARRANTY

Bunn-O-Matic Corp. ("Bunn") warrants the equipment manufactured by it to be commercially free from defects in material and workmanship existing at the time of manufacture and appearing within one year from the date of installation. In addition:

- 1.) Bunn warrants electronic circuit and/or control boards to be commercially free from defects in material and workmanship for three years from the date of installation.
- 2.) Bunn warrants the compressor on refrigeration equipment to be commercially free from defects in material and workmanship for two years from the date of installation.
- 3.) Bunn warrants that the grinding burrs on coffee grinding equipment will grind coffee to meet original factory screen sieve analysis for three years from date of installation or for 30,000 pounds of coffee, whichever comes first.

This warranty does not apply to any equipment, component or part that was not manufactured by Bunn or that, in Bunn's judgement, has been affected by misuse, neglect, alteration, improper installation or operation, improper maintenance or repair, damage or casualty.

THE FOREGOING WARRANTY IS EXCLUSIVE AND IS IN LIEU OF ANY OTHER WARRANTY, WRITTEN OR ORAL, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF EITHER MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. The agents, dealers or employees of Bunn are not authorized to make modifications to this warranty or to make additional warranties that are binding on Bunn. Accordingly, statements by such individuals, whether oral or written, do not constitute warranties and should not be relied upon.

The Buyer shall give Bunn prompt notice of any claim to be made under this warranty by telephone at (217) 529-6601 or by writing to Post Office Box 3227, Springfield, Illinois, 62708-3227. If requested by Bunn, the Buyer shall ship the defective equipment prepaid to an authorized Bunn service location. If Bunn determines, in its sole discretion, that the equipment does not conform to the warranty, Bunn shall repair the equipment with no charge for parts during the warranty period and no charge for labor by a Bunn Authorized Service Representative during the warranty period. If Bunn determines that repair is not feasible, Bunn shall, at its sole option, replace the equipment or refund the purchase price for the equipment.

THE BUYER'S REMEDY AGAINST BUNN FOR THE BREACH OF ANY OBLIGATION ARISING OUT OF THE SALE OF THIS EQUIPMENT, WHETHER DERIVED FROM WARRANTY OR OTHERWISE, SHALL BE LIMITED, AS SPECIFIED HEREIN, TO REPAIR OR, AT BUNN'S SOLE OPTION, REPLACEMENT OR REFUND.

In no event shall Bunn be liable for any other damage or loss, including, but not limited to, lost profits, lost sales, loss of use of equipment, claims of Buyer's customers, cost of capital, cost of down time, cost of substitute equipment, facilities or services, or any other special, incidental or consequential damages.