

Falcon[®] 4400 Series with Windows Mobile®



52-Key model

Quick Reference Guide



PSC Inc 959 Terry Street Eugene, Oregon 97402 Telephone: (541) 683-5700 Fax: (541) 345-7140

An Unpublished Work - All rights reserved. No part of the contents of this documentation or the procedures described therein may be reproduced or transmitted in any form or by any means without prior written permission of PSC Inc. or its wholly owned subsidiaries ("PSC"). Owners of PSC products are hereby granted a non-exclusive, revocable license to reproduce and transmit this documentation for the purchaser's own internal business purposes. Purchaser shall not remove or alter any proprietary notices, including copyright notices, contained in this documentation and shall ensure that all notices appear on any reproductions of the documentation.

Should future revisions of this manual be published, you can acquire printed versions by contacting your PSC representative. Electronic versions may either be downloadable from the PSC website (**www.psc.com**) or provided on appropriate media. If you visit our website and would like to make comments or suggestions about this or other PSC publications, please let us know via the "Contact PSC" page.

Disclaimer

PSC has taken reasonable measures to provide information in this manual that is complete and accurate, however, PSC reserves the right to change any specification at any time without prior notice.

PSC is a registered trademark of PSC Inc. The PSC logo is a trademark of PSC. All other trademarks and trade names referred to herein are property of their respective owners.

Falcon[®] is a registered trademark of PSC Inc. and of its wholly owned subsidiaries.

 $\label{eq:main_state} \begin{array}{l} {\sf Microsoft\ Windows}^{\circledast}, {\sf Windows}^{\circledast}\ 2000, {\sf Windows}^{\circledast}{\sf CE}, {\sf Windows\ Mobile}^{\circledast}\ , {\sf Windows}^{\circledast}\ {\sf NT}, {\sf and\ Windows}^{\circledast}\ {\sf XP}\ {\sf are\ registered\ trademarks\ of\ Microsoft\ Corporation.} \end{array}$

Patents

This product may be covered by one or more of the following patents: 4603262 • 4639606 • 4652750 • 4672215 • 4699447 • 4709369 • 4749879 4786798 • 4792666 • 4794240 • 4798943 • 4799164 • 4820911 • 4845349 • 4861972 • 4861973 • 4866257 • 4868836 • 4879456 • 4939355 • 4939356 • 4943127 • 4963719 • 4971176 • 4971177 • 4991692 • 5001406 • 5015831 • 5019697 • 5019698 • 5086879 • 5115120 • 5144118 • 5146463 • 5179270 • 5198649 • 5200597 • 5202784 • 5208449 • 5210397 • 5212371 • 5212372 • 5214270 • 5229590 • 5231293 • 5232185 • 5233169 • 5235168 • 5237161 • 5237162 • 5239165 • 5247161 • 5256864 • 5258604 • 5258699 • 5260554 • 5274219 • 5296689 • 5298728 • 5311000 • 5327451 • 5329103 • 5330370 • 5347113 • 5347121 • 5371361 • 5382783 • 5386105 • 5389917 • 5410108 • 5420410 • 5422472 • 5426507 • 5438187 • 5440110 • 5440111 • 5446271 • 5446749 • 5448050 • 5463211 • 5475206 • 5475207 • 5479011 • 5481098 • 5491328 • 5493108 • 5504350 • 5508505 • 5512740 • 5541397 • 5552593 • 5557095 • 5563402 • 5565668 • 5576531 • 5581707 • 5594231 • 5594441 • 5598070 • 5602376 • 5608201 • 5608399 • 5612529 • 5629510 • 5635699 • 5641958 • 5646391 • 5661435 • 5664231 • 5666045 • 5671374 • 5675138 • 5682028 • 5686716 • 5696370 • 5703347 • 5705802 • 5714750 • 5717194 • 5723852 • 5750976 • 5767502 • 5770847 • 5786581 • 5786585 • 5787103 • 5789732 • 5796222 • 5804809 • 5814803 • 5814804 • 5821721 • 5822343 • 5825009 • 5834708 • 5834750 • 5837983 • 5837988 • 5852286 • 5864129 • 5869827 • 5874722 • 5883370 • 5905249 • 5907147 • 5923023 • 5925868 • 5929421 • 5945670 • 5959284 • 5962838 • 5979769 • 6000619 • 6006991 • 6012639 • 6016135 • 6024284 • 6041374 • 6042012 • 6045044 • 6047889 • 6047894 • 6056198 • 6065676 • 6069696 • 6073849 • 6073851 • 6094288 • 6112993 • 6129279 • 6129282 • 6134039 • 6142376 • 6152368 • 6152372 • 6155488 • 6166375 • 6169614 • 6173894 • 6176429 • 6188500 • 6189784 • 6213397 • 6223986 • 6230975 • 6230976 • 6237852 • 6244510 • 6259545 • 6260763 • 6266175 • 6273336 • 6276605 • 6279829 • 6290134 • 6290135 • 6293467 • 6303927 • 6311895 • 6318634 • 6328216 • 6332576 • 6332577 • 6343741 • 6454168 • 6478224 • 6568598 • 6578765 • 6705527 • 6974084 • 6991169 •7051940 • AU703547 • D312631 • D313590 • D320011 • D320012 • D323492 • D330707 • D330708 • D349109 • D350127 • D350735 • D351149 • D351150 • D352936 • D352937 • D352938 • D352939 • D358588 • D361565 • D372234 • D374630 • D374869 • D375493 • D376357 • D377345 • D377346 • D377347 • D377348 • D388075 • D446524 • EP0256296 • EP0260155 • EP0260155 • EP0295936 • EP0325469 • EP0349770 • EP0368254 • EP0442215 • EP0498366 • EP0531645 • EP0663643 • EP0698251 • GB2252333 • GB2284086 • GB2301691 • GB2304954 • GB2307093 • GB2308267 • GB2308678 • GB2319103 • GB2333163 • GB2343079 • GB2344486 • GB2345568 • GB2354340 • ISR107546 • ISR118507 • ISR118508 • JP1962823 • JP1971216 • JP2513442 • JP2732459 • JP2829331 • JP2953593 • JP2964278 • MEX185552 • MEX187245 • RE37166 • Other Patents Pending

Table of Contents

Falcon® 4400 Series with Windows Mobile®	
Overview	
Getting Started	
System Requirements	
Connecting to a PC	4
Features of the Falcon	
Powering the Falcon	
Battery Pack	
Installing the Battery Pack	
Checking Battery Power	
Battery Status Indicators	
Charging the Batteries	
Charging with the Dock	
Backup Battery	
Charging with a Battery Charger	
Battery Discharge Characteristics	
Setting Up the Mobile Computer	
Touchscreen Calibration	
Entering a Password	
Radio Card Setup	
Entering Data	
Using the Stylus	
Navigating the Display	
Keypads	
Scanning Bar Codes	
Laser Scanning	
Bar Code Scanning with 2D Imager	
OCR Scanning	
Image Capture	
Accessing Help	
Resetting the Falcon	

Warm Reset	. 38
Hard Reset	. 39
Clean Boot	
Troubleshooting	
RF Connectivity Troubleshooting	
Technical Support	
PSC Website Support	
PSC Website TekForum	
Reseller Technical Support	
Telephone Technical Support	.47
Appendix A. PSC Falcon® Windows Mobile End User License Agreement	49
Appendix B. Microsoft® Windows Mobile Addendum to EULA	52
Appendix C: PSC Falcon [®] Windows Mobile [®] Product Series Warranty	55
Appendix D: Safety Information	56
Laser Safety Label	
Advisory Statement	
Regulatory Statements	
Radio Frequency Interference	
Canadian Compliance Statement	. 56
Appendix E: Laser Safety	57
International Caution Statements for CLASS 1, 2, 3R, II, and IIA Laser Devices	
English	. 57
French	. 57
German	. 58
Italian	
Danish	
Dutch	
Swedish	
Finnish	
Norwegian	
Portuguese	
Spanish	
Chinese	
Japanese	. 62

Falcon® 4400 Series with Windows Mobile®

Overview

The Falcon[®] 4400 series combines the flexibility of Windows Mobile[®] with the power of the Intel XScale processor, WiFi wireless technology, a large color display, and laser and imaging (1D and 2D) scanning in an ergonomic PDT. The Falcon[®] 4400 series is designed for warehouses, distribution centers, retail in-store environments, and other inventory management applications requiring maximum performance and durability.

Overmolded models will handle 5' / 1.5M drops to concrete, and have an IP54 environmental rating; and an 86dBA (at 24") / 100dBA (at 10 cm) beeper. The Falcon[®] 4400 Series will handle demanding data collection tasks in industrial environments.

The Falcon Management Utility (FMU) and Falcon Desktop Utility (FDU) are included on the CD that comes with every unit, providing remote management and configurability.

This Quick Reference Guide contains the following sections:

- Getting Started on page 4 getting your Falcon up and running.
- Features of the Falcon on page 6 describes the functions and keys of the Falcon.
- Powering the Falcon on page 9 gives information about the batteries, shows how to install the battery pack, and provides options for charging.
- Setting Up the Mobile Computer on page 17 tells how to calibrate the Touchscreen and set up a Password.
- Entering Data on page 19 using the stylus, navigating the display, about keypads, and bar code scanning.
- Accessing Help on page 37 accessing Help from the Falcon.
- Resetting the Falcon on page 38 describes Warm Reset, Hard Reset and Clean Boot.
- Troubleshooting and Technical Support on page 47.

Getting Started

Before using the Falcon for the first time, you must install the battery pack into the Falcon, then charge both the battery pack and the backup battery. See Installing the Battery Pack on page 10 for instructions.



CAUTION

You must charge the battery pack and backup battery in a dock or with a power cable prior to your first use of the Falcon. The initial charge time is approximately 24 hours. See Charging the Batteries on page 13 for more information.

System Requirements

Minimum Desktop Computer Requirements

- Microsoft Windows XP, Windows 2000, or Server 2003 with the most current Service Pack installed.
- Microsoft Outlook 98 or later required for synchronization to the desktop or portable computer of e-mail, calendar, contacts, tasks, and notes. (Outlook 2003 is recommended).
- Microsoft Internet Explorer 4.01 SP1 or later.
- Hard disk drive with 12 to 65 MB of available hard disk space (actual requirements will vary based on selection of features and user's current system configuration).
- Available 9- or 25-pin communications port (adaptor required for 25-pin communications port), or USB port.
- VGA graphics card or compatible video graphics adapter at 256 color or better.
- Keyboard.
- Microsoft Mouse or compatible input device.


Connecting to a PC

Falcons communicate with the host PC using Microsoft ActiveSync protocol via either a USB port or a serial port. Connect the Falcon to your PC as shown:

1. Connect the appropriate interface cable to the Falcon Dock and the computer.

- 2. Plug the power adapter into a power source, then plug the Power Cord into the Dock.
- 3. Seat the Falcon securely into the Dock.

Figure 1. Connecting your Falcon to a PC



Installing ActiveSync

If you don't already have ActiveSync (v4.0 or above) on your computer, you can install it from the Getting Started CD included with your device, or download it from the Microsoft website (www.microsoft.com).



When the device is connected to the PC using Activesync, a Desktop Pass-Through (DTPT) connection is established, causing any WiFi connections to be disconnected. To continue to use a WiFi connection while the device is in a cradle that is connected to a PC, disable the "Synchronization" option in Activesync on the Falcon.

Features of the Falcon

Four perspectives of the Falcon[®] 4400 Series with Windows[®] Mobile are shown. Refer to Table 1 on page 8 for a list of the illustrated parts with references to more detailed information.



Figure 2. Falcon Keypad and Connector Views

For a complete description of each key on the Falcon, refer to page 26.



Figure 3. Falcon Scanner and Battery Door Views

For more information, please refer to the *Falcon*[®] 4400 Windows Mobile[®] *Product Reference Guide (PRG)*, located on the Falcon 4400 Product CD that came with your device.

Figure 4. Model comparison




Table 1. Features of the Falcon

Feature	Function/Description	More Information
Battery Door	Rotate the latches to unlock the battery door to remove the battery pack.	Figure 5,
Display/Touch Screen	The equivalent of a PC monitor for viewing and interacting with the current application. This display is touch-sensitive; use it like you would a mouse on a PC.	Figure 2, page 18, page 21
Handle	The Falcon 4420 comes with a handle that is ergonomically designed for ease of use with a scanner trigger.	Figure 2
Reset	Insert an object, such as a paper clip, into this hole as part of the procedure to perform a Hard Reset or Clean Boot of the unit. Do not use a sharp object, or you could disable the reset function, puncture the keypad's industrial seal, and void your warranty.	page 38
Keypad	Use the alpha-numeric, function, and navigation keys on the keypad t o enter numbers, letters, symbols and navigate with the keypad.	page <mark>26</mark>
Lanyard Port	Insert a lanyard to secure a Falcon to a person or work station.	page 7
Scanner Aperture	The laser or imaging scanning beam is emitted from this aperture.	page 33
LED	When scanning, a red LED indicates the laser is on and a green LED indicates a good read. When the Falcon is charging in the dock, a red LED on the Falcon indicates charging and a green LED on the Falcon indicates fully charged.	Figure 2
POWER	Press POWER to turn the Falcon on and off, or to toggle the device between suspend (sleep) mode and resume (on).	Figure 2, page 26
Speaker	The speaker plays * . WAV and other media files, and emits beeps or tones to indicate errors or good reads when scanning bar codes or entering data using the keypad or stylus.	Figure 3
Strap Studs	The Falcon 4410 comes with a handstrap that connects to the strap studs.	Figure 3

Feature	Function/Description	More Information
	Use the stylus for navigation and to select items on the touch screen, and to select characters on the on-screen keyboard. Place the stylus in the holder after use so you don't lose or misplace it. An optional Stylus Tether is available for both models.	Figure 14, page 21

Powering the Falcon

Battery Pack

The battery pack in the Falcon is a 3.7 V, Lithium Ion battery pack. You will be alerted with a message dialog box when the battery pack reaches a low state.



After charging the first time, a complete charge takes about four (4) hours depending on the battery pack's state and the recharging method. A sample battery pack label is shown at the right.

CAUTION: Battery can explode, leak or catch fire if exposed to high temperature, water or fire. Do not short circuit, open or disassemble battery. Recycle or dispose of properly.



CAUTION

You must charge the battery pack and backup battery in a dock or with a power cable prior to your first use of the Falcon. The initial charge time is approximately 24 hours.

If you remove the battery pack or it fails, there is a 30 minute window in which to insert a charged battery pack before the backup battery fails. If your backup battery fails, the contents of the RAM memory will be lost. If your backup battery is less than fully charged, there is a proportionally smaller window of time available to replace the main battery. Usage time will also be reduced.

Always charge the battery pack within the temperature range of 32°–113°F (0°– 45°C).

Use only the authorized power supplies, battery packs, chargers, and docks supplied by your PSC reseller. The use of any other power supplies can damage the Falcon and void your warranty. Refer to the *PRG* for the correct power supplies and Accessories.

WARNING

Lithium-ion battery packs may get hot, explode, ignite, or/and cause serious injury if exposed to abusive conditions.

- Do not place the battery in or near fire, direct sunlight, or other high temperature locations, or heat the battery.
- Do not connect the positive terminal and negative terminal of the battery to each other with any metal object (such as wire or coin).
- Do not expose the battery to liquids, or allow the battery to get wet.
- Do not disassemble, modify, or pierce the battery. The battery contains safety and protection devices, which, if damaged, may cause the battery to generate heat, explode or ignite.

In the event the battery leaks and the fluid gets into your eye, do not rub the eye. Rinse well with water and immediately seek medical care. If left untreated, the battery fluid could cause damage to the eye.



PSC recommends annual replacement of rechargeable battery packs to ensure maximum performance.


Installing the Battery Pack

When you first remove the Falcon from the box, you must charge both the battery pack and the backup battery for a minimum of 24 hours.

Complete the following instructions to install the battery pack:

1. On a 441X, detach the elastic handstrap by releasing its hook from the strap studs at the base of the unit (refer to the PRG).





- 2. Turn the battery door latches to unlock the battery door. Remove the door.
- 3. Insert the battery pack with the pull tab on the outside and the battery contacts aligned with the matching contacts inside the battery compartment. The battery pack has a keying feature on one side to prevent incorrect installation (refer to Figure 5).
- 4. Replace the battery door by inserting the bottom tab into the slot. If the battery pack is installed incorrectly, the door will not seat properly.
- 5. Rotate the battery door latches on the battery door towards the base of the unit.
- 6. On the 441X, replace the handstrap hook on the strap stud at the base of the unit.



If you remove the battery pack or the battery fails, you have about 30 minutes to swap in a new battery pack or charge the battery pack before the backup battery fails (if the backup battery has been fully charged).

Checking Battery Power

Battery Status Indicators

Tap the Battery icon at the top of the screen to view the Battery status.

Figure 6. Battery level




Table 2. Battery Status Indicators

		Battery Status Icons
Battery Status	lcon	Description
Battery Full		This icon indicates that the battery is fully charged.
Battery Charging	θ	This icon indicates that the battery pack is in the process of recharging.
Battery Low	Ø	This icon indicates that the battery pack is low.
Discharged Battery Condition	no icon	When the battery is totally discharged, the battery sensor initiates a shutdown of all applications, and closes the RF Network connection. If the battery pack has completely discharged, when the battery pack is charged or replaced, the unit will resume as before.

Additionally, the **Power** control applet displays a battery power gauge. You can check the status of both the Main Battery and the Backup battery. Tap **Settings > System > Power**. See the *Falcon 4400 with Windows Mobile*[®] *Product Reference Guide (PRG)* for more information on configuration items.

f Settings	# # € 11:20 ol	k
Power		
Main battery: Recharging state:	LiIon Charging 100	
Backup battery	100	
Battery Advanced		

Figure 7. Battery Power Gauge

Charging the Batteries

There are several methods for charging the battery pack and backup battery. LEDs on the Falcon, the Single-Slot Dock, Four-Slot Dock, and Four-Slot Battery charger give visual indication of the charge state.



The initial charge for a Falcon should be done in a Dock in order to charge the Backup Battery.

Table 3 on page 14 gives an overview of all the LEDs and what they indicate.

Table 3. Battery Charging Methods and Indications

Charging Location:	PDT Charge LED	PDT Charge LEI	Spare Battery Charge LED	Charge Indicator LEDs
	Falcon seated in a Dock (Single or Four- Slot)	Falcon connected to an external power supply	Charging slot of Dock (Single or Four-Slot)	Four-Slot Battery Charger
Charging Duration	4-6 hours	4-6 hours	3-5 hours	> 3 hours
Battery Pack Charge Indication	Charging: RED Fully Charged:	Charging: RED Fully Charged:	N/A	N/A
Falcon Charge LED	GREEN	GREEN		
Dock or Charger Battery Charge LED(s)	No effect	No effect	Charging: Solid RED Fully charged: GREEN *Fault: Flashing RED	Charging: Charging LEDs are AMBER Fully charged: Ready LEDs are GREEN
Simultaneously Charges Backup Battery?	YES	YES	NO	NO
* Refer to page 45 for m	ore information.			

Charging with the Dock

There are two models of docks for the Falcon: a Single-Slot dock and a Four-Slot dock. On both models, an external power supply (AC adaptor) provides power to the dock.

There are two methods for charging a battery pack using a Single-Slot dock. Refer to Table 3 on page 14 to view methods of battery pack charging using the dock, charge duration, dock status indicators and their purpose. For more information on the dock, refer to the dock Operating Instructions that come with each dock.



Use only the correct battery chargers and docks with this color Falcon. This technology used for these models is incompatible with other PSC Falcon chargers and docks, including the Falcon 4410/4420 monochrome models.



Figure 8. Charging the Battery Pack in a Single-Slot Dock

Refer to Table 3 on page 14 for a list of LED indicators and their purpose. Refer to the *PRG* for more information on storage and disposal of batteries.

Backup Battery

The 3V Lithium Backup Battery receives its charge from the Battery Pack. To retain date, time, data, and other settings for the Falcon, maintain at least a minimal charge on the Battery Pack.

To view the status of the Backup battery, tap *Power*, then tap the **Battery** tab to view. See the *Falcon 4400 with Windows Mobile Product Reference Guide (PRG)* for more information on configuration items.

🏄 Settings	# # € 11:20 ok
Power	
Main battery: Recharging state:	
0	100
Backup battery	
0	100
Battery Advanced	

Figure 9. Battery Status Display

Charging with a Battery Charger

A Four-Slot Battery Charger is available to charge batteries independently from the Falcon. To use, insert the batteries into the slots in the charger, aligning the battery contacts with those in the Charger.



Figure 10. Four-Slot Battery Charger


Battery Discharge Characteristics

Battery discharge characteristics vary from eight to nine and a half (8-9.5) hours, depending upon device usage, number of scans per minute, backlight usage, and other factors that draw upon battery power.

Setting Up the Mobile Computer

At first use or a Clean Boot, the unit will go through a series of initial bootup sequences. See Touchscreen Calibration on page 18, Entering a Password on page 18, and Radio Card Setup on page 19.

Touchscreen Calibration



Follow the on-screen directions to calibrate the touchscreen.

For more information on touchscreen calibration, refer to the *PRG* and the Microsoft help on your device.

Entering a Password

The first time you use the Falcon you will be prompted to enter a password. Tap **Next** to continue, or **Skip** if you do not want the device to be passwordprotected.

Figure 12. Password setup

	Real Property
🏄 Settings 🛛 🖁 🗮 🕂 1:35	ok
Password	
Prompt if device unused 0 Minutes	Ŧ
Password type: Simple PIN	٣
Password:	
Confirm:	٦
Password Hint	

Follow the onscreen instructions to enter your password. Reference the Microsoft help system on your device for more information. You can return to the Password screen anytime by tapping *P* > Settings > Personal > Lock.

Radio Card Setup

Windows Zero Config should be used to administer the radio setup. For assistance in configuring the radio card, reference the online help on your Falcon. Go to \cancel{P} > Help for further information.

Entering Data

To open an application, tap a link on the **Today** page, or tap $A^{\text{reg}} > \text{Programs}$ to display a list of available programs. Tap a program icon to open it.

There are several ways to enter data with the Falcon:

- Use the keypad. Refer to Keypads starting on page 26.
- Use the stylus on the touchscreen display. Refer to Using the Stylus on page 20 for more information on using the stylus.
- Use the on-screen keyboard by typing with the stylus. Refer to On-Screen Keyboard on page 24.
- Select text. Use the stylus to highlight the desired text by dragging the stylus across the desired text, double-tapping to select one word, and triple-tapping to select an entire paragraph.
- Use the bar code scanner or imager to enter data. Press the trigger or scan button (26 or 52-key only) to initiate a scan. The scanned data will be entered into the current application's open file. Refer to Scanning Bar Codes starting on page 33 for more information on using the scanner.
- If your Falcon has the 2D Imaging module installed, you can read and decode traditional linear bar codes (1D), 2D and composite symbols, and some OCR fonts. You can also capture images such as signatures, labels, and other items. See Bar Code Scanning with 2D Imager starting on page 35 for further information.

Using the Stylus



Never use a pen, pencil, or other sharp object on the Falcon's touchscreen display. Use only the supplied stylus or plastic-tipped pens intended for use with a touch-sensitive display. Contact your reseller to replace a missing stylus; refer to the PSC price book at www.psc.com.

The stylus is located next to the scanning pod as illustrated in Figure 13. The stylus on the Falcon is the equivalent of the mouse on a PC. Use the stylus to:

- Navigate the touchscreen display.
- Select characters in the on-screen keyboard.
- Start programs.
- Select tabs, fields and text within applications and dialog boxes.

Figure 13. Back View of a Falcon 4420 with a Stylus



It is good practice to replace the stylus in the holder after each use so you don't misplace it. An optional Tethered Stylus is also available, preventing accidental loss of the stylus.

Figure 14. Tethered Stylus

Navigating the Display


There are several navigation areas on your display, including the title bar and the soft key bar. Each of these navigation areas have sub-areas of navigation as well. Take the time to familiarize yourself with these features to save yourself valuable time.

The Today Screen

After initial startup, the first screen you will see will be the **Today** screen (unless your device has been customized differently). You can also access the Today Screen anytime by tapping **P** > **Today**.

The **Title bar** at the top of the screen shows Connection status, a link to Volume control, and Time/Date settings.

Figure 15. The Today Screen



The Start Menu

The **Title bar** at the top of the screen contains the **Start** icon, program name, and notification icons. Tap *Programs* (Start) to open the **Start** menu. The **Start** menu includes access to **Programs**, **Settings**, **Help** and shortcuts to programs and functions.

The soft key bar at the bottom of the screen provides context-sensitive menus for tasks in programs, such as opening a file, saving a file, or editing a file.



Figure 16. Start Menu

On-Screen Keyboard

In applications that accept keyed input, the on-screen keyboard can be used to enter data using the stylus. The on-screen keyboard is a digital, QWERTY-style keyboard. Tap the **Keyboard** icon to open or close the on-screen keyboard.





Figure 17. On-Screen Keyboard

Use the stylus to select letters, numbers, or symbols from the on-screen keyboard for the current application. Tap the key to change the keypad to show international letters.

You can also set up the Falcon to use Block Recognizer, Letter Recognizer, or Transcriber to enter data. Reference the help system on the Falcon for more information on these features.

Settings

The Settings screen has three tabs: **Personal**, **System** and **Connections**. Each provides access to various options. Tap 2^{+} > **Settings** to open the **Settings** screen, then tap the tab you want to access.



Programs

Tap *Programs* to open the Programs screen to view and open the available Programs on your Falcon. Tap a program to open it.

Figure 19. Programs screen



Keypads

Overview

Refer to the *Falcon 4400 PRG* for more information on configuring the keypads.

The Falcon is available with several different keypad models:

- 26-Key Keypad on page 29
- 48-Key Keypad on page 30
- 52-Key Keypad on page 31
- 5250 Keypad on page 32

Keypad Attributes

There are a number of keys that are common to the different keypad models. Table 4 lists special function keys that are found on several keypads, as well as those which are unique to specific keypads.

Table 4. Keypad Overview - Special Keys

Key Name	Keypad Model(s)	Function/Description
<alpha></alpha>	26-key	Press < Alpha> to access lower case alpha characters and symbols on the 26- key keypad.
Alpha- Numeric Keys	All	In Normal mode, use the alpha-numeric keys to enter numbers and letters. In Shift and CAPS modes, the alpha-numeric keys enter upper case letters.
Backlight/ Brightness	26-key 48-key	<backlight> toggles the Backlight on or off when you press it.</backlight>
<fn></fn>	All	Press < Fn > to enter the FN input state. Use FN mode to access additional fea- tures and operations.
<power></power>	All	Press < POWER > to go into sleep (suspend) mode, and wake up (resume) if the Falcon was in sleep mode. Press and hold briefly to turn off.
<scan></scan>	26-key 52-key	Press < Scan > to activate the laser scanner.
Navigation Keys	26-key 52-key	 Press the NAVIGATION keys to move the cursor or highlighted text entry during a menu/list selection. In a text window: The <Up> arrow moves the cursor up one line. The <Right> arrow moves the cursor to the right one character. The <Down> arrow moves the cursor down one line. The <Left> arrow moves the cursor to the left one character.

Key Name	Keypad Model(s)	Function/Description
<ctrl></ctrl>		Set keyboard shortcuts like a PC with < Ctrl > You can perform functions such as Save (Ctrl-s) and Find (Ctrl-f). Toggle on and off for text formatting (for example, Ctrl-b for bold, Ctrl-i for italics, Ctrl-u for underline).
<alt></alt>	48-key 52-key	Press <alt> to enter the Alt input state. Use Alt mode to access application menus.</alt>
<shift></shift>	48-key 52-key	Press the <shift></shift> key to enter Shift input states. Use Shift mode to output upper-case characters and punctuation (identified over number keys).

Keyboard Indicators

The Keyboard Indicators are visible in the Title Bar at the top of the screen. The most recently activated state is on the left if more than one state is active.

Figure 20. Keyboard Indicators



- The 1 icon is displayed if either Shift or CAPS mode is active.
- If more than two states are active at the same time, only the last two states are displayed.

Scroll between icons to view the active modes.

Table 5. Input States and their Indicators
--

lcon	State	Keypad Model(s)	Function			
#	Normal (Numeric) Mode	26-key	Present only on keypads with an <alpha></alpha> key. It appears when Alpha or CAPS modes are not on.			
Q	Alpha Mode	26-key	Press <alpha></alpha> to enter lower case alpha characters and symbols. When in Alpha mode, the current alpha character is displayed by a keyboard indicator. Alpha mode is persistent, which means that the system stays in Alpha mode until you press <alpha></alpha> again.			
Ô	CAPS Mode	26-key	Press < Fn> + <alpha></alpha> to activate CAPS mode. CAPS mode generates upper case alpha characters A-Z . CAPS mode is persistent; press the < Fn> + <alpha></alpha> keys again to generate lower case characters. Punctuation keys are not affected.			
		48-key 52-key	Press < Fn> + < Shift> to activate Caps mode. Caps mode generates upper case alpha characters A-Z . CAPS mode is normally persistent; you must press < Fn> + < Shift> again to gen- erate lower case characters. Punctuation keys are not affected. If CAPS is active, and SHIFT is active, no icon is displayed.			
ß	Fn Mode	26-key	Press <fn> to enter FN mode. <fn> is independent of <alpha>. Use FN mode to access the features and oper- ations on the keypad.</alpha></fn></fn>			
		48-key 52-key	Fn mode converts alpha keys to punctuation and function keys. Fn mode is activated by pressing < Fn >.			
ſ	Shift Mode	48-key 52-key	Shift mode converts characters to upper-case letters or punctuation. Activated by pressing <shift></shift> . This state expires after a normal key is pressed unless <shift></shift> is held down.			
			Toggles to make the next alpha character capitalized. If Shift state is active when the Caps State is active, no icon is displayed.			
0	Alt Mode	48-key 52-key	On the 48-key keypad, converts keys to system keys that allow users to access the menu. Activated by pressing <alt></alt> . This state expires after a normal key is pressed unless <alt></alt> is held down.			
Θ	Ctrl Mode	48-key	Set keyboard shortcuts with <ctrl></ctrl> . You can perform functions such as Save (Ctrl-s) and Find (Ctrl-f). Toggle on and off for text formatting (for example, Ctrl-b for bold, Ctrl-i for italics, Ctrl-u for underline).			

26-Key Keypad

The 26-key keypad is organized like a cell phone, with multi-tap access to alpha characters on numeric keys (see Figure 21). Use the ten (10) alpha-numeric keys and **<Esc>** to type letters, numbers, and symbols listed in Table 6 on page 30.

Figure 21. 26-Key Keypad



26-Key Functions. Most of the keys on the keypad of the Falcon have more than one function. To access the secondary features and functions, you must first press another key to access the desired input state.

Alpha-Numeric Keys. Press the keys in Table 6 once, twice, or more times to cycle through the alpha letters and symbols until the desired character appears in the Title bar. After the last letter or symbol in the sequence for that key, the next keypress will generate the first letter or symbol in the sequence.

Normal Mode	Alpha Mode					
Key	First Keypress	Second Keypress	Third Keypress	Fourth Keypress	Fifth Keypress	
<esc></esc>	:	/	@	:	/	
<1>	3	/	*	,	١	
<2>	A	В	С	A	В	
<3>	D	E	F	D	E	
<4>	G	Н	I	G	Н	
<5>	J	K	L	J	К	
<6>	М	N	0	М	N	
<7>	Р	Q	R	S	Р	
<8>	Т	U	V	Т	U	
<9>	W	Х	Y	Z	W	

Table 6. 26-Key Keypad Alpha Characters and Symbols

48-Key Keypad

The 48-key keypad is designed so you can type all letters and numbers without requiring multiple key presses.

Figure 22. 48-Key Keypad



Some of the keys on the 48-key keypad of the Falcon have more than one function. To access the secondary features and functions, you must first press

another key to access the desired input state. See Table 4 on page 26 for further information.

48-Key Functions

Press **<Backlight>** to toggle the backlight on or off. Press **<Fn>+<Backlight>** to adjust the brightness. Press **<ENTER>** to accept the changes.

48-Key Input States

The input states for the 48-key keypad are **<Shift>**, **<Ctrl>**, **<Alt>**, and **<Fn>**. Each state is described in Table 5 on page 28.

52-Key Keypad

The standard 52-key keypad is designed to allow you to type all letters and numbers without requiring multiple key presses.

Figure 23. 52-Key Keypad



Some of the keys on the keypad of the Falcon have more than one function. To access the secondary features and functions, you must first press another key to access the desired input state. See Table 4 on page 26 for more information.

52-Key Functions

Press **<Fn>+<**. > (period/decimal) to toggle the backlight on or off. To adjust the brightness, press **<Fn>+<Alt>** or tap **// > Settings > System > Backlight**. Press **<ENTER>** to accept the changes.

52-Key Input States

The input states for the 52-key keypad are **<Shift>**, **<Alt>**, and **<Fn>**. Each is described in Table 5 on page 28.

The control panel for the 52-key keypad has some additional options and an additional tab for key mapping.

- Tap *P* > Settings > System > Keyboard to open the Keyboard control panel.
- 2. On the **Options** tab, adjust the slider for **Initial Delay**. This configures the time to hold down a key before it repeats.

5250 Keypad

The 5250 52-key keypad is designed to provide the keyboard functions needed to run 5250 terminal emulation software.

The 5250 keypad is a remapped version of the 52-key model.

Figure 24. 5250 Keypad



Scanning Bar Codes

Laser Scanning

To use the scanning function on units containing a laser scanning module, complete the following steps:


1. Select and open a bar code application, such as Microsoft[®] Word Mobile.



Figure 25. Scanning a bar code

- 2. Aim the scan window at the bar code following the guidelines outlined in Figure 26.
- 3. Press and hold the **<Scan>** button (26 or 52-key only) or the trigger. The laser scans as long as you hold the button or trigger until a good scan is obtained. There is a 10-second timeout for attempting to scan.
- 4. Aim the laser beam at the center of the bar code.
 - Position the unit close to the bar code when scanning small bar codes.
 - Position it at a distance when scanning larger bar codes.
 - The laser is disabled after you release the key or after 10 seconds, or once a good scan is obtained.

Figure 26. Laser Beam Positions



5. The device beeps and the green LED indicator comes on until the trigger is released. The green LED and the beep tone indicate a good read.



If the bar code scan failed, adjust the reading angle or distance. Make sure that the laser beam scans across all bars of the bar code. Refer to Figure 26.

- 6. The bar code data is entered in the current application.
- 7. Once a bar code is read successfully, the scanner turns off automatically.

Refer to the section on Scanner Configuration in the *PRG* to modify the default settings.

Bar Code Scanning with 2D Imager


Scanning bar codes with the 2D imaging device is similar to scanning with a laser scanner. The operation and configuration of the scanner is performed in the same way as laser scanning devices. Trigger behavior and scanning time-outs are the same as laser scanning devices.

Scanning Differences

Scanning Aimer

The imager contains an aiming beam rather than a red laser. The aiming beam mimics a laser line for purposes of orienting the imager to a bar code. Figure 27 shows how the aiming beam visually differs from the laser beam in laser scanning devices.

Figure 27. Laser vs. Imaging beam



Note that the aiming beam for the imager is green, rather than red.

Orientation

Rotational orientation does not affect the imager module's ability to read bar codes. For example, the imager can read a bar code when the aimer beam is parallel to the lines of the bar code. What is important is the location of the aimer in relation to the center of the bar code. The aiming beam should be centered over the bar code, but it can be positioned in any direction for a good read.



Figure 28. Aiming Beam Positioning

The aiming beam is smaller when the imager is closer to the code and larger when it is farther away. Symbologies with smaller bars or elements (mil size) should be read closer to the unit. Symbologies with larger bars or elements (mil size) should be read farther from the unit. To scan a label, hold the imager at an appropriate distance from the target, pull the trigger, and center the aiming beam on the symbol.

Scanning Illumination

Another feature that can be enabled for 2D scanning is an array of illumination LEDs. These LEDs provide illumination in dark environments and can improve scanning performance under certain lighting conditions. By default, the illumination LEDs are turned on. Illumination LEDs can be disabled using the PDT parameters. See the *PRG* for complete information on programming the LEDs.

OCR Scanning

Optical character recognition (OCR) decodes certain fonts and outputs the data as a string, in a similar fashion to bar code labels. The Falcon 2D Imager supports limited decoding of some OCR fonts. See the *PRG* for information on setup and programming for OCR fonts.

Image Capture

The 2D Imager can be used for capturing, manipulating, and transferring images.

You can set options for image capture in the Imaging Control Panel. Various image formats can be selected, including TIFF, JPEG and BMP. You can also scale, rotate, and modify image quality settings. See the *PRG* for detailed information on using the Falcon 2D for image capture.

Accessing Help

Access Microsoft Windows Mobile help by tapping 🎥 > Help from any screen.

Help Help ₩ 4:40 How do I enter information on Table of Contents my device? Learning the Basics You can enter information in several Security Tips Entering Text ways, depending on the type of Synchronizing Your Information device you have and the program Setting Up Connections you are using. Exchanging Messages Synchronizing Use ActiveSync to Personalizing Your Device Using Windows Media Player exchange information Device Performance and between your PC Maintenance and device. Setting Date, Time, Language, and Typing Use Input Panel to **Regional Options** enter typed text by Keeping Track of People tapping keys on the Managing Your Calendar on-screen keyboard Browsing the Web or by using Working with Pictures & Videos handwriting **Playing Games** recognition so

Figure 29. Using Windows Mobile Context Sensitive Help

Additionally, you can tap the 👩 in the upper right corner of some screens to access context sensitive help for that screen.

Resetting the Falcon

There are several reset methods for the Falcon.

- To simply reset a "hung" application, tap *Postimultary* > Settings > System > Memory > Running Programs. Select the problematic program(s) and tap Stop, or Stop All to stop all running applications.
- A Warm Reset forces all applications to close and clears working RAM and files.
- A Hard Reset forces all applications to close, clears working RAM and files, and resets the system time and date.
- A Clean Boot forces all applications to close and restores the Falcon to factory defaults. ALL USER-INSTALLED PROGRAMS, DATA AND REGISTRY SETTINGS ON THE DISK WILL BE ERASED.

Once you initiate a Clean Boot, all applications are forcibly closed and installed applications and data are deleted. PSC recommends that you first attempt a Warm Reset, then a Hard Reset, before initiating a Clean Boot.

DO NOT use a sharp object to reset. Sharp objects can puncture the keypad, disabling the reset function, rupturing the Falcon's industrial seal, and voiding your warranty. PSC recommends using a straightened paper clip

Warm Reset

A Warm Reset is a complete reset of the Falcon in which all applications are forcibly closed and working RAM is cleared.

Reason to Warm Reset. Perform a Warm Reset when the Windows Mobile operating system locks up and you cannot reset a "hung" application using the **Settings**, as described above.

Procedure to Warm Reset


The reset procedure varies, depending upon the keypad on your Falcon. The first two keys of the sequence can be pressed in any order, but the unit will not reset until they both are held down and then the third key (**Bksp**> or **<F1**>) is pressed. All three keys must be held down for the unit to reset. Refer to Figure 30 for the location of the reset keys.

26-Key Falcon. Press and hold: **<FN>+<Alpha>+<Bksp>**.

48-Key Falcon. Press and hold: <Ctrl>+<Alt>+<Bksp>.



Figure 30. Warm Reset Key Sequence



After Warm Reset

When a Falcon goes through the Warm Reset sequence, it clears the working RAM and initializes the file system.

The splash screen will appear after a short period.

- The Today screen appears.
- The custom settings in the registry are persistent.
- The RF Network PC Card (if present) connects to the network system.

Hard Reset

A Hard Reset is a complete reset of the Falcon in which all applications are forcibly closed, working RAM is cleared, and the system time and date are reset.

Reason to Hard Reset. Perform a Hard Reset when the Windows Mobile operating system locks up and you cannot reset a "hung" application using the **Settings** or **Warm Reset**, as described above.



Once you initiate a Hard Reset, all applications are forcibly closed, working RAM and files are cleared, and the Real Time clock is reset.

Any files or data in RAM will be lost if you Hard Reset.

Do not use a sharp object to perform a Hard Reset, as this can puncture the keypad, disabling the reset function, rupturing the Falcon industrial seal, and voiding your warranty. PSC recommends using a straightened paper clip.

Procedure to Hard Reset. To perform a Hard Reset, insert a paper clip into the **<Reset>** aperture while pressing the **<POWER>** button (refer to Figure 31).




Figure 31. Hard Reset Key Sequence

After Hard Reset

When a Falcon goes through the Hard Reset sequence, it clears the working RAM, initializes the file system and resets the system time and date.

The splash screen will appear after a short period.

- The Today screen appears.
- The custom settings in the registry are persistent.
- The RF Network PC Card (if present) connects to the network system.
- The system time and date are reset.

Clean Boot

A Clean Boot is a complete reset of the Falcon in which all applications are forcibly closed and the Falcon is restored to factory defaults. ALL USER-INSTALLED PROGRAMS, DATA AND REGISTRY SETTINGS ON THE DISK WILL BE ERASED.

Reason to perform a Clean Boot. Use Clean Boot if the Windows Mobile operating system locks up and the Hard Reset command does not work.



Once you initiate a Clean Boot, all applications are forcibly closed and installed applications and data are deleted. PSC recommends that you first attempt a Warm Reset, then a Hard Reset, before initiating a Clean Boot.


DO NOT use a sharp object to reset. Sharp objects can puncture the keypad, disabling the reset function, rupturing the Falcon's industrial seal, and voiding your warranty.

Procedure to perform a Clean Boot. The procedure is the same for all keyboards. To perform a Clean Boot:

 Insert a paper clip into the <Reset> aperture while pressing <POWER> (refer to Figure 32).

The Splash screen will appear after you remove the reset pin from the hole.

2. Press and hold **<Esc>** and **0** (zero) on the Falcon keypad until the unit beeps.



26-Key Model

48-Key Model

52-Key Model

After Clean Boot

When a Falcon goes through the Clean Boot sequence, it clears the working memory and initializes the file system. You will lose all user-installed applications, custom registry settings and data.

- Recalibrate the touch screen.
- Reset Password if desired.
- The Today screen appears.
- The RF Network PC Card (if present) will require reconfiguration to connect to the network system.

Troubleshooting

Refer to the Falcon 4400 with Windows Mobile® PRG for more information.

Table 7. Troubleshooting Problems, Causes, and Solutions

Problem	Possible Cause	Solution
The Falcon does not turn on.	The battery pack is not installed properly.	Ensure the battery is installed properly.
	The battery is not fully charged.	Insert the Falcon in dock and begin charging. The bat- tery pack backup battery and require 24 hours to fully charge at first use, and 4 hours thereafter.
	System failure.	Perform a Hard Reset or a Clean Boot. Refer to Reset- ting the Falcon starting on page 38.
Rechargeable battery pack did not charge.	Battery failure.	Replace the battery. If the Falcon terminal still does not operate, try a Hard Reset then a Clean Boot; refer to Resetting the Falcon starting on page 38.
	The Falcon was removed from the dock while battery was charging.	Insert the Falcon in dock and begin charging. The bat- tery pack and backup battery require 4 hours to fully charge.
Characters are not visible	The Falcon is not powered on.	Press <power>.</power>
on the display.	The ambient room light is too dark or low.	Turn on the backlight. Refer to the PRG.
No sound is audible.	Volume setting is low or turned off.	Adjust the sound volume by going to the Volume icon on the Task bar at the top of the screen.
	The expected sound is not con- figured in the software.	Ensure that sounds are enabled by tapping <i>P</i> > Settings > Personal > Sounds & Notifications, or
		> Settings > System > Decoding for sounds related to bar code scanning. OR
		Scan the appropriate bar code from the PRG.
The Falcon turns itself off.	The Falcon is inactive.	The Falcon turns off after a period of inactivity. You can set duration from one to 30 minutes. Refer to the <i>PRG</i> to modify the default settings.
The Falcon will not accept	A software application is "hung."	Tap 🞥 > Settings > System > Memory >
input from the stylus or the keypad.		Running Programs. Select the problematic pro- gram(s) and tap Stop, or Stop All to stop all running programs.
	System failure.	Perform a Hard Reset or a Clean Boot. Refer to Reset- ting the Falcon starting on page 38.


Troubleshooting

Problem	Possible Cause	Solution
During data communication, no data was transmitted, or transmitted data was incomplete.	The Falcon was removed from the dock or unplugged from host PC during communications.	Replace the terminal in the dock, or replace the serial cable, and retransmit.
	Incorrect cable configuration.	See your System Administrator.
	Communication software was incorrectly installed or config- ured.	Perform setup as described in the <i>PRG</i> .
The Falcon does not accept scan input.	The scanning window is dirty.	Carefully wipe the scanning window with a soft, clean cloth. Do not use abrasive cleaners.
	The scanning application is not loaded.	Verify that the unit is loaded with a scanning applica- tion. See your System Administrator.
	Unreadable bar code.	Be sure the symbol is not defaced.
	Distance between exit window and bar code is incorrect.	Be sure you are within proper scanning range.
	The Falcon is not programmed for that symbology.	Be sure the terminal is programmed to accept the type of bar code you are scanning. Try using FF3A to turn on maximum defaults, as described in "Programming Parameters" in the <i>Falcon 4400 PRG</i> .
	The Falcon is not programmed to generate a beep.	If you are expecting a beep on a good decode and don't hear one, check that the application is set to gen- erate a beep on good decode.
		Tap <i>Provide Settings > System > Decoding > Gen-</i> eral > Audio OR
		Scan the appropriate bar code from the PRG.
	Battery is low.	If the scanner stops emitting a laser beam when you press the trigger, check your battery level. Refer to the <i>PRG</i> .
		Note: If the scanner is still not reading sym- bols, contact your distributor or PSC Inc.
The UPC/EAN extension (supplemental label) is not always scanned.	Laser beam only crosses over base of UPC/EAN label.	Set the Read Verification for extensions (parameter 0528) to a value lower than the Read Verification for the base label. See the <i>PRG</i> .

Troubleshooting

Problem	Possible Cause	Solution
The Spare Battery LED on the dock is flashing RED.	Time-out fault: the spare bat- tery pack charging has exceeded the maximum time- out period. Over-voltage fault: the spare battery pack charging has exceeded the maximum charge voltage of the battery.	 In either case, if the Spare Battery LED is flashing red, do the following: Disconnect the AC adapter from the dock. Remove the spare battery pack and the Falcon from the dock. Connect the AC adapter to the dock. If the Spare Battery LED is flashing red, there is a problem with the dock. Disconnect the AC adapter from the dock and contact a service technician. If the Spare Battery LED is off, insert a different spare battery pack in the dock. If, in the course of charging the spare battery, the Spare Battery LED is flashing red, there is a problem with the dock. Disconnect the AC adapter from the dock and contact a service technician. Otherwise, there is a problem with the first spare battery pack. Discontinue use of the first spare bat- tery pack. Refer to the <i>PRG</i> for instructions on bat- tery disposal.

RF Connectivity Troubleshooting



(For more information on the Ping command, go to the command prompt on the PC and type PING. For more information on the trace route command, go to the command prompt on the PC and type tracert.)

Technical Support

PSC Website Support

The PSC website (www.psc.com) is the complete source for technical support and information for PSC products. The site offers the PSC TekForum, product support, product registration, warranty information, product manuals, product tech notes, software updates, demos, and instructions for returning products for repair.

PSC Website TekForum

Search for information on the TekForum by clicking on the Support link on the PSC home page. Browse the TekForum to find answers to your questions about common technical issues.

Reseller Technical Support

An excellent source for technical assistance and information is an authorized PSC reseller. A reseller is acquainted with specific types of businesses, application software, and computer systems and can provide individualized assistance.

Telephone Technical Support

If you do not have internet or email access, you may contact PSC technical support at (541) 349-8281.

NOTES

Appendix A. PSC Falcon® Windows Mobile End User License Agreement

Notice to End User: The product you have acquired contains software, which is integral to the product's operation. This software is provided only for use with, and for authorized end users of, the PSC Falcon® 44xx series Portable Computing Device ("PSC Product"). The PSC Product operates with PSC software, including but not limited to, PSC documentation and all PSC software applications and software tools (e.g. Falcon Update Utility, Falcon Management Utility, and Falcon desktop Utility)("Software") and the PSC Product also operates with either Microsoft Windows®CE .NET or Windows® Mobile™ 5.0 software ("SOFTWARE") (see Microsoft Addendum for specific terms and conditions)(hereinafter collectively referred to as "Software").

Software is provided only for use with the PSC Product and any other use of Software is strictly prohibited and may subject you to legal action. Software is provided to you under license, subject to the terms and conditions of this end user license agreement ("EULA"). Any and all updates to Software shall also be subject to this EULA. In the event upgrades are made available, you will be authorized to order only one upgrade for each licensed PSC Product. If you use the PSC Product, you will be deemed to have accepted the terms and conditions of this EULA. If you do not intend to be bound to the terms of this EULA, PSC is not willing to license the Software to you, you may not use the PSC Product or the Software, and you must contact the party from whom you acquired the PSC Product for instructions on how to return the PSC Product.

This End User Software License Agreement (\"EULA\") is a legally binding agreement governing the licensing of the Software and Documentation by PSC Inc. and its wholly owned subsidiaries and affiliates (\"PSC\") to the entity or person who has purchased or otherwise acquired a PSC Product (\"End User\"). For purposes of this EULA, any software that is associated with a separate end-user license agreement is licensed to you under the terms of that license agreement. PSC and End User hereby agree as follows:

GENERAL EULA TERMS AND CONDITIONS:

1. Definitions.

1.1 \"Documentation\" means materials such as user's guides, program reference guides, quick reference guides, manuals, or similar materials associated with or related to the PSC Product, whether in printed, \"online\", or other form.

1.2 \"Proprietary Information\" means: (a) source code, object code, software, documentation, and any related internal design, system design, data base design, algorithms, technology, technical data or information, implementation techniques, and trade secrets related to the Software, (b) any other trade secrets marked appropriately or identified as proprietary or confidential, and (c) any information that End User, under the circumstances, should recognize as confidential. Proprietary Information does not include any information that the receiving party can establish was (1) in the public domain, (2) already in the receiving party's possession or rightfully known prior to receipt, (3) rightfully learned from a third party not in violation of any other's proprietary rights, or (4) independently developed without access to Proprietary Information.

1.3 \"PSC Product\" means PSC's FALCON® Windows®CE .NET and/or Windows Mobile 5.0 44xx Series, including all preloaded Software in or provided in connection with the PSC Product and all Documentation related to such product, which has been purchased or otherwise acquired by End User, whether obtained directly or indirectly from PSC.

1.4 \"Software\" means any software or computer program of PSC or its third party licensors in machine readable form which is either preloaded in, or provided in connection with, the PSC Product, whether obtained directly or indirectly from PSC, including any related update or upgrade such as enhancements or modifications.

2. Scope Of License Granted.

2.1 PSC grants to End User a non-exclusive, non- transferable, perpetual license to use the Software, solely on a PSC Product, in machine- readable form only, solely for End User's internal business purposes. This EULA does not convey ownership of the Software to End User. Title to the Software shall be and remain with PSC or the third party from whom PSC has obtained a licensed right. As used in this EULA, the term \"purchase\" or its equivalents when applied to the Software shall mean \"acquire under license.\"

2.2 End User shall not copy, modify, decompile, disassemble, reverse engineer, or otherwise reproduce or remanufacture the Software, whether modified or unmodified, nor sell, assign, sublicense, distribute, lend, rent, give, or otherwise transfer the Software to any other person or organization, for purposes other than as expressly provided in this EULA, without PSC's prior written consent.

3. Transfers, Support.

3.1 Any copying, installing, reproduction, remanufacture, reverse engineering, electronic transfer, or other use of the Software on other than a PSC Product will be a material breach of this EULA.

3.2 End User shall not sell, assign, sublicense, distribute, lend, rent, give, or otherwise transfer a PSC Product containing Software to any third party unless such third party agrees with PSC in writing to be bound by the terms and conditions of this EULA. Any such transfer of a PSC Product absent such agreement shall be null and void.

3.3 End User may obtain support for Software from PSC at PSC's standard support fees and under PSC's standard support terms and conditions in effect at the time the support is requested.

4. Intellectual Property.

End User acknowledges that the Software constitutes valuable trade secrets of PSC or PSC's third party licensors and that the Software is protected by intellectual property laws and treaties. The license set forth in this EULA does not transfer to End User any ownership of PSC's or of its third party licensors' copyrights, patents, trademarks, service marks, trade secrets, or other intellectual property rights and End User shall have no right to commence any legal actions to obtain such rights. End User shall not remove, modify, or take any other action that would obscure any copyright, trademark, patent marking, or other intellectual property notices contained in or on the PSC Product.

5. Proprietary Information.

5.1 End User acknowledges that Proprietary Information is the confidential, proprietary, and trade secret property of PSC and PSC's third party licensors and End User acquires no right or interest in any Proprietary Information.

5.2 End User shall not disclose, provide, or otherwise make available the Proprietary Information of PSC or its third party licensors to any person other than End User's authorized employees or agents who are under confidentiality agreement, and End User shall not use the Proprietary Information other than in conjunction with use of the PSC Product exclusively for End User's internal business purposes. End User shall take steps to protect the Proprietary Information no less securely than if it were End User's own intellectual property.

5.3 The provisions of this Proprietary Information Section shall survive and continue for five (5) years after the termination of this EULA.

6. Limited Warranty.

6.1 PSC warrants that, under normal use and operation, the PSC Product will conform substantially to the applicable Documentation for the period specified in the Documentation. During this period, for all reproducible nonconformities for which PSC has been given written notice, PSC will use commercially reasonable efforts to remedy nonconformities verified by PSC. End User agrees to supply PSC with all reasonably requested information and assistance necessary to help PSC in remedying such nonconformities. For all defects reported to PSC within the warranty period, PSC's liability is limited to providing End User with one copy of corrections or responding to End User's problem reports according to PSC's standard assistance practices. PSC does not warrant that the product will meet End User's requirements or that use of the product will be uninterrupted or error free, or that PSC's remedial efforts will correct any non-conformance.

This limited warranty does not cover any product that has been subjected to damage or abuse, whether intentionally, accidentally, or by neglect, or to unauthorized repair or unauthorized installation, and shall be void if End User modifies the product, uses the product in any manner other than as established in the Documentation, or if End User breaches any of the provisions of this EULA.

6.2 EXCEPT AS PROVIDED IN THIS EULA, THE PSC PRODUCT IS PROVIDED \"AS IS\" AND PSC MAKES NO WARRAN-TIES OF ANY KIND, EXPRESS OR IMPLIED, WRITTEN OR ORAL, WITH RESPECT TO THE PRODUCT, AND SPECIFI-CALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

7. Infringement.

7.1 PSC will defend End User against any claim in a lawsuit that the PSC Product furnished hereunder infringes a United States patent or copyright of a third party and PSC will pay any damages finally awarded against End User by a court of competent jurisdiction that are directly attributable to such claim or will pay End User's part of any settlement that is attributable to such claim, provided, that 1) End User notifies PSC promptly in writing of the claim, 2) PSC controls the defense or settlement of the claim, and 3) End User cooperates fully with PSC in such defense or settlement. All notices of a claim should be sent to PSC Inc, 959 Terry Street, Eugene, OR 97402.

7.2 In the defense or settlement of any such claim, PSC may, at its option, 1) procure for End User the right to continue using the PSC Product, 2) modify the PSC Product so that it becomes non- infringing, 3) replace the PSC Product with an equivalent product not subject to such claim, or 4) provide End User an opportunity to return the PSC Product and receive a refund of the purchase price paid, less a reasonable allowance for use. 7.3 PSC shall have no liability to End User for claims of infringement based upon 1) the use of any PSC Product in combination with any product which PSC has not either furnished or authorized for use with such PSC Product 2) the use of any PSC Product designed, manufactured, or modified to the specifications of End User, or 3) End User's modification of the PSC Product without written authorization from PSC.

7.4 THE FOREGOING STATES PSC'S COMPLETE AND ENTIRE OBLIGATION CONCERNING CLAIMS OF PATENT, COPY-RIGHT, OR OTHER INTELLECTUAL PROPERTY INFRINGEMENT, CANCELS AND SUPERCEDES ANY PRIOR AGREE-MENTS, WHETHER ORAL OR WRITTEN, BETWEEN THE PARTIES CONCERNING SUCH CLAIMS, AND WILL NOT BE MODIFIED OR AMENDED BY ANY PAST, CONTEMPORANEOUS, OR FUTURE AGREEMENTS OR DEALINGS BETWEEN THE PARTIES, WHETHER ORAL OR WRITTEN, EXCEPT AS SET FORTH IN A FUTURE WRITING SIGNED BY BOTH PAR-TIES.

8. Limitation Of Liability.

EXCEPT AS PROVIDED IN SECTION 7 (above), PSC SHALL NOT BE LIABLE FOR ANY CLAIMS AGAINST END USER BYANY OTHER PARTY. IN NO EVENT SHALL PSC'S LIABILITY FOR DAMAGES, IF ANY, WHETHER BASED UPON CON-TRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, STRICT LIABILITY, WARRANTY, OR ANY OTHER BASIS, EXCEED THE PRICE OR FEE PAID BY END USER FOR THE PSC PRODUCT. UNDER NO CIRCUMSTANCES SHALL PSC BE LIABLE TO END USER OR ANY THIRD PARTY FOR LOST PROFITS, LOST DATA, INTERRUPTION OF BUSINESS OR SERVICE, OR FOR ANY OTHER SPECIAL, CONSEQUENTIAL, CONTINGENT, INDIRECT, INCIDENTAL, PUNITIVE, EXEM-PLARY, OR OTHER SIMILAR DAMAGES, EVEN IF PSC HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

9. Government Restricted Rights; International Use.

9.1 Use, duplication, or disclosure of the Software by the U.S. Government is subject to the restrictions for computer software developed at private expense as set forth in the U.S. Federal Acquisition Regulations at FAR 52.227-14(g), or 52.227-19 or in the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013(c)(1)(ii), whichever is applicable.

9.2 If End User is using the PSC Product outside of the United States, End User must comply with the applicable local laws of the country in which the PSC Product is used, with U.S. export control laws, and with the English language version of this EULA. The provisions of the \"United Nations Convention on International Sale of Goods\" shall not apply to this EULA.

10. Termination.

10.1 Either party may terminate this EULA or any license granted under this EULA at any time upon written notice if the other party breaches any provision of this EULA.

10.2 Upon termination of this EULA, End User immediately shall cease using any non-preloaded software and shall return to PSC or destroy all non-preloaded software covered by this EULA, and shall furnish PSC with a certificate of compliance with this provision signed by an officer or authorized representative of End User. For preloaded software, End User agrees to sign a waiver prepared by PSC concerning further use of the preloaded Software. End User's resumed or continued use of the preloaded Software after termination shall constitute End User's agreement to be bound by the terms and conditions of this EULA for such use.

11. General Provisions.

11.1 Entire EULA; Amendment. This document contains the entire agreement between the parties relating to the licensing of the Software and supersedes all prior or contemporaneous agreements, written or oral, between the parties concerning the licensing of the Software. This EULA may not be changed, amended, or modified except by written document signed by PSC.

11.2 Notice. All notices required or authorized under this EULA shall be given in writing, and shall be effective when received, with evidence of receipt. Notices to PSC shall be sent to the Legal Department, attention Contracts Administration, PSC Inc., 959 Terry Street, Eugene, OR 97402, or such other address as may be specified by PSC in writing.

11.3 Waiver. A party's failure to enforce any of the terms and conditions of this EULA shall not prevent the party's later enforcement of such terms and conditions.

11.4 Governing Law; Venue: This EULA and the rights of the parties hereunder shall be governed by and construed in accordance with the laws of the State of Oregon U.S.A, without regard to the rules governing conflicts of law. The state or federal courts of the State of Oregon located in either Multnomah or Lane counties shall have exclusive jurisdiction over all matters regarding this EULA, except that PSC shall have the right, at its absolute discretion, to initiate proceedings in the courts of any other state, country, or territory in which End User resides, or in which any of End User's assets are located.

11.5 Attorneys' Fees. In the event an action is brought to enforce the terms and conditions of this EULA, the prevailing party shall be entitled to reasonable attorneys' fees, both at trial and on appeal.

Appendix B. Microsoft® Windows Mobile Addendum to EULA

- End User ("you") have acquired a device ("DEVICE") that includes software licensed by PSC from an affiliate of Microsoft Corporation ("MS"). Those installed software products of MS origin, as well as associated media, printed materials, and "online" or electronic documentation ("SOFTWARE") are protected by international intellectual property laws and treaties. The SOFTWARE is licensed, not sold. All rights reserved.
- IF YOU DO NOT AGREE TO THIS END USER LICENSE AGREEMENT ("EULA"), DO NOT USE THE DEVICE OR COPY THE SOFTWARE. INSTEAD, PROMPTLY CONTACT PSC FOR INSTRUCTIONS ON RETURN OF THE UNUSED DEVICE(S) FOR A REFUND. ANY USE OF THE SOFTWARE, INCLUDING BUT NOT LIMITED TO USE ON THE DEVICE, WILL CONSTITUTE YOUR AGREEMENT TO THIS EULA (OR RATIFICATION OF ANY PREVIOUS CONSENT).
- SOFTWARE includes software already installed on the DEVICE ("DEVICE Software") and MS software contained on the CD-ROM disk ("Companion CD").

GRANT OF SOFTWARE LICENSE. This EULA grants you the following license:

DEVICE Software. You may use the DEVICE Software as installed on the DEVICE.

Companion CD. A Companion CD is included with your DEVICE, and you may install and use the Microsoft® ActiveSync® component on one (1) or more personal computers to exchange information with one (1) or more computing devices that contain a compatible version of the Microsoft® Windows Mobile[™] Version 5.0 operating system. For other software component(s) contained on the Companion CD, you may install and use such components only in accordance with the terms of the printed or online end user license agreement(s) provided with such component(s). In the absence of an end user license agreement for particular component(s) of the Companion CD, you may install and use only one (1) copy of such component(s) on the DEVICE or a single personal computer with which you use the DEVICE.

Phone Functionality. If the DEVICE Software includes phone functionality, all or certain portions of the DEVICE Software may be inoperable if you do not have and maintain a service account with an appropriate wireless telecommunication carrier to whom PSC may distribute its DEVICES ("Mobile Operator"), or if the Mobile Operator's network facilities are not operating or configured to operate with the DEVICE.

Microsoft® Outlook®. If Microsoft Outlook is included with your Device, the following terms apply to your use of Microsoft Outlook: (i) regardless of the information contained in the "Software Installation and Use" section of the online EULA you may install one (1) copy of Microsoft Outlook on one (1) personal computer to use, exchange data, share data, access and interact with the DEVICE, and (ii) the EULA for Microsoft Outlook is between PSC and the end user – not between the PC manufacturer and end user.

DESCRIPTION OF OTHER RIGHTS AND LIMITATIONS.

- Speech/Handwriting Recognition. If the DEVICE Software includes speech and/or handwriting recognition component(s), you should understand that speech and handwriting recognition are inherently statistical processes and that errors can occur in the component's recognition of your handwriting, and the final conversion into text. Neither PSC nor its suppliers shall be liable for any damages arising out of errors in the speech and handwriting recognition process.
- Limitations on Reverse Engineering, Decompilation and Disassembly. You may not reverse engineer, decompile, or disassemble the SOFTWARE, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation.
- Single DEVICE. The DEVICE Software is licensed with the DEVICE as a single integrated product. The DEVICE Software installed in read only memory ("ROM") of the DEVICE may only be used as part of the DEVICE.
- Single EULA. The package for the DEVICE may contain multiple versions of this EULA, such as multiple translations and/or multiple media versions (e.g., in the user documentation and in the software). Even if you receive multiple versions of the EULA, you are licensed to use only one (1) copy of the DEVICE Software.
- NOTICE REGARDING THE MPEG-4 VISUAL STANDARD. The DEVICE Software may include MPEG-4 visual decoding technology. MPEG LA, L.L.C. requires the following notice:

• USE OF THIS SOFTWARE IN ANY MANNER THAT COMPLIES WITH THE MPEG-4 VISUAL STANDARD IS PROHIB-ITED, EXCEPT FOR USE DIRECTLY RELATED TO (A) DATA OR INFORMATION (i) GENERATED BY AND OBTAINED WITHOUT CHARGE FROM A CONSUMER NOT THEREBY ENGAGED IN A BUSINESS ENTERPRISE, AND (ii) FOR PERSONAL USE ONLY; AND (B) OTHER USES SPECIFICALLY AND SEPARATELY LICENSED BY MPEG LA, L.L.C.

If you have questions regarding this Notice, please contact MPEG LA, L.L.C., 250 Steele Street, Suite 300, Denver, Colorado 80206; Telephone 303 331.1880; FAX 303 331.1879

- Rental. You may not rent, lease, or lend the SOFTWARE.
- SOFTWARE Transfer. You may permanently transfer all of your rights under this EULA only as part of a sale or transfer of the DEVICE, provided you retain no copies, you transfer all of the SOFTWARE (including all component parts, the media and printed materials, any upgrades, this EULA and, if applicable, the Certificate(s) of Authenticity), and the recipient agrees to the terms of this EULA. If the SOFTWARE is an upgrade, any transfer must include all prior versions of the SOFTWARE.

If the DEVICE Software includes phone functionality, you may not permanently transfer any of your rights under this EULA with regard to the DEVICE Software or Companion CD, except as permitted by the applicable Mobile Operator. In the event that the Mobile Operator permits such transfer, you may permanently transfer all of your rights under this EULA only as part of a sale or transfer of the DEVICE, provided you retain no copies, you transfer all of the SOFTWARE (including all component parts, the media and printed materials, any upgrades, this EULA and, if applicable, the Certificate(s) of Authenticity), and the recipient agrees to the terms of this EULA. If the SOFTWARE is an upgrade, any transfer must include all prior versions of the SOFTWARE.

- Termination. Without prejudice to any other rights, PSC or MS may terminate this EULA if you fail to comply with the terms and conditions of this EULA. In such event, you must destroy all copies of the SOFTWARE and all of its component parts.
- Security Updates/Digital Rights Management. Content providers are using the digital rights management technology ("DRM") contained in your DEVICE to protect the integrity of their content ("Secure Content") so that their intellectual property, including copyright, in such content is not misappropriated. Portions of the DEVICE Software and third party applications such as media players use DRM to play Secure Content ("DRM Software"). If the DRM Software's security has been compromised, owners of Secure Content ("Secure Content Owners") may request that MS block the ability of DRM license servers and personal computers to deliver new licenses that enable an affected DEVICE to play Secure Content. This action does not alter the DRM Software's ability to play unprotected content. A list of revoked DRM Software is sent to your DEVICE whenever you download a license for Secure Content from the Internet or from your personal computer. You therefore agree that MS may, in conjunction with such license, also download revocation lists onto your DEVICE on behalf of Secure Content Owners. MS will not retrieve any personally identifiable information, or any other information, from your DEVICE by downloading such revocation lists.
- Consent to Use of Data. You agree that MS, Microsoft Corporation, their affiliates and/or their designated agent may
 collect and use technical information gathered in any manner as part of product support services related to the DEVICE
 Software. MS, Microsoft Corporation, their affiliates and/or their designated agent may use this information solely to
 improve their products or to provide customized services or technologies to you. MS, Microsoft Corporation, their affiliates
 and/or their designated agent may disclose this information to others, but not in a form that personally identifies you.
- Internet Gaming/Update Features. If the DEVICE Software provides, and you choose to utilize, the Internet gaming or
 update features within the DEVICE Software, it is necessary to use certain computer system, hardware, and software
 information to implement the features. By using these features, you explicitly authorize MS, Microsoft Corporation and/or
 their designated agent to use this information solely to improve their products or to provide customized services or technologies to you. MS or Microsoft Corporation may disclose this information to others, but not in a form that personally
 identifies you.
- Internet-Based Services Components. The DEVICE Software may contain components that enable and facilitate the
 use of certain Internet-based services. You acknowledge and agree that MS, Microsoft Corporation, their affiliates and/or
 their designated agent may automatically check the version of the DEVICE Software and/or its components that you are
 utilizing and may provide upgrades or supplements to the DEVICE Software that may be automatically downloaded to
 your DEVICE.
- Additional Software/Services. The DEVICE Software may permit PSC, MS, Microsoft Corporation, their affiliates and/ or their designated agent to provide or make available to you SOFTWARE updates, supplements, add-on components, or Internet-based services components of the SOFTWARE after the date you obtain your initial copy of the SOFTWARE ("Supplemental Components").

- If PSC provides or makes available to you Supplemental Components and no other EULA terms are provided along with the Supplemental Components, then the terms of this EULA shall apply.
- If MS, Microsoft Corporation, their affiliates and/or their designated agent make available Supplemental Components, and no other EULA terms are provided, then the terms of this EULA shall apply, except that the MS, Microsoft Corporation or affiliate entity providing the Supplemental Component(s) shall be the licensor of the Supplemental Component(s).
- PSC, MS, Microsoft Corporation, their affiliates and/or their designated agent reserve the right to discontinue any Internet-based services provided to you or made available to you through the use of the DEVICE Software.
- Links to Third Party Sites. The DEVICE Software may provide you with the ability to link to third party sites through the use of the DEVICE Software. The third party sites are not under the control of MS, Microsoft Corporation, their affiliates and/or their designated agent. Neither MS nor Microsoft Corporation nor their affiliates nor their designated agent are responsible for (i) the contents of any third party sites, any links contained in third party sites, or any changes or updates to third party sites, or (ii) webcasting or any other form of transmission received from any third party sites. If the DEVICE Software provides links to third party sites, those links are provided to you only as a convenience, and the inclusion of any link does not imply an endorsement of the third party site by MS, Microsoft Corporation, their affiliates and/or their designated agent.

UPGRADES AND RECOVERY MEDIA.

- DEVICE Software. If the DEVICE Software is provided by PSC separate from the DEVICE on media such as a ROM chip, CD ROM disk(s) or via web download or other means, and is labeled "For Upgrade Purposes Only" you may install one (1) copy of such DEVICE Software onto the DEVICE as a replacement copy for the existing DEVICE Software, and use it in accordance with this EULA, including any additional EULA terms accompanying the upgrade DEVICE Software.
- COMPANION CD. If any software component(s) is provided by PSC separate from the DEVICE on CD ROM disk(s) or via web download or other means, and labeled "For Upgrade Purposes Only", you may (i) install and use one (1) copy of such component(s) on the computer(s) you use to exchange data with the DEVICE as a replacement copy for the existing Companion CD component(s).

COPYRIGHT. All title and intellectual property rights in and to the SOFTWARE (including but not limited to any images, photographs, animations, video, audio, music, text and "applets," incorporated into the SOFTWARE), the accompanying printed materials, and any copies of the SOFTWARE, are owned by MS or its suppliers (including Microsoft Corporation). You may not copy the printed materials accompanying the SOFTWARE. All title and intellectual property rights in and to the content which may be accessed through use of the SOFTWARE is the property of the respective content owner and may be protected by applicable copyright or other intellectual property laws and treaties. This EULA grants you no rights to use such content. All rights not specifically granted under this EULA are reserved by MS and its suppliers (including Microsoft Corporation).

EXPORT RESTRICTIONS. You acknowledge that the SOFTWARE is subject to U.S. and EU export jurisdiction. You agree to comply with all applicable international and national laws that apply to the SOFTWARE, including the U.S. Export Administration Regulations, as well as end-user, end-use and destination restrictions issued by U.S. and other governments. For additional information, see http://www.microsoft.com/exporting/.

PRODUCT SUPPORT. Product support for the SOFTWARE is not provided by MS, its parent corporation Microsoft Corporation, or their affiliates or subsidiaries. For product support, please refer to PSC support number provided in the documentation for the DEVICE. Should you have any questions concerning this EULA, or if you desire to contact PSC for any other reason, please refer to the address provided in the documentation for the DEVICE.

NO LIABILTIY FOR CERTAIN DAMAGES. EXCEPT AS PROHIBITED BY LAW, MICROSOFT CORPORATION AND ITS AFFILIATES SHALL HAVE NO LIABILITY FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES ARISING FROM OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE SOFTWARE. THIS LIMITATION SHALL APPLY EVEN IF ANY REMEDY FAILS OF ITS ESSENTIAL PURPOSE.

FOR APPLICABLE LIMITED WARRANTIES AND SPECIAL PROVISIONS PERTAINING TO YOUR PARTICULAR JURISDIC-TION, PLEASE REFER TO YOUR WARRANTY BOOKLET INCLUDED WITH THIS PACKAGE OR PROVIDED WITH THE SOFTWARE PRINTED MATERIALS.

- END -

Appendix C: PSC Falcon[®] Windows Mobile[®] Product Series Warranty

Warranty

Falcon products are guaranteed against defects in materials and workmanship for the period specified at the time of sale. This warranty shall apply to Falcon Portable Data Terminals (PDT's), Base Stations for the Falcon and Chargers for the Falcon. Cables, mounts and other accessory items are specifically warranted for a period of 90-days from product purchase. Customer must notify PSC of the claimed defect before the expiration of the Warranty period and obtain from PSC a return authorization number for return of the product to designated PSC service center. If PSC determines Customer's claim is valid, PSC will repair or replace product without additional charge for parts and labor. Customer shall be responsible for packaging and shipping the product to the designated PSC service center, with shipping charges prepaid. PSC shall pay for the return of the product to Customer shall be responsible for packaging and shipping the product to the shipment is to a location within the country in which the PSC service center is located. Customer shall be responsible for paying all shipping charges, duties, taxes, and any other charges for products returned to any other locations.

Warranty is subject to the limitations and exclusions set forth in the paragraphs that follow.

WARRANTY SET FORTH ABOVE IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING MER-CHANTABILITY AND FITNESS.

Exclusions

Warranty coverage shall not apply to any claimed defect, failure or damage which PSC determines was caused by: abuse, neglect, improper use of product; failure to provide product maintenance, including but not limited to cleaning of the display in accordance with product reference guide; installation or service of product by other than PSC representatives; use of product with any other instrument, equipment or apparatus; modification or alteration of product or units with Warranty Void labels that have been tampered with. External cables and replacement of upper window/cartridge due to scratching, stains or other degradation will not be covered under the Warranty. External power supplies returned for service must be accompanied by the original product for performance of service.

Returned products that PSC inc. has determined are not covered by Warranty, will be charged PSC Inc. standard repair rates then in effect for repair of product. Replacement of display due to scratching, stains or other degradation will not be covered under Warranty. If a product is determined to be not repairable customer will be notified and product may be returned to customer at their request. A minimum repair fee may be charged.

Limitation of Liability

PSC'S REPAIR OR REPLACEMENT OF DEFECTIVE PRODUCT AS SET FORTH ABOVE IS THE CUSTOMER'S SOLE AND EXCLUSIVE REMEDY ON ACCOUNT OF CLAIMS OF BREACH OF WARRANTY OR PRODUCT DEFECT. UNDER NO CIR-CUMSTANCES WILL PSC BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY LOST PROFITS, OR ANY INCI-DENTAL, CONSEQUENTIAL IN-DIRECT, SPECIAL OR CONTINGENT DAMAGES REGARDLESS OF WHETHER PSC HAD ADVANCE NOTICE OF THE POSSIBILITY OF SUCH DAMAGES.

Assignment

Customer may not assign or otherwise transfer its rights or obligations under Warranty except to a purchaser or transferee of product. No attempted assignment or transfer in violation of this provision shall be valid or binding upon PSC.


Risk of Loss

Customer shall bear risk of loss or damage for product in transit to PSC. PSC shall assume risk of loss or damage for product in PSC's possession or product being returned to Customer by PSC, except such loss or damage as may be caused by the negligence of Customer, its agents or employees. In the absence of specific written instructions for the return of product to Customer, PSC will select the carrier, but PSC shall not thereby assume any liability in connection with the return shipment.

Appendix D: Safety Information

Laser Safety Label

Figure 1. Laser Safety Label



This figure illustrates an example of a laser safety label, which is located on the scanning pod of laser-based Falcon 4400 series units. The label on your unit may appear different or have different informa-

tion. Please refer to your unit for specific laser safety requirements.

The Advanced Long Range Laser is rated Class 3R per EN60825-1 and Class II per CFR 1040.

Models with the Linear Imager are rated LED Class 1 per IEC 60 825-1:2001, only.

Advisory Statement



Use of controls, adjustments, or performance of procedures other than those specified herein may result in hazardous visible or invisible laser light exposure.

Regulatory Statements

Radio Frequency Interference

This equipment has been tested and found to comply with the limits of a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his or her own expense.

Canadian Compliance Statement

This Class A Digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la Classe A est confirme à la norme NMB-003 du Canada.



For information about the disposal of Waste Electrical and Electronic Equipment (WEEE), please refer to the PSC website at www.psc.com.

Appendix E: Laser Safety

International Caution Statements for CLASS 1¹, 2², 3R³, II⁴, and IIA⁵ Laser Devices

English

PSC scanners are certified in the U.S. to conform to the requirements of DHHS/CDRH 21CFR Subchapter J and to the requirements of IEC/EN 60825-1:1998-2001.

Class 1, 2, 3R, Class II, and IIA products are not considered to be hazardous. The scanner contains internally a Visible Laser Diode (VLD) whose emissions do not exceed the maximum limits as set forth in the above regulations. The scanner is designed so that there is no human access to harmful laser light during normal operation, user maintenance or during prescribed service operations.

CAUTION

If the scan pattern is a single dot when depressing the trigger, discontinue operation and return the scanner to PSC.

CAUTION

Do not attempt to open or otherwise service any components in the optics cavity. Opening or servicing any part of the optics cavity by unauthorized personnel may violate laser safety regulations. The optics system is a factory only repair item.

CAUTION

Use of optical systems with the scanner will increase eye hazard. Optical instruments include binoculars, microscopes and magnifying glasses. This does not include eye glasses worn by the user.

French

Ce scanneurs du PSC sont certifié conforme à la norme DHHS/CDRH 21CFR sous-chapitre J et à la norme IEC/ EN 60825-1:1998-2001.

Les produits de class 1, 2, 3R, class II, et de IIA ne sont pas considérés dangereux. Le scanneur contient une diode laser visible (VLD) dont les émissions ne dépassent pas les limites prescrites dans les normes précitées. Le scanneur est conçu de façon à ce qu'il ne soit pas possible d'accéder à la lumière laser pendant l'utilisation normale, l'entretien par l'utilisateur et les fonctions de maintenance prescrites.

ATTENTION

Si, quand la fonction de balayage est lancée, le diagramme de balayage est constitué d'un seul point, cesser d'utiliser le scanneur et le retourner à PSC.

ATTENTION

Ne pas essayer d'ouvrir ou de réparer les composants de la cavité optique. L'ouverture de la cavité optique ou la réparation de ses composants par une personne non qualifiée peut entraîner le non-respect des règles de sécurité relatives au laser. Le système optique ne peut être réparé qu'en usine.

- 1. Class 1 applies to IEC/EN STD (Europe).
- 2. Class 2 applies to IEC/EN STD (Europe).

- 4. Class II applies to CDRH STD (US/Canada).
- 5. Class IIA applies to CDRH STD (US/Canada).

^{3.} Class 3R applies to the Falcon 44xx using ALR (Advanced Long Range) Laser, only.

ATTENTION

L'utilisation d'instruments optiques avec le scanneur augmente le danger pour les yeux. Les instruments optiques comprennent les jumelles, les microscopes et les verres grossissants. Ils ne comprennent pas les lunettes portées par l'utilisateur.

German

Dieser Scanner ist den in den Vereinigten Staaten geltenden Vorschriften des DHHS/CDRH 21 CFR Subchapter J und den Vorschriften der IEC/EN 60825-1:1998-2001 entsprechend bescheinigt.

Produkte der Klasse 1, 2, 3R, Klasse II oder der IIA sind als ungefährlich eingestuft. Im Inneren des Scanners befindet sich eine VLD (Visible Laser Diode), deren Ausstrahlung die in den oben genannten Vorschriften angeführten Höchstgrenzen nicht überschreitet. Die Konstruktion des Scanners garantiert, daß bei normalem Betrieb, bei Wartung durch den Benutzer oder im Laufe planmäßiger Wartungsarbeiten kein Zugang zu schädlichem Laserlicht besteht.

VORSICHT:

Sollte das Abtastbild bei gedrücktem Auslöser aus einem einzigen Punkt bestehen, muß der Betrieb eingestellt und der Scanner an PSC zurückgesendet werden.

VORSICHT:

Unter keinen Umständen darf versucht werden, die Komponenten im Optikhohlraum zu öffnen oder auf irgendwelche andere Weise zu warten. Das Öffnen bzw. Warten der Komponenten im Optikhohlraum durch unbefugtes Personal verstößt gegen die Laser-Sicherheitsbestimmungen. Das Optiksystem darf nur werkseitig repariert werden.

VORSICHT:

Die Verwendung von Optiksystemen mit diesem Scanner erhöht die Gefahr einer Augenbeschädigung. Zu optischen Instrumenten gehören unter anderem Ferngläser, Mikroskope und Vergrößerungsgläser, nicht aber die von Benutzern getragenen Brillen.

Italian

È stato certificato che questo scanner si conforma ai requisiti della sezione J della normativa DHHS/CDRH 21CFR, e anche ai requisiti di IEC/EN 60825-1:1998-2001.

I prodotti di Classe 1, 2, 3R, Classe II, o IIA non sono considerati pericolosi. Lo scanner contiene al suo interno un Visible Laser Diode (VLD), diodo laser visibile, le cui emissioni non eccedono i limiti stabiliti dalle normative sunnominate. Lo scanner è progettato in modo che non ci sia alcun accesso alla luce dannosa del laser nel corso di uso normale, di manutenzione da parte dell'utente o durante la manutenzione periodica stabilita.

ATTENZIONE

Se, quando si preme l'azionamento, il pattern di scansione è un punto singolo, interrompere l'operazione e riportare lo scanner a PSC .

ATTENZIONE

Non tentare di accedere allo scomparto contenete i componenti ottici o di farne la manutenzione. L'apertura dello scomparto, o la manutenzione di qualsiasi parte ottica da parte di personale non autorizzato, potrebbe violare le norme della sicurezza. Il sistema ottico può essere riparato solamente alla fabbrica.

ATTENZIONE

L'uso di strumenti ottici assieme allo scanner può aumentare il pericolo di danno agli occhi. Tali strumenti ottici includono cannocchiali, microscopi e lenti di ingrandimento. Essi non includono gli occhiali indossati dall'utente.

Danish

Denne scanner opfylder de amerikanske krav stillet i "DHHS/CDRH 21CFR Subchapter J" og opfylder også de krav, der stilles i IEC/EN 60825-1:1998-2001.

Klasse 1, 2, 3R, klasse II eller klasse IIA produkter anses for at være sikre. Scanneren indeholder en Visible Laser Diode (VLD), der ikke overskrider maksimumgrænserne, som beskrevet i ovenstående reglement. Scanneren er konstrueret, så der ikke er nogen menneskelig kontakt medskadelige niveauer af laserbestråling under normal brug, normal vedligeholdelse eller under foreskrevet servicering.

ADVARSEL

Hvis scanningmønsteret er et enkelt punkt, når triggeren indtrykkes, skal betjening ophøre og scanneren returneres til PSC.

ADVARSEL

Forsøg ikke at åbne eller reparere komponenter i det optiske hulrum. Uautoriseret åbning eller reparation af komponenter i det optiske hulrum kan være en overtrædelse af lasersikkerhedsregulativer. Det optiske system må udelukkende repareres as PSC.

ADVARSEL

Anvendelse af optiske systemer med scanneren øger risikoen for øjenskader. Optiske instruments omfatter kikkerter, mikroskoper og lupper. Det omfatter ikke anvendelse af almindelige briller.

Dutch

Deze scanner is in de V.S. goedgekeurd en voldoet aan de vereisten van DHHS/CDRH 21CFR Subchapter J een aan de vereisten van IEC/EN 60825-1:1998-2001.

Producten van klasse 1 ,2, 3R, klasse II en IIA worden niet geacht gevaarlijk te zijn.

De scanner bevat een inwendige Visible Laser Diode (VLD) waarvan de emissies de maximumgrenzen van bovenstaande reglementen niet overschrijden.

De scanner is zo ontworpen dat men bij normaal gebruik, onderhoud of tijdens het uitvoeren van de voorgeschreven onderhoudswerkzaamheden niet aan schadelijke niveaus wordt blootgesteld.

WAARSCHUWING

Als het scanpatroon bij het overhalen van de trekker een enkele stip is, stop dan onmiddellijk en stuur de scanner terug naar PSC.

WAARSCHUWING

Probeer niet om onderdelen in de opticaruimte te openen of er onderhoud aan uit te voeren. Het openen of onderhouden van delen in de opticaruimte door onbevoegd personeel kan een inbreuk vormen op de laserveiligheidsreglementen. Het opticasysteem mag alleen in de fabriek worden gerepareerd.

WAARSCHUWING

Het gebruik van optische systemen samen met de scanner vergroot het risico voor de ogen. Optische instrumenten zijn onder andere binoculairs, microscopen en vergrootglazen, maar niet de bril die de gebruiker draagt.

Swedish

Denna scanner uppfyller de amerikanska kraven DHHS/CDRH 21CFR Subchapter J samt kraven i IEC/EN 60825-1:1998-2001.

Produkter i Klass 1, 2, 3R, Klass II och IIA anses ej farliga. Scannern är utrustad med en intern, synlig laserdiod (Visible Laser Diode - VLD) vars emission inte överstiger max. värdena i ova stående säkerhetsföreskrifter. Scannern har konstruerats så att personer vid normal användning, bruksunderhåll och föreskriven service inte utsätts för skadlig laserstrålning.

VAR FÖRSIKTIG

Om scanningsmönstret är en enda punkt när du trycker på avtryckaren, ska du avbryta användningen och ta scannerna tillbaka till PSC.

VAR FÖRSIKTIG

Försök inte öppna eller reparera komponenter i den optiska kamaren. Om icke auktoriserad personal öppnar eller reparerar delar i den optiska kammaren, kan detta strida mot säkerhetsföreskrifterna för laserutrustning. Det optiska systemet får endast repareras på fabriken.

VAR FÖRSIKTIG

Användning av optiska system med scannern ökar risken för ögoskada. Optiska instrument inkluderar kikare, mikroskop och förstoingsglas, men inte användarens glasögon.

Finnish

Tämä tutkain on hyväksytty Yhdysvalloissa vastaamaan DHHS/CDRH 21CFR Subchapter J luokka 60825-1:1998-2001 IEC/EN-vaatimuksia.

Luokka 1, 2, 3R, Luokka II tai IIAtuotteiden ei katsota olevan vaarallisia. Tutkain sisältää sisäisen näkyvän laserdiodin (Visible Laser Diode (VLD), jonka päästöt eivät ylitä yllä olevien säädösten asettamia maksimirajoja. Tutkain on suunniteltu siten, etteivät ihmiset altistu vaaralliselle lasersäteilylle normaalikäytön, käyttäjän suorittaman huollon tai ohjeiden mukaisten huoltotoimenpiteiden aikana.

VAROITUS

Jos skannauskuva on yksittäinen piste laukaisinta painettaessa, keskeytä käyttö ja palauta tutkain PSC:lle.

VAROITUS

Älä yritä avata tai muuten huoltaa mitään rakenneosia optisessa osassa. Valtuuttamattoman henkilöstön suorittaman optisen osan avauksen tai huoltotoimen voidaan katsoa olevan rikkomus lasersuojaohjeita vastaan. Optisen järjestelmän saa korjata ainoastaan tehtaalla.

VAROITUS

Mikäli optisia järjestelmiä käytetään tutkainmen kanssa, silmille aiheutuva vaara lisääntyy. Optiset kojeet käsittävät kiikarit, mikroskoopit ja suurennuslasit. Käyttäjän silmälasit eivät kuulu tähän ryhmään.

Norwegian

Denne skanneren er godkjent i USA i samsvar med retningslinjene for DHHS/CDRH 21CFR, avsnitt J, og til IEC/EN 60825-1:1998-2001.

Produkter i klasse 1 2, 3R, klasse II eller IIA ansees ikke som helsefarlige. Skanneren inneholder en innvendig, synlig laserdiode (VLD, Visible Laser Diode), som ikke overskrider maksimalgrensene som er fastsatt i retningslinjene ovenfor. Skanneren er konstruert, slik at personer ikke utsettes for farlige doser med laserstråler ved normal drift, brukers vedlikehold eller ved foreskrevet service.

OBS!

Hvis skanningsmønsteret består av én enkel prikk når utløseren trykkes inn, skal driften stanses, og skanneren settes tilbake til PSC.

OBS!

Prøv ikke å åpne eller på noen måte utføre service på noen av delene i det optiske kammeret. Ved å åpne eller utføre service på noen av delene i det optiske kammeret av uautorisert personell, kan krenke forskriftene for lasersikkerhet. Optikksystemet skal bare repareres på fabrikken.

OBS!

Bruk av optiske systemer med skanneren kan innebære høyere fare for øynene. Optiske instrumenter innbefatter, kikkerter, mikroskop og forstørrelsesglass. Dette omfatter ikke briller som brukeren har på seg.

Portuguese

Este scanner foi certificado nos EUA para atender os requisitos do subcapítulo J do DHHS/CDRH 21 CFR e os requisitos do IEC/EN 60825-1:1998-2001.

Os produtos da Classe 1, 2, 3R, Classe II ou IIA não são considerados perigosos. O scanner contém internamente um Diodo de Laser Visível (VLD - Visible Laser Diode) cujas emissões não ultrapassam os limites definidos nos regulamentos mencionados acima. O scanner foi projetado de maneira que não exista acesso humano à luz de laser nociva durante a operação normal, manutenção pelo usuário ou durante as operações recomendadas de serviço.

CUIDADO

Se ao pressionar o gatilho a luz do laser for um único ponto, interrompa a operação e devolva o scanner à PSC.

CUIDADO

Não tente abrir ou consertar qualquer componente da cavidade óptica. A abertura ou manutenção de qualquer peça da cavidade óptica por pessoal não autorizado pode infringir os regulamentos de segurança do laser. O sistema óptico só deve ser reparado na fábrica.

CUIDADO

O uso de instrumentos ópticos com o scanner aumenta o risco para a visão. Incluem-se entre os instrumentos ópticos os binóculos, microscópios e lentes de aumento. Não se incluem os óculos usados pelo usuário.

Spanish

Este escáner está certificado en los EE.UU. porque reúne los requisitos DHHS/CDRH 21CFR Sección J y los requisitos de IEC/EN 60825-1:1998-2001.

Los productos de Clase 1, 2, 3R, Clase II, o IIA no se consideran como peligrosos. El escáner tiene en su interior un Diodo Láser Visible (VLD) cuyas emisiones no exceden los límites máximos fijados en los reglamentos mencionados anteriormente. El escáner está diseñado de modo que las personas no tengan acceso a la luz láser peligrosa durante la operación normal, el mantenimiento por parte del usuario o durante las operaciones de servicio prescritas.

PRECAUCIÓN

Si al oprimir el interruptor, el patrón de exploración es un solo punto, discontinúe el uso y devuelva el escáner a PSC.

PRECAUCIÓN

No intente abrir o de ninguna manera dar servicio a ninguno de los componentes del receptáculo óptico. Abrir o dar servicio a las piezas del receptáculo óptico por parte del personal no autorizado podría ser una violación a los reglamentos de seguridad. El sistema óptico se puede reparar en la fábrica solamente.

PRECAUCIÓN

El uso de sistemas ópticos con el escáner aumentará el riesgo de daños oculares. Los instrumentos ópticos incluyen binoculares, microscopios y lupas. Esto no incluye los lentes recetados usados por el usuario.

Chinese

本扫描器在美国获得认证,符合 DHHS/CDRH 21CFR J 分章和 ICE 825-1:1993 规定的要求。

I级和 Ⅱ级激光产品均属于对人类无危害的产品。扫描器内有一个可见激光二极管 (VLD),它发出的辐射低于上述条例规定的最高限度。本扫描器经特别设计,在正常使用情况下,包括用户自行保养或进行规定的维修,人体均不会接触到有害的激光辐射。

注意:

如果按了扫描引发钮后,扫描图形为单个圆点,请停止使用扫描器并将其返送回 PSC 公司(只适用于 QS6000 型扫描器)。

注意:

请勿打开激光或检修激光发生器内的任何部件。未经授权的人员打开或修理激光发生器内部件可能 违反激光安全条例。光学系统只可送交工厂修理。

注意:

使用扫描器时不得用其他光学仪器,否则会增加对眼睛的危害。这些光学仪器包括望远镜、显微镜 和放大镜。但是,操作人员佩戴的眼镜不属于此范围。

Japanese

本スキャナ は米国においてDHHS/CDRH 21CFR の J項にある製品規格 準拠品であり、 IEC 825-1:1993の 製品規格に準拠する製品である ことが認定されています。

Class I 及び Class II 製品は『危険』とはみなされていません。 本 スキャナ内部には上記規格に定める最大値 超えない放射光量 を持つ可視光レーザ ダイオード(VLD) が使用されています。本 ス キャナ は通常の運用、ユーザによる保守、所定の修理作業において 有害なレーザ光が人体に影響を及ぼすことがないように設計されて います。

注意:

トリガーを押さえているときにスキャンのパターンがシングルの場 合は、操作を止めて、スキャナをPSC (QS6000 スキャナのみに適応) に戻して下さい。

注意:

所定の許可を得た人以外は本スキャナの光学部キャビティーを開け たり、その部品に手を触れたりしないで下さい。レーザ安全基準に 違反することになります。又工学部は工場でのみしか修理すること は出来ません。

注意:

光学機器を使用してスキャナ内部を覗くと、目に悪い影響を与える ことがあります。光学機器には双眼鏡、顕微鏡、拡大鏡等が含まれ ますが、使用者のかけている眼鏡はこれには該当しません。

NOTES

NOTES

DECLARATION OF CONFORMITY

PSC hereby declares that the Equipment specified below has been tested and found compliant to the following Directives and Standards:

Directives: EMC 89/336/EEC, Low Voltage 73/23/EEC, R&TTE 1999/5/EC

Standards

Equipment: EN 55022-B:2001; CISPR 22:2001; EN 55024:2001; EN 60825-1:2001; EN60950:2000

Power Supplies: EN 55014-1/2:1997, EN60950, EN 61558-1/2:1997+A1

Radios: EN 300-328-1 and -2:2000, EN 301.489.1/17:2000, EN60950:1992+A4

Equipment Type: Portable Data Terminal Equipment

Product: Falcon 44xx, Four-Slot Battery Charger, Single/Four-Slot Dock Stations

Declaration of Conformity with Regard to the R&TTE Directive 1999/5/EC

This equipment is in compliance with the essential requirements & other relevant provisions of Directive 1999/5/ English: Nederlands: EC. Suoma-Deze apparatuur voldoet aan de essentiële vereisten en andere relevante voorzieningen van EU-richtlijn 1999/5/ lainen: EC. Tämä laite noudattaa direktiivin 1999/5/EC keskeisiä vaatimuksia ja sen muita olennaisia määräyksiä. Français: Deutsch: Cet équipement répond aux exigences et provisions de la Directive 1999/5/EC. Diese Geräte entsprechen den Anforderungen und anderen relevanten Bestimmungen der Richtlinie 1999/5/EC. Italiano: Dansk: Questa apparecchiatura rispetta i requisiti essenziali e le altre clausole rilevanti della Direttiva 1999/5/CE. Português: Dette utstyret er i samsvar med de grunnleggende kravene og andre relevante forskrifter i 1999/5/EC-direktivet. Este equipamento está de acordo com os requisitos essenciais e outras provisões relevantes da Diretiva 1999/5/ Español: Svenska: EC. Este equipo cumple con los requisitos esenciales y otras provisiones relevantes de la Directiva 1999/5/EC. Norsk: Islenska: Denna utrustning uppfyller de väsentliga kraven och andra relevanta förordningar i Direktiv 1999/5/EC. Dette utstyret er i samsvar med de grunnleggende krav og andre relevante bestemmelser i EU-direktiv 1999/5/EF Þetta taeki er samkvaemnt grunnkröfum og öðrum viðeigandi ákvaðum Tilskipunar 1999/5/CE.

Brad West

Brad West Vice President Quality and Process Management PSC, Inc. 959 Terry Street Eugene, OR 97402 U.S.A.

Peter Lomax Vice President Europe, Middle East & Africa PSC Bar Code Ltd. Axis 3, Rhodes Way Watford Hertfordshire WD24 4TR UK

Asia Pacific

PSC Hong Kong Hong Kong Telephone: [852]-2-584-6210 Fax: [852]-2-521-0291

Australia

PSC Asia Pacific Pty Ltd. North Ryde, Australia Telephone: [61] 0 (2) 9878 8999 Fax: [61] 0 (2) 9878 8688

France

PSC S.A.R.L. LES ULIS Cedex, France Telephone: [33].01.64.86.71.00 Fax: [33].01.64 46.72.44

Germany

PSC GmbH Darmstadt, Germany Telephone: 49 (0) 61 51/93 58-0 Fax: 49 (0) 61 51/93 58 58

Italy

PSC S.p.A. Vimercate (MI), Italy Telephone: [39] (0) 39/62903.1 Fax: [39] (0) 39/6859496

Japan

PSC Japan K.K. Shinagawa-ku, Tokyo, Japan Telephone: 81 (0)3 3491 6761 Fax: 81 (0)3 3491 6656

Latin America

PSC S.A., INC. Miami, Florida, USA Telephone: (305) 591-3222 Fax: (305) 591-3007

United Kingdom

PSC Bar Code Ltd. Watford, England Telephone: 44 (0) 1923 809500 Fax: 44 (0) 1923 809 505



www.psc.com

PSC Inc. 959 Terry Street Eugene, OR Telephone: (541) 683-5700 Fax: (541) 345-7140



R44-2536 (Rev C)