




User Manual



Edition Notes The COLORDash™ Accent User Manual Rev. 5 covers the description, safety precautions, installation, programming, operation, and maintenance of the COLORDash™ Accent. CHAUVET® released this edition of the COLORDash™ Accent User Manual in August 2014.

Trademarks CHAUVET® is a registered trademark of CHAUVET & Sons Inc. (d/b/a CHAUVET® or Chauvet). The CHAUVET® logo in its entirety including the CHAUVET® name and the dotted triangle, and all other trademarks in this manual pertaining to services, products, or marketing statements (example: It's Green Thinking™) are owned or licensed by CHAUVET®. Any other product names, logos, brands, company names, and other trademarks featured or referred to within this document are the property of their respective trademark holders.

Copyright Notice CHAUVET® owns the content of this User Manual in its entirety, including but not limited to pictures, logos, trademarks, and resources.

© Copyright 2014 CHAUVET®. All rights reserved.

Electronically published by CHAUVET® in the United States of America.

Manual Use CHAUVET® authorizes its customers to download and print this manual for professional information purposes only. CHAUVET® expressly prohibits the usage, copy, storage, distribution, modification, or printing of this manual or its content for any other purpose without written consent from CHAUVET®.

Document Printing For better results, print this document in color, on letter size paper (8.5 x 11 in), double-sided. If using A4 paper (210 x 297 mm), configure your printer to scale the content accordingly.

Intended Audience Any person in charge of installing, operating, and/or maintaining this product should completely read through the guide that shipped with the product, as well as this manual, before installing, operating, or maintaining this product.

Disclaimer CHAUVET® believes that the information contained in this manual is accurate in all respects. However, CHAUVET® assumes no responsibility for any errors or omissions in this document. CHAUVET® reserves the right to revise and make changes to the content of this document without obligation that CHAUVET® notify any person or company of such revision or changes. This does not in any way constitute a commitment by CHAUVET® to make such changes. CHAUVET® may issue a revision of this manual or a new edition to incorporate such changes.

Document Revision The COLORDash™ Accent User Manual Rev. 5 supersedes all previous versions of this manual. Discard any older versions of this manual and replace with this version. Go to www.chauvetprofessional.com for the latest version.

Author	Date	Editor	Date
D. Coupe	8/1/14	A. Leon	8/1/14

Table of Contents

1. Before You Begin	1
What Is Included	1
Claims	1
Manual Conventions	1
Symbols	1
Product At A Glance	2
Safety Notes	2
Personal Safety.....	2
Mounting And Rigging.....	2
Power And Wiring	2
Operation	2
Expected LED Lifespan	2
2. Introduction	3
Description	3
Features.....	3
Overview	4
Dimensions	5
3. Setup.....	6
AC Power.....	6
AC Plug.....	6
DMX Linking.....	7
DMX Personalities.....	7
Master/Slave Connectivity.....	7
Mounting	8
Orientation	8
Rigging.....	8
Procedure	8
4. Operation	9
Control Panel Description	9
Control Options	9
Dip Switch Assignments.....	9
Operation Modes	10
Programming	10
Starting Address.....	10
Procedure	10
STATIC Mode	11
STATIC Mode Configuration	11
Procedure	11
AUTO Mode	11
Procedure	11
DMX Values	12
DMX Values (Cont.).....	13



5. Technical Information 14
 Product Maintenance..... 14

6. Technical Specifications..... 15
 Returns 16

Contact Us 17

1. BEFORE YOU BEGIN

- What Is Included**
- COLORdash™ Accent
 - Warranty Card
 - Quick Reference Guide

Claims Carefully unpack the product immediately and check the box to make sure all the parts are in the package and are in good condition.




If the box or the contents (the product and included accessories) appear damaged from shipping or show signs of mishandling, notify the carrier immediately, not CHAUVET®. Failure to report damage to the carrier immediately may invalidate your claim. In addition, keep the box and contents for inspection.

For other issues, such as missing components or parts, damage not related to shipping, or concealed damage, file a claim with CHAUVET® within 7 days of delivery.

Manual Conventions

Convention	Meaning
1–512	A range of values in the text
50/60	A set of mutually exclusive values in the text
[10]	A DIP switch to be configured
<SET>	A button on the product's control panel
Settings	A product function or a menu option
MENU>Settings	A sequence of menu options
1–10	A range of menu values from which to choose in a menu
Yes/No	A set of two mutually exclusive menu options in a menu
ON	A unique value to be entered or selected in a menu

Symbols

Symbols	Meaning
	Critical installation, configuration, or operation information. Failure to comply with this information may cause the product not to work, damage third-party equipment, or cause harm to the operator.
	Important installation or configuration information. Failure to comply with this information may keep the product from working.
	Useful information.



The term “DMX” used throughout this manual refers to the USITT DMX512-A digital data transmission protocol.

Product At A Glance

Use on Dimmer	X	Auto Programs	P
Outdoor Use	X	Auto-Ranging Power Supply	P
Master/Slave	P	Replaceable Fuse/Breaker	X
DMX	P	User-Serviceable	X

Safety Notes



Read all the following Safety Notes before working with this product. These notes include important information about the installation, usage, and maintenance of this product.

This product contains no user-serviceable parts. Any reference to servicing in this User Manual will only apply to properly trained CHAUVET® certified technicians. Do not open the housing or attempt any repairs.



All applicable local codes and regulations apply to proper installation of this product.

Personal Safety

- Avoid direct eye exposure to the light source while the product is on.
- Always disconnect this product from its power source before servicing.
- Always connect this product to a grounded circuit to avoid the risk of electrocution.
- Do not touch this product's housing during operation because it may be very hot.
- The product is not intended for permanent installation.
- This product is for indoor use only! To prevent risk of fire or shock, do not expose this product to rain or moisture. (IP20)
- Mount this product in a location with adequate ventilation, at least 20 in (50 cm) from adjacent surfaces.
- Make sure there are no flammable materials close to this product while it is operating.
- When hanging this product, always secure to a fastening device using a safety cable (included).

Mounting And Rigging

Power And Wiring

Operation

- Always make sure you are connecting this product to the proper voltage in accordance with the specifications in this manual or on the product's specification label.
- Never connect this product to a dimmer pack or rheostat.
- Never disconnect this product by pulling or tugging on the power cable.
- Do not operate this product if you see damage on the housing, lenses, or cables. Have the damaged parts replaced by an authorized technician at once.
- Do not cover the ventilation slots when operating to avoid internal overheating.
- The maximum ambient temperature is 113 °F (45 °C). Do not operate this product at a higher temperature.
- In case of a serious operating problem, stop using this product immediately!



Expected LED Lifespan

In the unlikely event that your CHAUVET® product may require service, contact CHAUVET® Technical Support.

LEDs gradually decline in brightness over time, mostly because of heat. Packaged in clusters, LEDs exhibit higher operating temperatures than in ideal, single-LED conditions. For this reason, using clustered LEDs at their fullest intensity significantly reduces the LEDs' lifespan. Under normal conditions, this lifespan can be 40,000 to 50,000 hours. If extending this lifespan is vital, lower the operating temperature by improving the ventilation around the product and reducing the ambient temperature to an optimal operating range. In addition, limiting the overall projection intensity may also help to extend the LEDs' lifespan.


2. INTRODUCTION

Description The COLORdash™ Accent is a small LED-based, DMX controllable, wash light designed for indoor applications.


The COLORdash™ Accent is a high-power, high luminance LED wash product. This product consists of a small aluminum casing that houses the internal power supply, the main control, the control panel, the LED drivers, the LED boards, as well as the power and signal connectors. The COLORdash™ Accent includes one double-bracketed yoke that can be both a floor mount and hanging support.

- Features**
- 3-, 4-, or 9-channel RGBW LED wash product
 - Operating modes:
 - 3-channel: RGB control
 - 4-channel: RGBW
 - 9-channel: RGBW, dimmer, strobe, macro, auto, auto speed
 - RGBW color mixing with or without DMX controller
 - Direct DMX input and output
 - Automatic programs with or without DMX controller
 - Static control with or without DMX controller
 - 0–100% dimmer
 - Macros
 - Master/Slave operation
 - Lightweight, black aluminum casing
 - Natural convection cooling (no fans)
 - High power (1 W, 350 mA) LEDs
 - Double-bracketed yoke that doubles as a floor stand


Overview




Front View



Top View




Rear View



Side View

Dimensions



3. SETUP

AC Power

Each COLORdash™ Accent has an auto-ranging power supply that works with an input voltage range of 100 to 240 VAC, 50/60 Hz. To determine the power requirements for each COLORdash™ Accent, refer to the label affixed to the product. You can also refer to the [Technical Specifications](#) chart in this manual.

The listed current rating indicates the maximum current draw during normal operation. For more information, you may download Sizing Circuit Breakers from the CHAUVET® website: www.chauvetlighting.com/download/pro.



Always connect this product to a protected circuit with an appropriate electrical ground to avoid the risk of electrocution or fire.



Never connect this product to a rheostat (variable resistor) or dimmer circuit, even if the rheostat or dimmer channel serves only as a 0 to 100% switch.

AC Plug

The COLORdash™ Accent comes with a hard-wired power input cord terminated with an Edison plug. The product side of this power cord enters the product through a strain reliever (rubber boot) and it cannot be disconnected from the product. If the power input cord that came with your product has no plug, or if you need to change the Edison plug, use the table below to wire the new plug.

Connection	Wire (U.S.)	Wire (Europe)	Screw Color
AC Live	Black	Brown	Yellow or Brass
AC Neutral	White	Blue	Silver
AC Ground	Green/Yellow	Green/Yellow	Green

DMX Linking You can link the COLORdash™ Accent to a DMX controller using a 3-pin DMX connection. If using other DMX-compatible products with the COLORdash™ Accent, you can control each individually with a single DMX controller.

DMX Personalities The COLORdash™ Accent uses a 3-pin DMX data connection for the **STAGE1**, **ARC.1**, and **ARC.2** DMX personalities.

- Refer to the [Introduction](#) chapter for a brief description of each DMX personality.
- Refer to the [Operation](#) chapter to learn how to configure the COLORdash™ Accent to work in these personalities.
- The [DMX Values](#) section provides you with detailed information regarding the DMX personalities.



If you are not familiar with or need more information about DMX standards, Master/Slave connectivity, or the DMX cables needed to link this product to a DMX controller, download the DMX Primer from the CHAUVET® website: www.chauvetlighting.com/download/pro.

Master/Slave Connectivity The Master/Slave mode allows a COLORdash™ Accent (the master) to control one or more COLORdash™ Accents (the slaves) without a DMX controller. One COLORdash™ Accent becomes the master when running an auto program, or by being in a Static mode.

You must configure each slave's control panel to operate in Slave mode. During Master/Slave operation, the slaves will operate in unison with the master.



DO NOT connect a DMX controller to products operating in Master/Slave mode. The DMX controller signals may interfere with the signals from the master.



The [Operation](#) section of this manual provides detailed instructions on how to configure the master and slaves.

Mounting Before mounting this product, read and follow the [Safety Notes](#). For our CHAUVET® line of mounting clamps, go to <http://trusst.com/productcategory/base-plates-accessories-clamps/>.


Orientation Always mount this product in a safe position and make sure there is adequate room for ventilation, configuration, and maintenance.

Rigging CHAUVET® recommends using the following general guidelines when mounting this product.

- When selecting an installation location, consider easy access to this product for operation, programming adjustments, and routine maintenance.
- The product is not intended for permanent installation.
- Make sure to mount this product away from any flammable material as indicated in the [Safety Notes](#).
- Never mount in places where rain, high humidity, extreme temperature changes, or restricted ventilation may affect the product.
- If hanging this product, make sure that the mounting location can support the product's weight. See the [Technical Specifications](#) for the weight-bearing requirements of this product.
- When hanging this product, always secure to a fastening device using a safety cable. For our CHAUVET® line of safety cables, go to <http://trusst.com/productcategory/base-plates-accessories-clamps/>.

Procedure The COLORdash™ Accent comes with a double-bracketed yoke to which you can either attach mounting clamps for hanging or simply use as a floor stand. You must supply your own mounting clamps. Make sure the clamps are capable of supporting the weight of this product. Use at least one mounting point per product. For our CHAUVET® line of mounting clamps, go to <http://trusst.com/productcategory/base-plates-accessories-clamps/>.

Mounting Diagram



4. OPERATION

Control Panel Description


The COLORdash™ Accent has a basic control panel, which consists of a single 12-switch dual in-line package (DIP) switch module. Each of the individual switches has a number (DIP switch [1] through [12]).

The only function of DIP switches [10] through [12] is to set the product's operation mode. The function of DIP switches [1] to [9] will vary depending on which operation mode you have selected. The diagram below shows the [DIP Switch Assignments](#). The [Operation Modes](#) table shows the DIP switch setting to enable the various operating modes for the COLORdash™ Accent.

Control Options

You can set the COLORdash™ Accent starting address in the **001–512** DMX range. This enables control of up to 56 products in the 9-channel **STAGE1** personality.

Dip Switch Assignments



- When the product is in DMX mode, DIP switches [1] to [9] define the product's starting address.
- When the product is in AUTO mode, DIP switches [1] to [5] determine which program will run.
- When the product is in STATIC mode, DIP switches [1] to [8] determine the intensity of the LEDs by color.

Operation Modes

DIP 10	DIP 11	DIP 12	Function
On	Off	On	STATIC (Master)
Off	Off	On	AUTO (Master)
On	Off	Off	Slave
Off	On	Off	ARC.1
On	On	Off	ARC.2
Off	Off	Off	STAGE1

Programming

It is possible to change the product's various operation modes, DMX address, Auto, or Static mode settings while the product is on. Always make sure that you have clear access to the DIP switches on the back of the product for easier product changes.

Starting Address

When any of the DMX modes is active as per the Operation Modes Table, you may select the product's starting DMX address (**001–512**) by setting DIP switches [1] through [9] as per the table below.

DIP Switch	1	2	3	4	5	6	7	8	9
Value	1	2	4	8	16	32	64	128	256


Procedure

1. Set DIP switches [10] through [12] to select a DMX operation mode, as per the [Operation Modes Table](#).
2. Select the desired starting address (**001–512**) by setting DIP switches [1] through [9] to **ON** or **OFF** until the sum of the value of the DIP switches in the **ON** position matches the desired address number.
3. Refer to the examples below for more information.


Starting Address Examples

These three examples are for STAGE1 DMX mode. Therefore, in all three cases, DIP switches [10], [11], and [12] are set to **OFF**.


- a. To select DMX Address **1**, set DIP switch [1] to **ON**.



- b. To select DMX Address **64**, set DIP switch [7] to **ON**.



- c. To select DMX Address **31**, set DIP switches [1], [2], [3], [4], and [5] to **ON** (1 + 2 + 4 + 8 + 16 = 31).



If you are not familiar with or need more information about DMX standards or the DMX cables needed to link this product to a DMX controller, download the DMX Primer from the CHAUVET® website: www.chauvetlighting.com/download/pro.

STATIC Mode

When selecting the Static mode, the COLORdash™ Accent can be set up to various colors and intensities without a DMX controller by using DIP switches [1] through [8] as per the tables below.

STATIC Mode Configuration

	Red		Green		Blue		White	
DIP Switch	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]
0 %	Off	Off	Off	Off	Off	Off	Off	Off
30 %	On	Off	On	Off	On	Off	On	Off
60 %	Off	On	Off	On	Off	On	Off	On
100 %	On	On	On	On	On	On	On	On

- Procedure**
1. Set DIP switches [10] and [12] to **ON**, and DIP switch [11] to **OFF** to select Static Mode.
 2. Select the color intensity as indicated in the [STATIC Mode Configuration](#) table above.

AUTO Mode


Auto Mode allows the user to select one of the 32 preset programs (0–31) on each individual COLORdash™ Accent.

Dip Switch	[1]	[2]	[3]	[4]	[5]
Value	1	2	4	8	16


- Procedure**
1. Set DIP switches [10] and [11] to **OFF**, and DIP switch [12] to **ON** (Auto Mode).
 2. Select the desired program (0–31) by setting DIP switches [1] through [5] to **ON** or **OFF** until the sum of the value of the DIP switches in the ON position matches the desired program number.
 3. Refer to the examples below for more information.

Auto Mode Examples

- a. To select Auto program 0, set DIP switches [1] through [5] to **OFF** and DIP switch [12] to **ON**.



- b. To select Auto program 9, set DIP switches [1], [4], and [12] to **ON**.



Master/Slave

The Master/Slave mode allows a group of COLORdash™ Accents (the slave products) to simultaneously duplicate the output of another COLORdash™ Accent (the master product) without a DMX controller.

- a. Connect all COLORdash™ Accents in a daisy chain.
- b. Set up the first product in the daisy chain (Master) as explained in [STATIC Mode](#) or [AUTO Mode](#).
- c. On the rest of the COLORdash™ Accents, set DIP switch [10] to **ON**.



- **The master product is the one that runs a program whether in Auto or Static mode.**
- **Do not connect a DMX controller to the products configured for Master/Slave operation. The DMX controller may interfere with signals from the master product.**
- **The master product should be the first product in the daisy chain.**

DMX Values

STAGE1

Channel	Function	Value	Percent/Setting
1	Dimmer	000↺ 255	0–100%
2	Red	000↺ 255	0–100%
3	Green	000↺ 255	0–100%
4	Blue	000↺ 255	0–100%
5	White	000↺ 255	0–100%
6	Color Macro + White Balance	000↺ 010	No function
		011↺ 035	R: 100% G: 0-100% B: 0
		036↺ 060	R: 100%-0 G: 100% B: 0
		061↺ 085	R: 0 G: 100% B: 0-100%
		086↺ 110	R: 0 G: 100%-0 B: 100%
		111↺ 135	R: 0-100% G: 0 B: 100%
		136↺ 160	R: 100% G: 0 B: 100%-0
		161↺ 185	R: 100% G: 0-100% B: 0-100%
		186↺ 210	R: 100%-0 G: 100%-0 B: 100%
		211↺ 215	White 1
		216↺ 220	White 2
		221↺ 225	White 3
		226↺ 230	White 4
		231↺ 235	White 5
		236↺ 240	White 6
		241↺ 245	White 7
		246↺ 250	White 8
		251↺ 255	White 9
7	Strobe	000↺ 009	No Function
		010↺ 255	0–20 Hz

DMX Values (Cont.)

STAGE1 (Cont.)	Channel	Function	Value	Percent/Setting
	8	Programs	000↺ 020 021↺ 030 031↺ 040 041↺ 050 051↺ 060 061↺ 070 071↺ 080 081↺ 090 091↺ 100 101↺ 110 111↺ 120 121↺ 130 131↺ 140 141↺ 150 151↺ 160 161↺ 170 171↺ 180 181↺ 190 191↺ 200 201↺ 210 211↺ 220 221↺ 223 224↺ 226 227↺ 229 230↺ 232 233↺ 235 236↺ 238 239↺ 241 242↺ 244 245↺ 247 248↺ 250 251↺ 253 254↺ 255	No Function Auto 0 Auto 1 Auto 2 Auto 3 Auto 4 Auto 5 Auto 6 Auto 7 Auto 8 Auto 9 Auto 10 Auto 11 Auto 12 Auto 13 Auto 14 Auto 15 Auto 16 Auto 17 Auto 18 Auto 19 Auto 20 (Red) Auto 21 (Red & Green) Auto 22 (Red & Blue) Auto 23 (Red & White) Auto 24 (Green) Auto 25 (Green & Blue) Auto 26 (Green & White) Auto 27 (Blue) Auto 28 (Blue & White) Auto 29 (White) Auto 30 (Red & Green & Blue) Auto 31 (Red & Green & Blue & White)
	9	Auto Speed	000↺ 255	Only when Auto 0–19 in Ch. 8 is activated

ARC.1	Channel	Function	Value	Percent/Setting
	1	Red	000↺ 255	0–100%
	2	Green	000↺ 255	0–100%
	3	Blue	000↺ 255	0–100%

ARC.2	Channel	Function	Value	Percent/Setting
	1	Red	000↺ 255	0–100%
	2	Green	000↺ 255	0–100%
	3	Blue	000↺ 255	0–100%
	4	White	000↺ 255	0–100%

5. TECHNICAL INFORMATION

Product Maintenance

To maintain optimum performance and minimize wear, you should clean this product frequently. Usage and environment are contributing factors in determining the cleaning frequency.

As a rule, clean this product at least twice a month. Dust build-up reduces light output performance and can cause overheating. This can lead to reduced light source life and increased mechanical wear.

To clean your product:

1. Unplug the product from power.
2. Wait until the product is at room temperature.
3. Use a vacuum (or dry compressed air) and a soft brush to remove dust collected on the external vents.
4. Clean all external surfaces with a mild solution of non-ammonia glass cleaner or isopropyl alcohol.
5. Apply the solution directly to a soft, lint-free cotton cloth or a lens cleaning tissue.
6. Wipe any dirt or grime to the outside edges of the lens surface.
7. Gently polish the lens surfaces until they are free of haze and lint.



Always dry the external surfaces thoroughly and carefully after cleaning them.

6. TECHNICAL SPECIFICATIONS

Dimensions and Weight	Length	Width	Height	Weight
	6.9 in (174 mm)	4.3 in (108 mm)	2.5 in (65 mm)	1.5 lb (0.6 kg)
	Note: Dimensions in inches rounded to the nearest decimal digit.			
Power	Power Supply Type	Range	Voltage Selection	
	Switching (internal)	100–240 VAC, 50/60 Hz	Auto-ranging	
	Parameter	120 VAC, 60 Hz	230 VAC, 50 Hz	
	Consumption	10 W	10 W	
	Current	0.1 A	0.1 A	
	Power I/O	U.S./Canada	Worldwide	
	Power input connector	Hard-wired	Hard-wired	
Light Source	Power cord plug	Edison (U.S.)	Local plug	
	Type	Power	Lifespan	
	LED	1 W	50,000 hours	
	Color	Quantity	Current	
	Red	2	350 mA	
	Green	2	350 mA	
	Blue	2	350 mA	
Photo Optic	White	1	350 mA	
	Parameter	Standard 18° Optics		
	Illuminance @ 5 m	153 lux		
	Beam angle	20°		
Thermal	Field angle	37.5°		
	Max. External Temperature	Cooling System		
	113 °F (45 °C)	Convection		
DMX	I/O Connectors	Connector Type	Channel Range	
	3-pin XLR	Sockets	3, 4 or 9	
Ordering	Product Name	Item Code	UPC Number	
	COLORdash™ Accent	01030111	781462203825	



CONFORMS TO
UL STD. 1573

CERTIFIED TO
CSA STD. C22.2
No. 166



Returns You must send the product prepaid, in the original box, and with the original packing and accessories. CHAUVET® will not issue call tags.
Call CHAUVET® and request a Return Merchandise Authorization (RMA) number before shipping the product. Be prepared to provide the model number, serial number, and a brief description of the cause(s) for the return.
Clearly label the package with an RMA number. CHAUVET® will refuse any product returned without an RMA number.



DO NOT write the RMA number directly on the box. Instead, write it on a properly affixed label.

Once you have received the RMA number, include the following information on a piece of paper inside the box:

- Your name
- Your address
- Your phone number
- The RMA number
- A brief description of the problem(s)

Be sure to pack the product properly. Any shipping damage resulting from inadequate packaging will be the customer's responsibility. FedEx packing or double-boxing is recommended.



CHAUVET® reserves the right to use its own discretion to repair or replace returned product(s).

CONTACT Us

WORLD HEADQUARTERS - CHAUVET®

General Information

Address: 5200 NW 108th Avenue
Sunrise, FL 33351
Voice: (954) 577-4455
Fax: (954) 929-5560
Toll free: (800) 762-1084

Technical Support

Voice: (954) 577-4455 (Press 4)
Fax: (954) 756-8015
Email: tech@chauvetlighting.com

World Wide Web www.chauvetlighting.com

UNITED KINGDOM AND IRELAND - CHAUVET® Europe Ltd.

General Information

Address: Unit 1C
Brookhill Road Industrial Estate
Pinxton, Nottingham, UK
NG16 6NT
Voice: +44 (0)1773 511115
Fax: +44 (0)1773 511110

Technical Support

Email: uktech@chauvetlighting.com

World Wide Web www.chauvetlighting.co.uk

MEXICO - CHAUVET® Mexico

General Information

Address: Av. Santa Ana 30
Parque Industrial Lerma
Lerma, Mexico C.P. 52000
Voice: +52 (728) 285-5000

Technical Support

Email: servicio@chauvet.com.mx

World Wide Web www.chauvet.com.mx

Outside the U.S., United Kingdom, Ireland, or Mexico, contact the dealer of record. Follow their instructions to request support or to return a product. Visit our website for contact details.